

**Disclaimer**

The following online version of the Owner's Manual describes all models as well as all the standard and optional equipment of your vehicle. Country-specific differences in the language variants are possible. Note that your vehicle may not be fitted with all features described. This is also the case for safety-relevant systems and functions. Please contact your authorised Mercedes-Benz dealer if you would like to have a printed Owner's Manual for other vehicle models and vehicle model years. The online version is the current valid Owner's Manual version. Possible variations to your vehicle may not be taken into account as Mercedes-Benz constantly updates their vehicles and equipment to the state of the art and introduces changes in design and equipment. Please also read the printed Owner's Manual, any supplementary documents and the digital Owner's Manual in the vehicle.

**Copyright**

All Rights Reserved. All texts, images, graphics, are subject to Copyright and other laws for the protection of intellectual property. They may not be copied for commercial purposes or for transmission, nor changed and used on other websites.





# EQE

Owner's Manual

Mercedes-Benz





### Front passenger airbag warning



**⚠ WARNING** Risk of injury or death if the co-driver airbag is enabled

If the co-driver airbag is enabled, a child on the co-driver seat may be struck by the co-driver airbag during an accident.

NEVER use a rearward-facing child restraint system on a seat with an ENABLED FRONT

AIRBAG; DEATH or SERIOUS INJURY to the CHILD can occur.

Observe the chapter "Children in the vehicle".

## Thank you for buying Mercedes-Benz

Before you first drive off, read this operator's manual carefully and familiarise yourself with your vehicle. For your own safety and a longer operating lifespan of the vehicle, follow the instructions and warning notices in this operator's manual. Disregarding them may lead to damage to the vehicle or injury to people.

The standard equipment and product description of your vehicle may vary and depends on the following factors:

- Model
- Order
- National version
- Availability

Your vehicle may therefore differ, in individual cases, from that shown in the descriptions and illustrations.

The illustrations in this operator's manual show a left-hand drive vehicle. On right-hand drive vehicles, the layout of vehicle parts and controls differs accordingly.

Mercedes-Benz is constantly developing its vehicles further.

Mercedes-Benz therefore reserves the right to introduce changes in the following areas:

- Design
- Equipment
- Technical features

The following documents are integral parts of the vehicle:

- Digital operator's manual
- Printed operator's manual
- Service booklet
- Equipment-dependent supplements
- Supplementary documents

Keep these documents in the vehicle at all times. Ensure that all documents are in the vehicle or passed on in the event of sale or rental.

2955848700Z102



|                                                        |    |                                                                              |    |                                                                                     |     |
|--------------------------------------------------------|----|------------------------------------------------------------------------------|----|-------------------------------------------------------------------------------------|-----|
| <b>Symbols</b> .....                                   | 5  | Declarations of conformity and notes on driving in different countries ..... | 27 | <b>Opening and closing</b> .....                                                    | 80  |
| <b>At a glance</b> .....                               | 6  | Diagnostics connection .....                                                 | 36 | Key .....                                                                           | 80  |
| Cockpit (central display) .....                        | 6  | Qualified specialist workshop .....                                          | 37 | Doors .....                                                                         | 84  |
| Cockpit (MBUX Hyperscreen) .....                       | 8  | Vehicle registration .....                                                   | 37 | Boot .....                                                                          | 95  |
| Indicator and warning lamps (standard) .....           | 10 | Correct use of the vehicle .....                                             | 37 | Side windows .....                                                                  | 100 |
| Indicator and warning lamps (with driver camera) ..... | 12 | Information on the REACH regulation .....                                    | 38 | Sliding sunroof .....                                                               | 103 |
| Overhead control panel .....                           | 14 | Notes for persons with electronic medical aids .....                         | 38 | Anti-theft protection .....                                                         | 107 |
| Door operating unit and seat adjustment .....          | 16 | Implied warranty .....                                                       | 39 | <b>Seats and stowing</b> .....                                                      | 110 |
| Emergencies and breakdowns .....                       | 18 | QR code for rescue card .....                                                | 39 | Notes on the correct driver's seat position ..                                      | 110 |
| <b>Digital Owner's Manual</b> .....                    | 20 | Data storage .....                                                           | 39 | Seats .....                                                                         | 110 |
| Calling up the Digital Owner's Manual .....            | 20 | Copyright .....                                                              | 42 | Steering wheel .....                                                                | 120 |
| <b>General notes</b> .....                             | 21 | <b>Occupant safety</b> .....                                                 | 43 | Easy entry and exit feature .....                                                   | 121 |
| Protection of the environment .....                    | 21 | Restraint system .....                                                       | 43 | Memory function .....                                                               | 123 |
| Take-back of end-of-life vehicles .....                | 21 | Seat belts .....                                                             | 45 | Stowage areas .....                                                                 | 124 |
| Mercedes-Benz GenuineParts .....                       | 21 | Airbags .....                                                                | 49 | Cup holders .....                                                                   | 131 |
| Operator's manual .....                                | 23 | PRE-SAFE® system .....                                                       | 57 | Sockets .....                                                                       | 136 |
| Touch-sensitive controls .....                         | 23 | Automatic measures after an accident .....                                   | 58 | Wireless charging of the mobile phone and connection with the exterior aerial ..... | 137 |
| Mercedes me App .....                                  | 24 | Safely transporting children in the vehicle .....                            | 59 | Fitting and removing the floor mats .....                                           | 140 |
| Operating safety .....                                 | 24 | Notes on pets in the vehicle .....                                           | 78 | <b>Light and sight</b> .....                                                        | 141 |
|                                                        |    |                                                                              |    | Exterior lighting .....                                                             | 141 |
|                                                        |    |                                                                              |    | Interior lighting .....                                                             | 152 |

|                                                       |     |
|-------------------------------------------------------|-----|
| Windscreen wipers and windscreen washer system .....  | 155 |
| Mirrors .....                                         | 157 |
| Area permeable to radio waves on the windscreen ..... | 160 |
| Infrared-reflective windscreen function .....         | 160 |

|                                            |            |
|--------------------------------------------|------------|
| <b>Climate control .....</b>               | <b>161</b> |
| Overview of climate control systems .....  | 161        |
| Operating the climate control system ..... | 164        |

|                                          |            |
|------------------------------------------|------------|
| <b>Driving and parking .....</b>         | <b>176</b> |
| Driving .....                            | 176        |
| DYNAMIC SELECT button .....              | 188        |
| Transmission .....                       | 191        |
| Function of the 4MATIC .....             | 192        |
| Charging the high-voltage battery .....  | 193        |
| Parking .....                            | 212        |
| Driving and driving safety systems ..... | 217        |
| Trailer hitch .....                      | 290        |
| Bicycle rack function .....              | 295        |
| Vehicle towing instructions .....        | 297        |

|                                                           |            |
|-----------------------------------------------------------|------------|
| <b>Driver display .....</b>                               | <b>298</b> |
| Notes on the driver's display .....                       | 298        |
| Notes on the range .....                                  | 298        |
| Operating the driver's display .....                      | 299        |
| Driver display menus .....                                | 300        |
| Head-up display .....                                     | 300        |
| Overview of status displays on the driver's display ..... | 302        |

|                                           |            |
|-------------------------------------------|------------|
| <b>MBUX multimedia system .....</b>       | <b>304</b> |
| Overview and operation .....              | 304        |
| System settings .....                     | 320        |
| AMG TRACK PACE .....                      | 324        |
| Drive system settings .....               | 329        |
| Navigation and traffic .....              | 330        |
| Telephone .....                           | 341        |
| Mercedes me app .....                     | 344        |
| Mercedes-Benz emergency call system ..... | 353        |
| Radio, media & TV .....                   | 360        |
| Sound settings .....                      | 366        |

|                                            |            |
|--------------------------------------------|------------|
| <b>Maintenance and care .....</b>          | <b>367</b> |
| ASSYST PLUS service interval display ..... | 367        |
| Engine compartment .....                   | 368        |

|                                            |     |
|--------------------------------------------|-----|
| Topping up the windscreen washer system .. | 370 |
| Cleaning and care .....                    | 370 |

|                                   |            |
|-----------------------------------|------------|
| <b>Breakdown assistance .....</b> | <b>378</b> |
| Emergency .....                   | 378        |
| Flat tyre .....                   | 380        |
| Battery (vehicle) .....           | 385        |
| Tow-starting or towing away ..... | 388        |
| Electrical fuses .....            | 394        |

|                                                          |            |
|----------------------------------------------------------|------------|
| <b>Wheels and tyres .....</b>                            | <b>396</b> |
| Notes on noise or unusual handling characteristics ..... | 396        |
| Notes on regularly inspecting wheels and tyres .....     | 396        |
| Notes on snow chains .....                               | 396        |
| Activating or deactivating snow chain mode .....         | 397        |
| Tyre pressure .....                                      | 397        |
| Wheel change .....                                       | 401        |
| Emergency spare wheel .....                              | 410        |

|                                                                       |            |
|-----------------------------------------------------------------------|------------|
| <b>Technical data .....</b>                                           | <b>412</b> |
| Notes on technical data .....                                         | 412        |
| On-board electronics .....                                            | 412        |
| Regulatory radio identification and notes .....                       | 414        |
| Vehicle identification plate, VIN and<br>engine number overview ..... | 415        |
| Operating fluids .....                                                | 417        |
| Vehicle data .....                                                    | 419        |
| Trailer hitch .....                                                   | 421        |

|                                                               |            |
|---------------------------------------------------------------|------------|
| <b>Display messages and warning/indicator<br/>lamps .....</b> | <b>424</b> |
| Display messages .....                                        | 424        |
| Warning and indicator lamps .....                             | 489        |

|                    |            |
|--------------------|------------|
| <b>Index .....</b> | <b>505</b> |
|--------------------|------------|

In this Owner's Manual, you will find the following symbols:



**WARNING** Danger due to not observing the warning notices

Warning notices draw your attention to hazards that may endanger your health or life, or the health or life of others.

 Observe the warning notices.



**ENVIRONMENTAL NOTE** Environmental damage due to failure to observe environmental notes

Environmental notes include information on environmentally responsible behaviour or environmentally responsible disposal.

 Observe environmental notes.



**NOTE** Damage to property due to failure to observe notes on material damage

Notes on material damage inform you of risks which may lead to your vehicle being damaged.

 Observe notes on material damage.

 These symbols indicate useful instructions or further information that could be helpful to you.

 Instruction

 Further information on a topic


 Display in the central display

 Highest menu level, which is to be selected in the multimedia system

 Relevant submenus, which are to be selected in the multimedia system


 Indicates a cause





Left-hand-drive vehicles (with central display)

|   |                                            |   |     |                                                       |   |     |
|---|--------------------------------------------|---|-----|-------------------------------------------------------|---|-----|
| ① | Increases recuperation                     | → | 185 | Switches sound on/off                                 | → | 304 |
|   | Reduces recuperation                       | → | 185 | Adjusts the volume                                    | → | 304 |
| ② | Combination switch                         | → | 143 | ⑨  Hazard warning light system                        | → | 144 |
| ③ | Driver's display                           | → | 299 | ⑩ Start/stop button                                   | → | 180 |
| ④ | DIRECT SELECT lever                        | → | 191 | ⑪ Control panel for the MBUX multimedia system        | → | 312 |
| ⑤ | Central display                            | → | 304 | ⑫ Adjusts the steering wheel                          | → | 120 |
| ⑥ | Glove compartment                          | → | 126 | ⑬  Electric parking brake                             | → | 214 |
| ⑦ | Stowage compartment                        | → | 126 | ⑭ Diagnostics connection                              | → | 36  |
| ⑧ | Switch panel for:                          |   |     | ⑮ Light switch                                        | → | 141 |
|   | DYNAMIC SELECT button                      | → | 190 | ⑯ Control panel:                                      |   |     |
|   | Active Parking Assist                      | → | 277 | Driver's display                                      | → | 299 |
|   | Calls up the EQ menu                       | → | 211 | Active Distance Assist DISTRONIC and variable limiter | → | 233 |
|   | Quick vehicle access                       |   |     |                                                       |   |     |
|   | Fingerprint sensor                         | → | 304 |                                                       |   |     |
|   | Switches the MBUX multimedia system on/off | → | 304 |                                                       |   |     |




Left-hand-drive vehicles (with MBUX hyperscreen)

|   |                                              |   |     |
|---|----------------------------------------------|---|-----|
| ① | Increases recuperation                       | → | 185 |
|   | Reduces recuperation                         | → | 185 |
| ② | Combination switch                           | → | 143 |
| ③ | DIRECT SELECT lever                          | → | 191 |
| ④ | MBUX hyperscreen with:                       |   |     |
|   | Driver's display                             | → | 298 |
|   | Central display                              | → | 304 |
|   | Front passenger display                      | → | 304 |
| ⑤ | Control panel for the MBUX multimedia system | → | 312 |
| ⑥ | Glove compartment                            | → | 126 |
| ⑦ | Stowage compartment                          | → | 126 |
| ⑧ | Hazard warning light system                  | → | 144 |
| ⑨ | Switch panel for:                            |   |     |
|   | DYNAMIC SELECT button                        | → | 190 |
|   | Active Parking Assist                        | → | 277 |
|   | Calls up the EQ menu                         | → | 211 |

|   |                                                       |   |     |
|---|-------------------------------------------------------|---|-----|
|   | Quick vehicle access                                  |   |     |
|   | Fingerprint sensor                                    | → | 304 |
|   | Switches the MBUX multimedia system on/off            | → | 304 |
|   | Switches sound on/off                                 | → | 304 |
|   | Adjusts the volume                                    | → | 304 |
| ⑩ | Start/stop button                                     | → | 180 |
| ⑪ | Adjusts the steering wheel                            | → | 120 |
| ⑫ | Electric parking brake                                | → | 214 |
| ⑬ | Diagnostics connection                                | → | 36  |
| ⑭ | Light switch                                          | → | 141 |
| ⑮ | Control panel:                                        |   |     |
|   | Driver's display                                      | → | 299 |
|   | Active Distance Assist DISTRONIC and variable limiter | → | 233 |


## 10 At a glance – Indicator and warning lamps (standard)



Standard driver's display

|   |                                                                                                                                                                     |                                       |   |     |
|---|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------|---|-----|
| ① |   | Turn signal lights                    | → | 143 |
| ② |                                                                                    | System error                          | → | 492 |
| ③ |                                                                                    | Trailer hitch                         | → | 493 |
| ④ |                                                                                    | Suspension (red)                      | → | 498 |
|   |                                                                                    | Suspension (yellow)                   | → | 498 |
| ⑤ |                                                                                    | Electrical fault                      | → | 492 |
| ⑥ |                                                                                    | Power steering (red)                  | → | 493 |
|   |                                                                                    | Power steering (yellow)               | → | 493 |
|   |                                                                                    | Rear axle steering (red)              | → | 493 |
|   |                                                                                    | Rear axle steering (yellow)           | → | 493 |
| ⑦ |                                                                                    | Restraint system                      | → | 491 |
| ⑧ |                                                                                    | Seat belt                             | → | 491 |
| ⑨ |                                                                                    | Distance warning                      | → | 498 |
| ⑩ |                                                                                    | ABS                                   | → | 500 |
| ⑪ |                                                                                    | Tyre pressure monitoring system       | → | 503 |
| ⑫ |                                                                                  | ESP® OFF                              | → | 500 |
|   |                                                                                  | ESP®                                  | → | 500 |
| ⑬ |                                                                                  | Reduced power                         | → | 492 |
| ⑭ |                                                                                  | Operational readiness of drive system | → | 180 |
| ⑮ |                                                                                  | Electric parking brake (yellow)       | → | 496 |
| ⑯ |                                                                                  | Electric parking brake (red)          | → | 496 |
| ⑰ |                                                                                  | Brakes (red)                          | → | 496 |
|   |                                                                                  | Brakes (yellow)                       | → | 496 |
| ⑱ |                                                                                  | Range                                 |   |     |
| ⑲ |                                                                                                                                                                     | Charge level display                  |   |     |
| ⑳ |                                                                                  | High beam                             | → | 143 |
|   |                                                                                  | Low beam                              | → | 141 |
|   |                                                                                  | Standing lights                       | → | 141 |
| ㉑ |                                                                                  | Rear fog light                        | → | 142 |
| ㉒ |                                                                                  | Mercedes-Benz emergency call system   | → | 502 |


12 At a glance – Indicator and warning lamps (with driver camera)




Driver's display with driver camera

|   |                                                                                   |                                                                                   |                    |     |     |                                                                                     |                                     |   |     |
|---|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|--------------------|-----|-----|-------------------------------------------------------------------------------------|-------------------------------------|---|-----|
| ① |  | System error                                                                      | →                  | 492 | ⑭   |  | Range                               |   |     |
| ② |  |  | Turn signal lights | →   | 143 | ⑮                                                                                   | Charge level display                |   |     |
| ③ |  | Seat belt                                                                         | →                  | 491 | ⑯   |  | Rear fog light                      | → | 142 |
| ④ |  | Distance warning                                                                  | →                  | 498 | ⑰   |  | High beam                           | → | 143 |
| ⑤ |  | Restraint system                                                                  | →                  | 491 |     |  | Low beam                            | → | 141 |
| ⑥ |  | Reduced power                                                                     | →                  | 492 |     |  | Standing lights                     | → | 141 |
| ⑦ |  | Tyre pressure monitoring system                                                   | →                  | 503 | ⑱   |  | Mercedes-Benz emergency call system | → | 502 |
| ⑧ |  | ESP® OFF                                                                          | →                  | 500 | ⑲   |  | Trailer hitch                       | → | 493 |
|   |  | ESP®                                                                              | →                  | 500 | ⑳   |  | Electrical fault                    | → | 492 |
| ⑨ |  | ABS                                                                               | →                  | 500 | ㉑   |  | Power steering (red)                | → | 493 |
| ⑩ | READY                                                                             | Operational readiness of drive system                                             | →                  | 180 |     |  | Power steering (yellow)             | → | 493 |
| ⑪ |  | Electric parking brake (yellow)                                                   | →                  | 496 |     |  | Rear axle steering (red)            | → | 493 |
| ⑫ |  | Electric parking brake (red)                                                      | →                  | 496 |     |  | Rear axle steering (yellow)         | → | 493 |
| ⑬ |  | Brakes (red)                                                                      | →                  | 496 | ㉒   |  | Suspension (red)                    | → | 498 |
|   |  | Brakes (yellow)                                                                   | →                  | 496 |     |  | Suspension (yellow)                 | → | 498 |






|   |                                                                                                                                               |   |     |
|---|-----------------------------------------------------------------------------------------------------------------------------------------------|---|-----|
| ① | Sun visors                                                                                                                                    |   |     |
| ② |  Switches the front interior lighting on/off                 | → | 152 |
| ③ |  Switches the rear interior lighting on/off                  | → | 152 |
| ④ |  me button                                                   | → | 344 |
| ⑤ |  Switches automatic interior lighting control on/off         | → | 152 |
| ⑥ |  SOS button                                                  | → | 344 |
| ⑦ | Switches the right-hand reading lamp on/off                                                                                                   | → | 152 |
| ⑧ |  Opens/closes the panorama sliding sunroof                 | → | 103 |
|   |  Opens/closes the panorama sliding sunroof roller sunblind | → | 103 |
| ⑨ | PASSENGER AIR BAG indicator lamps                                                                                                             | → | 54  |
| ⑩ | Inside rearview mirror                                                                                                                        | → | 158 |
| ⑪ | Switches the left-hand reading lamp on/off                                                                                                    | → | 152 |



|   |                                                                                                                                                                     |                                      |   |     |   |                                                                                     |                                             |   |     |
|---|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------|---|-----|---|-------------------------------------------------------------------------------------|---------------------------------------------|---|-----|
| ① |   | Locks/unlocks the vehicle            | → | 85  | ⑨ |  | Opens/closes the right side window          | → | 100 |
| ② |                                                                                                                                                                     | Opens the door                       | → | 84  | ⑩ |  | Opens/closes the rear right side window     | → | 100 |
| ③ |                                                                                                                                                                     | Adjusts the seats electrically       | → | 113 | ⑪ |  | Child safety lock for the rear side windows | → | 78  |
| ④ |                                                                                    | Switches the seat heating on/off     | → | 118 | ⑫ |  | Opens/closes the rear left side window      | → | 100 |
| ⑤ |                                                                                    | Switches the seat ventilation on/off | → | 119 | ⑬ |  | Opens/closes the left side window           | → | 100 |
| ⑥ |                                                                                    | Operates the memory function         | → | 124 | ⑭ |                                                                                     | Adjusts the head restraints                 | → | 114 |
| ⑦ |                                                                                    | Opens/closes the boot lid            | → | 95  | ⑮ |                                                                                     | Seat adjustment using the multimedia system | → | 116 |
| ⑧ |                                                                                    | Operates the outside mirrors         | → | 157 |   |                                                                                     |                                             |   |     |



|   |                                                                                                               |   |     |
|---|---------------------------------------------------------------------------------------------------------------|---|-----|
| ① | B-pillar with:                                                                                                |   |     |
|   | QR code for accessing the rescue card                                                                         | → | 39  |
| ② | Safety vests                                                                                                  | → | 378 |
| ③ |  me button                   | → | 344 |
|   |  SOS button                  | → | 344 |
| ④ | Towing away                                                                                                   | → | 388 |
| ⑤ | Flat tyre                                                                                                     | → | 380 |
| ⑥ | To operate the high-voltage disconnect device                                                                 | → | 177 |
| ⑦ |  Hazard warning light system | → | 144 |

|   |                                       |   |     |
|---|---------------------------------------|---|-----|
| ⑧ | Fire extinguisher                     | → | 379 |
| ⑨ | Socket flap with:                     |   |     |
|   | information label on tyre pressure    | → | 398 |
|   | QR code for accessing the rescue card | → | 39  |
| ⑩ | First-aid kit (soft sided)            | → | 379 |
| ⑪ | Towing away                           | → | 388 |
| ⑫ | TIREFIT kit                           | → | 382 |
| ⑬ | Warning triangle                      | → | 378 |

## Calling up the Digital Owner's Manual


Multimedia system:

- ➔  ➔ Settings ➔ Info
- ➔ Owner's Manual
- ➔ Open Digital Owner's Manual

The Digital Owner's Manual describes the functions and operation of the vehicle and the multimedia system.

- ▶ Select one of the following menu items in the Digital Owner's Manual:
  - **Quick start:** find the first steps towards adjusting your seat (driver's side).
  - **Tips:** find information that prepares you for certain everyday situations with your vehicle.
  - **Animations:** watch animations of the vehicle functions.
  - **Messages:** receive additional information about the messages in the driver's display.
  - **Language:** select the language for the Digital Owner's Manual.

You can search for keywords using the search field **Search**, in order to find quick answers to questions about the operation of the vehicle.



- ① Menu
- ② Search
- ③ Back
- ④ Contents section

Some sections in the Digital Owner's Manual, such as warning notes, can be expanded and collapsed.

**Additional methods of calling up the Digital Owner's Manual:**

**Driver's display:** call up brief information as display messages in the driver's display

**MBUX Voice Assistant:** call up via the voice control system

**Global search:** call up search results for contents of the Digital Owner's Manual in the home screen  
For safety reasons, the Digital Owner's Manual is deactivated while driving.

## Protection of the environment

 **ENVIRONMENTAL NOTE** Environmental damage due to operating conditions and personal driving style

Operate your vehicle in an environmentally responsible manner to help protect the environment. Please observe the following recommendations on operating conditions and personal driving style.

### Operating conditions:

- ▶ Make sure that the tyre pressure is correct.
- ▶ Do not carry any unnecessary weight (e.g. roof luggage racks once you no longer need them).
- ▶ Monitor energy consumption.
- ▶ Adhere to the service intervals.  
A regularly serviced vehicle will contribute to environmental protection.
- ▶ Always have maintenance work carried out at a qualified specialist workshop.

### Personal driving style:

- ▶ Drive carefully and maintain a suitable distance from the vehicle in front.
- ▶ Avoid frequent, sudden acceleration and braking.
- ▶ Drive in a way that conserves energy.  
Observe the ECO display for an economical driving style.

 **ENVIRONMENTAL NOTE** Environmental pollution caused by irresponsible disposal of the high-voltage battery

A high-voltage battery contains materials which are harmful to the environment.

- ▶ Dispose of faulty high-voltage batteries at a qualified specialist workshop.

## Take-back of end-of-life vehicles

### EU countries only:

Mercedes-Benz will take back your end-of-life vehicle for environment-friendly disposal in

accordance with the European Union (EU) End-of-Life Vehicles Directive.

A network of vehicle take-back points and dismantlers has been established for you to return your vehicle. You can leave it at any of these points free of charge. This makes an important contribution to closing the recycling circle and conserving resources.

For further information about the recycling and disposal of end-of-life vehicles, and the take-back conditions, please visit the national Mercedes-Benz website for your country.

## Mercedes-Benz GenuineParts

 **ENVIRONMENTAL NOTE** Environmental damage caused by not using recycled/reconditioned components

Mercedes-Benz AG offers recycled/reconditioned components and parts with the same quality as new parts. The same entitlement from the implied warranty is valid as for new parts.



- ▶ Recycled reconditioned components and parts from Mercedes-Benz AG.

**!** **NOTE** Impairment of the operating efficiency of the restraint systems from installing accessory parts or from repairs or welding

Airbags and seat belt tensioners, as well as control units and sensors for the restraint systems, may be installed in the following areas of your vehicle:

- doors
- door pillars
- Sill
- Seats
- Cockpit
- Driver's display
- Centre console
- lateral roof frame

- ▶ Do not install accessory parts such as audio systems in these areas.

- ▶ Do not carry out repairs or welding.
- ▶ Have accessories retrofitted at a qualified specialist workshop.

You could jeopardise the operating safety of your vehicle if you use parts, tyres and wheels as well as accessories relevant to safety which have not been approved by Mercedes-Benz. Safety-relevant systems (e.g. the brake system) may malfunction. Only use Mercedes-Benz GenuineParts or parts of equal quality. Only use tyres, wheels and accessory parts that have been specifically approved for your vehicle model.

Mercedes-Benz tests original parts and conversion parts and accessory parts that have been specifically approved for your vehicle model for their reliability, safety and suitability. Despite ongoing market research, Mercedes-Benz is unable to assess other parts. Mercedes-Benz therefore accepts no responsibility for the use of such parts in Mercedes-Benz vehicles, even if they have been officially approved or independently approved by a testing centre.

Certain parts are only officially approved for installation or modification if they comply with legal requirements. All Mercedes-Benz GenuineParts meet the approval requirements. The use of non-approved parts may invalidate the vehicle's general operating permit.

This is the case in the following situations:

- The vehicle type is different from that for which the vehicle's general operating permit was granted.
- Other road users could be endangered.
- The noise level gets worse.

Always specify the vehicle identification number (VIN) (→ page 415) when ordering Mercedes-Benz GenuineParts.

## Operator's manual

This Owner's Manual and the Digital Owner's Manual in the vehicle describe the following models and the standard and special equipment for your vehicle:

- The models and the standard and special equipment available at the time of this Owner's Manual going to press.
- The models and the standard and special equipment only available in certain countries.
- The models and the standard and special equipment, which will only be available at a later date.

Note that your vehicle may not be fitted with all features described. This is also the case for systems relevant to safety. Therefore, the equipment on your vehicle may differ from that in the descriptions and illustrations.

The original purchase agreement for your vehicle contains a list of the equipment in your vehicle at the time of delivery.

Should you have any questions concerning equipment and operation, please consult a Mercedes-Benz Service Centre.

The Owner's Manual, Supplement, further supplementary documents and Service Booklet are important documents and should be kept in the vehicle.

## Touch-sensitive controls

In addition to conventional switches and buttons, your vehicle is equipped with touch-sensitive controls.

These are located in the following areas of your vehicle:

- Roof and door control panel
- Climate control
- Steering wheel
- MBUX multimedia system

The controls have touch-sensitive user interface surfaces. The surfaces are controlled by pressing or swiping to adjust settings or to trigger functions, forexample.

In the area of the touchscreen, you also receive haptic feedback in the form of a pulse or a vibration, or the surface structure changes on the touch-sensitive user interface surface, forexample.

You receive haptic feedback in the following situations, forexample:

- When pressing a button on the user interface surface
- When scrolling in a list or table
- When reaching a new area on the user interface surface, e.g. a pop-up window

When handling touch-sensitive user interface surfaces, observe the following points to avoid problems operating:

- Do not affix stickers or similar objects on the surfaces
- Keep the surfaces protected from moisture and wet conditions
- Keep the surfaces free of dust and dirt (→ page 375).

Some touch-sensitive control elements have a symbol and integrated indicator lamps. When operating, make sure to press on the symbol of the control element.

### Mercedes me App

#### Notes about the on-demand feature

You can also activate various functions (on-demand feature) subsequently via Mercedes me after purchasing your vehicle.

Information is available at any Mercedes-Benz Service Centre.

#### Activating on-demand feature using Mercedes me

##### Requirements:

- The vehicle has a wireless connection.
- The vehicle is linked to the Mercedes me user account.

#### Ordering and activating on-demand feature

- ▶ Add the desired on-demand feature for the vehicle to the shopping basket in the Mercedes me Store.
- ▶ Complete the order.  
The on-demand feature is activated when operating the vehicle.

#### Speeding up activation

- ▶ Switch the vehicle off and lock it.
- ▶ Unlock the vehicle after about two minutes and switch on the vehicle.  
The on-demand feature has been activated.  
For some features, a notification also appears in the vehicle's multimedia system.

If the activation was not successful, repeat the process.

#### Operating safety

**⚠ WARNING** Risk of accident due to malfunctions or system failures

If you do not have the prescribed service / maintenance work or any required repairs carried out, this could result in malfunctions or system failures.

- ▶ Always have the prescribed service and maintenance work as well any required repairs carried out at a qualified specialist workshop.

**⚠ WARNING** Risk of accident or injury due to improper modifications to electronic components

Modifications to electronic components, their software or wiring can impair their functionality and/or the functionality of other networked components or safety-relevant systems.

This can endanger the vehicle's operating safety.

- ▶ You must not tamper with wiring, electronic components, or their software.
- ▶ Always have work on electrical and electronic devices carried out at a qualified specialist workshop.

If you modify the on-board electronics, the general operating permit is rendered invalid.

Observe the "On-board electronics" section in "Technical data".

**!** **NOTE** Impairment of the operating efficiency of the vehicle or individual components due to tampering with the on-board electronics

The vehicle is equipped by the manufacturer with various safety mechanisms that interact with each other.

If the system detects tampering with the on-board electronics due to an unauthorised modification of control units and/or their software/data, this may have the following effects:

- Individual vehicle functions are (temporarily) no longer operational.
- The overall vehicle is (temporarily) no longer operational.

▶ Have the vehicle checked immediately at a qualified specialist workshop and, if necessary, reset to factory settings.

**!** **NOTE** Damage to the vehicle due to driving too fast and due to impacts to the vehicle underbody and suspension components

In the following situations, in particular, there is a risk of damage to the vehicle:

- the vehicle becomes grounded, e.g. on a high kerb or an unpaved road

- the vehicle is driven too fast over an obstacle, e.g. a kerb, speed bump or pothole
- a heavy object strikes the underbody or suspension components

In situations such as these, damage to the body, underbody, suspension components, wheels or tyres and high-voltage battery components may not be visible. Components damaged in this way can unexpectedly fail or, in the case of an accident, may no longer absorb the resulting force as intended.

▶ Have the vehicle checked and repaired immediately at a qualified specialist workshop.

or

▶ If driving safety is impaired while continuing your journey, pull over and stop the vehicle immediately, while paying attention to road and traffic conditions, and contact a qualified specialist workshop.

Electric vehicles have an electric motor. The electric motor's energy supply is provided by the high-voltage on-board electrical system.

**⚠ DANGER** Risk of death and fire due to modified and/or damaged components of the high-voltage on-board electrical system

The vehicle's high-voltage on-board electrical system is under high voltage. If you modify component parts in the vehicle's high-voltage on-board electrical system or touch damaged component parts, you may be electrocuted. In addition, modified and/or damaged components may cause a fire.


In the event of an accident or impact to the vehicle underbody, components of the high-voltage electrical system may be damaged although the damage is not visible.

- ▶ Never make any modifications to the high-voltage on-board electrical system.
- ▶ Do not switch on or use the vehicle if its high-voltage on-board electrical system


components have been modified or damaged.

- ▶ Never touch damaged components of the high-voltage on-board electrical system.
- ▶ After an accident, do not touch any components of the high-voltage on-board electrical system.
- ▶ After an accident, have the vehicle transported away.
- ▶ Have the components of the high-voltage on-board electrical system checked at a qualified specialist workshop and replaced if necessary.

The components of the vehicle's high-voltage on-board electrical system are marked with yellow warning stickers. The cables of the high-voltage on-board electrical system are orange.



High-voltage components that can become very hot are marked with an additional warning sticker:



Vehicles with an electric motor generate significantly less vehicle noise emissions than vehicles

with combustion engines. As a result, your vehicle may not be heard by other road users in certain situations. This can occur, for example, when you are parking and your vehicle cannot be seen by other road users. This requires you to adopt a particularly anticipatory driving style, as it is necessary to allow for the possibility that other road users may behave unpredictably.

### Declarations of conformity and notes on driving in different countries

#### Electromagnetic compatibility

The electromagnetic compatibility of the vehicle components has been checked and certified according to the currently valid version of Regulation UN-R 10.

#### Vehicle installed radio components

**Only for EU and EFTA countries and countries that recognise the EU manufacturer's declaration of conformity:**



The following information applies to all wireless components of the vehicle and of the information systems and communication devices integrated in the vehicle:

The manufacturers of the wireless components ensure that all wireless components installed in the vehicle comply with Directive 2014/53/EU. The full texts of the EU declarations of conformity are available at the following web address:

[https://moba.i.daimler.com/markets/ece-row/baix/cars/certificates-of-conformity/en\\_GB/index.html](https://moba.i.daimler.com/markets/ece-row/baix/cars/certificates-of-conformity/en_GB/index.html)



You can obtain further information from a Mercedes-Benz service centre.

#### For Israel only:

It is prohibited to make any change to a vehicle-installed radio component that could affect the wireless specifications of the device, including software changes, replacement of the original antenna, or adding the option to connect the device to an external antenna, without first obtain-

ing approval from the Communications Ministry, because of concern about wireless interference.

**For the United Kingdom only:**



The following information applies to all wireless components of the vehicle and of the information systems and communication devices integrated in the vehicle:

The manufacturers of the radio components declare that all radio equipment installed in the vehicle is in compliance with the relevant statutory requirements. The full texts of the declarations of conformity are available at the following web address:

[https://moba.i.daimler.com/markets/ece-row/baix/cars/certificates-of-conformity/en\\_GB/index.html](https://moba.i.daimler.com/markets/ece-row/baix/cars/certificates-of-conformity/en_GB/index.html)



**For Brazil only:**




Note on two-way radio systems in the vehicle:

These systems are not protected against harmful interference and must not cause interference in properly approved systems.

**For Jamaica only:**

All wireless vehicle components have received type approval from the SMA.

**For Nigeria only:**



Connection and use of the radio communications equipment in this vehicle is permitted by the Nigerian Communications Commission

**For Russia only:**

The manufacturers of the wireless components installed in the vehicle hereby declare that all

wireless components installed in the vehicle comply with the technical regulations for two-way radios. You can obtain further information from a Mercedes-Benz service centre.

**For Ukraine only:**

The manufacturers of the wireless components installed in the vehicle hereby declare that the wireless components installed in the vehicle com-

ply with the technical regulations for two-way radios. You can obtain further information from a Mercedes-Benz service centre.

**Type of wireless applications and specifications in accordance with 2014/53/EU**

Besides the typical frequencies for mobile communication cars by Mercedes-Benz make use of the following automotive radio applications.

**Type of wireless applications and specifications in accordance with 2014/53/EU**

| Technology                  | Frequency range       | Transmission output/magnetic field strength |
|-----------------------------|-----------------------|---------------------------------------------|
| Remote Keyless Entry        | 20 kHz (9–90 kHz)     | ≤ 72 dBμA/m at 10m                          |
| Wireless Power Transmission | 105 kHz (90–119 kHz)  | ≤ 42 dBμA/m at 10m                          |
| Remote Keyless Entry        | 120 kHz (119–135 kHz) | ≤ 42 dBμA/m at 10m                          |



| Technology                                                         | Frequency range                    | Transmission output/magnetic field strength                                                              |
|--------------------------------------------------------------------|------------------------------------|----------------------------------------------------------------------------------------------------------|
| Wireless Power Transmission                                        | 127 kHz (119–135 kHz)              | $\leq 66$ dB $\mu$ A/m at 10m with the magnetic field strength level decreasing 3dB/octave above 119 kHz |
| Near-field communication                                           | 13.553–13.567 MHz                  | $\leq 42$ dB $\mu$ A/m at 10m                                                                            |
| Remote Keyless Entry, Garage Door Opener, Tire Pressure Monitoring | 433 MHz (433.05–434.79 MHz)        | $\leq 10$ mW ERP                                                                                         |
| Block Heater Remote Control, Garage Door Opener                    | 868 MHz (868.0–868.6 MHz)          | $\leq 25$ mW ERP                                                                                         |
| Block Heater Remote Control, Garage Door Opener                    | 869 MHz (868.7–869.2 MHz)          | $\leq 25$ mW ERP                                                                                         |
| Bluetooth, Klear, RLAN, wireless Headphones                        | 2.4 GHz ISM band (2400–2483.5 MHz) | $\leq 100$ mW EIRP                                                                                       |
| RLAN                                                               | 5.1 GHz UNII-1 (5150–5250 MHz)     | $\leq 25$ mW EIRP                                                                                        |
| Interior Monitoring Radar, RLAN                                    | 5.8 GHz UNII-3 (5725–5875 MHz)     | $\leq 25$ mW EIRP                                                                                        |
| Remote Keyless Entry                                               | 7.25 GHz UWB (6.0–8.5 GHz)         | $\leq -41.3$ dBm/MHz EIRP mean $\leq 0$ dBm/MHz EIRP peak                                                |
| 76 GHz radar                                                       | 76–77 GHz                          | $\leq 55$ dBm peak EIRP                                                                                  |

| Technology                                  | Frequency range                                                                                                                          | Transmission output/magnetic field strength                                                                      |
|---------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------|
| Carsharing Module                           | <b>NFC:</b><br>13.553–13.567 MHz<br><b>Bluetooth®:</b><br>2402–2480 MHz                                                                  | <b>NFC:</b><br>≤ 42 dBμA/m at 10 m<br><b>Bluetooth®:</b><br>≤ +4 dBm (class 2)                                   |
| Rear Seat Entertainment System              | <b>Bluetooth®:</b><br>2400–2483.5 MHz<br><b>WLAN 2.4 GHZ:</b><br>2400–2483.5 MHz<br><b>WLAN 5 GHz:</b><br>5150–5250 MHz<br>5725–5875 MHz | <b>Bluetooth®:</b><br>–0.8 dBm<br><b>WLAN 2.4 GHZ:</b><br>14.5 dBm<br><b>WLAN 5 GHz:</b><br>20.5 dBm<br>13.3 dBm |
| Two-way radio (Tel7 telephone control unit) | E-GSM (900 MHz)<br>GSM (1800 MHz)                                                                                                        | +33 dBm<br>+30 dBm                                                                                               |
|                                             | UMTS (Band I, III, VIII)                                                                                                                 | +24 dBm (+1 /–3 dB)                                                                                              |
|                                             | LTE (Band 1, 3, 7, 8, 20, 28)                                                                                                            | +23 dBm (±2 dB)                                                                                                  |

| Technology                          | Frequency range                                                       | Transmission output/magnetic field strength |
|-------------------------------------|-----------------------------------------------------------------------|---------------------------------------------|
| RAMSES (Router And Mobile ServiceS) | GSM (E-GSM 850 / E-GSM 900, Class 4)                                  | < +32.5 dBm ( $\pm 1$ dB)                   |
|                                     | GSM (E-GSM 1800 / E-GSM 1900, Class 4)                                | < +29.5 dBm ( $\pm 1$ dB)                   |
|                                     | UMTS (WCDMA FDD I, II, III, IV, V, VIII, XIX, Class 3)                | < +23.5 dBm ( $\pm 1$ dB)                   |
|                                     | LTE (FDD B1, B2, B3, B4, B5, B7, B8, B9, B18, B19, B21, B28, Class 3) | < +23 dBm ( $\pm 1$ dB)                     |
|                                     | LTE (TDD B38, B40, B41, Class 3)                                      | < +23 dBm ( $\pm 1$ dB)                     |
|                                     | GNSS (1559–1610 MHz)                                                  | Receiving only                              |

### Information about the specific absorption rate

For France only:

The values were determined and tested in accordance with the Décret n° 2019-1186 guideline regarding the indication of the specific absorption rate (SAR) of wireless vehicle components.

Further information and updates are available at the following web address:

[https://moba.i.daimler.com/baix/cars/SAR/fr\\_FR/index.html](https://moba.i.daimler.com/baix/cars/SAR/fr_FR/index.html)



**Information about the specific absorption rate**

| Vehicle components                | SAR value in W/kg | Applicable limit value |
|-----------------------------------|-------------------|------------------------|
| Compensator ECE DE003 & ECE DE004 | < 0.2 W/kg        | 2 W/kg                 |
| DAI RSE                           | 1.8 W/kg          | 2 W/kg                 |
| HERMES communication module       | < 0.4 W/kg        | 2 W/kg                 |

| Vehicle components                       | SAR value in W/kg | Applicable limit value |
|------------------------------------------|-------------------|------------------------|
| RAMSES communication module              | 0.036 W/kg        | 2 W/kg                 |
| NRCS2P                                   | 0.003 W/kg        | 2 W/kg                 |
| NTG6                                     | 0.199 W/kg        | 4 W/kg                 |
| NTG7                                     | 0.08 W/kg         | 2 W/kg                 |
| NTG7RSU                                  | 0.07 W/kg         | 2 W/kg                 |
| Tablet PC SM-T230NZ                      | 0.7 W/kg          | 4 W/kg                 |
| Radio data transmission telephone system | 0.24 W/kg         | 2 W/kg                 |

### Importer information for wireless components

#### **For Moldova only:**

##### **Importer**

S.C. GRAND PREMIUM S.R.L. Moldova  
mun. Chisinau, str. Hîncesti sos., 2/2

#### **For Turkey only:**

##### **Importer**

Mercedes Benz Otomotiv Ticaret ve Hizmetler  
A.Ş. Genel Merkez

Akçaburgaz Mah. Süleyman Şah Cad. No: 6/1  
34522 Esenyurt/İstanbul

#### **For Ukraine only:**

##### **Importer**

PJSC "AUTOCAPITAL"  
Velyka Vasylykivska str. 15/2  
01004 Kyiv  
Ukraine

#### **For the United Kingdom only:**

##### **Importer**

Mercedes-Benz Cars UK Limited  
Delaware Drive, Tongwell  
Milton Keynes, MK15 8BA  
England

#### **Importer of Mercedes-Benz spare parts**

Mercedes-Benz Parts Logistics  
Delaware Drive, Tongwell

Milton Keynes, MK15 8BA  
England

### Jack

Copy and translation of the original declaration of conformity:

#### **EC declaration of conformity**

1.

The undersigned, representing

Manufacturer:

BRANO a.s.

747 41 Hradec nad Moravicí, Opavská 1000,

The Czech Republic

ID No.: 64-387-5933

VAT No.: CZ64-387-5933

herewith declares under our sole responsibility that the product:

2. a)

Name:

Jack

Type, Number:

A) A 164 580 02 18, A 166 580 01 18

B) A 240 580 00 18

C) A 639 580 02 18

D) A 639 580 03 18

E) A 910 580 00 00

F) A 247 580 00 00, A 293 580 00 00

Year of manufacture: 2020

Complies with all relevant provisions

Directive No. 2006/42/EC

b)

Description and purpose of use:

Car jack is intended solely for lifting of the concrete car, in accordance with the instruction label on the car jack.

3.

References of harmonized and other standards or specifications

ISO 4063, EN ISO 14341-A, AS 2693, DBL 8230.10, DBL 7382.20, DBL 7392.10, DBL 8451.15, MBN 10435,

Technical documentation of the product is stored at the premise of the manufacturer. The person responsible for assembling the technical documentation of the product: Head of the Technical Department Brano a.s.

4.

Hradec nad Moravicí

Place

5.

05.10.2020

Date

Engineer Petr Petr

[Signature]

Director of division ZZ

### TIREFIT kit

Copy and translation of the original declaration of conformity:

#### **EC declaration of conformity**

In accordance with EC Directive 2006/42/EC

We hereby declare that the product

Product designation: Daimler electric air pump  
Model designation: 0867, DT/UW 200056  
MB part no.: A 000 583 5101  
complies with the following relevant regulations:  
2004/108/EC  
Applied harmonised standards, in particular:  
DIN EN 55014-1: 2012  
DIN EN 55014-2: 2016  
Manufacturer: Dunlop Tech GmbH  
Address: Offenbacher Landstr. 8, 63456 Hanau  
Authorised representative: IMS dept.  
Date: October 2019  
Signature: IMS-AE, IMS-AE-L

### Diagnostics connection

The diagnostics connection is a technical interface in the vehicle. It is used, for example, during repair and maintenance work or for reading out vehicle data in a specialist workshop. Diagnostic devices should therefore only be connected in a qualified specialist workshop.

**⚠ WARNING** Risk of accident due to connecting devices to the diagnostics connection

If you connect devices to the diagnostics connection of the vehicle, the function of vehicle systems and operating safety may be impaired.

- ▶ For safety reasons, we recommend that you only use and connect products approved by a Mercedes-Benz service centre.

**⚠ WARNING** Risk of accident due to objects in the driver's footwell

Objects in the driver's footwell may impede pedal travel or block a depressed pedal.

This jeopardises the operating and road safety of the vehicle.


- ▶ Stow all objects in the vehicle securely so that they cannot get into the driver's footwell.

- ▶ Always fit the floor mats securely and as prescribed in order to ensure that there is always sufficient room for the pedals.
- ▶ Do not use loose floor mats and do not place floor mats on top of one another.

**! NOTE** Battery discharging from using devices connected to the diagnostics connection

Using devices at the diagnostics connection drains the battery.

- ▶ Check the charge level of the battery.
- ▶ If the charge level is low, charge the battery, e.g. by driving a considerable distance.



Connecting and using another device with the diagnostics connection can have the following effects:

- Malfunctions in the vehicle system
- Permanent damage to vehicle components

Please refer to the warranty terms and conditions for this matter.

### Qualified specialist workshop

A qualified specialist workshop has the necessary special skills, tools and qualifications to correctly carry out any necessary work on your vehicle. This particularly applies to safety-relevant works.

Always have the following work carried out on your vehicle at a qualified specialist workshop:

- Safety-relevant works
- Service and maintenance work
- Repair work
- Modifications as well as installations and conversions
- Work on electronic components

Mercedes-Benz recommends a Mercedes-Benz service centre.

### Vehicle registration

Mercedes-Benz may ask its service centres to carry out technical inspections on certain vehicles. The quality or safety of the vehicle is improved as a result of the inspection.

Mercedes-Benz can only inform you about vehicle checks if Mercedes-Benz has your registration data.

It is possible that your vehicle has not yet been registered in your name in the following cases:

- if your vehicle was not purchased at an authorised specialist dealer.
- if your vehicle has not yet been examined at a Mercedes-Benz service centre.

It is advisable to register your vehicle with a Mercedes-Benz service centre.

Inform Mercedes-Benz as soon as possible about any change in address or vehicle ownership. You can do this at a Mercedes-Benz service centre, for example.

### Correct use of the vehicle

If you remove any warning stickers, you or others could fail to recognise certain dangers. Leave warning stickers in position.



Observe the following information in particular when driving your vehicle:

- the safety notes in this Owner's Manual, vehicle-specific supplements and further supplementary documents
- technical data for the vehicle
- traffic rules and -regulations
- laws and safety standards pertaining to motor vehicles

### Information on the REACH regulation

#### EU and EFTA countries only:

the REACH regulation (Regulation (EC) No. 1907/2006, Article 33) stipulates a duty to supply information about substances of very high concern (SVHCs).

Mercedes-Benz AG acts to the best of its knowledge to prevent these SVHCs from being used and to enable customers to safely handle these substances. There are SVHCs known to Mercedes-Benz AG, according to supplier information and internal product information, found in

individual components of this vehicle in quantities of over 0.1 percent by weight.

Further information can be obtained at the following addresses:

- <https://reach.daimler.com/de/home/>
- <https://reach.daimler.com/en/home/>

### Notes for persons with electronic medical aids

Mercedes-Benz AG cannot, despite carefully developing vehicle systems, completely rule out the interaction of vehicle systems with electronic medical aids such as cardiac pacemakers.

In addition, there are components installed in the vehicle that, regardless of the operating status of the vehicle, can generate magnetic fields on a par with permanent magnets. These fields can be found, for example, in the area around the multimedia and sound system or also in the area of the seats, depending on the vehicle equipment.

For this reason, the following can occur in isolated cases, depending on the aids used:

- Medical aids malfunctioning

- Adverse health effects

Observe the notes and warnings of the manufacturer of the medical aids; if in doubt, contact the device manufacturer and/or your doctor. If there is continuing uncertainty concerning the possibility of medical aids malfunctioning, Mercedes-Benz AG recommends using only few electrical vehicle systems and/or maintaining a distance from the components.

When charging the high-voltage battery, keep a distance of at least an arm's length between the medical aid and the following components:

- the power supply equipment  
This includes charging stations in the form of a wallbox or a public charging point, for example.
- vehicle components carrying live voltage  
This includes the charging cable and the charging control box, for example.

Only have repairs and maintenance work in the area of the following components carried out at a qualified specialist workshop:

- vehicle components carrying live voltage

- transmission aerials
- multimedia system and sound system

If you have any queries or suggestions, consult a qualified specialist workshop.

### Implied warranty

**!** **NOTE** Damage to the vehicle arising from violation of these operating instructions.

Damage to the vehicle can arise from violation of these operating instructions.

This damage is not covered either by the Mercedes-Benz implied warranty or by the New- or Used-Vehicle Warranty.

- ▶ Follow the instructions in these operating instructions on proper operation of your vehicle as well as on possible vehicle damage.

### QR code for rescue card

QR codes are attached in the socket flap and on the opposite side on the B-pillar. In the event of an accident, rescue services can use the QR code to quickly find the appropriate rescue card for your vehicle. The current rescue card contains the most important information about your vehicle (e.g. the routing of the electric lines) in compact form.

Further information can be obtained at <https://www.mercedes-benz.de/qrcode>

### Data storage

#### Data processing in the vehicle

#### Electronic control units

Electronic control units are fitted in your vehicle. Control units process data which, for example, they receive from vehicle sensors, generate themselves or exchange between themselves. Some control units are required for the safe operation of your vehicle, some assist you when driving, such as driver assistance systems, while others enable convenience or infotainment functions.

The following provides you with general information regarding data processing in the vehicle. Additional information regarding exactly which data in your vehicle are collected, saved and transmitted to third parties, and for what purpose, can be found in the information directly related to the functional characteristics in question in their respective operating instructions. This information is also available online and, depending on the vehicle equipment, digitally.

#### Personal data

Every vehicle is identified by a unique vehicle identification number. Depending on the country, this vehicle identification number can be used by, for example, governmental authorities to determine the identity of the owner. There are other possibilities to use data collected from the vehicle to identify the owner or driver, such as the licence plate number.

Therefore, data generated or processed by control units may be attributable to a person or, under certain conditions, become attributable to a person. Depending on which vehicle data are available, it may be possible to make inferences about,

forexample, your driving behaviour, your location, your route or your use patterns.

### **Legal requirements regarding the disclosure of data**

If legally required to do so, manufacturers are, in individual cases, legally obliged to provide governmental entities, upon request and to the extent required, data stored by the manufacturer. Forexample, this may be the case during the investigation of a criminal offence.

Governmental entities are themselves, in individual cases and within the applicable legal framework, authorised to read out data from the vehicle. In the case of an accident, information that can help with an investigation can, therefore, be taken from the airbag control unit, forexample.

### **Operational data in the vehicle**

This is data regarding the operation of the vehicle, which have been processed by control units.

This includes the following data, forexample:

- vehicle status information such as the speed, longitudinal acceleration, lateral acceleration, number of wheel revolutions or the fastened seat belts display

- ambient conditions, such as temperature, rain sensor or distance sensor

Generally, the use of these data is temporary; they will not be stored beyond the period of operation and will only be processed within the vehicle itself. Control units often contain data memories for vehicle keys, forexample. Their use permits the temporary or permanent documentation of technical information about the vehicle's operating state, component loads, maintenance requirements and technical events or faults.

Depending on the vehicle equipment, the following data are stored:

- operating status of system components, such as fill levels, tyre pressure or battery status
- malfunctions or faults in important system components, such as lights or brakes
- system reactions in special driving situations, such as airbag deployment or the intervention of stability control systems
- information on events leading to vehicle damage

- charge level of the high-voltage battery, estimated range

In certain cases, it may be required to store data that would have otherwise been used only temporarily. This may be the case if the vehicle has detected a malfunction, forexample.

If you use services, such as repair services and maintenance work, stored operational data as well as the vehicle identification number can be read out and used. They can be read out by service network employees, such as workshops and manufacturers or third parties, such as breakdown services. The same is true in the case of warranty claims and quality assurance measures.

In general, the readout is performed via the legally prescribed port for the diagnostics connection in the vehicle. The operational data that are read out document technical states of the vehicle or of individual components and assist in the diagnosis of malfunctions, compliance with warranty obligations and quality improvement. To that end, these data, in particular information about component loads, technical events, malfunctions and other faults may be transmitted along with the vehicle

identification number to the manufacturer. Furthermore, the manufacturer is subject to product liability. For this reason the manufacturer also uses operational data from the vehicle, for example, for recalls. These data can also be used to examine the customer's warranty and guarantee claims.

Fault memories in the vehicle can be reset by a service outlet or at your request as part of repair or maintenance work.

### **Convenience and infotainment functions**

You can store convenience settings and individual settings in the vehicle and change or reset them at any time.

Depending on the vehicle equipment, this includes the following settings, for example:

- seat and steering wheel positions
- suspension and climate control settings
- individual settings, such as interior lighting

Depending on the selected equipment, you can import data into vehicle infotainment functions yourself.

Depending on the vehicle equipment, this includes the following data, for example:

- multimedia data, such as music, films or photos for playback in an integrated multimedia system
- address book data for use in connection with an integrated hands-free system or an integrated navigation system
- entered navigation destinations
- data about the use of Internet services

These data for convenience and infotainment functions may be saved locally in the vehicle or they may be located on a device which you have connected to the vehicle, such as a smartphone, USB flash drive or MP3 player. If you have entered these data yourself, you can delete them at any time.

This data is transmitted from the vehicle to third parties only at your request. This applies, in particular, when you use online services in accordance with the settings that you have selected.

### **Smartphone integration (e.g. Android Auto or Apple CarPlay®)**

If your vehicle is accordingly equipped, you can connect your smartphone or another mobile end device to the vehicle. You can then control them by means of the control elements integrated in the vehicle. Images and audio from the smartphone can be output via the multimedia system. Certain information is simultaneously transferred to your smartphone. Depending on the type and integration, this includes position data, day/night mode and other general vehicle statuses. For more information please consult the Owner's Manual of the vehicle/infotainment system.

This integration allows the use of selected smartphone apps, such as navigation or music player apps. There is no further interaction between the smartphone and the vehicle; in particular, vehicle data is not directly accessible. The type of additional data processing is determined by the provider of the app being used. Which settings you can make, if any, depends on the specific app and the operating system of your smartphone.

## Online services

### Wireless network connection

If your vehicle has a wireless network connection, it enables data to be exchanged between your vehicle and additional systems. The wireless network connection is made possible by the vehicle's own transmitter and receiver or by a mobile end device that you have brought into the vehicle, foreexample, a smartphone. Online functions can be used via the wireless network connection. This includes online services and applications/apps provided to you by the manufacturer or by other providers.

### Manufacturer's services

Regarding the manufacturer's online services, the individual functions are described by the manufacturer in a suitable place, foreexample, in the Owner's Manual or on the manufacturer's website, where the relevant data protection information is also given. Personal data may be used for the provision of online services. Data are exchanged via a secure connection, such as the manufacturer's designated IT systems. Any personal data which are collected, processed and

used, other than for the provision of services, is done so exclusively on the basis of legal permission. This is the case, foreexample, for a legally prescribed emergency call system, a contractual agreement or when consent has been given.

You can have services and functions, some of which are subject to a fee, activated or deactivated. This excludes legally prescribed functions and services, such as an emergency call system.

### Third party services

If you use online services from other providers (third parties), these services are the responsibility of the provider in question and subject to that provider's data protection conditions and terms of use. As a general rule, the manufacturer has no influence on the content exchanged.

For this reason, when services are provided by third parties, please ask the service provider in question for information about the type, extent and purpose of the collection and use of personal data.

## Data protection rights

Depending on your country or the equipment and range of functions of your vehicle as well as the services you use and the services on offer, you are entitled to different data protection rights. Further information on data protection and your data protection rights can either be found on the manufacturer's website or you will receive this information as part of the various services and service offers. There you will also find the contact information for the manufacturer and its data protection officers.

At a workshop, foreexample, with the support of a specialist and possibly for a fee, you can have data read out which is stored only locally in the vehicle.

## Copyright

Information on licences for free and open-source software used in your vehicle can be found on the data carrier in your vehicle document wallet and with updates on the following website:

<https://www.mercedes-benz.com/opensource>

## Restraint system

### Protection provided by the restraint system

The restraint system includes the following components:

- Seat belt system
- Airbags
- Child restraint system
- Child seat securing systems

The restraint system can help prevent the vehicle occupants from coming into contact with parts of the vehicle interior in the event of an accident. In the event of an accident, the restraint system can also reduce the forces to which the vehicle occupants are subjected.

A seat belt can only provide the best level of protection if it is worn correctly. Depending on the detected accident situation, seat belt tensioners and/or airbags supplement the protection offered by a correctly worn seat belt. Seat belt tensioners and/or airbags are not deployed in every accident.

In order for the restraint system to provide the intended level of protection, each vehicle occupant must observe the following information:

- Fasten seat belts correctly.
- Sit in an almost upright seat position with their back against the seat backrest.
- Sit with their feet resting on the floor, if possible.
- Always secure persons under 1.50 m tall in an additional restraint system suitable for Mercedes-Benz vehicles.

However, no system available today can completely eliminate injuries and fatalities in every accident situation. In particular, the seat belt and airbag generally do not protect against objects penetrating the vehicle from the outside. It is also not possible to completely rule out the risk of injury caused by the airbag deploying.

### Limitations of the protection provided by the restraint system

**⚠ WARNING** Risk of injury or death due to modifications to the restraint system

Vehicle occupants may no longer be protected as intended if alterations are made to the restraint system.

- ▶ Never alter the parts of the restraint system.
- ▶ Never tamper with the wiring or any electronic component parts or their software.

If it is necessary to modify the vehicle to accommodate a person with disabilities, contact a qualified specialist workshop.

Mercedes-Benz recommends that you use driving aids which have been approved for your vehicle by Mercedes-Benz.

### Restraint system functionality

When the vehicle is switched on, a self-test is performed, during which the  restraint system warning lamp lights up. It goes out no later than a few seconds after the vehicle is started. The components of the restraint system are then functional.

### Malfunctioning restraint system

A malfunction has occurred in the restraint system if:

- the  restraint system warning lamp does not light up when the vehicle is switched on
- the  restraint system warning lamp lights up continuously or repeatedly during a journey

**⚠ DANGER** Risk of fatal injuries due to restraint system malfunctions

Components in the restraint system may be activated unintentionally or not deploy as planned in an accident. In the event of an accident, the high-voltage on-board electrical system may not be deactivated as intended.

You may suffer an electric shock if you touch the damaged components of the high-voltage on-board electrical system.

- ▶ Have the restraint system checked and repaired immediately at a qualified specialist workshop.
- ▶ After an accident, switch off the vehicle immediately.

### Function of the restraint system in an accident

How the restraint system works depends on the severity of the impact detected and the apparent type of accident:

- Frontal impact
- Rear impact
- Side impact
- Rollover

The activation thresholds for the components of the restraint system are determined based on the evaluation of the sensor values measured at various points in the vehicle. This process is pre-emptive in nature. The triggering/deployment of the

components of the restraint system must take place in good time at the start of the collision.

Factors which can only be seen and measured after a collision has occurred cannot play a decisive role in airbag deployment. Nor do they provide an indication of airbag deployment.

The vehicle may be deformed significantly without an airbag being deployed. This is the case if only parts which are relatively easily deformed are affected and the rate of vehicle deceleration is not high. Conversely, an airbag may be deployed even though the vehicle suffers only minor deformation. If very rigid vehicle parts such as longitudinal members are hit, this may result in sufficiently high levels of vehicle deceleration.

Depending on the detected deployment situation, the components of the restraint system can be activated or deployed independently of each other:

- Seat belt tensioner: frontal impact, rear impact, side impact, rollover
- Driver's airbag, front passenger airbag: frontal impact
- Knee airbag: frontal impact

- Side airbag: side impact
- Centre airbag: side impact, rollover
- Window airbag: side impact, rollover, frontal impact
- PRE-SAFE® Impulse Side: side impact

The front passenger airbag can only be deployed in an accident if the PASSENGER AIR BAG OFF indicator lamp is off. If the front passenger seat is occupied, make sure, both before and during the journey, that the status of the front passenger airbag is correct (→ page 54).

**⚠ WARNING** Risk of burns from hot airbag components

The airbag parts are hot after an airbag has been deployed.

- ▶ Do not touch the airbag parts.
- ▶ Have a deployed airbag replaced at a qualified specialist workshop as soon as possible.

Mercedes-Benz recommends that you have the vehicle towed to a qualified specialist workshop

after an accident. Take this into account, particularly if a seat belt tensioner is triggered or an airbag deployed.

If the seat belt tensioners are triggered or an airbag is deployed, you will hear a bang, and a small amount of powder may also be released:

- The bang will not generally affect your hearing.
- In general, the powder released is not hazardous to health but may cause short-term breathing difficulties to persons suffering from asthma or other pulmonary conditions.

Provided it is safe to do so, leave the vehicle immediately or open the window in order to prevent breathing difficulties.

## Seat belts

### Protection provided by the seat belt

Always fasten your seat belt correctly before starting a journey. A seat belt can only provide the best level of protection if it is worn correctly.

**⚠ WARNING** Risk of injury or death due to incorrectly fastened seat belt

If the seat belt is not worn correctly, it cannot perform its intended protective function.

In addition, an incorrectly fastened seat belt can also cause injuries, for example, in the event of an accident or when braking or changing direction suddenly.

- ▶ Always ensure that all vehicle occupants have their seat belts fastened correctly and are sitting properly.

Always observe the instructions about the correct driver's seat position and adjusting the seat (→ page 110).

In order for the correctly worn seat belt to provide the intended level of protection, each vehicle occupant must observe the following information:

- The seat belt must not be twisted and must fit tightly and snugly across the body.
- The seat belt must be routed across the centre of the shoulder and as low down across the hips as possible.



- The shoulder section of the seat belt should not touch your neck nor be routed under your arm or behind your back.
- Avoid wearing bulky clothing, e.g. a winter coat.
- Push the lap belt down as far as possible across your hips and pull tight with the shoulder section of the belt. Never route the lap belt across your abdomen.

Pregnant women must also take particular care with this.

- Never route the seat belt across sharp, pointed, abrasive or fragile objects.
- Only one person should use each seat belt at any one time.
- Never secure objects with a seat belt if the seat belt is also being used by one of the vehicle's occupants.

Also ensure that no objects, e.g. a cushion, are ever placed between a person and the seat.

If children are travelling in the vehicle, be sure to observe the instructions and safety notes on "Children in the vehicle" (→ page 60).

Always observe the instructions for loading the vehicle when securing objects, luggage or loads (→ page 124).

### Limitations of the protection provided by the seat belt

**⚠ WARNING** Risk of injury or death due to incorrect seat position

The seat belt will not offer the intended level of protection if you have not moved the seat backrest to an almost vertical position.

In particular, you may slip under the seatbelt and injure yourself.

- ▶ Adjust the seat properly before beginning your journey.
- ▶ Always ensure that the seat backrest is in an almost vertical position and that the shoulder section of your seat belt is

▶ routed across the centre of your shoulder.

**⚠ WARNING** Risk of injury or death when additional restraint systems are not used for persons with a smaller stature

Persons under 1.50 m tall cannot wear the seat belt correctly without a suitable additional restraint system.

- ▶ Always secure persons under 1.50 m tall in a suitable restraint system.

**⚠ WARNING** Risk of injury or death due to damaged or modified seat belts

Seat belts cannot provide protection in the following situations:

- the seat belt is damaged, has been modified, is extremely dirty, bleached or dyed
- the seat belt buckle is damaged or extremely dirty

- modifications have been made to the seat belt tensioner, seat belt anchorage or seat belt retractor

Seat belts may sustain non-visible damage in an accident, e.g. due to glass splinters.

Modified or damaged seat belts could tear or fail in the event of an accident, for example.

Modified seat belt tensioners could accidentally trigger or fail to function as intended.

- ▶ Never modify the seat belt system, for example the seat belt, seat belt buckle, seat belt tensioner, seat belt anchorage and seat belt retractor.
- ▶ Make sure that the seat belts are undamaged, not worn and clean.
- ▶ Always have the seat belts checked immediately after an accident at a qualified specialist workshop.

Mercedes-Benz recommends that you use seat belts which have been approved for your vehicle by Mercedes-Benz.

**! WARNING** Risk of injury or death from deployed pyrotechnic seat belt tensioners

Pyrotechnic seat belt tensioners that have been deployed are no longer operational and are unable to perform their intended protective function.

- ▶ Therefore, have deployed pyrotechnic seat belt tensioners immediately replaced at a qualified specialist workshop.

Mercedes-Benz recommends that you have the vehicle towed to a qualified specialist workshop after an accident.

**! NOTE** Damage caused by trapping the seat belt

If an unused seat belt is not fully retracted, it may become trapped in the door or in the seat mechanism.

- ▶ Always ensure that an unused seat belt is fully retracted.

## Fastening and adjusting seat belts

If the seat belt is pulled quickly or sharply, the seat belt retractor locks. The seat belt strap cannot be pulled out any further.



- ▶ Always engage seat belt tongue ① of the seat belt into seat belt buckle ② of the corresponding seat.

▶ **To adjust the seat belt height:** press button ③ on the seat belt outlet and slide the seat belt outlet to the desired position.

▶ **To engage the seat belt outlet:** release button ③ and ensure that the seat belt outlet engages.

① A seat belt can only provide the best level of protection if it is worn correctly. Observe the notes on fastening the seat belt (→ page 45).

**! NOTE** Deployment of components of the restraint system when the front passenger seat is unoccupied and a seat belt is buckled

When the front passenger seat is unoccupied and the seat belt tongue of the seat belt is engaged in the seat belt buckle, components of the restraint system may deploy unnecessarily on the front passenger side, e.g. the seat belt tensioner.

▶ Only buckle the seat belts as intended.

① Observe the notes on stowage areas (→ page 124).

Information on fitting a child restraint system and on children travelling in the vehicle can be found in the "Children in the vehicle" section (→ page 63).

### Seat belt adjustment function

**Vehicles with PRE-SAFE®:** after a front seat belt has been fastened, the automatic seat belt adjustment may apply a certain tightening force. Do not hold the seat belt tightly while it is adjusting.

You can activate and deactivate the seat belt adjustment function using the multimedia system (→ page 48).

### Activating/deactivating seat belt adjustment via the multimedia system

Multimedia system:

→  ▶ Settings ▶ Vehicle  
▶ Occupant protection

▶ Activate or deactivate **Belt adjustment**.

### Releasing seat belts

▶ Press the release button in the seat belt buckle and guide the seat belt back with the seat belt tongue.

### Seat belt warning function for the driver and front passenger

The  seat belt warning lamp in the driver's display is a reminder that all vehicle occupants must wear their seat belts correctly.

In addition, a warning tone may sound.

As soon as the driver and front passenger fasten their seat belts, the seat belt warning goes out.

### Function of the rear seat belt status display

The rear seat belt status display is only available for certain countries.



When the vehicle is switched on, the rear seat belt status display informs you for a certain amount of time which rear seat belt is not fastened.

The status of the rear seat belt can be recognised by the colour of the symbol in the driver's display:

- Grey: the seat belt tongue of a rear seat belt is not engaged in the seat belt buckle of the corresponding seat.
- Green: the seat belt tongue of a rear seat belt is engaged in the seat belt buckle of the corresponding seat.

Every vehicle occupant must always fasten their seat belt correctly before starting a journey.


- Red: a vehicle occupant in the rear passenger compartment has released the seat belt buckle using the release button and may not be properly secured.

If a vehicle occupant unfastens a seat belt in the rear, the rear seat belt status display appears again.

In addition, a warning tone may sound.

## Airbags


### Overview of airbags



Driver's/front passenger seat:

- ① Knee airbag
- ② Driver's airbag
- ③ Front passenger airbag
- ④ Window airbag
- ⑤ Side airbag
- ⑥ Centre airbag<sup>1)</sup>

<sup>1)</sup> Only for certain countries.



Rear seats:

- ④ Window airbag
- ⑦ Side airbag

The installation location of an airbag is identified by the AIRBAG symbol. An additional arrow symbol ► indicates the installation location for certain airbags.

When enabled, an airbag can provide additional protection for the respective vehicle occupant.

Potential protection provided by each airbag:

- Knee airbag: thigh, knee and lower leg
- Driver's airbag, front passenger airbag: head and ribcage

- Side airbag: ribcage, also pelvis for front seat occupants
- Centre airbag: head and ribcage
- Window airbag: head

#### Information on child restraint systems on the front passenger seat

**⚠ WARNING** Risk of injury or death if the co-driver airbag is enabled

If the co-driver airbag is enabled, a child on the co-driver seat may be struck by the co-driver airbag during an accident.

NEVER use a rearward-facing child restraint system on a seat with an ENABLED FRONT AIRBAG; DEATH or SERIOUS INJURY to the CHILD can occur.

When fitting a child restraint system to the front passenger seat, observe the vehicle-specific information (→ page 75). Also, always observe the notes on rearward-facing or forward-facing child restraint systems on the front passenger seat (→ page 74).

#### Information on automatic front passenger airbag shutoff

The front passenger airbag can only be deployed in an accident if the PASSENGER AIR BAG OFF indicator lamp is off. If the front passenger seat is occupied, make sure, both before and during the journey, that the status of the front passenger airbag is correct (→ page 54).

**! NOTE** Deployment of components of the restraint system when the front passenger seat is unoccupied

In an accident, the components of the restraint system may deploy unnecessarily on the front passenger side if:

- There are heavy objects on the front passenger seat.
- The seat belt tongue is engaged in the seat belt buckle of the front passenger seat and the front passenger seat is unoccupied.

- Stow objects in a suitable place.
- Only one person should use each seat belt at any one time.

Depending on the detected accident situation, the window airbag on the front passenger side may deploy. The airbag is deployed regardless of whether the front passenger seat is occupied.

### Information on the centre airbag

When triggered, the centre airbag deploys between the front seats. Do not stow any objects in the deployment area of the centre airbag.

### Protection provided by the airbags

Depending on the accident situation, an airbag may supplement the protection offered by a correctly fastened seat belt.

**! WARNING** Risk of injury or death due to an incorrect seat position

If you deviate from the correct seat position, the airbag cannot perform its intended protective function.

Each vehicle occupant must make sure of the following:

- Fasten seat belts correctly. Pregnant women must take particular care to ensure that the lap belt never lies across the abdomen.
- Adopt the correct seat position and keep as far away as possible from the airbags.
- Observe the following information.

► Always make sure that there are no objects between the airbag and vehicle occupant.

To avoid the risks resulting from the deployment of an airbag, each vehicle occupant must observe the following information in particular:

- Before starting your journey, adjust your seat correctly; the driver's seat and front passenger seat should be moved as far back as possible.

When doing so, always observe the information on the correct driver's seat position (→ page 110).

- Only hold the steering wheel by the steering wheel rim. This allows the airbag to be fully deployed.
- Always lean against the seat backrest when the vehicle is in motion. Do not lean forwards or against the door or side window. You may otherwise be in the deployment area of the airbags.
- The occupants must always keep their feet on the floor. Do not put your feet on the cockpit, for example. Your feet may otherwise be in the deployment area of the airbag.
- If children are travelling in the vehicle, observe the additional notes (→ page 60).
- Always stow and secure objects correctly.

Objects in the vehicle interior may prevent an airbag from functioning correctly. Each vehicle occupant must always make sure of the following in particular:

- There are no people, animals or objects between the vehicle occupants and an airbag.
- There are no objects between the seat, door and door pillar (B-pillar).

- There are no hard objects, e.g. coat hangers, hanging on the grab handles or coat hooks.
- There are no accessories, such as mobile navigation devices, mobile phones or cup holders, within the deployment area of an airbag, e.g. on the cockpit, on the door, on the side window or on the side trim.

In addition, no connecting cables, tensioning straps or retaining straps must be routed or attached to the vehicle within the deployment area of an airbag. Always comply with the accessory manufacturer's installation instructions and, in particular, the notes on suitable places for installation.

- There are no heavy, sharp-edged or fragile objects in the pockets of your clothing. Store such objects in a suitable place.

### Limitations of the protection provided by airbags

#### **⚠ WARNING** Risk of injury due to modifications to the cover of an airbag

If you modify the cover of an airbag or affix objects such as stickers to it, the airbag can no longer function as intended.

- ▶ Never modify the cover of an airbag.
- ▶ Do not attach any objects to the cover.

The installation location of an airbag is identified by the AIRBAG symbol (→ page 49).

Objects in the deployment area of an airbag may prevent the airbag from functioning correctly.

#### **⚠ WARNING** Risk of injury from objects in the deployment area of an airbag

Objects in the deployment area of an airbag can hinder or prevent the correct deployment of the airbag.

The airbag may then deploy in an uncontrolled manner and may even cause additional injuries to the vehicle occupants by deploying.

This may be the case in particular if the airbag is integrated into the seat.

- ▶ Always stow and secure objects correctly.
- ▶ Before commencing your journey, make sure that no objects are stowed in the deployment area of an airbag.

Observe the notes on loading the vehicle (→ page 124). When triggered, the centre airbag deploys between the front seats (→ page 49).

#### **⚠ WARNING** Risk of injury or death due to the use of unsuitable seat covers

Due to unsuitable seat covers, the airbags cannot protect vehicle occupants as intended.

In addition, the operation of the automatic front passenger airbag shutoff could be restricted.

- ▶ You should only use seat covers that have been approved for the corresponding seats by Mercedes-Benz.

**⚠ WARNING** Risk of injury due to malfunctioning sensors in the door

The function of the airbags can be impaired due to modifications or incorrect work performed on the doors or door trim, or if the doors are damaged.

- ▶ Never modify the doors or parts of the doors.
- ▶ Always have work on the doors or door trim carried out at a qualified specialist workshop.

**⚠ WARNING** Risk of injury due to deployed airbag

A deployed airbag no longer offers any protection.

- ▶ Have the vehicle towed to a qualified specialist workshop in order to have the deployed airbag replaced.

Have deployed airbags replaced immediately.

### Status of the front passenger front airbag

#### **Function of the automatic front passenger airbag shutoff**

The automatic front passenger airbag shutoff is able to detect whether the front passenger seat is occupied by a person or a child restraint system. The front passenger airbag is enabled or disabled accordingly.

**⚠ WARNING** Risk of injury or death due to objects under the co-driver seat

Objects trapped under the co-driver seat can interfere with the function of the automatic co-driver airbag shutoff or damage the system.

- ▶ Do not store any objects under the co-driver seat.
- ▶ When the co-driver seat is occupied, make sure that no objects are trapped under the co-driver seat.

When fitting a child restraint system to the front passenger seat, observe the vehicle-specific information (→ page 75). Also, always observe the notes on rearward-facing or forward-facing child

restraint systems on the front passenger seat (→ page 74).

A person on the front passenger seat must observe the following information:

- Fasten seat belts correctly (→ page 45).
- Sit in an almost upright seat position with their back against the seat backrest.
- Sit with their feet resting on the floor, if possible.

The front passenger airbag may otherwise be disabled by mistake, for example, in the following situations:

- The front passenger transfers their weight by supporting themselves on a vehicle armrest.
- The front passenger sits in such a way that their weight is raised from the seat surface.

**⚠ WARNING** Risk of injury or death due to a disabled front passenger airbag

The front passenger airbag is disabled when the PASSENGER AIR BAG OFF indicator lamp is lit.



A person in the front passenger seat could then, for example, come into contact with the vehicle interior, especially if the person is sitting too close to the cockpit.

If the front passenger seat is occupied, always ensure that:

- the classification of the person in the front passenger seat is correct and the front passenger airbag is enabled or disabled in accordance with the person in the front passenger seat.
- the front passenger seat has been moved as far back as possible.
- the person is seated correctly.

► Both before and during the journey, ensure that the status of the front passenger airbag is correct.

If the front passenger seat is occupied, the classification of the person or child restraint system on the front passenger seat takes place after the front passenger airbag shutoff self-test. The PASSENGER AIR BAG indicator lamps display the status of the front passenger airbag.

Always observe the notes on the function of the PASSENGER AIR BAG indicator lamps (→ page 54).

### Function of the PASSENGER AIR BAG indicator lamps



Vehicles without automatic front passenger airbag shutoff have a special sticker affixed to the side of

the cockpit on the front passenger side (→ page 74).

### Self-test of automatic front passenger airbag shutoff

When the vehicle is switched on, a self-test is performed during which the two PASSENGER AIR BAG ON and OFF indicator lamps light up simultaneously.

The status of the front passenger airbag is displayed via the PASSENGER AIR BAG indicator lamps after the self-test:

- **ON is lit:** the front passenger airbag may deploy during an accident.  
The indicator lamp goes out after 60 seconds.
- **ON and OFF are not lit:** the front passenger airbag may deploy during an accident.
- **OFF is lit:** the front passenger airbag is disabled. It will then not be deployed in the event of an accident.

If the PASSENGER AIR BAG ON indicator lamp is off, only the PASSENGER AIR BAG OFF indicator lamp shows the status of the front passenger air-

bag. The PASSENGER AIR BAG OFF indicator lamp may be lit continuously or be off.

If the PASSENGER AIR BAG OFF indicator lamp and the  restraint system warning lamp light up simultaneously, the front passenger seat may not be used. Also in this case, do not fit a child restraint system to the front passenger seat. Have the automatic front passenger airbag shutoff checked and repaired immediately at a qualified specialist workshop.

### Status display

If the front passenger seat is occupied, ensure, both before and during the journey, that the status of the front passenger airbag is correct for the current situation.

**After fitting a rearward-facing child restraint system to the front passenger seat:** PASSENGER AIR BAG OFF must be lit continuously.

**⚠ WARNING** Risk of injury or death when using a rearward-facing child restraint system while the front passenger airbag is enabled

If you secure a child in a rearward-facing child restraint system on the front passenger seat and the PASSENGER AIR BAG OFF indicator lamp is off, the front passenger airbag can deploy in the event of an accident.

The child could be struck by the airbag.

- ▶ Always ensure that the front passenger airbag is disabled. The PASSENGER AIR BAG OFF indicator lamp must be lit.
- ▶ NEVER use a rearward-facing child restraint system on a seat with an ENABLED FRONT AIRBAG. This can result in the DEATH of or SERIOUS INJURY to the CHILD.

When fitting a child restraint system to the front passenger seat, observe the vehicle-specific information (→ page 74).

Depending on the child restraint system and the stature of the child, the PASSENGER AIR BAG OFF

indicator lamp may be off. In this case, do not fit the rearward-facing child restraint system to the front passenger seat.

Instead, fit the rearward-facing child restraint system to a suitable rear seat.

**After fitting a forward-facing child restraint system to the front passenger seat:** depending on the child restraint system and the stature of the child, PASSENGER AIR BAG OFF may be lit continuously or be off. Always observe the following information.

**⚠ WARNING** Risk of injury or death due to incorrect positioning of the forward-facing child restraint system

If you secure a child in a forward-facing child restraint system on the front passenger seat that is positioned too close to the cockpit, in the event of an accident, the child could:

- come into contact with the vehicle interior if the PASSENGER AIR BAG OFF indicator lamp is lit, for example
- be struck by the airbag if the PASSENGER AIR BAG OFF indicator lamp is off.

- ▶ Always move the front passenger seat as far back as possible and fully retract the seat cushion length adjustment. While doing so, always make sure that the shoulder belt strap is correctly routed from the seat belt outlet of the vehicle to the shoulder belt guide on the child restraint system. The shoulder belt strap must be routed forwards and downwards from the seat belt outlet. If necessary, adjust the seat belt outlet and the front passenger seat accordingly.
- ▶ Always comply with the child restraint system manufacturer's installation instructions.

When fitting a child restraint system to the front passenger seat, observe the vehicle-specific information (→ page 74).

**If a person is sitting on the front passenger seat:** PASSENGER AIR BAG OFF may be lit continuously or be off, depending on the person's stature.

A person on the front passenger seat must always observe the following information:

- If the front passenger seat is occupied by an adult or a person with a stature corresponding to that of an adult, the PASSENGER AIR BAG OFF indicator lamp must be off. This indicates that the front passenger airbag is enabled.  
If the PASSENGER AIR BAG OFF indicator lamp is lit continuously, an adult or person with a build corresponding to that of an adult must not use the front passenger seat. Instead, they should use a rear seat.
- If the front passenger seat is occupied by a person of smaller stature (e.g. a teenager or small adult), the PASSENGER AIR BAG OFF indicator lamp is either lit continuously or remains off, depending on the classification.
  - If the PASSENGER AIR BAG OFF indicator lamp is off: move the front passenger seat as far back as possible, or the person of smaller stature should use a rear seat.
  - If the PASSENGER AIR BAG OFF indicator lamp is lit continuously: the person of

smaller stature should not use the front passenger seat.

**⚠ WARNING** Risk of injury or death when the PASSENGER AIR BAG OFF indicator lamp is lit

If the PASSENGER AIR BAG OFF indicator lamp remains lit after the self-test, the front passenger airbag is disabled.

If the front passenger seat is occupied, always ensure that:

- The classification of the person in the front passenger seat is correct and the front passenger airbag is enabled or disabled in accordance with the person in the front passenger seat.
- The person is seated properly with a correctly fastened seat belt.
- The front passenger seat has been moved as far back as possible.

Be sure to also observe the following further related subjects:

- Child restraint system on the front passenger seat (→ page 74)
- Suitable positioning of the child restraint system (→ page 63)

## PRE-SAFE® system

### Function of PRE-SAFE® (anticipatory occupant protection)

PRE-SAFE® is able to detect certain critical driving situations and implement pre-emptive measures to protect the vehicle occupants.

PRE-SAFE® can implement the following measures independently of each other:

- Tightening the seat belts on the driver's seat and front passenger seat.
- Closing the side windows.
- **Vehicles with sliding sunroof:** closing the sliding sunroof.

- **Vehicles with memory function:** moving the front passenger seat to a more favourable seat position.
- **Vehicles with multicontour seat:** increasing the air pressure in the seat side bolsters of the seat backrest.
- PRE-SAFE® Sound: provided that the multimedia system is switched on, generating a brief noise signal to stimulate the innate protective mechanism of a person's hearing.

**!** **NOTE** Damage caused by objects in the footwell or behind the seat

The automatic adjustment of the seat position may result in damage to the seat and/or the object.

► Stow objects in a suitable place.

### Reversing the PRE-SAFE® system measures

If an accident did not occur, the pre-emptive measures that were taken are reversed.

You will need to perform certain settings yourself.

- If the seat belt pre-tensioning is not reduced, move the seat backrest back slightly. The locking mechanism releases.

### Function of PRE-SAFE® PLUS (anticipatory occupant protection plus)

PRE-SAFE® PLUS can detect certain impacts, particularly an imminent rear impact, and take pre-emptive measures to protect the vehicle occupants. These measures cannot necessarily prevent an imminent impact.

PRE-SAFE® PLUS can implement the following measures independently of each other:

- Tightening the seat belts on the driver's seat and front passenger seat.
- Activating the rear hazard warning lights at a higher flashing frequency.
- Increasing brake pressure when the vehicle is stationary. This brake application is cancelled automatically when the vehicle pulls away.

If an accident did not occur, the pre-emptive measures that were taken are reversed.

### System limits

The system will not initiate any action in the following situations:

- when reversing  
or
- when the vehicle is towing a trailer and there is a risk of a rear impact

The system will not initiate any braking application in the following situations:

- whilst driving  
or
- when entering or exiting a parking space while using Active Parking Assist

### Function of PRE-SAFE® Impulse Side

If an imminent side impact is detected, PRE-SAFE® Impulse Side can pre-emptively move the front seat vehicle occupant's upper body towards the centre of the vehicle. It does this by rapidly inflating an air cushion in the outer seat side bolster of the seat backrest on the side on which the

impact is anticipated. This increases the distance between the door and the vehicle occupant.

If PRE-SAFE® Impulse Side has been deployed or is faulty, the **PRE-SAFE impulse side inoperative** See Owner's Manual (→ page 425) display message appears.

### Automatic measures after an accident

Depending on the type and severity of the accident, and depending on the vehicle's equipment, the following measures can be implemented, for example:

- automatic braking (post-collision brake)
- activating the hazard warning lights
- triggering an automatic emergency call (→ page 355)
- switching off the drive system and high-voltage on-board electrical system
- unlocking the vehicle doors
- lowering the side windows
- displaying the emergency guide in the central display

- switching on the interior lighting

### Function of the post-collision brake

Depending on the accident situation, the post-collision brake can minimise the severity of a further collision or even avoid it.

If an accident is detected, the post-collision brake can implement automatic braking. When the vehicle has come to a standstill, the electric parking brake is automatically applied.

The driver can cancel automatic braking by taking the following actions:

- braking more strongly than automatic braking
- fully depressing the accelerator pedal with force

## Safely transporting children in the vehicle

### Always observe when children are travelling in the vehicle

- i** Also strictly observe the safety notes for the specific situation. In this way you can recognise potential risks and avoid dangers if children are travelling in the vehicle (→ page 60).

#### Be diligent

Bear in mind that negligence when securing a child in the child restraint system may have serious consequences. Always be diligent in securing a child carefully before every journey.

Never allow babies and children to travel sitting on the lap of another vehicle occupant.

To improve protection for children younger than 12 years old or under 1.50 m in height, Mercedes-Benz recommends you observe the following information:

- Always secure the child in a child restraint system suitable for this Mercedes-Benz vehicle.
- The child restraint system must be appropriate to the age, weight and size of the child.

- The vehicle seat must be suitable for fitting a child restraint system (→ page 63).

Accident statistics show that children secured on the rear seats are generally safer than children secured on the front seats. For this reason, Mercedes-Benz strongly advises that you fit a child restraint system to a rear seat.

#### The generic term child restraint system

The generic term child restraint system is used in this Owner's Manual. A child restraint system is, for example:

- a baby car seat
- a rearward-facing child seat
- a forward-facing child seat
- a child booster seat with a backrest and seat belt guide

Mercedes-Benz recommends using a child booster seat with a backrest.

The child restraint system must be appropriate to the age, weight and size of the child.

#### Observe laws and legal requirements

Always observe the legal requirements when using a child restraint system in the vehicle.

Make sure that the child restraint system is approved in accordance with the valid test specifications and guidelines. Further information can be obtained at a qualified specialist workshop. Mercedes-Benz recommends that you use a Mercedes-Benz Service Centre for this purpose.

#### Only use approved child restraint systems

Only child restraint systems that meet the following UNECE standards are permitted for use in the vehicle:

- UN-R44
- UN-R129 (i-Size child restraint systems)

Information on child restraint system approval categories and details on the approval label on the child restraint system (→ page 64).

## Detecting risks, avoiding danger

### Securing systems for child restraint systems in the vehicle

Only use the following securing systems for child restraint systems:

- the ISOFIX or i-Size securing rings
- the vehicle's seat belt system
- the Top Tether anchorages

Fitting an ISOFIX or an i-Size child restraint system is preferred.

Simply attaching to the securing rings on the vehicle can reduce the risk of fitting the child restraint system incorrectly.

When securing a child with the integrated seat belt of the ISOFIX or i-Size child restraint system, always comply with the permissible gross weight for the child and child restraint system (→ page 67).

### Advantage of a rearward-facing child restraint system

It is preferable to transport a baby or a small child in a suitable rearward-facing child restraint sys-

tem. In this case, the child sits in the opposite direction to the direction of travel and faces backwards.

Babies and small children have comparatively weak neck muscles in relation to the size and weight of their head. The risk of injury to the cervical spine during an accident can be reduced in a rearward-facing child restraint system.

### Always secure a child restraint system correctly

**⚠ WARNING** Risk of injury or death due to incorrect installation of the child restraint system

The child can then not be protected or restrained as intended.

- ▶ Be sure to comply with the manufacturer's installation instructions for the child restraint system and its correct use.
- ▶ Make sure that the entire base of the child restraint system always rests on the sitting surface of the seat.

- ▶ Never place objects (e.g. cushions) under or behind the child restraint system.
- ▶ Use child restraint systems only with the original cover designed for them.
- ▶ Always replace damaged covers with genuine covers.

**⚠ WARNING** Risk of injury or death due to unsecured child restraint systems in the vehicle

If the child restraint system is incorrectly fitted or not secured, it can come loose.

The child restraint system could be flung around and hit vehicle occupants.

- ▶ Always install child restraint systems correctly, even when not in use.
- ▶ Always comply with the child restraint system manufacturer's installation instructions.

- Always observe the child restraint system manufacturer's installation and operating

instructions as well as the vehicle-specific information:

- Fitting the ISOFIX or i-Size child restraint system to the rear seat (→ page 67).
- Securing the child restraint system with the seat belt on the rear seat (→ page 73).
- Securing the child restraint system with the seat belt on the front passenger seat (→ page 75). Observe the specific instructions for the rearward-facing and forward-facing child restraint systems (→ page 74).

If the front passenger seat is occupied, ensure, both before and during the journey, that the status of the front passenger airbag is correct for the current situation (→ page 54).

- Observe the warning labels in the vehicle interior and on the child restraint system.
- Also secure Top Tether if present.

### Do not modify the child restraint system

#### **WARNING** Risk of injury due to modifications to the child restraint system

The child restraint system can no longer function properly. This poses an increased risk of injury.

- ▶ Never modify a child restraint system.
- ▶ Only affix accessories which have been specially approved for this child restraint system by the child restraint system's manufacturer.

Mercedes-Benz recommends Mercedes-Benz care products for cleaning child restraint systems recommended by Mercedes-Benz.

### Only use child restraint systems which are in proper working condition

#### **WARNING** Risk of injury or death caused by the use of damaged child restraint systems

Child restraint systems or their retaining systems that have been subjected to stress in an accident may not be able to perform their intended protective function.

It may be the case that the child cannot be properly restrained.

- ▶ Always immediately replace child restraint systems that have been damaged or involved in an accident.
- ▶ Have the securing systems for the child restraint systems checked at a qualified specialist workshop before installing a child restraint system again.



### Avoid direct sunlight

**⚠ WARNING** Risk of burns when the child seat is exposed to direct sunlight

If the child restraint system is exposed to direct sunlight or heat, parts could heat up. Children could suffer burns from these parts, particularly on metallic parts of the child restraint system.

- ▶ Always make sure that the child restraint system is not exposed to direct sunlight.
- ▶ Protect the child restraint system with a blanket, for example.
- ▶ If the child restraint system has been exposed to direct sunlight, allow it to cool before securing a child into it.
- ▶ Never leave children unattended in the vehicle.

### Observe when stopping or parking

**⚠ WARNING** Risk of accident and injury due to leaving children unattended in the vehicle

If children are left unattended in the vehicle, they could, in particular:

- open doors, thereby endangering other persons or road users.
- get out and be struck by oncoming traffic.
- operate vehicle equipment and become trapped, for example.

In addition, the children could also set the vehicle in motion by, for example:

- releasing the parking brake.
- changing the transmission position.
- starting the vehicle.

- ▶ Never leave children unattended in the vehicle.
- ▶ When leaving the vehicle, always take the key with you and lock the vehicle.

- ▶ Keep the vehicle key out of the reach of children.

**⚠ WARNING** Risk of fatal injury due to exposure to extreme heat or cold in the vehicle

If persons, particularly children, are subjected to prolonged exposure to intense heat or cold, there is a risk of severe injury or even death.

- ▶ Never leave persons, particularly children, unattended in the vehicle.

### Overview of recommended child restraint systems

- ① Further information on the correct child restraint system can be obtained at a qualified specialist workshop. Mercedes-Benz recommends that you use a Mercedes-Benz Service Centre for this purpose.

### Securing with ISOFIX

Weight category 0+ (up to 13 kg and up to approx. 15 months)

| Type <sup>1</sup>             | BABY SAFE plus           |
|-------------------------------|--------------------------|
| Size category                 | E                        |
| Approval                      | E1 04 301 146            |
| Order number <sup>2</sup>     | B6 6 86 8224             |
| 1 Manufacturer: Britax Römer. | 2 With colour code 9H95. |

Weight category I (9 to 18 kg and from approximately 9 months to 4 years)

| Type <sup>1</sup>             | DUO plus                 |
|-------------------------------|--------------------------|
| Size category                 | B1                       |
| Approval                      | E1 04 301 133            |
| Order number <sup>2</sup>     | A 000 970 43 02          |
| 1 Manufacturer: Britax Römer. | 2 With colour code 9H95. |

### Securing with the vehicle seat belt

Weight category 0 (up to 10 kg and approximately 6 months) and weight category 0+ (up to 13 kg and approximately 15 months)

| Type <sup>1</sup>             | BABY SAFE plus II        |
|-------------------------------|--------------------------|
| Approval                      | E1 04 301 146            |
| Order number <sup>2</sup>     | A 000 970 38 02          |
| 1 Manufacturer: Britax Römer. | 2 With colour code 9H95. |

Weight category I (9 to 18 kg and from approximately 9 months to 4 years)

| Type <sup>1</sup>             | DUO plus                 |
|-------------------------------|--------------------------|
| Approval                      | E1 04 301 133            |
| Order number <sup>2</sup>     | A 000 970 43 02          |
| 1 Manufacturer: Britax Römer. | 2 With colour code 9H95. |

Weight category II/III (15 to 36 kg and from approximately 3 to 12 years)

| Type <sup>1</sup>             | KIDFIX XP                |
|-------------------------------|--------------------------|
| Approval                      | E1 04 301 304            |
| Order number <sup>2</sup>     | A 000 970 49 02          |
| Type <sup>1</sup>             | AMG KIDFIX XP            |
| Approval                      | E1 04 301 304            |
| Order number <sup>2</sup>     | A 000 970 33 02          |
| 1 Manufacturer: Britax Römer. | 2 With colour code 9H95. |

### Overview of suitable seats in the vehicle for fitting a child restraint system

#### Left/right rear seat

Preferred securing system:

 ISOFIX child seat anchor (→ page 66)

or

 i-Size child seat anchor (→ page 67)



Also secure Top Tether if present  
(→ page 69).

Alternative securing system:



Vehicle seat belt (→ page 71)

### Front passenger seat

Securing system:



Vehicle seat belt (→ page 71)

Be sure to observe:

- If the front passenger seat is occupied, ensure, both before and during the journey, that the status of the front passenger airbag is correct for the current situation (→ page 54).
- Notes on automatic front passenger airbag shutoff (→ page 53).

### Centre rear seat

Securing system:



Vehicle seat belt (→ page 71)

### Approval categories for child restraint systems

#### Only use approved child restraint systems

Only child restraint systems that meet the following UNECE standards are permitted for use in the vehicle:

- UN-R44
- UN-R129 (i-Size child restraint systems)

#### Identification on the child restraint system

Information about the approval category, weight category and approval number, for example, is on the approval label on the child restraint system.

There may be further information such as the ISO-FIX size categories, depending on the approval category of the child restraint system.

### Approval categories in accordance with UN-R44



Example of an approval label

- **Universal:** child restraint systems in the "Universal" category are approved for installation in vehicles. They can be used, in accordance with overviews of the suitability of seats for securing child restraint systems, on seats labelled U, UF or IUF.

The identification IUF refers to ISOFIX child restraint systems in the "Universal" category. These child restraint systems must also be secured using Top Tether or support points.

- **Semi-Universal:** child restraint systems in the "Semi-Universal" category may only be used if the vehicle and vehicle seat are listed in the child restraint system manufacturer's vehicle model list.
- **Vehicle-specific:** child restraint systems in the "vehicle-specific" category may only be used if the vehicle and vehicle seat are listed in the child restraint system manufacturer's vehicle model list.

### Approval categories in accordance with UN-R129



Example of an approval label

- **i-Size:** child restraint systems in the "i-Size" category are approved for installation in vehicles with i-Size mounting brackets. They can be used, in accordance with overviews of the suitability of seats for securing child restraint systems, on seats labelled i-U.

The identification i-U refers to i-Size child restraint systems in the "Universal" category. These child restraint systems must also be secured using Top Tether or support points.

### Observe the suitability of vehicle seats

Depending on the approval category, there are forward-facing and rearward-facing child restraint systems. Their use can be restricted for certain vehicle seats:

- Suitability of seats for attaching ISOFIX child restraint systems (→ page 66)
- Suitability of seats for securing i-Size child restraint systems (→ page 67).
- Suitability of seats for attaching belt-secured child restraint systems (→ page 71)

### Fitting an ISOFIX or i-Size child restraint system on the left and right rear seats

#### Overview of suitability of the seats for attaching ISOFIX child restraint systems

ISOFIX is a standardised securing system for specially designed child restraint systems.



The symbol indicates seats suitable for attaching an ISOFIX child restraint system in accordance with UN R44 (→ page 64).

Attach only child restraint systems that are approved in accordance with UN R44 as per the following ISOFIX tables.

#### Carry cot

| Size class – Equipment                                                                      | Left/right rear seat |
|---------------------------------------------------------------------------------------------|----------------------|
| F – ISO/L1                                                                                  | X                    |
| G – ISO/L2                                                                                  | X                    |
| X Not suitable for an ISOFIX child restraint system in this weight group and/or size class. |                      |

#### Weight group 0 (up to 10 kg and up to approx. 6 months)

| Size class – Equipment                                                                                                                                                                                                                     | Left/right rear seat |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------|
| E – ISO/R1                                                                                                                                                                                                                                 | IL                   |
| IL Suitable for ISOFIX child restraint systems according to the table in "Overview of the recommended child restraint systems", or if the vehicle and the seat are listed on the child restraint system manufacturer's vehicle model list. |                      |

#### Weight group 0+ (up to 13 kg and up to approx. 15 months)

| Size class – Equipment | Left/right rear seat |
|------------------------|----------------------|
| E – ISO/R1             | IL                   |
| D – ISO/R2, ISO/R2X    | IL                   |

| Size class – Equipment                                                                                                                                                                                                                     | Left/right rear seat |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------|
| C – ISO/R3                                                                                                                                                                                                                                 | IL (1)               |
| IL Suitable for ISOFIX child restraint systems according to the table in "Overview of the recommended child restraint systems", or if the vehicle and the seat are listed on the child restraint system manufacturer's vehicle model list. |                      |
| (1) When using a child restraint system of size class (ISO/R3), move the front seat into the highest position. Make sure that the seat backrest of the front seat does not rest against the child restraint system.                        |                      |

#### Weight group 1 (9–18 kg and approx. 9 months to 4 years)

| Size class – Equipment | Left/right rear seat |
|------------------------|----------------------|
| D – ISO/R2, ISO/R2X    | IL                   |
| C – ISO/R3             | IL (1)               |
| B – ISO/F2             | IUF                  |

| Size class – Equipment | Left/right rear seat |
|------------------------|----------------------|
| B1 – ISO/F2X           | IUF                  |
| A – ISO/F3             | IUF                  |

IL Suitable for ISOFIX child restraint systems according to the table in "Overview of the recommended child restraint systems", or if the vehicle and the seat are listed on the child restraint system manufacturer's vehicle model list.

IUF Suitable for forward-facing ISOFIX child restraint systems of the "Universal" category in this weight group.

(1) When using a child restraint system of size class (ISO/R3), move the front seat into the highest position. Make sure that the seat backrest of the front seat does not rest against the child restraint system.

### Overview of suitability of the seats for attaching i-Size child restraint systems

i-Size is a standardised securing system for specially designed child restraint systems.



The symbol indicates seats suitable for attaching an i-Size child restraint system in accordance with UN R129 (→ page 64).

Child restraint systems that are permitted in accordance with UN R44 as per the ISO-FIX tables (→ page 66) or UN R129 as per the following i-Size tables may be attached.

### i-Size child restraint systems (ISO/R2, ISO/F2X, ISO/B2, ISO/B3)

| Front passenger seat                                                             | Left/right rear seat                                                                                            |
|----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------|
| X                                                                                | i-U                                                                                                             |
| X Not suitable for an i-Size child restraint system in the "Universal" category. | i-U Suitable for forward-facing and rearward-facing i-Size child restraint systems in the "Universal" category. |

### Fitting the ISOFIX or i-Size child restraint system on the left and right rear seats

**⚠ WARNING** Risk of accident if the rear bench seat, rear seat and seat backrest are not engaged

The rear bench seat, rear seat and seat backrest may fold forwards, even while the vehicle is in motion.

- As a result, the vehicle occupant will be pressed into the seat belt with increased force. The seat belt will not be able to protect as intended and could cause additional injury.
- Objects or loads in the boot or load compartment cannot be restrained by the seat backrest.

▶ Make sure that the rear bench seat, the rear seat and the seat backrest are engaged before every trip.

If the rear seat backrest is not engaged and locked in place, the red lock verification indicator will be visible.

**⚠ WARNING** Risk of injury or death if the permissible gross mass of the child and child restraint system together is exceeded.

Too much load may be placed on the ISOFIX or i-Size child restraint systems and the child may not be restrained correctly in the event of an accident, for example.

- ▶ If the child and the child restraint system together weigh more than 33 kg, only use an ISOFIX or i-Size child restraint system with which the child is secured with the vehicle seat belt.
- ▶ Also secure the child restraint system with the Top Tether belt, if available.

Always comply with the information about the mass of the child restraint system:

- in the manufacturer's installation and operating instructions for the child restraint system used
- on a label on the child restraint system, if present

Regularly check that the permissible gross mass of the child and child restraint system is still complied with.

When fitting a child restraint system, observe the following:

- ✓ Always observe the correct use of the seats and consider their suitability for attaching a child restraint system.  
ISOFIX child seat anchor (→ page 66)  
or  
i-Size child seat anchor (→ page 67)
- ✓ Always comply with the manufacturer's installation and operating instructions for the child restraint system used.
- ✓ Make sure that the child's feet do not touch the front seat. If necessary, move the front seat slightly forwards.
-  When fitting an ISOFIX child restraint system, also observe the following:
- ✓ **When using a baby car seat in weight group 0/0+ and a rearward-facing child restraint system in weight group 1 on a rear seat:**

adjust the front seat so that the seat does not touch the child restraint system.

- ✓ **When using a forward-facing child restraint system in weight group 1:** remove the head restraint from the respective seat, if possible. In addition, the backrest of the child restraint system must lie as flat as possible against the backrest of the vehicle seat.

After the child restraint system has been removed, replace the head restraint immediately and adjust all head restraints correctly.

- ✓ If the head restraint of the child seat cannot be fully extended when it is installed in the vehicle, this will result in restrictions on the maximum size setting for child restraint systems in weight group 2 or 3.

Contact with the roof when the head restraint is fully extended and locked in place will not result in any restrictions on use.


- ✓ The child restraint system must not be put under strain between the roof and the seat cushion and/or be fitted facing the wrong direction. Where possible, adjust the seat cushion inclination accordingly.

- ✓ The child restraint system must not be put under strain by the head restraint. Adjust the head restraints as appropriate.

 When fitting an i-Size child restraint system, also observe the following:

- ✓ **When using a rearward-facing child restraint system:** adjust the front seat so that it does not touch the child restraint system.
- ✓ **When using a forward-facing child restraint system:** remove the head restraint from the respective seat, if possible. In addition, the backrest of the child restraint system must lie as flat as possible against the backrest of the vehicle seat.

After the child restraint system has been removed, replace the head restraint immediately and adjust all head restraints correctly.



- ① ISOFIX mounting bracket
- ② i-Size mounting bracket

- ▶ Remove and stow away covers ① or ②.
- ▶ Before every journey, make sure that the ISO-FIX child restraint system or the i-Size child restraint system is engaged correctly in both mounting brackets in the vehicle.

**!** **NOTE** Damage to the seat belt for the centre seat during installation of the child restraint system

- ▶ Make sure that the seat belt is not trapped.

- ▶ Attach the ISOFIX or i-Size child restraint system to both mounting brackets in the vehicle.
- ▶ After removing the child seat, reattach covers ① or ②.

### Fastening a Top Tether

**!** **WARNING** Risk of injury or death if the rear seat backrests are not locked after Top Tether belts are fitted

The rear seat backrests may fold forwards when you are driving.

As a result, child restraint systems will no longer be able to perform their intended protective function. This may also cause additional injuries.




- ▶ Always lock rear seat backrests after fitting Top Tether belts.
- ▶ Observe the lock verification indicator.

If the rear seat backrest is not engaged and locked in place, the red lock verification indicator will be visible.




If the child restraint system is equipped with a Top Tether belt:

The risk of injury may be reduced by Top Tether. The Top Tether belt enables an additional connection between the child restraint system attached with ISOFIX or i-Size and the vehicle.



- ▶ If necessary, slide head restraint ① upwards (→ page 115).
- ▶ Fold up cover ② of Top Tether anchorage ③.
- ▶ Fit the ISOFIX or i-Size child restraint system with Top Tether. In doing so, comply with the child restraint system manufacturer's installation instructions.



- ▶ Guide Top Tether belt ④ under head restraint ① between the two head restraint bars.
- ▶ Hook Top Tether hook ⑤ of Top Tether belt ④ into Top Tether anchorage ③ without twisting.
- ▶ Tension Top Tether belt ④. In doing so, comply with the child restraint system manufacturer's installation instructions.
- ▶ Fold down cover ② of Top Tether anchorage ③.
- ▶ If necessary, slide head restraint ① downwards (→ page 115). Make sure that you do not interfere with the correct routing of Top Tether belt ④.

## Securing the child restraint system with the seat belt

Notes on the suitability of seats for attaching belt-secured child restraint systems

### Rear seats

|                                        |      |
|----------------------------------------|------|
| <b>Weight category 0: to 10 kg</b>     |      |
| Left/right rear seat                   | U, L |
| Centre rear seat <sup>1</sup>          | U, L |
| <b>Weight category 0+: to 13 kg</b>    |      |
| Left/right rear seat                   | U, L |
| Centre rear seat <sup>1</sup>          | U, L |
| <b>Weight category I: 9 to 18 kg</b>   |      |
| Left/right rear seat                   | U, L |
| Centre rear seat <sup>1</sup>          | U, L |
| <b>Weight category II: 15 to 25 kg</b> |      |
| Left/right rear seat                   | U, L |

|                                         |              |
|-----------------------------------------|--------------|
| Centre rear seat <sup>1</sup>           | U, L         |
| <b>Weight category III: 22 to 36 kg</b> |              |
| Left/right rear seat                    | U, L         |
| Centre rear seat <sup>1</sup>           | U, L         |
| <b>UN-R129 child restraint systems</b>  |              |
| Left/right rear seat                    | U, L, B2, B3 |
| Centre rear seat <sup>1</sup>           | U, L, B2, B3 |

<sup>1</sup> Child restraint systems with a supporting bracket are not suitable for this seat.

U Suitable for child restraint systems of the "Universal" category in this weight category.

L Suitable for semi-universal child restraint systems according to the table in "Recommended child restraint systems", or if the vehicle and the seat are listed in the child restraint system manufacturer's vehicle model list.

B2, B3 Suitable for the installation of child restraint systems complying with ISO/B2 and ISO/B3 child seat cushion test equipment.

### Notes on child restraint systems on the front passenger seat

- If it is absolutely necessary for you to fit a child restraint system to the front passenger seat, be sure to observe the information on child restraint systems on the front passenger seat (→ page 75).
- Observe the specific instructions for the rearward-facing and forward-facing child restraint systems. If the front passenger seat is occupied, ensure, both before and during the journey,

ney, that the status of the front passenger airbag is correct for the current situation (→ page 54).

Front passenger seat

| Weight category 0: to 10 kg                     |       |
|-------------------------------------------------|-------|
| Front passenger airbag enabled <sup>1</sup>     | X     |
| Front passenger airbag disabled <sup>1, 2</sup> | U, L  |
| Weight category 0+: to 13 kg                    |       |
| Front passenger airbag enabled <sup>1</sup>     | X     |
| Front passenger airbag disabled <sup>1, 2</sup> | U, L  |
| Weight category I: 9 to 18 kg                   |       |
| Front passenger airbag enabled <sup>1</sup>     | UF, L |
| Front passenger airbag disabled <sup>1, 2</sup> | U, L  |
| Weight category II: 15 to 25 kg                 |       |
| Front passenger airbag enabled <sup>1</sup>     | UF, L |
| Front passenger airbag disabled <sup>1, 2</sup> | U, L  |

| Weight category III: 22 to 36 kg                |               |
|-------------------------------------------------|---------------|
| Front passenger airbag enabled <sup>1</sup>     | UF, L         |
| Front passenger airbag disabled <sup>1, 2</sup> | U, L          |
| UN-R129 child restraint systems                 |               |
| Front passenger airbag enabled <sup>1</sup>     | UF, L, B2, B3 |
| Front passenger airbag disabled <sup>1, 2</sup> | U, L, B2, B3  |

|                                                                                                                                                                                                                                   |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1 Adjust the seat cushion inclination so that the front edge of the seat cushion is in the highest position and the rear edge of the seat cushion is in the lowest position.                                                      |
| 2 The vehicle is equipped with automatic front passenger airbag shutoff. The PASSENGER AIR BAG OFF indicator lamp must be lit.                                                                                                    |
| X Not suitable for children in this weight category.                                                                                                                                                                              |
| U Suitable for child restraint systems of the "Universal" category in this weight category.                                                                                                                                       |
| L Suitable for semi-universal child restraint systems according to the table in "Recommended child restraint systems", or if the vehicle and the seat are listed in the child restraint system manufacturer's vehicle model list. |
| UF Suitable for forward-facing child restraint systems of the "Universal" category in this weight category.                                                                                                                       |
| B2, B3 Suitable for the installation of child restraint systems complying with ISO/B2 and ISO/B3 child seat cushion test equipment.                                                                                               |

## Securing the child restraint system with the seat belt on the rear seat

**⚠ WARNING** Risk of accident if the rear bench seat, rear seat and seat backrest are not engaged

The rear bench seat, rear seat and seat backrest may fold forwards, even while the vehicle is in motion.

- As a result, the vehicle occupant will be pressed into the seat belt with increased force. The seat belt will not be able to protect as intended and could cause additional injury.
- Objects or loads in the boot or load compartment cannot be restrained by the seat backrest.

▶ Make sure that the rear bench seat, the rear seat and the seat backrest are engaged before every trip.

If the rear seat backrest is not engaged and locked in place, the red lock verification indicator will be visible.

## When fitting a belt-secured child restraint system, observe the following:

- ✓ Always comply with the manufacturer's installation and operating instructions for the child restraint system used.
- ✓ For a child restraint system in the "Universal" or "Semi-Universal" category, make sure that the system has been approved for the vehicle seat.

Observe the notes under "Suitability of seats for attaching belt-secured child restraint systems" (→ page 71).

- ✓ **When using a weight category 0/0+ baby car seat and a weight category I rearward-facing child restraint system on a rear seat:** adjust the front seat so that the seat does not touch the child restraint system.
- ✓ **When using a weight category I forward-facing child restraint system:** remove the head restraint from the respective seat, if possible.

After the child restraint system has been removed, replace the head restraint immediately and adjust all head restraints correctly.

- ✓ The backrest of the forward-facing child restraint system must, as far as possible, be resting on the seat backrest of the rear seat.
- ✓ If the head restraint of the child seat cannot be fully extended when it is installed in the vehicle, this will result in restrictions on the maximum size setting for child restraint systems in weight category II or III.  
Contact with the roof when the head restraint is fully extended and locked in place will not result in any restrictions on use.
- ✓ The child restraint system must not be put under strain between the roof and the seat cushion and/or be fitted facing the wrong direction. Where possible, adjust the seat cushion inclination accordingly.
- ✓ The child restraint system must not be put under strain by the head restraint. Adjust the head restraints as appropriate.
- ✓ Make sure that the child's feet do not touch the front seat. If necessary, move the front seat slightly forwards.

- ▶ Install the child restraint system.  
The entire base of the child restraint system must always rest on the seat surface of the rear seat.
- ▶ Always make sure that the shoulder belt strap is correctly routed from the seat belt outlet of the vehicle to the shoulder belt guide on the child restraint system.  
The shoulder belt strap must be routed forward from the seat belt outlet.

### Notes on vehicles without automatic front passenger airbag shutoff



Sticker visible when the front passenger door is open

Vehicles without automatic front passenger airbag shutoff have a special sticker affixed to the side of the cockpit on the front passenger side.

Make sure you observe the following information:

- Never fit a rearward-facing child restraint system to the front passenger seat
- Always fit a rearward-facing child restraint system to a suitable rear seat
  - Seats suitable for attaching belted child restraint systems (→ page 71).
  - Secure the child restraint system with the seat belt on the rear seat (→ page 73).
- Notes on rearward-facing and forward-facing child restraint systems on the front passenger seat (→ page 74)

### Notes on rearward-facing and forward-facing child restraint systems on the front passenger seat

**⚠ WARNING** Risk of injury or death when using a rearward-facing child restraint system while the front passenger airbag is enabled


If you secure a child in a rearward-facing child restraint system on the front passenger seat and the PASSENGER AIR BAG OFF indicator

lamp is off, the front passenger airbag can deploy in the event of an accident.

The child could be struck by the airbag.

- ▶ Always ensure that the front passenger airbag is disabled. The PASSENGER AIR BAG OFF indicator lamp must be lit.
- ▶ NEVER use a rearward-facing child restraint system on a seat with an ENABLED FRONT AIRBAG. This can result in the DEATH of or SERIOUS INJURY to the CHILD.

Observe the specific instructions for the rearward-facing and forward-facing child restraint systems (→ page 75).



Warning notice on the front passenger sun visor

Always observe the status of the front passenger airbag on the PASSENGER AIR BAG OFF indicator lamp:

- If it is absolutely necessary to fit a child restraint system to the front passenger seat, always observe the information on automatic front passenger airbag shutoff (→ page 53).
- When using a rearward-facing child restraint system on the front passenger seat, the front passenger airbag must always be disabled. This is only the case if the PASSENGER AIR BAG OFF indicator lamp is lit continuously (→ page 54).

- If the PASSENGER AIR BAG OFF indicator lamp is off, the front passenger airbag is enabled. The front passenger airbag may deploy during an accident.

### Securing the child restraint system with the seat belt on the front passenger seat

When fitting a belt-secured child restraint system on the front passenger seat, always observe the following:

- ☑ Observe the notes on rearward-facing and forward-facing child restraint systems on the front passenger seat (→ page 74).
- ☑ Observe the child restraint system manufacturer's installation and operating instructions.
- ☑ For a child restraint system in the "Universal" or "Semi-Universal" category, make sure that the system has been approved for the vehicle seat.

Observe the notes under "Suitability of seats for attaching belt-secured child restraint systems" (→ page 71).

- ✓ When using a forward-facing child restraint system in weight category I: remove the head restraint from the respective seat, if possible.  
After the child restraint system has been removed, replace the head restraint immediately and adjust all head restraints correctly.
- ✓ The backrest of the forward-facing child restraint system must, as far as possible, be resting on the seat backrest of the front passenger seat.
- ✓ If the head restraint of the child seat cannot be fully extended when it is installed in the vehicle, this will result in restrictions on the maximum size setting for child restraint systems in weight category II or III.  
Contact with the roof when the head restraint is fully extended and locked in place will not result in any restrictions on use.
- ✓ The child restraint system must not be put under strain between the roof and the seat cushion and/or be fitted facing the wrong direction.

- ✓ The child restraint system must not be put under strain by the head restraint. Adjust the head restraints as appropriate.
- ✓ Never place objects (e.g. cushions) under or behind the child restraint system.



**WARNING** Risk of injury or death due to objects between the seat surface and the child restraint system

Objects between the seat surface and the child restraint system could affect the function of the automatic front passenger airbag shut-off.

- ▶ Do not place any objects between the seat surface and the child restraint system.
- ▶ Always make sure that the child restraint system is correctly fitted.

- ▶ Set the front passenger seat as far back as possible and move the seat into the highest position if possible.

- ▶ Fully retract the seat cushion length adjustment.
- ▶ Adjust the seat cushion inclination so that the front edge of the seat cushion is in the highest position and the rear edge of the seat cushion is in the lowest position.
- ▶ Set the seat backrest to the most vertical position possible.
- ▶ Install the child restraint system.  
The entire base of the child restraint system must always rest on the sitting surface of the front passenger seat.
- ▶ Always make sure that the shoulder belt strap is correctly routed from the seat belt outlet of the vehicle to the shoulder belt guide on the child restraint system.  
The shoulder belt strap must be routed forwards and downwards from the seat belt outlet.
- ▶ If necessary, adjust the seat belt outlet and the front passenger seat accordingly.

## Child safety locks

### Activating or deactivating the child safety lock for the rear doors

**⚠ WARNING** Risk of accident and injury due to leaving children unattended in the vehicle

If children are left unattended in the vehicle, they could, in particular:

- open doors, thereby endangering other persons or road users.
- get out and be struck by oncoming traffic.
- operate vehicle equipment and become trapped, for example.

In addition, the children could also set the vehicle in motion by, for example:

- releasing the parking brake.
- changing the transmission position.
- starting the vehicle.

▶ Never leave children unattended in the vehicle.

- ▶ When leaving the vehicle, always take the key with you and lock the vehicle.
- ▶ Keep the vehicle key out of the reach of children.

**⚠ WARNING** Risk of fatal injury due to exposure to extreme heat or cold in the vehicle

If persons, particularly children, are subjected to prolonged exposure to intense heat or cold, there is a risk of severe injury or even death.

- ▶ Never leave persons, particularly children, unattended in the vehicle.

**⚠ WARNING** Risk of accident and injury due to children left unattended in the vehicle

If children are travelling in the vehicle, they could, in particular:

- open doors, thereby endangering other persons or road users.
- get out and be struck by oncoming traffic.
- operate vehicle equipment and become trapped, for example.


- ▶ Always activate the installed child safety locks if children are travelling in the vehicle.
- ▶ Never leave children unattended in the vehicle.
- ▶ When leaving the vehicle, always take the key with you and lock the vehicle.

Vehicles for the United Kingdom: observe the important safety notes in the "Notes on the additional door lock" section.

There are child safety locks for the rear doors and the rear side windows.


The child safety lock on the rear doors secures each door separately. The doors can no longer be opened from the inside.





- ▶ Press the lever in direction ① (activate) or ② (deactivate).
- ▶ Make sure that the child safety locks are working properly.

### Activating and deactivating the child safety lock for the rear side windows



- ▶ **To activate/deactivate:** press button ②.

The rear side window can be opened or closed in the following cases:

- indicator lamp ① is lit: via the switch on the driver's door

- indicator lamp ① is off: via the switch on the corresponding rear door or driver's door

### Notes on pets in the vehicle

**⚠ WARNING** Risk of accident and injury due to animals left unsecured or unattended in the vehicle

If you leave animals in the vehicle unattended or unsecured, they could press buttons or switches, for instance.

An animal may:

- activate vehicle equipment and become trapped, for example
- switch systems on or off and endanger other road users

Unsecured animals may be thrown about the vehicle in the event of an accident, or sudden steering and braking manoeuvres, and injure vehicle occupants.

- ▶ Never leave animals unattended in the vehicle.
- ▶ Always correctly secure animals while driving, e.g. using a suitable animal carrier.

## Key

## Overview of key functions

**⚠ WARNING** Risk of accident and injury due to leaving children unattended in the vehicle

If children are left unattended in the vehicle, they could, in particular:

- open doors, thereby endangering other persons or road users.
- get out and be struck by oncoming traffic.
- operate vehicle equipment and become trapped, for example.

In addition, the children could also set the vehicle in motion by, for example:


- releasing the parking brake.
- changing the transmission position.
- starting the vehicle.

▶ Never leave children unattended in the vehicle.

- ▶ When leaving the vehicle, always take the key with you and lock the vehicle.
- ▶ Keep the vehicle key out of the reach of children.

**! NOTE** Damage to the key caused by magnetic fields

- ▶ Keep the key away from strong magnetic fields.



Vehicle key

- ① Indicator lamp
- ② To lock

③ Unlocks (with embossed surface)

④ Opens/closes the boot lid

**i** If indicator lamp ① does not light up after pressing the or button, the battery is weak or possibly discharged. Replace the battery as soon as possible.

Replace the key battery (→ page 82).

**i Vehicles with convenience doors:** if you have activated the convenience doors function in the multimedia system (→ page 92), you can open or close the driver's or front passenger door by pressing the or button. Additional information on the convenience doors (→ page 87).

The key locks and unlocks the following components:

- doors
- Socket flap
- boot lid

If the vehicle is not opened within approximately 40 seconds after unlocking, it locks again. Anti-theft protection is primed again.

Do not keep the key together with electronic devices or metal objects. This can affect the key's functionality.

### Activating/deactivating the acoustic locking verification signal

Multimedia system:

→  » Settings » Vehicle  
» Open/close

▶ Activate or deactivate the **Acoustic lock**.

#### Please observe:

The selected setting for the acoustic locking verification signal must comply with the relevant national road and traffic regulations. In some countries, including Germany, using the acoustic locking verification signal is forbidden by traffic laws (in accordance with §16 Para. 1 and §30 Para. 1 of the German national road traffic regulations). The driver of the vehicle must comply with these regulations. In countries where the use of this function is forbidden, this function is not activated in the vehicle and must not be activated.

### Changing the unlocking settings

Possible unlocking functions of the key:

- Central unlocking
- Unlocking the driver's door and socket flap

▶ **To switch between settings:** press the  and  buttons simultaneously for approximately six seconds until the indicator lamp flashes twice.

Options if the unlocking function for the driver's door and socket flap has been selected:

- **To unlock the vehicle centrally:** press the  button twice.
- **Vehicles with KEYLESS-GO:** if you touch the inner surface of the door handle on the driver's door, only the driver's door and the socket flap are unlocked.

### Deactivating the function of the key

**Vehicles with KEYLESS-GO:** if you deactivate the function of the key, the KEYLESS-GO functions are also deactivated. Access or drive authorization by KEYLESS-GO is then no longer possible with that

particular key. Activate the function of the key so that all its functions will again be available.

You can also deactivate the function of the key to reduce the energy consumption of the key if you do not use the vehicle or a key for an extended period of time.


▶ **To deactivate:** press the  button on the key twice in quick succession. The key indicator lamp flashes twice briefly and lights up once.

▶ **To activate:** press any button on the key.

 When the vehicle is started with the key in the stowage compartment of the centre console, the function of the key is automatically activated (→ page 180).


## Removing/inserting the emergency key

### Removing the emergency key



- ▶ Press release button ①.
- ▶ Emergency key ② is pushed out slightly.
- ▶ Fully remove emergency key ②.

### Inserting the emergency key



- ▶ Insert emergency key ② at marking ③ until it engages.
- ① You can use emergency key ② to attach the key to a key ring.

### Replacing the key battery

**⚠ DANGER** Risk of fatal injuries if batteries are swallowed

Batteries contain toxic and corrosive substances. Swallowing batteries may cause severe internal burns within two hours.

There is a risk of fatal injury.

- ▶ Keep batteries out of the reach of children.
- ▶ If the cover and/or lid of the battery compartment does not close securely, do not use the key and keep it away from children.
- ▶ If batteries are swallowed, seek medical attention immediately.



**ENVIRONMENTAL NOTE** Environmental damage due to improper disposal of batteries



Batteries contain pollutants. It is illegal to dispose of them with the household rubbish.



Dispose of batteries in an environmentally responsible manner.


Take discharged batteries to a qualified specialist workshop or to a collection point for used batteries.

#### Requirements:

- You require a CR 2032 3 V cell battery.


Mercedes-Benz recommends that you have the battery replaced at a qualified specialist workshop.

- Remove the emergency key (→ page 82).



- Press emergency key ② into the opening in the key in the direction of the arrow until

cover ① opens. When doing so, do not hold cover ① closed.



- Insert emergency key ② into the opening and lift up covering ③ and remove it.
- Repeatedly tap the key against your palm until battery ④ falls out of the key.
- Insert the new battery with the positive pole facing upwards. Use a lint-free cloth to do so.
- Make sure that the surface of the battery is free of lint, grease and other impurities.
- Insert the front tabs of covering ③ into the housing and then press on both sides to close it.

- Make sure that covering ③ is completely closed.

- Insert the front tabs of cover ① into the housing and then press until it is completely closed.

- Insert the emergency key again (→ page 82).

#### Problems with the key, troubleshooting

##### You can no longer lock or unlock the vehicle

Possible causes:

- The key battery is weak or discharged.
- Check the battery using the indicator lamp (→ page 80).
- Replace the key battery, if necessary (→ page 82).
- Use the replacement key.
- Use the emergency key to lock or unlock (→ page 93).
- Have the key checked at a qualified specialist workshop.

**There is interference from a powerful radio signal source**

Possible causes if the function of the key is impaired:

- high voltage power lines
- mobile phones
- electronic devices (notebooks, tablets)
- shielding due to metal objects or induction loops for electrical gate systems or automatic barriers

▶ Make sure that there is sufficient distance between the key and the potential source of interference.

**You have lost a key**

- ▶ Have the key deactivated at a qualified specialist workshop.
- ▶ If necessary, have the mechanical lock replaced as well.

**Doors****Notes on the additional door lock**

The additional door lock is only available for vehicles for the United Kingdom.

**⚠ WARNING** Risk of injury to persons inside the vehicle when the additional door lock is activated

If the additional door lock is activated, the doors can no longer be opened from the inside.

- ▶ Never leave persons, in particular children, unattended in the vehicle.
- ▶ If there are persons in the vehicle, do not activate the additional door lock.

The additional door lock is automatically activated in the following situations:

- The vehicle is locked using the key.
- The vehicle is locked using KEYLESS-GO.

If the vehicle has been locked via Mercedes me connect, the additional door lock is not activated (→ page 348).


If the additional door lock is activated, the doors cannot be opened from the inside.

❗ After locking you can issue a signal with the horn.

You can prevent the additional door lock from being activated by deactivating interior protection before locking the vehicle (→ page 109).


**Unlocking/opening the doors from the inside**

▶ **United Kingdom only:** observe the notes on the additional door lock (→ page 84).



► Pull door handle ①.

### Centrally locking and unlocking the vehicle from the inside



► **To unlock:** press ① button.

► **To lock:** press button ②.

The red indicator lamp on button ② lights up once the vehicle is locked.

The socket flap is also locked and unlocked. The socket flap can be opened even if a key is detected in the car.

The vehicle is not unlocked:

- if you have locked the vehicle using the key
- if you have locked the vehicle using KEYLESS-GO

### Locking/unlocking the vehicle with KEYLESS-GO

#### Requirements:

- The key is outside the vehicle.
- The distance between the key and the vehicle does not exceed 1 m.
- The driver's door and the door on which the door handle is used are closed.

The door handles are extended when:

- the vehicle is unlocked
- the vehicle key is detected
- a door is opened

The door handles retract:

- when the vehicle is locked



- when pulling away
- after waiting for a time

**! NOTE** Damage to the vehicle caused by unintentionally opening the boot lid or a door

- when using an automatic car wash
- when using a high pressure cleaner


► Deactivate the function of the key in these situations.

or


► Make sure that the key is at a minimum distance of 3 m (high-pressure cleaner) or 6 m (automatic car wash) away from the vehicle.

Observe the notes:

- on washing the vehicle in a car wash (→ page 370)
- on using a high pressure cleaner (→ page 371)



► **To unlock the vehicle:** touch the ❶ inner surface of the door handle.



❶ If the door handle is not extended, touch sensor surface ❷ to unlock.

► **To lock the vehicle:** touch recessed sensor surface ❸.

► **Convenience closing:** touch recessed sensor surface ❸ for an extended period.

❶ Further information on convenience closing (→ page 102).

### Problems with KEYLESS-GO, troubleshooting

#### You can no longer lock or unlock the vehicle using KEYLESS-GO

Possible causes:

- The function of the key has been deactivated.
- The key battery is weak or discharged.
- ▶ Activate the function of the key (→ page 81).
- ▶ Check the battery using the indicator lamp (→ page 80).
- ▶ Replace the key battery, if necessary (→ page 82).
- ▶ Use the replacement key.
- ▶ Use the emergency key to lock or unlock (→ page 93).
- ▶ Have the vehicle and key checked at a qualified specialist workshop.

#### There is interference from a powerful radio signal source

Possible causes if the function of KEYLESS-GO is impaired:

- high voltage power lines

- mobile phones
- electronic devices (notebooks, tablets)
- shielding due to metal objects or induction loops for electrical gate systems or automatic barriers

- ▶ Make sure that there is sufficient distance between the key and the potential source of interference.

### Activating or deactivating the automatic locking feature

Multimedia system:

→  ▶ Settings ▶ Vehicle  
▶ Open/close

- ⓘ The vehicle is locked automatically when the vehicle is switched on and the wheels are turning faster than walking pace.
- ▶ Activate or deactivate **Automatic locking**.

In the following situations, there is a danger of being locked out when the function is activated:

- The vehicle is being towed or pushed.

- If the vehicle is being tested on a roller dynamometer.

### Opening and closing the front convenience doors

**⚠ WARNING** Risk of becoming trapped during automatic closing of the front convenience doors

Parts of the body could become trapped. There may be people or animals in the closing area.

- ▶ Make sure that nobody is in the vicinity of the closing area.
- ▶ Use one of the following options to stop the closing process:
  - Press the  or  button on the key.
  - Driver's door: depress the brake pedal.
  - Pull the inner or outer door handles.
  - Push against or pull the door.

- Touch the touch screen in the convenience menu in the multimedia system.

**NOTE** Always observe the following during automatic opening and closing of the front convenience doors

Your view of your surroundings may be restricted.

- ▶ Make sure that there are no persons, animals or objects in the area of the doors when opening and closing.
- ▶ When opening, pay particular attention to low objects and obstacles in the side window area.

### Opening or closing the front convenience doors

The following functions are required to automatically open and close the front convenience doors:

- KEYLESS-GO (→ page 85)
- Power closing function (→ page 92)
- Parking Package with 360° Camera (→ page 266)

or

Remote Parking Assist with Mirror Package (→ page 280)

- Active Blind Spot Assist (→ page 255)

The convenience doors can then be opened and closed automatically.

- ❗ If Active Blind Spot Assist is deactivated or unavailable, the convenience doors cannot be opened from inside.

The following options are available for opening or closing the front convenience doors:

- the key (to open and close)
- approaching the vehicle (to open the driver's door)
- depressing the brake pedal (to close the driver's door)
- the inner front door handles (to open and close)
- the outer front door handles (to open and close)
- the multimedia system (→ page 92)

Special features of the front convenience doors:

- If, when closing, the front door has reached the first detent position, the power closing function (→ page 92) will automatically draw the door into the lock.

▶ **To open using the key:** press and hold the  button on the key until the door starts to open.

- ❗ In the multimedia system, you can set whether the driver's door, the front passenger door or no door opens when you press the  button on the key (→ page 92). If no front door opens, the convenience opening function is carried out when the  button is pressed. The convenience opening function opens, for example, the side windows and the panoramic sliding sunroof. Further information on convenience opening (→ page 102).

▶ **To close using the key:** press and hold the  button on the key until the door starts to close.

Both open front doors close.

- ▶ **Convenience closing with the key:** press and hold the  button on the key. All open front doors, side windows and the panoramic sliding sunroof close.

- ❶ Press the  button on the key again to lock the vehicle.

#### To open the vehicle by approaching it:

**!** **NOTE** Damage to the vehicle due to the unintentional opening of a door

- when walking past the vehicle
- when using an automatic car wash
- when using a high pressure cleaner

▶ Deactivate the function of the key in these situations.

or

▶ Make sure that the key is at a minimum distance of 6 m away from the vehicle.

When you approach your vehicle and the key is detected, the vehicle is unlocked and the driver's door opens automatically.

- ▶ Set the function in the multimedia system (→ page 92).

- ❶ If no further operations are performed when the driver's door has been opened automatically, the door closes after a set time. The driver's door will not be locked.

#### To close the driver's door with the brake pedal:


- ▶ Depress the brake pedal until the door starts to close.

#### To open or close the front convenience doors from inside:

- ▶ Briefly pull the door handle (→ page 84). Automatic operation is then started.

- ❶ If you pull the door handle during automatic operation, the opening or closing process is stopped. If you pull the door handle again, the process continues in reverse order.

- ▶ **To open the front convenience doors from outside:** pull on the outside door handle.



- ▶ **To close the front convenience doors from outside:** touch recessed sensor surface ❶ on the door handle.

#### Object detection


Object detection uses several sensors to monitor the opening range of the convenience doors in order to detect objects. If one of the sensors detects an object, the convenience doors are

stopped and a warning is displayed in the multi-media system.

- ▶ Manually open a door stopped in an intermediate position.

Even if the convenience doors are equipped with sensors, it cannot be guaranteed that all objects are detected. Object detection is only an aid and is not a substitute for the attention of the vehicle occupants to their immediate surroundings when opening and closing the convenience doors. The vehicle occupants are always responsible for opening and closing the doors safely.

### Detection range of the sensors



① approximately 1 m

**!** **NOTE** Risk of an accident from objects at close range

Object recognition may not detect certain objects at close range.

- ▶ When opening the convenience doors, pay particular attention to low objects and obstacles in the side window area. Object detection does not always detect such objects at close range, especially during movement. The vehicle or other objects could otherwise be damaged.

**!** **NOTE** Risk of accident due to faulty sensors

The sensors may malfunction because of snow or due to objects that absorb ultrasonic waves.

- ▶ Make sure that the convenience doors are free from dirt, ice or slush.
- ▶ Be especially careful when opening the convenience doors if other ultrasonic sources are nearby.

**!** **NOTE** Risk of accidents if the detection performance of the sensors in the convenience doors is restricted

If the sensors are covered, the convenience doors cannot function reliably.

- ▶ Do not apply stickers, foils or other coatings to the outside of the convenience doors. The sensors may otherwise be blocked and obstacles may not be detected or only detected to a limited extent.

### Exit warning when opening the front doors from inside

The exit warning of Active Blind Spot Assist is used as an additional safeguard. If an obstacle is detected, the convenience function is deactivated and the moving door will be stopped.

- ▶ Manually open a door stopped in an intermediate position.

#### **⚠ WARNING** Risk of accident despite exit warning

The exit warning neither reacts to stationary objects nor to persons or road users approaching you at a greatly differing speed. The exit warning cannot warn drivers in these situations.

- ▶ Always pay particular attention to the traffic situation when opening the doors and make sure there is sufficient clearance.

The exit warning is only an aid and not a substitute for the attention of vehicle occupants. The responsibility for opening and closing the doors

and for leaving the vehicle remains with the vehicle occupants.

- ❗ Further information on Active Blind Spot Assist with exit warning (→ page 255).

### Blockage detection when opening the front doors

If an obstacle obstructs a door during the automatic opening process, blockage detection will stop the door. The automatic blockage detection function is only an aid and is not a substitute for your attentiveness.

- ▶ Manually open a door stopped in an intermediate position.

#### **! NOTE** Damage to the convenience doors despite blockage detection

Blockage detection may not be able to stop the automatic opening process of the doors in all cases. This can be the case in particular with light, soft objects.

- ▶ Therefore, make sure that there is sufficient clearance next to the vehicle.

### Automatic reversing function when closing the front doors

The doors are equipped with automatic blockage detection with a reversing function. If an obstacle stops a door during the automatic closing process, it will automatically open again. The automatic reversing function is only an aid and is not a substitute for your attentiveness.

- ▶ During the closing process, make sure that no body parts are in the closing area.

#### **⚠ WARNING** Risk of becoming trapped despite reversing function

The reversing function will not react:

- to soft, light and thin objects, e.g. fingers.
- towards the end of the closing process.

In these situations in particular, the reversing function cannot prevent someone being trapped.

- ▶ Make sure that no body parts are in the closing area.
- ▶ If someone is trapped, use one of the following options:

- Press the  or  button on the key.
- Driver's door: depress the brake pedal.
- Pull the inner or outer door handles.
- Push against or pull the door.
- Touch the touch screen in the convenience menu in the multimedia system.

### Setting convenience doors

Multimedia system:

→  » Settings » Vehicle » Comfort

- ▶ Activate or deactivate **Convenience doors**.

### Operating convenience doors

- ▶ Select .
- ▶ Select **Open door control**.  
The window for operating the doors opens.  
The doors can be opened or closed by using the slider.

- ▶ Select **Cancel process**.  
The procedure is interrupted and the door remains in the position it has reached.
- ▶ Select **Close all**.  
All doors are closed simultaneously.

### Setting the key function for the convenience doors

- ▶ Select .
- ▶ Select **Key assignment**.  
**Convenience opening, windows**, opening **Front door, right** and opening **Front door, left** can be set separately for operation with the key.

### Door opening on approach

- ▶ Activate or deactivate the function.  
When the function is activated, the driver's door opens automatically when the vehicle is approached.

### Warning of obstacles in the door area

- ▶ Activate or deactivate the function.  
The vehicle warns you of obstacles in the door area with acoustic feedback and a graphic display.

### Power closing function

**⚠ WARNING** Risk of becoming trapped when the doors close automatically

Body parts or objects can become trapped, causing injuries.

- ▶ Ensure that no body parts or objects are in the closing area.
- ▶ Automatic closing of the doors can be cancelled by pulling the outer or inner door handle.

If you push the door into the lock to the first detent position, the power closing function will automatically pull the door into the lock.


- ❗ If the vehicle is locked from the outside, or while pulling away, an automatic closing of the doors can be triggered.

### Locking/unlocking the vehicle with the emergency key

#### Unlocking a left-hand vehicle door with the emergency key element

##### Vehicles without KEYLESS-GO

- ▶ Remove the emergency key (→ page 82).




- ▶ Pull and hold the door handle.
- ▶ Insert the emergency key into the lock cylinder.
- ▶ Turn the emergency key anti-clockwise to position **1**.
- ▶ Turn the emergency key back to its starting position.

- ▶ Remove the emergency key and release the door handle.

#### Vehicles with KEYLESS-GO


- ▶ Remove the emergency key (→ page 82).



If the door handle is retracted:




- ▶ Insert a flat, non-metallic object behind door handle ❶ from above and pry it slightly outward.
- ▶ Reach behind door handle ❶ from below, pull it outward to the pressure point and hold it there.



If the door handle is extended:

- ▶ Pull door handle ❶ outward to the pressure point and hold it there.
- ▶ Insert the emergency key into the lock cylinder.
- ▶ Turn the emergency key anti-clockwise to position ❶.
- ▶ Forcefully pull door handle ❶ outward past the pressure point.
- ▶ Remove the emergency key and release the door handle.

## Locking the doors



- ▶ Insert a suitable object, e.g. the emergency key, into opening ❶ on the door lock.
- ▶ **To lock the left-hand side of the vehicle:** turn the emergency key clockwise as far as it will go.

- ▶ **To lock the right-hand side of the vehicle:** turn the emergency key anti-clockwise as far as it will go.

If the locked door is then closed, it can no longer be opened from the outside.

## Boot

### Opening the boot lid


- ❗ **NOTE** Damage to the boot lid by obstacles above the vehicle

The boot lid swings upwards when it is opened.

- ▶ Therefore, make sure that there is sufficient clearance above the boot lid.

- ▶ With the boot lid unlocked, press the top of the Mercedes star.
- ▶ **Vehicles with HANDS-FREE ACCESS:** make a kicking movement with your foot below the bumper (→ page 98).

### Vehicles with boot lid convenience closing



- ▶ Pull remote operating switch ① until the boot lid opens.

or

- ▶ Press and hold the  button on the key.
- ▶ If the boot lid is stopped in an intermediate position, pull it upwards. Release it as soon as it begins to open.

- ▶ With the boot lid opening limiter activated, manually pull the stopped boot lid upwards.

If an obstacle obstructs the boot lid during the automatic opening process, blockage detection will stop the boot lid. The automatic blockage detection function is only an aid and is not a substitute for your attentiveness.

### Closing the boot lid

- ⚠ **WARNING** Risk of injury from unsecured items in the vehicle

If objects, luggage or loads are not secured or not secured sufficiently, they could slip, tip over or be thrown around and thereby hit vehicle occupants.

There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

- ▶ Always stow objects in such a way that they cannot be thrown around.

- ▶ Before the journey, secure objects, luggage or loads against slipping or tipping over.

Observe the notes on loading the vehicle.

**Notes on closing the boot lid:** your vehicle is equipped with automatic key recognition. If a key belonging to the vehicle is detected in the vehicle, the boot lid will not be locked and will pop open again.

Note that the boot lid will not be locked if the following situation occurs:

- You have locked the vehicle and close the boot lid while a key belonging to the vehicle is inside the vehicle.
- and
- A second key belonging to the vehicle is not detected outside the vehicle.

Automatic key recognition is only an aid and is not a substitute for your attentiveness.

- ▶ Before locking, ensure that at least one key belonging to the vehicle is outside the vehicle.

- ▶ **To close the boot lid:** pull the boot lid downwards using the handle recess and push it closed.

- ❗ **Vehicles with boot lid convenience closing:** if you lightly push the boot lid closed, the power closing function will automatically pull the boot lid into the lock.

#### Vehicles with boot lid convenience closing

**⚠ WARNING** Risk of becoming trapped during automatic closing of the boot lid


Parts of the body could become trapped. There may be people in the closing area.

- ▶ Make sure that nobody is in the vicinity of the closing area.
- ▶ Use one of the following options to stop the closing process:
  - Press the  button on the key.
  - Press or pull the remote operating switch on the driver's door.
  - Press the closing or locking button on the boot lid.


- Pull the boot lid handle.

**Vehicles with HANDS-FREE ACCESS:** it is also possible to stop the closing process by making a kicking movement below the rear bumper.

- ▶ Pull the boot lid handle. Release it as soon as it begins to close.
- ▶ If the boot lid is stopped in an intermediate position, push it downwards. The boot lid will continue to close.



- ▶ Push remote operating switch ① until the boot lid is fully closed.



- ▶ Press closing button ① on the boot lid.

#### Vehicles with KEYLESS-GO

- ▶ Press locking button ② on the boot lid. If a key is detected outside the vehicle, the boot lid will close and the vehicle will be locked.

- ▶ With the boot lid completely open, press and hold the  button on the key. The key must be in the vicinity of the vehicle.

#### Vehicles with HANDS-FREE ACCESS

- ▶ With the boot lid completely open, make a kicking movement with your foot below the bumper (→ page 98).

#### Boot lid automatic reversing function

The boot lid is equipped with automatic blockage detection with a reversing function. If an obstacle obstructs the boot lid during the automatic closing process, it will automatically open again. The automatic reversing function is only an aid and is not a substitute for your attentiveness.

- ▶ During the closing process, make sure that no body parts are in the closing area.

**⚠ WARNING** Risk of becoming trapped despite reversing function


The reversing function will not react:

- to soft, light and thin objects, e.g. fingers
- towards the end of the closing procedure

In these situations in particular, the reversing function cannot prevent someone being trapped.

- Ensure that no body parts are in the closing area.
- If someone is trapped, use one of the following options:
  - Press the  button on the key.
  - Press the remote operating switch on the driver's door.
  - Press the closing or locking button on the boot lid.
  - Pull the boot lid handle.

### HANDS-FREE ACCESS function



With HANDS-FREE ACCESS you can open, close or interrupt boot lid movement by performing a kicking movement under the rear bumper.

The kicking movement triggers the opening or closing process alternately.

Observe the notes when opening (→ page 95) and closing (→ page 95) the boot lid.

 A warning tone sounds while the boot lid is opening or closing.

 **NOTE** Damage to the vehicle caused by unintentionally opening the boot lid or a door

- when using an automatic car wash
- when using a high pressure cleaner

► Deactivate the function of the key in these situations.

or


► Make sure that the key is at a minimum distance of 3 m (high-pressure cleaner) or 6 m (automatic car wash) away from the vehicle.

When making the kicking movement, make sure that you are standing firmly on the ground. You could otherwise lose your balance, e.g. on ice.

Observe the following notes:

- The key is behind the vehicle.
- Stand at least 30 cm away from the vehicle while performing the kicking movement.

- Do not come into contact with the bumper while making the kicking movement.
- Do not carry out the kicking movement too slowly.
- The kicking movement must be towards the vehicle and back again.



#### ① Detection range of the sensors

If several consecutive kicking movements are not successful, wait ten seconds.

### System limits

The system may be impaired or may not function in the following cases:

- The sensors are dirty, e.g. due to road salt or snow.
- The kicking movement is made using a prosthetic leg.

The boot lid could be opened or closed unintentionally, in the following situations:

- A person's arms or legs are moving in the sensor detection range, e.g. when polishing the vehicle or picking up objects.
- Objects are moved or placed behind the vehicle, e.g. a charging cable or luggage.
- Clamping straps, tarpaulins or other coverings are pulled over the bumper.
- A protective mat with a length reaching over the boot sill down into the detection range of the sensors is used.
- The protective mat is not secured correctly.
- Work is being done on the trailer hitch, trailers or rear bicycle racks.

Deactivate the function of the key (→ page 81) or do not carry the key about your person in such situations.

### Switching separate boot locking on and off

Multimedia system:

→ » Settings » Vehicle  
» Open/close

#### Switching separate boot locking on

- ▶ Select **Block boot**.
- ▶ Create a PIN.
- ▶ Press **OK** to confirm the PIN.
- ▶ Enter the PIN again and confirm it.  
The boot will remain locked if you unlock the vehicle centrally.
- ① If an accident has been detected, the boot will unlock even if separate locking is switched on.
- ① You can open the boot with the emergency key even while boot locking is active. Separate boot locking will remain active.

**Switching separate boot locking off**

- ▶ Select **Block boot**.
- ▶ Enter the PIN.  
If the PIN is correct, separate boot locking will be switched off and the PIN deleted.

**Activating/deactivating the boot lid opening limiter**

Multimedia system:

- ➔  ➔ **Settings** ➔ **Vehicle**
- ➔ **Opening/closing**

- ▶ Activate or deactivate the **Opening height limiter**.

This function prevents the boot lid from hitting a low garage ceiling, for example.

**Side windows****Opening and closing the side windows**

- ⚠ WARNING** Risk of becoming trapped when opening a side window

When you open a side window, parts of the body could be drawn in or become trapped between the side window and window frame.

- ▶ When opening, make sure that nobody is touching the side window.
- ▶ If someone is trapped, release the button immediately or pull it in order to close the side window again.

- ⚠ WARNING** Risk of becoming trapped when closing a side window

When closing a side window, body parts could be trapped in the closing area in the process.

- ▶ When closing, make sure that no body parts are in the closing area.

- ▶ If someone is trapped, release the button immediately or press the button in order to reopen the side window.


- ⚠ WARNING** Risk of becoming trapped when children operate the side windows

Children could become trapped if they operate the side windows, particularly when unattended.

- ▶ Activate the child safety lock for the rear side windows.
- ▶ When leaving the vehicle, always take the key with you and lock the vehicle.
- ▶ Never leave children unattended in the vehicle.

**Requirements:**

- The power supply or the vehicle has been switched on.



- ① To close
- ② To open

The buttons on the driver's door take precedence.

- ▶ **To start automatic operation:** press the  button beyond the point of resistance or pull and release it.
- ▶ **To interrupt automatic operation:** press or pull the  button again.

When the vehicle is switched off, you can continue to operate the side windows.

### Automatic reversing function of the side windows

If an obstacle impedes a side window during the closing process, the side window will open again automatically. The automatic reversing function is only an aid and is not a substitute for your attentiveness.

- ▶ During the closing process, make sure that no body parts are in the closing area.

**⚠ WARNING** Risk of becoming trapped despite there being reversing protection on the side window

The reversing function does not react:

- to soft, light and thin objects, e.g. fingers.
- during resetting.

The reversing function cannot prevent someone from becoming trapped in these situations.

- ▶ During the closing process, make sure that no body parts are in the closing area.
- ▶ If someone becomes trapped, press the  button to open the side window again.

### Automatic function of the side windows

In the following cases, the side windows will be closed automatically when the vehicle is switched off:

- if it starts to rain  
Rain is detected by a rain sensor on the wind-screen.
- in extreme temperatures
- after a certain time (depending on the on-board electrical system voltage)
- if there is a malfunction in the power supply

The side windows will be closed as far as the ventilation position.



**Vehicles with a panorama sliding sunroof:** the side windows will be closed completely if the sliding sunroof is open.

If the side windows are obstructed during automatic closing, the side window concerned will open again slightly. After another automatic closing process, the automatic function for the sunroof and side windows may be deactivated. The automatic function will be active again the next time the vehicle is started.

### Convenience opening (ventilating the vehicle before starting a journey)

**⚠ WARNING** Risk of entrapment when opening a side window

When opening a side window, parts of the body could be drawn in or become trapped between the side window and window frame.

- ▶ When opening, make sure that nobody is touching the side window.
- ▶ Release the button immediately if somebody becomes trapped.

#### Requirements:

- The key is in the immediate vicinity of the vehicle.

▶ Press and hold the  button on the key.

The following functions are performed:

- The vehicle is unlocked.
- The side windows are opened.
- The panoramic sliding roof is opened.
- The seat ventilation of the driver's seat is switched on.

① If the roller sunblind of the panoramic sliding sunroof is closed, the roller sunblind is opened first.

▶ **To interrupt convenience opening:** release  the button.

▶ **To continue convenience opening:** press and hold the  button again.

### Convenience closing (closing the vehicle from outside)

**⚠ WARNING** Risk of entrapment due to not paying attention during convenience closing

When the convenience closing feature is operating, parts of the body could become trapped in the closing area of the side window and the sliding sunroof.

- ▶ When the convenience closing feature is operating, monitor the entire closing process and make sure that no body parts are in the closing area.

#### Requirements:

- The key is in the immediate vicinity of the vehicle.

▶ Press and hold the  button on the key.

The following functions are performed:

- The vehicle is locked.
- The side windows are closed.
- The panoramic sliding roof is closed.

- ▶ **To interrupt convenience closing:** release the  button.
- ▶ **To continue convenience closing:** press and hold the  button again.
- ① Convenience closing also functions with KEY-LESS-GO (→ page 85).

### Resolving problems with the side windows

**⚠ WARNING** Risk of becoming trapped or fatally injured if reversing protection is not activated

If you close a side window again immediately after it has been blocked, the side window will close with increased or maximum force. The reversing function is then not active and body parts may become trapped.

- ▶ Make sure that no parts of the body are in the closing area.
- ▶ To stop the closing process, release the button or press the button again to reopen the side window.

**A side window cannot be closed and you cannot see the cause.**

- ▶ Check to see whether any objects are in the window guide.
- ▶ Adjust the side windows.

### Adjusting the side windows

If a side window is obstructed during closing and reopens again immediately:

- ▶ Immediately after this, pull and hold the corresponding button again until the side window has closed and hold the button for at least one more second (re-adjustment). The side window will be closed without the automatic reversing function.

If the side window is obstructed again and reopens again immediately:

- ▶ Immediately after this, pull and hold the corresponding button again until the side window has closed and hold the button for at least one more second (follow-up adjustment). The side window will be closed without the automatic reversing function.

**The side windows cannot be opened or closed using the convenience opening feature.**

Possible causes:

- The key battery is weak or discharged.
- ▶ Check the battery using the indicator lamp (→ page 80).
  - ▶ Replace the key battery, if necessary (→ page 82).

### Sliding sunroof

#### Opening and closing the sliding sunroof

- ① The term "sliding sunroof" refers to the panorama sliding sunroof.

**⚠ WARNING** Risk of becoming trapped when the sliding sunroof is being opened and closed

Body parts may become trapped in the range of movement.

- ▶ During the opening and closing process, make sure that no body parts are in the sweep of the sliding sunroof.
- ▶ If someone is trapped, release the control panel immediately.

or

- ▶ Touch the control panel during automatic operation.  
The opening/closing process will be stopped.

**⚠ WARNING** Risk of entrapment if the sliding sunroof is operated by children

Children operating the sliding sunroof could get caught in the moving parts, particularly if unattended.

- ▶ Never leave children unattended in the vehicle.
- ▶ When leaving the vehicle, always take the key with you and lock the vehicle.

**⚠ WARNING** Risk of becoming trapped when the roller sunblind is being opened and closed

Body parts may become trapped between the roller sunblind and frame or sliding roof.

- ▶ During the opening or closing process, make sure that no body parts are in the roller sunblind's range of movement.
- ▶ If someone is trapped, release the control panel immediately.

or

- ▶ Touch the control panel during automatic operation.  
The opening/closing process will be stopped.

**! NOTE** Malfunction due to snow and ice

Snow and ice may cause the sliding sunroof to malfunction.

- ▶ Open the sliding sunroof only if it is free of snow and ice.

**! NOTE** Damage caused by protruding objects


Objects that protrude from the sliding sunroof may damage the seals.

- ▶ Do not allow anything to protrude from the sliding sunroof.

**! NOTE** Damage to panorama sliding sunroof caused by roof luggage rack

If the panorama sliding sunroof is opened when a roof luggage rack is fitted, the panorama sliding sunroof may be damaged by the roof luggage rack.

- ▶ Do not open the panorama sliding sunroof if a roof luggage rack is fitted.



The sliding sunroof and the roller sunblind are operated using control panel ①.

The panorama sliding sunroof can be operated only when the roller sunblind is open.

- ▶ **To open:** swipe backwards across control panel ① and hold.
- ▶ **To close:** swipe forwards across control panel ① and hold.

- ▶ **To raise or lower:** press control panel ① briefly.
- ▶ **To start automatic operation:** swipe forwards or backwards across control panel ①.
- ▶ **To cancel automatic operation:** press control panel ① again.  
The opening/closing process will be stopped.

#### Automatic reversing function of the sliding sunroof

If an obstacle obstructs the sliding sunroof during the closing process, the sliding sunroof will open again automatically. The automatic reversing function is only an aid and is not a substitute for your attentiveness.

- ▶ During the closing process, make sure that no body parts are in the closing area.

**⚠ WARNING** Risk of becoming trapped despite reversing function

The reversing function will not react:

- to soft, light and thin objects, e.g. fingers.
- towards the end of the closing procedure.

- during resetting.
  - ▶ During the closing process, make sure that no body parts are in the closing area.
  - ▶ If someone is trapped, release the control panel immediately.
- or
- ▶ Touch the control panel during automatic closing.  
The closing process will be stopped.

#### Automatic reversing function of the roller sunblind

If an obstacle obstructs the roller sunblind during the closing process, the roller sunblind will open again automatically. The automatic reversing function is only an aid and is not a substitute for your attentiveness.

- ▶ When closing the roller sunblind, make sure that no body parts are in the range of movement.

**⚠ WARNING** Risk of becoming trapped despite reversing function

In particular, the reversing function does not react to soft, light and thin objects, e.g. fingers.

- ▶ When closing the roller sunblind, make sure that no body parts are in the range of movement.
- ▶ If someone is trapped, release the control panel immediately.

or

- ▶ Touch the control panel during automatic closing.  
The closing process will be stopped.

### Automatic functions of the sliding sunroof

- ❗ The term "sliding sunroof" refers to the panorama sliding sunroof.

The sliding sunroof will be closed automatically when the vehicle has been switched off in the following situations:

- if it starts to rain

Rain is detected by a rain sensor on the windscreen.

- in extreme temperatures
- after a certain time (depending on the on-board electrical system voltage)
- if there is a malfunction in the power supply

The sliding sunroof will rise at the rear in order to continue ventilating the vehicle interior.

If the sliding sunroof is obstructed during an automatic closing procedure, the roof will be opened again slightly. The automatic function for the sliding sunroof and the side windows will then be deactivated.

#### Rain closing function when driving

**Vehicles with a panorama sliding sunroof:** if it starts to rain, the raised sliding sunroof will automatically be lowered while the vehicle is in motion.

#### Automatic lowering function

**Vehicles with a panorama sliding sunroof:** if the sliding sunroof is raised at the rear, it will automatically be lowered slightly at higher speeds. At low speeds, it will be raised again automatically.

**⚠ WARNING** Risk of becoming trapped by automatic lowering of the sliding sunroof

At higher speeds, the raised sliding sunroof will automatically be lowered slightly at the rear.

- ▶ Make sure that nobody reaches into the sliding sunroof's range of movement while the vehicle is in motion.
- ▶ If someone becomes trapped, touch the control panel.

### Rectifying problems with the sliding sunroof

**⚠ WARNING** Risk of becoming trapped or fatal injuries when the sliding sunroof is closed again

If you close the sliding sunroof again immediately after it has been blocked or reset, the sliding sunroof will close with increased or maximum force.

There is a risk of becoming trapped or even of fatal injuries!

- ▶ Make sure that no parts of the body are in the closing area.
- ▶ If someone is trapped, release the control panel immediately.

or

- ▶ Touch the control panel during automatic closing.  
The closing process will be stopped.

**The sliding sunroof cannot be closed and you cannot see the cause.**

- ❗ The term "sliding sunroof" refers to the panorama sliding sunroof.

If the sliding sunroof is obstructed during closing and reopens again slightly:

- ▶ Immediately after automatic reversing, swipe forwards across the control panel (→ page 103) and hold until the sliding sunroof is closed.  
The sliding sunroof will be closed with increased force.

If the sliding sunroof is obstructed again and opens again slightly:

- ▶ Repeat the previous step.  
The sliding sunroof will be closed again with increased force.

**The sliding sunroof or the roller sunblind is not operating smoothly.**

- ▶ Reset the sliding sunroof and the roller sunblind.

**Resetting the sliding sunroof and the roller sunblind**

- ▶ Swipe forwards across the control panel (→ page 103) and hold repeatedly until the sliding sunroof is completely closed.
- ▶ Press and hold the control panel for another second.
- ▶ Press and hold the control panel until the front roller sunblind is completely closed.
- ▶ Press and hold the control panel for another second.
- ▶ Use automatic operation to fully open and then close the sliding sunroof.

## Anti-theft protection

### Function of the immobiliser

The immobiliser prevents your vehicle from being started without the correct key.

The immobiliser is automatically activated when the vehicle is switched off, and deactivated when the vehicle is switched on.

### ATA (Anti-Theft Alarm system)


#### Function of the ATA system

If the ATA system is primed, a visual and audible alarm is triggered in the following situations:

- when a door is opened
- when the boot lid is opened
- when interior protection is triggered (→ page 109)
- when tow-away protection is triggered (→ page 108)

The ATA system is primed automatically after approximately ten seconds in the following situations:

- after locking the vehicle with the key
- after locking the vehicle using KEYLESS-GO



Example: with MBUX hyperscreen

Indicator lamp ❶ flashes when the ATA system is primed.

The ATA system is deactivated automatically in the following situations:

- after unlocking the vehicle with the key
- after unlocking the vehicle using KEYLESS-GO
- after pressing the start/stop button with the key in the stowage compartment (→ page 180)

❶ When the Mercedes-Benz emergency call system is active and the alarm stays on for more than 30 seconds, a message is automatically sent to the Customer Assistance Centre (→ page 355).

### Deactivating the ATA

▶ Press the , or button on the key.

or

▶ Press the start/stop button with the key in the stowage compartment (→ page 180)

### Deactivating the alarm using KEYLESS-GO

▶ With the key outside the vehicle, touch the inner surface of the door handle.

### Function of tow-away protection

An audible and visual alarm is triggered if an alteration to your vehicle's angle of inclination is detected while tow-away protection is primed.

Tow-away protection is automatically primed after approximately 60 seconds:

- after locking the vehicle with the key
- after locking the vehicle using KEYLESS-GO

Tow-away protection is only primed when the following components are closed:

- doors
- boot lid

Tow-away protection is automatically deactivated:

- after pressing the or button on the key
- after pressing the start/stop button with the key in the stowage compartment (→ page 180)
- after unlocking the vehicle using KEYLESS-GO
- when using HANDS-FREE ACCESS

Information on collision detection on a parked vehicle (→ page 215).

### Priming/deactivating tow-away protection

Multimedia system:

-  » Settings » Vehicle  
 » Opening/closing » Vehicle protection  
 ► Prime or deactivate **Tow-away protection**.

Tow-away protection is primed again in the following cases:

- The vehicle is unlocked again.
- A door is opened.
- The vehicle is locked again.

### Function of interior protection

When interior protection is primed, a visual and audible alarm is triggered if movement is detected in the vehicle interior.

Interior protection is primed automatically after approximately ten seconds:

- after locking the vehicle with the key

- after locking the vehicle using KEYLESS-GO

Interior protection is only primed when the following components are closed:

- doors
- boot lid

Interior protection is automatically deactivated:

- after pressing the  or  button on the key
- after pressing the start/stop button with the key in the stowage compartment (→ page 180)
- after unlocking the vehicle using KEYLESS-GO
- when using HANDS-FREE ACCESS

The following situations can lead to a false alarm:

- when there are moving objects such as mascots in the vehicle interior
- when a side window is open
- when a panoramic sliding sunroof is open

### Priming/deactivating interior protection

Multimedia system:

-  » Settings » Vehicle  
 » Opening/closing » Vehicle protection  
 ► Prime or deactivate **Interior motion sensor**.

Interior protection is primed again in the following cases:

- The vehicle is unlocked again.
- A door is opened.
- The vehicle is locked again.




### Notes on the correct driver's seat position

**⚠ WARNING** Risk of accident due to adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations in particular:

- if you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
- if you fasten your seat belt while the vehicle is in motion

► Before starting the vehicle: in particular, adjust the driver's seat, head restraint, steering wheel and mirror, and fasten your seat belt.



Ensure the following when adjusting the steering wheel ①, seat belt ② and driver's seat ③:

- You are sitting as far away from the driver's airbag as possible, taking the following points into consideration:
- You are sitting in an upright position
- Your thighs are slightly supported by the seat cushion

- Your legs are not fully extended and you can depress the pedals properly
- The back of your head is supported at eye level by the centre of the head restraint
- You can hold the steering wheel with your arms slightly bent
- You can move your legs freely
- You can see all the displays on the instrument cluster clearly
- You have a good overview of the traffic conditions
- Your seat belt sits snugly against your body and passes across the centre of your shoulder and across your hips in the pelvic area

### Seats

#### Adjusting the front seat manually and electrically

**⚠ WARNING** Risk of becoming trapped if the seats are adjusted by children

Children could become trapped if they adjust the seats, particularly when unattended.

- ▶ When leaving the vehicle, always take the key with you and lock the vehicle.
- ▶ Never leave children unattended in the vehicle.

You can adjust the seats when the vehicle is switched off.

**⚠ WARNING** Risk of becoming trapped during seat adjustment

When you adjust a seat, you or other vehicle occupants could become trapped, e.g. on the seat guide rail.

- ▶ Make sure when adjusting a seat that no one has any body parts in the sweep of the seat.

Observe the safety notes on "Airbags" and "Children in the vehicle".

**⚠ WARNING** Risk of accident due to the driver's seat not being engaged

The driver's seat may move unexpectedly while driving.

This could cause you to lose control of the vehicle.

- ▶ Always make sure that the driver's seat is engaged before starting the vehicle.

**⚠ WARNING** Risk of accident due to adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations in particular:

- if you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
  - if you fasten your seat belt while the vehicle is in motion
- ▶ Before starting the vehicle: in particular, adjust the driver's seat, head restraint, steering wheel and mirror, and fasten your seat belt.

**⚠ WARNING** Risk of becoming trapped if the seat height is adjusted carelessly

If you adjust the seat height carelessly, you or other vehicle occupants could be trapped and thereby injured.

Children in particular could accidentally press the electrical seat adjustment buttons and become trapped.

- ▶ While moving the seats, make sure that hands or other body parts do not get under the lever assembly of the seat adjustment system.

**⚠ WARNING** Risk of injury due to head restraints not being fitted or being adjusted incorrectly

If head restraints have not been installed or have not been adjusted correctly, there is an increased risk of injury in the head and neck area, e.g. in the event of an accident or when braking.

- ▶ Always drive with the head restraints fitted.
- ▶ Before driving off, make sure for every vehicle occupant that the centre of the head restraint supports the back of the head at about eye level.

Adjust the head restraint fore-and-aft position so that it is as close as possible to the back of your head.

**⚠ WARNING** Risk of injury or death due to incorrect seat position

The seat belt will not offer the intended level of protection if you have not moved the seat backrest to an almost vertical position.

In particular, you may slip under the seatbelt and injure yourself.

- ▶ Adjust the seat properly before beginning your journey.
- ▶ Always ensure that the seat backrest is in an almost vertical position and that the shoulder section of your seat belt is

routed across the centre of your shoulder.

**⚠ WARNING** Risk of injury or death due to objects under the co-driver seat


Objects trapped under the co-driver seat can interfere with the function of the automatic co-driver airbag shutoff or damage the system.

- ▶ Do not store any objects under the co-driver seat.
- ▶ When the co-driver seat is occupied, make sure that no objects are trapped under the co-driver seat.

**⚠ NOTE** Damage to the seats when adjusting

The seats may be damaged by objects when adjusting the seats.

- ▶ When adjusting the seats, make sure that there are no objects in the footwell, under or behind the seats.




- ① Seat backrest inclination
- ② Seat height
- ③ Seat fore-and-aft position

▶ **To adjust the seat fore-and-aft position:** lift lever ③ and slide the seat into the desired position.

▶ Make sure that the seat is engaged.

### Adjusting the front seat electrically

The switches for adjusting the seats do not move. You will therefore receive no direct feedback on the switch while pressing the switch. Feedback is provided only by the movement of the seat.




- ① Head restraint height
- ② Seat height
- ③ Seat cushion inclination

- ④ Seat cushion length
- ⑤ Seat fore-and-aft position
- ⑥ Seat backrest inclination

► Save the settings with the memory function (→ page 124).

- ⓘ The head restraint height will be adjusted automatically when you adjust the seat height or the seat fore-and-aft position.

### Adjusting the 4-way lumbar support



- ① Higher
- ② Firmer
- ③ Lower
- ④ Softer

► Use buttons ① to ④ to adjust the contour of the backrest.

## Head restraints

### Adjusting the front seat head restraints manually

**⚠ WARNING** Risk of accident due to adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations in particular:

- if you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
  - if you fasten your seat belt while the vehicle is in motion
- ▶ Before starting the vehicle: in particular, adjust the driver's seat, head restraint, steering wheel and mirror, and fasten your seat belt.


**⚠ WARNING** Risk of injury due to head restraints not being fitted or being adjusted incorrectly

If head restraints have not been installed or have not been adjusted correctly, there is an increased risk of injury in the head and neck area, e.g. in the event of an accident or when braking.

- ▶ Always drive with the head restraints fitted.
- ▶ Before driving off, make sure for every vehicle occupant that the centre of the head restraint supports the back of the head at about eye level.


Adjust the head restraint fore-and-aft position so that it is as close as possible to the back of your head.

### Adjusting manually



- ▶ Take hold of the head restraint on both sides and press release knob ①. The head restraint will be unlocked in all directions of movement simultaneously.
- ▶ **To raise or lower:** pull the head restraint upwards or push it downwards.
- ▶ **To move forwards or backwards:** pull the head restraint forwards or push it backwards.
- ▶ Let go of release knob ①.


### Adjusting partially electrically



- ▶ **To raise or lower:** adjust the head restraint using the buttons on the door operating unit (→ page 113).
- ▶ **To move forwards or backwards:** take hold of the head restraint on both sides and press release knob ①.
- ▶ Pull the headrest forwards or push it backwards.
- ▶ Let go of release knob ①.

### Adjusting the head restraints of the rear seats manually

Adjust the head restraint so that it is as close as possible to the back of your head.




- ▶ **To set the centre head restraint in the first position:** pull the head restraint up until it engages.

- ▶ **To raise:** push release knob ① in the direction of the arrow and pull the head restraint up until it engages.
- ▶ **To lower:** press release knob ① in the direction of the arrow and push the head restraint down until it engages.

### Fitting/removing the rear seat head restraints

#### Removal



- ▶ Release the rear seat backrest and fold it forwards slightly (→ page 127).
- ▶ Press release knob ② and pull the head restraint upwards as far as it will go. Release knob ① will extend.
- ▶ Push both release knobs ① and ② at the same time in the direction of the arrow and pull out the head restraint.
- ▶ Fold the rear seat backrest back until it engages.

### Installation

- ▶ Release the rear seat backrest and fold it forwards slightly (→ page 127).
- ▶ Insert the head restraint such that the notches on the bar are on the left when viewed in the direction of travel.
- ▶ Push the head restraint down until it engages.
- ▶ Fold the rear seat backrest back until it engages.

### Configuring the seat settings

Multimedia system:

→  ▶ Comfort ▶ Seat

### Adjusting the air cushions

- ▶ On the corresponding menu, adjust the air cushions for **Lumbar**, **Shoulders** or **Side bolsters**.

### Setting the seat heating balance

- ▶ Select **Heating settings**.
  - ▶ Select **Seat heating balance**.
  - ▶ Adjust the heat distribution for the desired seat.
- ⓘ The seat heating balance can be set in the **Seat climate control** menu in the rear.

### Coupling neck heat to seat heating

- ▶ Select **Additional neck warmer**.
  - ▶ Switch the function for the desired seat on or off.
- If the function is active, the neck heat of the additional cushion has been coupled to the seat heating.

### Setting automatic seat adjustment

**⚠ WARNING** Risk of becoming trapped during adjustment of the driver's seat after calling up a driver profile

Selecting a user profile may trigger an adjustment of the driver's seat to the position saved under the user profile. You or other vehicle occupants could be injured in the process.

- ▶ Make sure that when the position of the driver's seat is being adjusted via the multimedia system, no people or body parts are in the seat's range of movement.

If there is a risk of someone becoming trapped, stop the adjustment process immediately:

- ▶ a) Tap the warning message on the central display.

or

- ▶ b) Press a memory function position button or a seat adjustment switch on the driver's door.  
The adjustment process will be stopped.

Multimedia system:

➞  ➞ **Comfort** ➞ **Seat**  
➞ **Position seat automatically**

### Manually adjusting driver's seat and steering wheel position to body size

The vehicle calculates a suitable driver's seat and steering wheel position on the basis of the driver's body size and sets this directly.

- ▶ **To set the unit of measurement:** select **cm** or **ft/in**.
- ▶ Set the size using the scale.
- ▶ Select **Start positioning**.  
The driver's seat and steering wheel position is adjusted to the body size that has been set.
- ❶ You can also configure these settings via the Mercedes me user account for your user profile. By synchronising the profiles in the vehicle and the Mercedes me connect profiles,

you can carry over these settings for your vehicle. Further information about synchronising user profiles .

### Automatically adjusting driver's seat and steering wheel position to body size

If the vehicle has the Interior Assistant, the driver's body size can be determined automatically using the 3D laser cameras in the overhead control panel.

- ▶ Wait until the Interior Assistant has determined the body size.
- ▶ Select **Start positioning**.  
The driver's seat and steering wheel position is adjusted to the body size that has been determined.
- ❶ Further information on the Interior Assistant:
- ❶ If the driver's seat and steering wheel position calculated by the vehicle is not practical or comfortable, it can be manually adapted at any time via the control buttons.  
The outside mirrors are not set via this function. Instead, they have to be set manually via the operating switches.

### Overview of relaxation programmes

- **Hot Relaxing back** Based on hot stone massage, the programme combines heat and massage. It starts by massaging the back. In addition, warm pressure points become noticeable, starting in the pelvic area.
- **Hot Relaxing shoulders** Combination of heat and massage. It starts by massaging the shoulders. In addition, warm pressure points become noticeable, starting in the pelvic area.
- **Activating Massage** Activating massage programme with upward-moving relaxing waves.
- **Classic Massage** Calming back massage programme.
- **Wave Massage** Regenerating massage programme via relaxing waves across the back and in the seat cushion.
- **Mobilizing Massage** Mobilising massage programme with upward-moving relaxing waves. Can promote slower, deeper respiration. This can improve the supply of oxygen to cells and the brain.



- **Workout, backrest** and **Workout, cushion**  
These programs require your cooperation. Alternating between tensing and releasing helps to improve blood flow to your muscles. Press against a pressure point as soon as you feel it to activate back, abdominal and leg muscles.
- **Depth waves** Wave-like movements in the cushion can promote blood flow and metabolic processes in the lower back and legs.
- **Deep workout** Connect the **Workout, backrest** to the **Workout, cushion**. The vibrations in the cushion intensify the effectiveness of tensing and releasing muscles when you tense against the pressure point. This supports metabolic processes and blood flow in the buttocks and legs.

### Selecting the relaxation programme for the front seats

Multimedia system:

→  ► **Comfort** ► **Massage**

- Select a massage programme (→ page 117).

- Start the programme for the desired seat .

- **To set the massage intensity:** switch **High intensity** on or off.

- ⓘ The availability of this function is dependent on the vehicle's equipment.

### Resetting seat settings

Multimedia system:

→  ► **Comfort** ► **Seat**

- Select **Reset**.
- Select  for the desired seat.

### Switching the seat heating on/off

**⚠ WARNING** Risk of burns due to repeatedly switching on the seat heating

Repeatedly switching on the seat heating can cause the seat cushion and seat backrest padding to become very hot.

In particular, the health of persons with limited temperature sensitivity or a limited ability to react to high temperatures may be affected or they may even suffer burn-like injuries.

- Do not repeatedly switch on the seat heating.

To protect against overheating, the seat heating may be temporarily deactivated after it has been switched on repeatedly.


**! NOTE** Damage to the seats caused by objects or documents when the seat heater is switched on

When the seat heater is switched on, overheating may occur due to objects or documents placed on the seats e.g. seat cushions or child seats. This could cause damage to the seat surface.

- Make sure that no objects or documents are on the seats when the seat heater is switched on.

**Requirements:**

- The power supply is switched on.




- ▶ Press button ❶ repeatedly until the desired heating level is set. Depending on the heating level, up to three indicator lamps will light up. If all indicator lamps are off, the seat heating is switched off.
- ❶ The seat heating will automatically switch down from the three heating levels after 8, 10 and 20 minutes until the seat heating switches off.

- ❶ If you switch the power supply off and on again within 20 minutes, the previous setting of the seat heating for the driver's seat will remain active.

**Switching the seat ventilation on/off****Requirements:**

- The power supply is switched on.



- ▶ Press button ① repeatedly until the desired blower setting has been reached. Depending on the blower setting, up to three indicator lamps will light up. If all indicator lamps are off, the seat ventilation is switched off.

❗ If you switch the power supply off and on again within 20 minutes, the previous seat ventilation setting for the driver's seat will remain active.

## Steering wheel

### Adjusting the steering wheel manually

**⚠ WARNING** Risk of accident due to adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations in particular:

- if you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion


- if you fasten your seat belt while the vehicle is in motion
- ▶ Before starting the vehicle: in particular, adjust the driver's seat, head restraint, steering wheel and mirror, and fasten your seat belt.

**⚠ WARNING** Risk of entrapment for children when adjusting the steering wheel

Children could injure themselves if they adjust the steering wheel.

- ▶ Never leave children unattended in the vehicle.
- ▶ When leaving the vehicle, always take the key with you and lock the vehicle.

## Unlocking



- ▶ Fold release lever ① down as far as it will go.
- ▶ Adjust height ② and distance ③ to the steering wheel.

## Locking

- ▶ Fold release lever ① up as far as it will go.

- ▶ Check and make sure that the steering column is locked by moving the steering wheel.

### Coupling the steering wheel heater with the seat heating

#### Requirements:

- The power supply or the vehicle has been switched on.

Multimedia system:

→  » Comfort » Seat  
» Heating settings

- ▶ Tap on **Additional steering wheel heater**.  
The steering wheel heater will be coupled to the seat heating.

When the function has been activated, the steering wheel heater is automatically activated and deactivated when you switch the switch the seat heating on and off.

### Easy entry and exit feature

#### Using the easy entry and exit feature

**⚠ WARNING** Risk of accident when pulling away during the adjustment process of the easy entry and exit feature

You could lose control of the vehicle.

- ▶ Always wait until the adjustment process is complete before driving off.

**⚠ WARNING** Risk of becoming trapped during adjustment of the easy entry and exit feature

You and other vehicle occupants – particularly children – could become trapped.

- ▶ Ensure that no one has a body part in the sweep of the steering wheel or driver's seat.

If there is a risk of becoming trapped by the steering wheel:

- ▶ Move the adjustment lever of the steering wheel.  
The adjustment process will be stopped.

If there is a risk of becoming trapped by the driver's seat:

- ▶ Press the seat adjustment switch.  
The adjustment process will be stopped.
- ▶ Never leave children unattended in the vehicle.
- ▶ When leaving the vehicle, always take the key with you and lock the vehicle.

**Vehicles with memory function:** you can stop the adjustment process by pressing one of the memory function position switches.

**⚠ WARNING** Risk of becoming trapped if children activate the easy entry and exit feature-

Children could become trapped if they activate the easy entry- and exit feature, particularly when unattended.

- ▶ Never leave children unattended in the vehicle.
- ▶ When leaving the vehicle, always take the key with you and lock the vehicle.

In order to use the easy entry and exit feature, the automatic seat adjustment function must have been switched on (→ page 116).

When the easy entry and exit feature is active, the steering wheel and driver's seat will move as follows:

- The steering wheel will move upwards.
- The driver's seat will move forward or backward to a seat position suitable for getting out of the vehicle.

This will occur in the following situations:

- You switch off the vehicle when the driver's door is open.
- You open the driver's door when the vehicle is switched off.

- ❗ The steering wheel will then move upwards only if it is not already as high as it will go.

The driver's seat will then move backwards only if it is not already at the rear of the seat adjustment range.

The steering wheel and the driver's seat will move back to the last driving position in the following cases:

- You switch the power supply or the vehicle on when the driver's door is closed
- You close the driver's door when the vehicle is switched on.

The last driving position will be saved when:

- You switch off the vehicle.
- **Vehicles with memory function:** you call up the seat settings via the memory function.
- **Vehicles with memory function:** you save the seat settings via the memory function.

**Vehicles with memory function:** press one of the memory function position switches to stop the adjustment process.

## Setting the easy entry and exit feature

### Requirements:

- The automatic seat adjustment has been activated (→ page 116).

Multimedia system:

→  » Settings » Vehicle » Comfort » Easy entry and exit feature

- ▶ Activate/deactivate [seat positioning](#) or [steering wheel positioning](#).

- ❗ If you are using an individual user profile, this information is used for the easy entry and exit feature. This will cause the driver's seat and steering wheel to move into the correct position automatically.

## Memory function

### Function of the memory function

**⚠ WARNING** Risk of an accident if the memory function is used while driving

If you use the memory function on the driver's side while driving, you could lose control of the vehicle as a result of the adjustments being made.

- ▶ Only use the memory function on the driver's side when the vehicle is stationary.

**⚠ WARNING** Risk of entrapment when adjusting the seat with the memory function

When the memory function adjusts the seat, you and other vehicle occupants – particularly children – could become trapped.

- ▶ During the adjusting process of the memory function, ensure that no body

parts are in the area of movement of the seat or the steering wheel.

- ▶ If someone becomes trapped, press a preset position button or seat adjustment switch immediately.  
The adjustment process is stopped.

**⚠ WARNING** Risk of entrapment if the memory function is activated by children

Children could become trapped if they activate the memory function, particularly when unattended.

- ▶ Never leave children unattended in the vehicle.
- ▶ When leaving the vehicle, always take the key with you and lock the vehicle.

You can use the memory function when the vehicle is switched off.


Seat adjustments for up to three people can be stored and called up using the memory function.

You can save the following settings for the front seat:

- Seat, backrest, head restraint position and contour of the seat backrest in the lumbar region
- Seat heating: distribution of the heated sections of the seat cushion and seat backrest
- Driver's side: steering wheel position and position of the outside mirrors on the driver's and front passenger sides
- Head-up display

## Operating the memory function

### Storing



- ▶ Set the seat, the steering wheel, the head-up display and the outside mirror to the desired position.
- ▶ Press the **M** button and then release it.

- ▶ Press one of the preset position buttons **1**, **2** or **3** within three seconds. An acoustic signal sounds. The settings are stored.
- ▶ **To call up:** press the preset position button **1**, **2** or **3**.  
The seat is moved to the stored position. After releasing the button, the front seat, outside mirror, head-up display and steering column continue to move into the stored position automatically.

### Stowage areas

#### Notes on loading the vehicle

Objects in the deployment area of an airbag may prevent the airbag from functioning correctly. Observe the notes on protection provided by the airbag (→ page 51).

**⚠ WARNING** Risk of injury from unsecured items in the vehicle

If objects, luggage or loads are not secured or not secured sufficiently, they could slip, tip

over or be thrown around and thereby hit vehicle occupants.

There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

- ▶ Always stow objects in such a way that they cannot be thrown around.
- ▶ Before the journey, secure objects, luggage or loads against slipping or tipping over.

**⚠ WARNING** Risk of injury due to objects being stowed incorrectly

If objects in the vehicle interior are stowed incorrectly, they can slide or be thrown around and hit vehicle occupants. In addition, cup holders, open stowage spaces and mobile phone brackets cannot always retain all objects they contain.

There is a risk of injury, particularly in the event of braking manoeuvres or abrupt changes in direction.

- ▶ Always stow objects so that they cannot be thrown around in such situations.
- ▶ Always make sure that objects do not protrude from stowage spaces, luggage nets or stowage nets.
- ▶ Close the lockable stowage spaces before starting a journey.
- ▶ Stow and secure objects that are heavy, hard, pointed, sharp-edged, fragile or too large in the load compartment.

**⚠ WARNING** Risk of accident from objects in the driver's footwell and front-passenger footwell

Objects in the driver's footwell and front-passenger footwell may impede pedal travel or block a depressed pedal.

This jeopardises the operating and road safety of the vehicle.

- ▶ Stow all objects in the vehicle securely so that they cannot get into the driver's footwell or front-passenger footwell.

- ▶ Always fit the floor mats securely and as prescribed in order to ensure that there is always sufficient clearance for the pedals.
- ▶ Do not use loose floor mats and do not lay multiple floor mats on top of one another.

#### **Vehicles with automatic front passenger airbag**

**shutoff:** objects trapped under the front passenger seat may interfere with the function of the automatic front passenger airbag shutoff or damage the system. Please observe the notes on the function of the automatic front passenger airbag shutoff (→ page 53).

The driving characteristics of your vehicle are dependent on the distribution of the load within the vehicle. You should bear the following in mind when loading the vehicle:

- never exceed the permissible gross mass or the permissible axle loads for the vehicle (including occupants).

Information can be found on the vehicle identification plate (→ page 415).

- the load must not protrude above the upper edge of the seat backrests.
- always place the load behind unoccupied seats if possible.
- secure the load using the tie-down eyes and distribute the load evenly.


#### Notes on driving with a roof load

- Evenly distribute the roof load, and place heavy objects at the bottom. Also comply with the notes on loading the vehicle.
  - Drive attentively, and avoid suddenly pulling away, braking and steering as well as rapid cornering.
  - When transporting roof loads and when the vehicle is fully loaded or fully occupied, select drive programs **E** and **C**. These are designed to focus on stability (→ page 188).
- i** For more information on stowage compartments and stowage areas, please refer to the Digital Owner's Manual.



## Stowage spaces in the vehicle interior

### Overview of the front stowage compartments



- ❶ Stowage spaces in the doors
- ❷ Stowage and telephone compartment beneath the armrest with multimedia and USB ports as well as stowage space, e.g. for an MP3 player
- ❸ Stowage compartment in the front centre console with cup holders, USB ports and charging module for wireless charging of mobile phones
- ❶ The rubber mat in the stowage compartment in front centre console ❸ can be removed

for cleaning with clean, lukewarm water. Please comply with the notes on caring for the interior (→ page 375).

- ❶ Use the rubber strap to securely store objects in the stowage tray under the central display.

### Opening and closing the stowage compartment in the front centre console

**⚠ WARNING** Risk of injury due to objects being stowed incorrectly


If objects in the vehicle interior are stowed incorrectly, they can slide or be thrown around and hit vehicle occupants. In addition, cup holders, open stowage spaces and mobile phone brackets cannot always retain all objects they contain.

There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

- Always stow objects in such a way that they cannot be thrown around in such situations.

- Always make sure that objects do not protrude from stowage spaces, luggage nets or stowage nets.
- Close the lockable stowage spaces before starting a journey.
- Always stow and secure heavy, hard, pointed, sharp-edged, fragile or bulky objects in the boot.

Observe the notes on loading the vehicle.




- **To open:** slide the cover of the stowage compartment in the front centre console all the

way forwards in the direction of the arrow using handle ①.

- ▶ **To close:** briefly push handle ① of the open cover of the stowage compartment in the front centre console forwards. The cover will automatically close the stowage compartment in the front centre console.

### Opening and closing the glove compartment



- ▶ **To open:** press button ①.

The glove compartment is open.

- ▶ **To close:** fold the glove compartment upwards.

The glove compartment is closed.

### Through-loading feature in the rear bench seat (EASY-PACK Quickfold)

#### Folding the rear seat backrests forward

**⚠ WARNING** Risk of becoming trapped when adjusting the seats

When you adjust a seat, you may trap yourself or a vehicle occupant.

- ▶ When adjusting a seat, make sure that no one has any body parts in the sweep of the seat.

**⚠ WARNING** Risk of an accident because the seat backrest is not engaged

The seat backrest may fold forwards.

There is a risk of the following, in particular:

- The vehicle occupant may be pressed against the seat belt. The seat belt cannot protect as intended and could cause additional injury.
- A child restraint system is no longer properly supported or properly positioned and may no longer fulfil its function as intended.
- The seat backrest cannot restrain objects or goods in the boot or load compartment.

Always ensure that the seat backrest is engaged, especially:

- After the seat has been adjusted.
- After the load compartment enlargement has been folded forwards

Make sure that the red marking of the lock verification indicator is no longer visible. Otherwise, the seat backrest will not be locked.

Always ensure that all vehicle occupants have their seat belts fastened correctly and are sitting

properly. Particular attention must be paid to children.

### Requirements:

- The rear seat backrest head restraints are fully inserted.
- Vehicles with a folding rear armrest: the rear armrest has been folded up.


### Folding the rear outer seat backrests forward

You can fold the centre and right seat backrests forwards separately.


The left seat backrest can be folded forwards only together with the centre seat backrest.

If you no longer require the folded-down rear seat backrest as a load area, fold the backrest back into place.

- ▶ Ensure that the centre seat backrest is in an upright position and locked to the left seat backrest (→ page 130).




- ▶ Press the seat belt tongue of seat belt ① into marked position ②.
- ▶ Move the driver's or front passenger seat forwards, if necessary.



- ▶ Pull release lever ①.
- ▶ Fold the corresponding seat backrest forwards.

### Folding the centre rear seat backrest forwards separately

If you no longer require the folded-down seat backrest as a loading area, fold the backrest back into place.




- ▶ Press release catch ③.
- ▶ Fold the seat backrest ② forwards.

### Folding back the rear seat backrest

**!** **NOTE** Damage caused by trapping the seat belt when folding back the seat backrest

The seat belt could become trapped and thus be damaged when the seat backrest is folded back.


- ▶ Make sure that the seat belt is not trapped when folding back the seat backrest.



- ▶ Move the driver's or front passenger seat forwards, if necessary.
- ▶ Swivel seat backrest ① back until it engages. If the seat backrest is not engaged and locked in place, red lock verification indicator ② will be visible.

### Locking and releasing the release catch of the centre rear seat backrest


You can lock the centre seat backrest release catch if you want to secure the boot against unauthorised access. The centre seat backrest can then be folded forwards only together with the left seat backrest.



▶ **To lock or unlock:** slide catch ① upwards or downwards.

### Overview of the tie-down eyes

Observe the notes on loading the vehicle (→ page 124).



- ① Tie-down eyes
- ② Four tie-down eyes are available only in vehicles equipped with the through-loading feature in the rear bench seat (EASY-PACK Quickfold).

### Attaching a roof luggage rack

**⚠ WARNING** Risk of accident due to exceeding the maximum roof load

The vehicle centre of gravity and the usual driving characteristics as well as the steering and braking characteristics alter.

If you exceed the maximum roof load, the driving characteristics, as well as steering and braking, will be greatly impaired.

▶ Never exceed the maximum roof load and adjust your driving style.

You will find information on the maximum roof load in the "Technical data" section.

**! NOTE** Damage to the vehicle due to not observing the maximum permitted headroom clearance

If the vehicle height is greater than the maximum permitted headroom clearance, the roof and other parts of the vehicle may be damaged.

- ▶ Observe the signposted headroom clearance.
- ▶ If the vehicle height is greater than the permitted headroom clearance, do not enter.
- ▶ Observe the changed vehicle height with add-on roof equipment.

**! NOTE** Vehicle damage from non-approved roof luggage racks


The vehicle could be damaged by roof luggage racks that have not been tested and approved by Mercedes-Benz.

- ▶ Only use roof luggage racks tested and approved for Mercedes-Benz.
- ▶ Depending on the vehicle equipment, ensure that when the roof luggage rack is fitted, the tailgate can be fully opened.
- ▶ Position the load on the roof luggage rack in such a way that the vehicle will not sustain damage even when it is in motion.

**! NOTE** Damage to panorama sliding sunroof caused by roof luggage rack

If the panorama sliding sunroof is opened when a roof luggage rack is fitted, the panorama sliding sunroof may be damaged by the roof luggage rack.

- ▶ Do not open the panorama sliding sunroof if a roof luggage rack is fitted.



**! NOTE** Damage to the covers

The covers may be damaged and scratched when being opened.

- ▶ Do not use metallic or hard objects.

- ▶ Carefully fold covers ① upwards in the direction of the arrow.
- ▶ Secure the roof luggage rack to the fastening points beneath covers ①.
- ▶ Comply with the installation instructions of the roof luggage rack manufacturer.
- ▶ Secure the load on the roof luggage rack.

### Cup holders

#### Fitting the cup holder in or removing it from the centre console

**! WARNING** - Risk of accident or injury when using the cup holder while the vehicle is in motion

The cup holder cannot hold a container secure while the vehicle is in motion.

If you use a cup holder while the vehicle is in motion, the container may be flung around and liquids could be spilled. The vehicle occupants may come into contact with the liquid and if it is hot, they could be scalded. You could be distracted from traffic conditions and you may lose control of the vehicle.

- ▶ Only use the cup holder when the vehicle is stationary.
- ▶ Only use the cup holder for containers of the right size.
- ▶ Always close the container, particularly if the liquid is hot.

**⚠ WARNING** Risk of injury due to objects being stowed incorrectly

If objects in the vehicle interior are stowed incorrectly, they can slide or be thrown around and hit vehicle occupants. In addition, cup holders, open stowage spaces and mobile phone brackets cannot always retain all objects they contain.


There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

- ▶ Always stow objects in such a way that they cannot be thrown around in such situations.
- ▶ Always make sure that objects do not protrude from stowage spaces, luggage nets or stowage nets.
- ▶ Close the lockable stowage spaces before starting a journey.
- ▶ Always stow and secure heavy, hard, pointed, sharp-edged, fragile or bulky objects in the boot.

#### Requirements:


- For installation: the locking catch is pushed in the direction of the cup holder.

#### Installation




- ▶ Insert cup holder housing ① into the stowage compartment on a slight angle.
- ▶ Place cup holder housing ① in the stowage compartment, aligning the recesses with the two hubs ② so that they fit.
- ▶ Push the cup holder down.

### Locking




- ▶ Slide locking catch ① toward the side wall of the centre console.  
The cup holder will be locked.

### Removal



- ▶ Slide locking catch ① toward the cup holder. The cup holder will be unlocked.
- ▶ First pull the cup holder up in the direction of arrow ② and then tilt it slightly to remove it from the stowage compartment.

### Using the cup holder



- ▶ Placing a beverage container in the cup holder.  
Bottom ② of the cup holder lowers automatically and side walls ① of the cup holder move forward automatically.
- ① The cup holder automatically adjusts to the size of the container placed in it.




The side walls of the cup holder can also be activated manually in different ways:

- Slightly press down the bottom with the beverage container.
- Press the grooved surface on the side wall of the cup holder.

- ❗ Check whether the beverage container is firmly held by the cup holder. Some beverage containers are not adequately secured in the cup holder due to their shape or size.

### Original position

When the cup holder is not in use, the side walls of the cup holder can be retracted manually. The bracket arms of the cup holder are automatically retracted as well, and the cup holder's holding function will then no longer be available.



- ▶ Manually push back the side walls of cup holder ② in the direction of the arrow.

### Opening or closing the cup holder and small storage compartment in the rear armrest

**⚠ WARNING** – Risk of accident or injury when using the cup holder while the vehicle is in motion

The cup holder cannot hold a container secure while the vehicle is in motion.

If you use a cup holder while the vehicle is in motion, the container may be flung around and liquids could be spilled. The vehicle occupants may come into contact with the liquid and if it is hot, they could be scalded. You could be distracted from traffic conditions and you may lose control of the vehicle.

- ▶ Only use the cup holder when the vehicle is stationary.
- ▶ Only use the cup holder for containers of the right size.
- ▶ Always close the container, particularly if the liquid is hot.

**!** **NOTE** Damage to the rear armrest due to body weight

When folded out, the rear armrest can be damaged by body weight.


- ▶ Do not sit or support yourself on the rear seat armrest.

**!** **NOTE** Damage to the cup holder

When the rear armrest is folded back the cup holder could become damaged.

- ▶ Only fold the rear armrest back when the cup holder is closed.

### Opening the mobile phone holder in the rear armrest



- ▶ Press cover trim **1** once. The mobile phone holder will open in the direction of the arrow.
- ▶ Place the mobile phone in or remove it from the holder.


### Closing the mobile phone holder in the rear armrest

- ▶ Press cover trim **1**. The mobile phone holder and the cup holder are both open.

- ▶ Press cover trim **1** a second time. The mobile phone holder will be closed.

- i** The mobile phone holder is designed for two mobile phones or one tablet. The devices can also be charged in the holder by inserting the charging cable into the devices through the opening on the underside of the holder.
- i** Observe the notes on loading the vehicle (→ page 124).

### Opening or closing the cup holders in the rear armrest



- ▶ **To open:** press cover trim ❶ twice.  
The cup holder will open in the direction of the arrow.
- ▶ Place a container in or remove a container from the cup holder.
- ▶ **To close:** slide the cup holder back into the rear armrest.


## Sockets

### Using the 12 V socket in the front passenger footwell

#### Requirements:

- Only connect devices up to a maximum of 180 W (15 A).

Depending on the vehicle equipment, the vehicle has a 12 V socket in the front passenger footwell.



- ▶ Lift up socket cap ❶.
- ▶ Insert the plug of the device.
- ▶ Make sure that no cables are running through or secured in the airbag deployment area when using the socket. Also observe the notes on airbag protection (→ page 51).

## USB ports

Depending on its equipment, the vehicle has the following USB ports:

- In the stowage compartment in the front centre console
- In the stowage compartment under the front armrest
- In front of the stowage tray under the central display of the multimedia system
- In the electronics compartment in the centre console of the rear passenger compartment

You can charge a USB device, such as a mobile phone, at the USB ports using a suitable charging cable. Depending on the vehicle equipment, the devices can be charged with up to 20 V (5 A) when the vehicle is switched on.

## Wireless charging of the mobile phone and connection with the exterior aerial

### Notes on wirelessly charging the mobile phone

#### **⚠ WARNING** Risk of injury due to objects being stowed incorrectly

If objects in the vehicle interior are stowed incorrectly, they can slide or be thrown around and hit vehicle occupants. In addition, cup holders, open stowage spaces and mobile phone receptacles cannot always retain all objects within.

There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

- ▶ Always stow objects so that they cannot be thrown around in such situations.
- ▶ Always make sure that objects do not protrude from stowage spaces, luggage nets or stowage nets.
- ▶ Close the lockable stowage spaces before starting a journey.

- ▶ Always stow and secure heavy, hard, pointed, sharp-edged, fragile or bulky objects in the boot/load compartment.

Observe the notes on loading the vehicle.

#### **⚠ WARNING** Risk of fire from placing objects in the mobile phone stowage compartment

Placing other objects in the mobile phone stowage compartment could constitute a fire hazard.

- ▶ Apart from a mobile phone, do not place any other objects in the mobile phone stowage compartment, especially those made of metal.

#### **! NOTE** Damage to objects caused by placing them in the mobile phone stowage compartment

If objects are placed in the mobile phone stowage compartment, these may be damaged by electromagnetic fields.

- ▶ Do not place credit cards, storage media, ski passes or other objects sensitive to electromagnetic fields in the mobile phone stowage compartment.

#### **! NOTE** Damage to the mobile phone stowage compartment caused by liquids

If liquids enter the mobile phone stowage compartment, the compartment may be damaged.

- ▶ Ensure that no liquids enter the mobile phone stowage compartment.

Always observe the notes for persons with electronic medical aids (→ page 38).

- Depending on the vehicle equipment, the mobile phone is connected to the vehicle's exterior aerial via the charging module.
- The charging function and wireless connection of the mobile phone to the vehicle's exterior aerial are only available if the vehicle is switched on.

- Small mobile phones may not be able to be charged in every position of the mobile phone stowage compartment.
- Large mobile phones which do not rest flat in the mobile phone stowage compartment may not be able to be charged or connected with the vehicle's exterior aerial.
- The mobile phone may heat up during the charging process. This may also depend on the applications (apps) currently open in the background.
- To ensure more efficient charging and connection with the vehicle's exterior aerial, remove the protective cover from the mobile phone. Protective covers which are necessary for wireless charging are an exception.

### Wirelessly charging a mobile phone in the front


#### **Requirements:**

- The mobile phone is suitable for wireless charging.

A list of compatible mobile phones can be found at: <https://www.mercedes-benz-mobile.com/>

Depending on the vehicle's equipment, the vehicle has the following options for wirelessly charging a mobile phone in the cockpit:

- in the front stowage compartment of the centre console



Example: wirelessly charging the mobile phone in the front stowage compartment (with MBUX hyper-screen)

- ▶ Place the mobile phone as close to the centre of mat ① as possible with the display facing upwards.

When a message is shown in the multimedia system, the mobile phone is being charged. In addition, malfunctions during the mobile phone's charging process are shown in the multimedia system display.

- ① The mat can be removed for cleaning, e.g. using clean, lukewarm water.

#### **Radio equipment approval numbers for Brazil**

This device operates on a secondary basis, that is to say it has no protection against harmful interference, not even from the same type of stations, and must not cause interference with systems operating on a primary basis.

This product is permitted in accordance with the procedure defined in Directive 242/2000 by the Brazilian telecommunications agency ANATEL and meets the applicable technical requirements.

Further information is available on the ANATEL website. [www.anatel.gov.br](http://www.anatel.gov.br)


- ▶ Further information on the declaration of conformity for vehicle components which receive and/or transmit radio waves.

### Wirelessly charging a mobile phone in the rear passenger compartment

#### Requirements:


- The mobile phone is suitable for wireless charging.

A list of compatible mobile phones can be found at: <https://www.mercedes-benz-mobile.com/>



Wireless charging in the rear passenger compartment in vehicles without MBUX rear tablet

- ▶ Fold down the rear armrest.
- ▶ Place the mobile phone as close to the centre of mat ① as possible with the display facing upwards.  
When the indicator lamp at the front of the mobile phone system lights up, the mobile phone is being charged. In addition, malfunctions during the mobile phone's charging process are shown by the indicator lamp flashing three times.



Wireless charging in the rear passenger compartment in vehicles with MBUX rear tablet

- ▶ Fold down the rear armrest.
- ▶ Open the stowage compartment in rear armrest ①.
- ▶ Place the mobile phone as close to the centre of mat ② as possible with the display facing upwards.  
When the indicator lamp at the front of the mobile phone system lights up, the mobile phone is being charged. In addition, malfunctions during the mobile phone's charging process are shown by the indicator lamp flashing three times.

- ⓘ Observe the notes on loading the vehicle (→ page 124).


### Fitting and removing the floor mats

**⚠ WARNING** Risk of accident due to objects in the driver's footwell

Objects in the driver's footwell may impede pedal travel or block a depressed pedal. This jeopardises the operating and road safety of the vehicle.

- ▶ Stow all objects in the vehicle securely so that they cannot get into the driver's footwell.
- ▶ Always fit the floor mats securely and as prescribed in order to ensure that there is always sufficient room for the pedals.
- ▶ Do not use loose floor mats and do not place floor mats on top of one another.

### Fitting floor mats



- ▶ Slide the corresponding seat backwards and lay the floor mat in the footwell such that it fits.
- ▶ Press studs ① onto holders ②.
- ▶ Adjust the corresponding seat.

### Removing floor mats

- ▶ Slide the corresponding seat backwards and pull the floor mat off holders ②.
- ▶ Adjust the corresponding seat.

## Exterior lighting

### Notes on adjusting the lights when driving abroad

The headlamps will automatically be adjusted when the vehicle crosses the border into countries in which traffic drives on the other side of the road and will retain their full range of functions. If necessary, the headlamps can also be adjusted manually in the **Low beam** menu (→ page 152).

In the following cases, check the headlamp setting and change it manually if necessary:

- If the **Dipped-beam setting (left/right-side traffic) Manual adjustment only** display message is displayed.
- If the **Check dipped-beam setting (left/right-side traffic)** display message is displayed.

Following manual adjustment:


- Oncoming traffic will not be dazzled.
- The edge of the road will not be illuminated as far or as high.
- The "motorway mode" and "enhanced fog light" functions will not be available.

### Information about lighting systems and your responsibility

The various lighting systems of the vehicle are only aids. The driver of the vehicle is responsible for correct vehicle illumination in accordance with the prevailing light and visibility conditions, legal requirements and traffic situation.

### Light switch

#### Operating the light switch



- 1 Left-hand parking lights
- 2 Right-hand parking lights
- 3 Standing lights and licence plate lighting
- 4 **AUTO** Automatic driving lights (preferred light switch position)



- 5  Low beam/high beam
- 6  Switches the rear fog light on/off

When low beam is activated, the  indicator lamp for the standing lights will be deactivated and replaced by the  low-beam indicator lamp.

- ▶ Always park your vehicle safely using sufficient lighting, in accordance with the relevant legal stipulations.

**!** **NOTE** Battery discharging by operating the standing lights

Operating the standing lights over a period of hours puts a strain on the battery.

- ▶ Where possible, switch on the right  or left  parking light.

For vehicles that are wider than 2 m or longer than 6 m, single-sided parking lighting is not permitted in some countries. In this case, the standing lights are also switched on in the parking lights position.

If the battery is insufficiently charged, the standing lights or parking lights will be switched off automatically to facilitate the next engine start.

The exterior lighting (except standing and parking lights) will switch off automatically when the driver's door is opened.

- Observe the notes on locator lighting (→ page 152).

### Automatic driving lights function

When the vehicle is switched on, the standing lights, low beam and daytime running lights are switched on automatically depending on the light conditions.

**!** **WARNING** Risk of accident when the dipped beam is switched off in poor visibility

When the light switch is set to **AUTO**, the dipped beam may not be switched on automatically if there is fog, snow or other causes of poor visibility such as spray.

- ▶ In such cases, turn the light switch to .

The automatic driving lights are only an aid. You are responsible for vehicle lighting.

### Switching the rear fog light on/off


#### Requirements:

- The light switch is in the  or **AUTO** position.

- ▶ Press button .

Please observe the country-specific laws on the use of rear fog lamps.

## Operating the combination switch for the lights



- ① High beam
- ② Turn signal light, right
- ③ Headlamp flashing
- ④ Turn signal light, left

► Use the combination switch to select the desired function.

## Switching on high beam

- Turn the light switch to the  or **AUTO** position.
- Push the combination switch in the direction of arrow ①.  
When the high beam is activated, the indicator lamp for low beam  will be deactivated and replaced by the indicator lamp for high beam .

## Switching off high beam

- Push the combination switch in the direction of arrow ① or pull it in the direction of arrow ③.

## Headlamp flashing

- Pull the combination switch in the direction of arrow ③.

## Turn signal light


- **To indicate briefly:** push the combination switch briefly to the point of resistance in the direction of arrow ② or ④.  
The corresponding turn signal light will flash three times.

- **To indicate permanently:** push the combination switch beyond the point of resistance in the direction of arrow ② or ④.


Vehicles with Active Lane Change Assist:

- A turn signal indicator activated by the driver may continue to operate for the duration of the lane change.
- If the driver indicated directly beforehand but a lane change was not immediately possible, the turn signal indicator may activate automatically.

### Activating/deactivating the hazard warning lights



Vehicles without MBUX Hyperscreen



Vehicles with MBUX Hyperscreen

▶ Press button ①.

The hazard warning lights will switch on automatically if:

- the airbag has been deployed.
- the vehicle is braked heavily from a speed of more than 70 km/h to a standstill.

When you pull away again, the hazard warning light system will switch off automatically at approximately 10 km/h. You can also switch off the hazard warning light system using the warning lamp button.

### Adaptive functions of the DIGITAL LIGHT

#### Intelligent Light System function


In this system, the headlamps adapt to the driving and weather situation. It also provides extended functions for improved illumination of the road.

The system comprises the following functions:

- Active headlamps (→ page 145)
- Cornering light (→ page 145)
- Motorway mode (→ page 145)
- Enhanced fog light function (→ page 146)
- Bad weather light (→ page 146)
- City lighting (→ page 146)
- Topographical compensation (→ page 146)

The system is active only when it is dark.

### Active headlamps function




- The headlamps follow the steering movements.
- Relevant areas are better illuminated during a journey.

The functions are active when the low beam is switched on.

Depending on the vehicle's equipment, the course of the lane in which you are driving will also be evaluated and the active headlamps function will adjust the light in advance.

### Cornering light function



The cornering light improves the illumination of the carriageway over a wide angle in the turning direction, enabling better visibility on tight bends, for example. The cornering light can be activated only when the low beam is switched on.


The function is active in the following cases:

- At speeds below 40 km/h when the turn signal light is switched on or the steering wheel is turned
- At speeds between 40 km/h and 70 km/h and when the steering wheel is turned

**Roundabout and junction function:** the cornering light will be activated on both sides based on an evaluation of the vehicle's current navigation position. It will remain active until after the vehicle has left the roundabout or the junction.

### Motorway mode function

Motorway mode increases the range and brightness of the cone of light, enabling better visibility.



The function will be active if a motorway journey is detected by means of:


- the vehicle's speed
- the multifunction camera
- the navigation system

The function is not active in the following cases:

- at speeds below 80 km/h

### Enhanced fog light function

The enhanced fog light function reduces self-dazzling and improves the illumination of the edge of the carriageway.



The function is automatically activated under the following conditions:

- At speeds below 70 km/h and when the rear fog light is switched on.

The function is automatically deactivated under the following conditions:

- When speeds greater than 100 km/h are reached.
- When the rear fog light is switched off.

### Function of the bad weather light

The bad weather light reduces reflections in rainy conditions by dimming individual areas of the headlamps. The driver and other road users are dazzled less as a result.

### The city lighting function

City lighting improves the illumination of roadsides in urban areas using a broad distribution of light.

The function is active in the following cases:

- At low speeds
- In illuminated parts of urban areas

### Function of the topographical compensation

Based on map data, the lighting system responds pre-emptively to different road heights. This means that the headlamp range remains virtually constant when you are driving on uphill or downhill gradients.

- ❗ Only vehicles with a multimedia system with navigation have this function.

### Assistance functions of the DIGITAL LIGHT


DIGITAL LIGHT visually expands on the driver assistance systems by projecting the assistant displays in front of the vehicle while it is in motion. DIGITAL LIGHT can therefore help the driver in critical situations.

- ❗ The availability of the functions is dependent on the country.
- ❗ The assistance functions of the DIGITAL LIGHT are available on-demand (→ page 24).

The system is active in the following cases:

- The light switch is in the **AUTO** position.
- The high beam is switched on.
- ❗ Depending on the country in which you are currently driving, certain functions may be disabled due to different legal requirements, even if they are enabled in the multimedia system. When a border is crossed, the vehicle will automatically adapt to the valid requirements.

## Spotlight




The spotlight function runs in the background and flashes the headlamps at detected persons within the lane markings in four short bursts. The driver is also made aware of the position of the person by a symbol projection.

The function is active under the following conditions:

- You are driving outside illuminated areas.
- The system detects a lane marking.

## Warnings




If Traffic Sign Assist detects a corresponding situation, a triangle will be projected onto the road in the following situations at speeds of at least 30 km/h:

- You are driving in the opposite direction to the permissible direction of travel, e.g. on a motorway slip road.
- You are driving towards a stop sign without reducing your speed.
- You are driving towards a red traffic light without reducing your speed.


Observe the system limitations of Traffic Sign Assist (→ page 251).

## Notes




If Traffic Sign Assist detects a roadworks zone, the system will provide support as follows:

- A corresponding symbol will be projected onto the road when you enter a roadworks zone.
- When you drive through a roadworks zone, guide lines will be projected onto the road that roughly match the width of the vehicle. The guide lines will be suppressed for a while on tight bends.



Observe the system limitations of Traffic Sign Assist (→ page 251).


### **Collision warning**



If you fall below the safe distance at speeds of at least 30 km/h, a collision warning symbol will be projected onto the road.

Observe the system limitations of Active Brake Assist (→ page 245).


### **Lane change warning**



During assisted lane changes at speeds of at least 30 km/h, the course of the lane change will be brightened. This enables you to identify possible dangers in the new lane at an early stage.

Observe the system limitations of Active Lane Change Assist (→ page 242).

### **Lane keeping and blind spot warning**



At speeds of at least 30 km/h, a triangle that indicates a lane correction and its direction will be projected onto the road in the following cases:

- The lane is left unintentionally.  
Observe the system limitations of Active Lane Keeping Assist (→ page 259).
- You switch on the turn signal light while an object or obstacle is in your blind spot.  
Observe the system limitations of Active Blind Spot Assist (→ page 255).

## Switching the Intelligent Light System on/off

### Requirements:

- The vehicle is switched on.

Multimedia system:

→  » Settings » Lights  
» DIGITAL LIGHT

- ▶ Activate or deactivate **Dynamic low beam**.

### Activating or deactivating enhanced assistance functions

- ① The availability of the functions is dependent on the country.
- ① This function is an on-demand feature (→ page 24).
- ▶ Select **Supporting projections**.
- ▶ Activate or deactivate the desired projection.
- ▶ Activate or deactivate **Projection when opening/closing**.

If the locator lighting or the exterior switch-off delay time is activated, a high-resolution greeting or farewell scene will be played back for a short period of time when the vehicle is

opened or locked. You can choose between the **Digital Rain** and **Particle Flow** sequences.

- ① More information on locator lighting (→ page 152)  
More information on the exterior switch-off delay time (→ page 152)

## Adaptive Highbeam Assist

### Adaptive Highbeam Assist function

**⚠ WARNING** Risk of accident despite Adaptive Highbeam Assist

Adaptive Highbeam Assist does not react to:

- road users without lights, e.g. pedestrians
- road users with poor lighting, e.g. cyclists
- road users whose lighting is obstructed, e.g. by a barrier

On very rare occasions, Adaptive Highbeam Assist may fail to recognise other road users with their own lighting, or may recognise them too late.

In these, or in similar situations, the automatic high beam will not be deactivated or will be activated despite the presence of other road users.

- ▶ Always observe the road and traffic conditions carefully and switch off the high beam in good time.

Adaptive Highbeam Assist cannot take into account road, weather or traffic conditions.


Detection may be restricted in the following cases:

- in poor visibility, e.g. fog, heavy rain or snow
- if there is dirt on the sensors or the sensors are obscured

Adaptive Highbeam Assist is only an aid. You are responsible for adjusting the vehicle's lighting to the prevailing light, visibility and traffic conditions.

- ① Adaptive Highbeam Assist is available on demand (→ page 24).





Adaptive Highbeam Assist automatically switches between the following types of light:

- Low beam
- High beam

At speeds greater than 30 km/h:

- If no other road users are detected, the high beam will switch on automatically.

The high beam will switch off automatically in the following cases:

- At speeds below 25 km/h
  - If other road users are detected
  - If street lighting is sufficient
- i** The system's optical sensor is located behind the windscreen near the overhead control panel.

### Switching Adaptive Highbeam Assist on/off

#### Switching on

- ▶ Turn the light switch to the **AUTO** position.
- ▶ Switch on the high beam using the combination switch.  
If Adaptive Highbeam Assist is activated, the  indicator lamp will light up on the driver display.

#### Switching off

- ▶ Switch off the high beam using the combination switch.

### Adaptive Highbeam Assist Plus

#### Adaptive Highbeam Assist Plus function

**⚠ WARNING** Risk of accident despite Adaptive Highbeam Assist Plus

Adaptive Highbeam Assist Plus does not react to:

- road users without lights, e.g. pedestrians
- road users with poor lighting, e.g. cyclists
- road users whose lighting is obstructed, e.g. by a barrier

On very rare occasions, Adaptive Highbeam Assist Plus may fail to recognise other road users with their own lighting, or may recognise them too late.

In these, or in similar situations, the automatic high beam will not be deactivated or will be activated despite the presence of other road users.

- ▶ Always observe the road and traffic conditions carefully and switch off the high beam in good time.

Adaptive Highbeam Assist Plus cannot take into account road, weather or traffic conditions.

Detection may be restricted in the following cases:

- In poor visibility, e.g. fog, heavy rain or snow
- If there is dirt on the sensors or the sensors are obscured

Adaptive Highbeam Assist Plus is only an aid. You are responsible for adjusting the vehicle's lighting to the prevailing light, visibility and traffic conditions.



Adaptive Highbeam Assist Plus automatically switches between the following types of light:

- Low beam
- Partial high beam
- High beam

Partial high beam does not include other road users in the high beam area. It does not dazzle

them but enables full high beam illumination for the driver apart from the excluded vehicles.

At speeds below 25 km/h or when there is sufficient street lighting:

- The partial high beam and the high beam will be switched off automatically.

At speeds greater than 30 km/h:

- If no other road users are detected, the high beam will switch on automatically.
- If other road users are detected, the partial high beam will switch on automatically.

At speeds above 40 km/h:

- If other road users are detected, the partial high beam will switch on automatically.

**i** The system's optical sensor is located behind the windscreen near the overhead control panel.

### Switching Adaptive Highbeam Assist Plus on/off

#### Switching on

► Turn the light switch to the **AUTO** position.

- ▶ Switch on the high beam using the combination switch.  
If Adaptive Highbeam Assist Plus is activated, the  indicator lamp will light up on the driver's display. When partial high beam or high beam is active, the corresponding blue indicator lamp will also light up.

### Switching off

- ▶ Switch off the high beam using the combination switch.

### Setting low beam

Multimedia system:

- ▶  ▶ Settings ▶ Lights
- ▶ DIGITAL LIGHT ▶ Low beam

- ▶ Select **Right-side traffic**, **Left-side traffic** or **Automatic**.

### Setting the exterior lighting switch-off delay time

Multimedia system:

- ▶  ▶ Settings ▶ Lights
- ▶ Interior/exterior lighting
- ▶ Exterior lighting delayed switch off

- ▶ Set the switch-off delay time.  
When the vehicle's engine is switched off, the exterior lighting will be activated for the set time.

### Activating/deactivating the locator lighting

Multimedia system:


- ▶  ▶ Settings ▶ Lights
- ▶ Interior/exterior lighting

- ▶ Activate or deactivate **Locator lighting**.

When the function is activated, the exterior lighting will light up for 40 seconds after the vehicle is unlocked. When you start the vehicle, the locator lighting will be deactivated and the automatic driving lights activated.

### Interior lighting


#### Adjusting the interior lighting



- ①  Switches the front interior lighting on/off
- ②  Switches the rear interior lighting on/off
- ③  Switches automatic interior lighting control on/off

- ▶ **To switch reading lamps on/off:** touch respective reading lamp ④ or ⑤.

## Control panel in the rear passenger compartment



① Rear reading lamp

▶ To switch on or off: press button ①.

## Adjusting the ambient lighting

Multimedia system:

➡ ➡ Comfort ➡ Ambient lighting

## Setting the colour

- ▶ Select **Colour**.
- ▶ Select **Monochrome** or **Multi-colour**.
- ▶ Set the desired colour or colour scheme.

## Energy Shine

- The interactive Energy Shine colour world shows the different phases during the journey. Depending on the type of driving condition (speed, boost effect or recuperation), this is shown in colour by the active ambient lighting.

## Adjusting the brightness

- ▶ Select **Brightness**.
- ▶ Adjust the brightness.
- ① Depending on the ambient light conditions, the ambient lighting will automatically switch between day and night modes.

## Activating the brightness for zones

- ▶ Select **Brightness**.
- ▶ Switch off **Link zones** .  
The **Direct**, **Indirect** and **Accents** zones can be set separately.
- ① The **Light strip** zone can also be set in vehicles with active ambient lighting.

## Activating effects

**⚠ WARNING** Risk of an accident despite activated effects of ambient lighting and active ambient lighting

To use the Warning Assistance effects, the respective functions must be activated in the driver assist menu.

- ▶ Make sure that the functions and assists are switched on.

- ① Observe the notes on driving systems and your responsibility; you may otherwise fail to recognise dangers (→ page 217).
- ▶ Select **Effects**.
- ▶ Activate the desired effect.
- ① Depending on the vehicle equipment, different effects are available.

## Operating feedback effects

- **Climate**: If changes are made to the temperature setting in the vehicle, the colour of the ambient lighting will change briefly.

- **Voice assistant:** For vehicles with active ambient lighting, the voice assistant is visually animated.
- **Greeting:** When you get into the vehicle, a special colour animation will play.
- **Charging sequence:** The ambient lighting provides visual feedback on the different states of charge when the vehicle is connected to or disconnected from the charging station.

#### Warning assistance effects

- **Warning when exiting:** If an object is detected in the blind spot while you are getting out of the vehicle, the ambient lighting in the affected door will flash red.  
Further information on the exit warning (→ page 255).
- **Active Lane Keeping Assist:** If there is a warning from Active Lane Keeping Assist, the active ambient lighting will flash red.  
Further information on Active Lane Keeping Assist (→ page 259).

- **Active Brake Assist:** If there is an Active Brake Assist warning, the active ambient lighting in the centre of the cockpit will flash bright red.  
Further information on the Active Brake Assist (→ page 245).
- **Active Blind Spot Assist:** In vehicles with active ambient lighting, the ambient lighting on the affected side will flash red if there is a warning from Active Blind Spot Assist.  
Further information on Active Blind Spot Assist (→ page 255).
- **Parking Assist PARKTRONIC:** The information from the parking sensors during parking manoeuvres is displayed in colour.  
Further information on Parking Assist PARKTRONIC: (→ page 271)

#### Multi-colour animat.

- The chosen colour combination will change at predefined intervals.
- i** In vehicles with active ambient lighting, an animation will be played.

- i** The desired operating feedback and warning assistance can be activated or deactivated via the  symbol. Depending on the equipment, different operating feedback and warning assistance effects are available.
- i** If the brightness is set to a low level, warning animations will be displayed at a higher basic brightness.

#### Switching the interior lighting switch-off delay time on/off


Multimedia system:

→  >> Settings >> Lights  
>> Interior/exterior lighting  
>> Interior lighting delayed switch off

- ▶ Switch **Interior lighting delayed switch off** on or off.  
When this function is active, the interior lighting will light up for a short time after the vehicle is locked.

## Windscreen wipers and windscreen washer system

### Switching the windscreen wipers on/off



- 1 0 Windscreen wipers off
- 2 ... Automatic wiping, normal
- 3 .... Automatic wiping, frequent

- 4 — Continuous wiping, slow
- 5 == Continuous wiping, fast

► Turn the combination switch to the corresponding position 1 - 5.

► **Single wipe/washing:** push the button on the combination switch in the direction of arrow 1.

-  Single wipe
-  Wipes with washer fluid

ⓘ Observe the notes on washing the vehicle in a car wash (→ page 370).

### Replacing the windscreen wiper blades

**⚠ WARNING** Risk of becoming trapped if the windscreen wipers are switched on while wiper blades are being replaced

If the windscreen wipers begin to move while you are changing the wiper blades, you can be trapped by the wiper arm.


► Always switch off the windscreen wipers and vehicle before changing the wiper blades.

### Moving the wiper arms into the replacement position

- Switch the vehicle on and then off again immediately.
- Within around 15 seconds, press the  button on the combination switch for approximately three seconds (→ page 155). The wiper arms will move into the replacement position.


### Removing the wiper blades

- Fold the wiper arms away from the windscreen.



- ▶ Hold the wiper arm with one hand. With the other hand, turn the wiper blade away from the wiper arm in the direction of arrow ① as far as it will go.
- ▶ Press release knob ②.
- ▶ Remove the wiper blade from the wiper arm in the direction of arrow ③.

### Fitting the wiper blades



- ▶ Push the new wiper blade into the wiper arm in the direction of arrow ① until release knob ② engages.
- ▶ Make sure that the wiper blade is seated correctly.
- ▶ Fold the wiper arms back onto the windscreen.


- ▶ Switch on the vehicle.
- ▶ Press the  button on the combination switch. The wiper arms will return to their original positions.

- ▶ Switch off the vehicle.

- ① Check the condition of the wiper blades regularly and replace them in the event of visible damage or ongoing smearing.

### Maintenance display

There is a maintenance display at the tip of the newly mounted wiper blade.



- ▶ Remove protective film ❶ from the maintenance display.

When the colour of the maintenance display changes from black to yellow, the wiper blades should be replaced.

## Mirrors

### Operating the outside mirrors

- ⚠ **WARNING** Risk of accident due to adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations in particular:

- if you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
- if you fasten your seat belt while the vehicle is in motion

- ▶ Before starting the vehicle: in particular, adjust the driver's seat, head restraint, steering wheel and mirror, and fasten your seat belt.


- ⚠ **WARNING** Risk of accident due to misjudgement of distance when using the outside mirror

The outside mirrors reflect objects on a smaller scale. The objects in view are in fact closer than they appear.

- ▶ Therefore, always look over your shoulder in order to ensure that you are aware of the actual distance between you and the road users driving behind you.



## Adjusting the outside mirrors



- ▶ Use button ② or ④ to select the desired mirror.
- ▶ Use button ① to adjust the position of the selected mirror.

## Folding the outside mirrors in/out (vehicles with electrically folding outside mirrors)

- ▶ Briefly press button ③.

- ① If the battery has been disconnected or has discharged, the outside mirrors must be moved briefly using button ③. Only then will the automatic mirror folding function work properly.

## Engaging the outside mirrors

If an outside mirror has been forcibly disengaged, proceed as follows.

- ▶ Vehicles without electrically folding outside mirrors: manually move the outside mirror into the correct position.
- ▶ Vehicles with electrically folding outside mirrors: press and hold button ③. You will hear a click and the mirror will audibly engage. The outside mirror will now be set to the correct position.

## Automatic anti-dazzle mirrors function

**⚠ WARNING** Risk of acid burns and poisoning due to the anti-dazzle mirror electrolyte

Electrolyte may escape if the glass in an automatic anti-dazzle mirror breaks.

The electrolyte is hazardous to health and causes irritation. It must not come into contact with your skin, eyes, respiratory organs or clothing or be swallowed.

- ▶ If you come into contact with electrolyte, observe the following:
  - Immediately rinse the electrolyte from your skin with water and seek medical attention.
  - If electrolyte comes into contact with your eyes, immediately rinse them thoroughly with clean water and seek medical attention.
  - If the electrolyte is swallowed, immediately rinse your mouth out thoroughly. Do not induce vomiting. Seek medical attention immediately.

- Immediately change out of clothing which has been contaminated with electrolyte.
- If an allergic reaction occurs, seek medical attention immediately.

The inside rearview mirror and the outside mirror on the driver's side will automatically go into anti-dazzle mode if light from a headlamp hits the sensor on the inside rearview mirror.

### System limits

The system will not go into anti-dazzle mode if:

- The vehicle is switched off.
- Reverse gear is engaged.
- The interior lighting is switched on.

### Front-passenger outside mirror parking position function

The parking position makes parking easier.

The front-passenger outside mirror will swivel downwards in the direction of the rear wheel on the front passenger's side when:


- the parking position is stored (→ page 159).
- the front-passenger mirror is selected.
- reverse gear is engaged.

The front-passenger outside mirror will move back to its original position when:

- you shift the transmission to another transmission position.
- you are travelling at a speed greater than 15 km/h.
- you press the button for the outside mirror on the driver's side.

### Storing the parking position of the front-passenger outside mirror using reverse gear

#### Storing



- ▶ Select the front-passenger outside mirror using button ②.
- ▶ Engage reverse gear.
- ▶ Move the front-passenger outside mirror into the desired parking position using button ①.

### Calling up

- ▶ Select the front-passenger outside mirror using button ②.
- ▶ Engage reverse gear.  
The front-passenger outside mirror will move into the stored parking position.


### Activating/deactivating the automatic mirror folding function

Multimedia system:

- ➞  ➞ Settings ➞ Vehicle
- ➞ Opening/closing

- ▶ Activate or deactivate [Automatic mirror fold-in](#).

### Area permeable to radio waves on the windscreen



Radio-controlled equipment such as toll systems can be mounted only on areas ① of the windscreen that are permeable to radio waves.

Areas permeable to radio waves ① are best visible from outside the vehicle when the windscreen is illuminated with an external light source.

Note this position for vehicles with:

- Windscreen heater
- Infra-red reflective windscreen

### Infrared-reflective windscreen function

The infrared-reflective windscreen is coated and reduces the build-up of heat in the vehicle interior. The coating shields the vehicle interior from radio waves.


## Overview of climate control systems

### Notes on climate control

An interior filter in combination with the prefilter in the engine compartment must always be used so that the air conditioning system, pollution level monitoring and the air filtration work correctly. Use filters recommended and approved by Mercedes-Benz. Always have maintenance work carried out at a qualified specialist workshop.

### Overview of the THERMATIC climate bar

The indicator lamps indicate that the corresponding function is activated.



Front climate bar on the central display in vehicles (example)


- ① Increases the temperature
- ② Upper display area of the climate bar with the examples of switching climate control on/off (→ page 164) and **SYNC** synchronisation function (→ page 167)
- ③ Demists the windscreen (→ page 165)

- ④ Switches air-recirculation mode on/off (→ page 168, 167) or Fine particle prefilter status display (→ page 164)
- ⑤ Switches the rear window heater on/off
- ⑥ Reduces the temperature
- ⑦ Depending on vehicle equipment and settings: temperature display, display for the demist function, airflow, pre-entry climate control or climate mode
- ⑧ **A/C** Switches the A/C function on/off (→ page 165)
- ⑨ **CLIMATE MENU** Calls up the air conditioning menu (→ page 164)
- ⑩ **AUTO** Sets climate control to automatic mode (→ page 165)
- ⑪ Increases the airflow or switches on climate control (→ page 164)
- ⑫ Reduces the airflow or switches off climate control (→ page 164)
- ① The climate bar is visible even when the vehicle is parked or the air conditioning is switched off (→ page 164).

- ❗ The availability of individual functions is country and equipment-dependent.

### Overview of the THERMOTRONIC climate bar

The indicator lamps indicate that the corresponding function is activated.



Front climate bar on the central display in vehicles (example)


- ① ▲ Increases the temperature
- ② Upper display area of the climate bar with the examples of switching off climate control (→ page 164), switching the A/C function on/off (→ page 165) and synchronisation function (→ page 167)
- ③ Demists the windscreen

- ④ Switches air-recirculation mode on/off (→ page 168, 167) or Fine particle prefilter status display (→ page 164)
- ⑤ Switches the rear window heater on/off
- ⑥ Depending on vehicle equipment and settings: temperature display, display for pre-entry climate control or climate mode
- ⑦ Increases the airflow or switches on climate control (→ page 164)
- ⑧ ▼ Reduces the temperature
- ⑨ **AUTO** Sets climate control to automatic mode, right (→ page 165)
- ⑩ Calls up the air conditioning menu (→ page 164)
- ⑪ **AUTO** Sets climate control to automatic mode, left (→ page 165)
- ⑫ Reduces the airflow or switches off climate control (→ page 164)
- ❗ The climate bar is visible even when the vehicle is parked or the air conditioning is switched off (→ page 164).

- ❗ The availability of individual functions is country and equipment-dependent.

### Overview of the rear operating unit

The rear operating unit is available only for vehicles with the THERMOTRONIC air conditioning control panel.



- ❶ Sets air distribution to the centre and side air vents in the rear passenger compartment, left
- ❷ Sets the temperature in the rear passenger compartment, left
- ❸ Sets the airflow in the rear passenger compartment, left, or switches climate control on/off (→ page 164)
- ❹ Switches climate control on/off (→ page 164)

- ❺ Sets the airflow in the rear passenger compartment, right, or switches climate control on/off (→ page 164)
- ❻ Sets the temperature in the rear passenger compartment, right
- ❼ Sets air distribution to the centre and side air vents in the rear passenger compartment, right
- ❽ Sets rear climate control to automatic mode, right
- ❾ Sets the air distribution to the right rear footwell vents
- ❿ Synchronisation is activated (→ page 167)
- ⓫ Sets the air distribution to the rear left footwell vents
- ⓬ Sets rear climate control to automatic mode, left

The settings for the second row of seats can be configured via the rear operating unit or the multimedia system (→ page 167) depending on the vehicle's equipment.

## Operating the climate control system

### Switching climate control on/off

#### Switching on climate control

▶ Set the airflow to level 1 or higher via  on the climate bar on the central display

or

▶ Press **AUTO**, ,  or .

#### Switching off climate control

▶ Set the airflow to level 0 via  on the climate bar on the central display

or

▶ Press .

If climate control is switched off, the windows may mist up more quickly. Switch climate control off only briefly.

- ❗ If the climate control is switched off via , **OFF** will be shown on the climate bar.
- ❗ When the range maximisation function is activated, certain climate control functions are restricted and the window and mirror heaters are switched off. This can lead to windows misting up and reduced visibility due to

weather conditions. To quickly reactivate the climate control functions, press the  button on the climate bar on the central display.

### Switching climate control on/off via the rear operating unit

#### Switching on

▶ Press button .

or

▶ Set the airflow to level 1 or higher using buttons  and .

or

▶ Press buttons , ,  or .

#### Switching off

▶ Press button .

or

▶ Set the airflow to level 0 using buttons  and .

- ❗ If rear climate control is switched off via button , **OFF** will be shown on the rear display.

### Activating/deactivating the A/C function via the climate bar

#### Requirements:

- THERMATIC automatic climate control is fitted.

The A/C function heats, cools and dehumidifies the vehicle's interior air.

▶ Press  on the climate bar on the central display.

- ❗ Switch off the A/C function only briefly; otherwise, the windows may mist up more quickly. Condensation may drip from the underside of the vehicle when cooling mode is active. This is not indicative of a fault.

### Calling up the air conditioning menu using the climate bar

The air conditioning menu can be called up via the air conditioning line. The air conditioning line is always shown on the lower edge of the central display.

- ▶ Select the **Climate menu** entry in the air conditioning line.  
The **First row of seats** menu is opened.

### Jumping directly to the **Air quality** menu

- ▶ Select the  fine particle prefilter status display in the climate bar.  
The **Air quality** menu is opened. An animation of the automatic air cleaning taking place is shown.

- ① The fine particle prefilter status display is on the home screen next to the temperature display on the right and it informs you of the current particulate levels inside and outside of the vehicle.  
The measurement values are shown with the  $\mu\text{g}/\text{m}^3$  units (microgrammes per cubic metre).

### Defrosting the windscreen via the climate bar

#### Switching on

- ▶ Press  on the climate bar on the central display.

#### Switching off

- ▶ Press , **AUTO** or  on the climate bar on the central display  
or
- ▶ set the airflow to 0.
- ① When the defrost function is activated, some functions (e.g. the temperature setting) will automatically be deactivated.

### Activating/deactivating the A/C function via the air conditioning menu

Multimedia system:

➞ **Climate menu** ➞ **First row of seats**

Depending on the external conditions, improved cooling and dehumidification of the interior air are supported when the A/C function is activated. If it is not possible to operate the A/C function on the climate bar on the central display, switch the function on or off in the climate menu of the central display.

- ▶ Select **A/C** (A/C).

### Setting climate control to automatic mode via the climate bar

In automatic mode, the set vehicle interior temperature is controlled automatically and maintained at a constant level by the air supply.

- ▶ Press **AUTO** on the climate bar on the central display.
- ① You can increase or reduce the airflow by pressing  on the climate bar on the central display.
- ▶ **To switch to manual operation:** switch off automatic mode or adjust an aspect of air distribution, e.g. .

### Selecting climate modes via the air conditioning menu

Multimedia system:

➞ **Climate menu** ➞ **First row of seats**

It is possible to switch between different climate modes on the Climate menu.



If ECO or ECO+ mode is activated, certain climate control functions will be restricted to conserve energy and extend the vehicle's range.

The following modes are available on the Climate menu:

- **Comfort:** maximum climate comfort
  - **ECO:** while heating and cooling output are limited, it remains possible to operate climate control without restriction. If you activate , the system will automatically switch to Comfort mode.
  - **ECO+:** mode using only the blower and waste heat, if applicable. The temperature can no longer be adjusted. If you activate , the system will automatically switch to Comfort mode.
-  The windows may mist up more when ECO or ECO+ mode is activated.
-  ECO+ climate mode can also be switched on and off via the range maximisation button. When the range maximisation function is deactivated, the system will automatically switch to the last selected climate mode.

Pressing the temperature or blower display on the climate bar of the central display allows direct access to the air conditioning menu when ECO or ECO+ mode is active. The climate mode can be changed by pressing the ECO button.

-  The vehicle's climate control automatically detects seat occupancy. When the system switches to ECO or ECO+ mode, the climate control functions of the unoccupied seats are further restricted. If you activate , the system will automatically switch to Comfort mode.
-  If the vehicle is parked in ECO or ECO+ mode, it will automatically switch to Comfort mode the next time it is started.
-  Tap on **ECO**.
-  Select **Comfort**, **ECO** or **ECO+**.

If an ECO mode is selected via the air conditioning menu, two LEDs will appear on the temperature display on the climate bar. When ECO mode is switched on, one LED will light up green on the temperature display. When ECO+ mode is

switched on, both LEDs will light up green and the ECO+ display will appear.

### Setting air distribution using the air conditioning menu

Multimedia system:

 **Climate menu**

-  Select **First row of seats** or **Second row of seats**.
-  To set the air distribution: select ,  or .
-  Set the airflow.

- ❗ When the air conditioning system is switched on, at least one zone is always active. However, several air distribution options can be selected at the same time, for example to set the climate control for the interior and the footwells simultaneously. The  windscreen climate control can only be selected for the first row of seats. When automatic mode is active, the buttons for setting the air distribution are automatically deactivated. When the air conditioning system is switched off, the buttons remain operable and the last setting is saved.

### Setting rear climate control using the air conditioning menu

Multimedia system:

➡ Climate menu

#### Setting the temperature

- ▶ Select **Second row of seats**.
- ▶ Set the temperature.

#### Setting the airflow

- ▶ Select **Second row of seats**.
- ▶ Set the air flow with  or .

#### Controlling the rear climate control automatically

- ▶ Select **AUTO**.
- ❗ When the defrost function is activated, some functions (e.g. the temperature setting) are automatically deactivated. To deactivate the defrost function, either press , **AUTO** or  or set the air volume to level 0 (→ page 165).

### Switching the synchronisation function on/off via the air conditioning menu

Multimedia system:

➡ Climate menu

Climate control can be set centrally using the synchronisation function. The driver's settings for temperature, airflow and air distribution will be adopted automatically for all climate zones.

- ▶ Select **First row of seats**.

- ▶ Select **SYNC** (SYNC).

### Demisting the windows

#### Windows misted up on the inside

- ▶ Press **AUTO** on the climate bar on the central display.
- ▶ If the windows remain misted up: press  on the climate bar on the central display.

#### Windows misted up on the outside

- ▶ Switch on the windscreen wipers.
- ▶ Press **AUTO** on the climate bar on the central display.

### Switching air-recirculation mode on/off via the climate bar

#### Requirements:

- No fine particle prefilter is installed in the vehicle.
- ▶ Press  on the climate bar on the central display.  
The interior air will be recirculated.

Air-recirculation mode will automatically switch to fresh air mode after a while.

- ❗ If air-recirculation mode is switched on, the windows may mist up more quickly. Switch on air-recirculation mode only briefly.

### Switching the air-recirculation mode on/off via the air conditioning menu

#### Requirements:

- A fine particle prefilter is installed in the vehicle.

Multimedia system:

➞ Climate menu ➞ Air quality

- ▶ Press  on the upper display area of the climate bar.  
The interior air will be recirculated.

Air-recirculation mode will automatically switch to fresh air mode after a while.

- ❗ If air-recirculation mode is switched on, the windows may mist up more quickly. Switch on air-recirculation mode only briefly.

- ❗ By selecting the fine particle status display  on the climate bar, you can jump directly to the air quality menu.

### Activating or deactivating ionisation via the air conditioning menu

Multimedia system:

➞ Climate menu ➞ Air quality

Ionisation improves the quality of the vehicle's interior air. Ionisation of the interior air is odourless.

- ▶ Select **Ionisation**.

- ❗ The function can only be performed if the AUTO mode is activated or the air distribution is set to the side air vent. The function is restricted if the side air vent on the driver's side is closed.

### Fragrance system

#### Activating/deactivating the fragrance system using the multimedia system

#### Requirements:

- Automatic climate control is activated.
- The glove compartment is closed.
- A flacon is inserted.

Multimedia system:

➞ Climate menu ➞ Air quality

The fragrance system distributes a pleasant fragrance throughout the vehicle interior from a flacon located in the glove box.

- ▶ Navigate down until the climate control bar is active.
- ▶ Select **Air freshener**.
- ▶ Activate or deactivate fragrancing.

#### Setting the fragrance system using the multimedia system

#### Requirements:

- A flacon is inserted.

- The glove compartment is closed.
- Climate control is activated.

Multimedia system:

➞ **Climate menu** ➞ **Air quality**

The fragrance system distributes a pleasant fragrance throughout the vehicle interior from a flacon located in the glove compartment.

- ▶ Select **Air freshener**.
- ▶ Keep pressing until the desired intensity is reached.

### Inserting or removing the flacon of the fragrance system

**⚠ WARNING** Risk of injury from liquid perfume

If children open the flacon, they could drink the liquid perfume or it could come into contact with their eyes.

- ▶ Do not leave children unattended in the vehicle.

- ▶ Consult a doctor immediately if liquid perfume has been drunk.
- ▶ If liquid perfume comes into contact with your eyes or skin, rinse your eyes with clean water.
- ▶ If symptoms continue, consult a doctor.




**ENVIRONMENTAL NOTE** Environmental damage due to improper disposal of full flacons



Full flacons must not be disposed of with household waste.



Full flacons must be taken to a harmful substance collection point.



- ① Cap
- ② Flacon

- ▶ **To insert:** slide the flacon into the holder as far as it will go.
- ▶ **To remove:** after opening the glove box, wait for approximately seven seconds and pull out the flacon.

If you do not use genuine Mercedes-Benz interior perfumes, observe the manufacturers' safety notices on the perfume packaging.

Dispose of the genuine Mercedes-Benz interior perfume flacon when it is empty and do not refill it.

### Refillable flacon

- ▶ Unscrew the cap of the empty flacon.
- ▶ Fill the flacon with a maximum of 15 ml.
- ▶ Screw the cap back onto the flacon.

Always refill the empty refillable flacon with the same perfume. Observe the separate information sheet with the flacon.

### Information on the windscreen heater

**⚠ WARNING** Risk of burns from touching the windscreen when the windscreen heater is switched on

The windscreen can become very hot when the windscreen heater is switched on.

The health of persons with limited temperature sensitivity or a limited ability to react to high temperatures may be affected or they may even suffer burn-like injuries.

- ▶ Do not touch the windscreen while the windscreen heater is switched on.
- ▶ Allow the windscreen to cool down before touching it.

The windscreen heater will be enabled automatically if  is activated on the climate bar on the central display.

After the vehicle is started, the windscreen heater will be switched on automatically as required.

- ❗ If the on-board electrical system voltage is low, the function of the windshield heater may be impaired.

### Pre-entry climate control when the vehicle is unlocked

#### Function of pre-entry climate control when the vehicle is unlocked

The seats can be briefly pre-warmed or pre-cooled before you get into the vehicle.

Depending on the vehicle's equipment, the following functions will be activated as needed during pre-cooling:

- Automatic climate control
- Blower
- Seat ventilation

Depending on the vehicle's equipment, the following functions will be activated as needed during pre-warming:

- Automatic climate control
- Blower
- Seat heating
- Steering wheel heater
- Mirror heater
- Rear window heater

- Windscreen heater

Depending on the vehicle's equipment, the following functions will also be adjusted during pre-entry climate control if they have already been switched on during regular vehicle operation:

- Fragrancing
- Ionisation

### Setting pre-entry climate control when the vehicle is unlocked in the multimedia system

Multimedia system:

➞ Climate menu ➞ Pre-entry climate ctrl

- ▶ Activate or deactivate the function.

### Selecting seats

- ▶ Select **Driver**, **Passenger**, **Rear left** or **Rear right**.

Pre-entry climate control will take place for the selected seats.

An LED on the climate bar on the central display indicates when pre-entry climate control is activated. It lights up blue when the vehicle is being cooled and red when it is being heated.

### Activating/deactivating pre-entry climate control when the vehicle is unlocked

#### Requirements:

- The high-voltage battery is charged sufficiently.
- The function has been activated via the multimedia system.

- ▶ **To switch on:** unlock the vehicle.  
The climate control functions are activated for up to five minutes for pre-heating and pre-cooling.

Pre-entry climate control via unlocking cannot be activated more than three times in succession when the vehicle is switched off.

- ▶ **To switch off:** press  on the climate bar on the central display.

The following functions will remain active once the vehicle has been started:

- Seat heating
- Seat ventilation

Depending on the vehicle's equipment, the following functions will also be adjusted during pre-entry climate control if they have already been switched on during regular vehicle operation:

- Fragrancing
- Ionisation

### Pre-entry climate control for departure time

#### Pre-entry climate control for departure time function

**⚠ WARNING** Risk of fatal injury due to exposure to extreme heat or cold in the vehicle

If persons, particularly children, are subjected to prolonged exposure to intense heat or cold, there is a risk of severe injury or even death.

- ▶ Never leave persons, particularly children, unattended in the vehicle.

**⚠ WARNING** Risk of burns due to repeatedly switching on the seat heating

Repeatedly switching on the seat heating can cause the seat cushion and seat backrest padding to become very hot.

In particular, the health of persons with limited temperature sensitivity or a limited ability to react to high temperatures may be affected or they may even suffer burn-like injuries.

- ▶ Do not repeatedly switch on the seat heating.

To protect against overheating, the seat heating may be temporarily deactivated after it has been switched on repeatedly.

The air inside the vehicle can be heated, ventilated or cooled to the set temperature when the vehicle is parked.

When the vehicle is connected to power supply equipment, priority is given to charging the high-voltage battery to a specified minimum charge.

The running time of pre-entry climate control may be reduced under the following conditions:

- The vehicle is not connected to power supply equipment.
- The high-voltage battery is not fully charged.

With active pre-entry climate control, the charge level of the high-voltage battery may be reduced, even if the charging cable connector is connected.

If present, seat ventilation is activated in cooling and ventilation mode.

If present, the following functions are activated in heating mode:

- Seat heating
- Steering wheel heater
- Mirror heater
- Rear window heater
- Windscreen heater

When the set temperature is changed, the climate control mode will automatically be updated. It will be switched from heating mode to ventilation or cooling mode, from cooling mode to ventilation or

heating mode or from ventilation mode to heating or cooling mode.

Depending on the vehicle's equipment, the following functions will also be adjusted during pre-entry climate control if they have already been switched on during regular vehicle operation:

- Fragrancing
- Ionisation

### Setting pre-entry climate control for departure time via the climate bar

Multimedia system:

➡ Climate menu ➡ Pre-entry climate ctrl

### Setting the departure time

- i** The set departure times are used for the vehicle's pre-entry climate control and for predictions regarding the approximate state of charge and range at the time selected. Additional information on the charging settings: (→ page 211).

▶ Select **Edit departure time** .

▶ Select a departure time or set a new departure time.

- ❗ If the range maximisation function is activated, an approximate time for reaching the desired state of charge is automatically determined during a charging stop. This is used as an approximate departure time for pre-entry climate control and is set automatically. Departure times previously set cannot be edited when the function is switched on. The automatically determined departure time can be activated or deactivated via the air conditioning menu.

### Setting the repeat days

- ▶ Select **Edit departure time** .
- ▶ Set the desired departure time and select the corresponding weekdays on which this departure time is to apply.
- ▶ Press **OK** to confirm.

### Selecting seats

- ▶ Select **Driver**, **Passenger**, **Rear left** or **Rear right**.  
Pre-entry climate control will take place for the selected seats.

If a departure time is set, a yellow LED will appear on the climate bar of the central display. In addition, an LED on the climate bar will indicate when pre-entry climate control is activated. It lights up blue when the vehicle is being cooled and red when it is being heated.

**Operation using the app:** the pre-entry climate control for departure time can also be set via the Mercedes me connect app. You can find further information in the separate Owner's Manual at [https://moba.i.daimler.com/markets/ece-row/baix/cars/connectmeen\\_GB/#emotions/Startseite.html](https://moba.i.daimler.com/markets/ece-row/baix/cars/connectmeen_GB/#emotions/Startseite.html).

### Activating/deactivating pre-entry climate control for departure time

#### Requirements:

- The high-voltage battery is charged sufficiently.
- The function has been activated via the multimedia system.

- ▶ **To activate:** set the departure time (→ page 172).

Pre-entry climate control for departure time switches on a maximum of 55 minutes before the selected departure time. It will remain active for another five minutes if the departure is delayed.

- ▶ **To deactivate the pre-entry climate control for departure time early:** press  on the climate bar on the central display or switch off the preselection of the time in the climate menu.

If present, the following functions will remain active once the vehicle has been started:

- Seat heating
- Seat ventilation

Depending on the vehicle's equipment, the following functions will also be adjusted during pre-entry climate control if they have already been switched on during regular vehicle operation:

- Fragrancing
- Ionisation



## Operating immediate pre-entry climate control via the climate bar

**⚠ WARNING** Risk of fatal injury due to exposure to extreme heat or cold in the vehicle

If persons, particularly children, are subjected to prolonged exposure to intense heat or cold, there is a risk of severe injury or even death.

- ▶ Never leave persons, particularly children, unattended in the vehicle.

**⚠ WARNING** Risk of burns due to repeatedly switching on the seat heating

Repeatedly switching on the seat heating can cause the seat cushion and seat backrest padding to become very hot.

In particular, the health of persons with limited temperature sensitivity or a limited ability to react to high temperatures may be affected or they may even suffer burn-like injuries.

- ▶ Do not repeatedly switch on the seat heating.

To protect against overheating, the seat heating may be temporarily deactivated after it has been switched on repeatedly.

### Requirements:

- The vehicle is switched off.

Air conditioning of the vehicle interior can continue for up to 50 minutes, e.g. if the journey is interrupted.

- ▶ Press the  button on the climate bar on the central display.
- ▶ Set the temperature using the arrows  or  on the climate bar on the central display.

An LED on the climate bar on the central display indicates when pre-entry climate control is activated. It lights up blue when the vehicle is being cooled and red when it is being heated.

## Air vents

### Adjusting the front air vents


**⚠ WARNING** Risk of burns or frostbite due to being too close to the air vents

Very hot or very cold air can flow from the air vents.

- ▶ Make sure that all vehicle occupants always maintain a sufficient distance from the air vents.
- ▶ If necessary, direct the airflow to another area of the vehicle interior.

To guarantee the flow of fresh air through the air vents into the vehicle interior, comply with the following:

- Always keep the vents and ventilation grilles in the vehicle interior clear.
- Keep the air inlet grilles free of residue build-up (→ page 370).




- ▶ **To open or close the side air vents:** hold the outer ring of side air vent ① and turn it to the left or right as far as it will go.
- ▶ **To open or close the centre air vents:** move controller ② inwards or outwards as far as it will go.
- ▶ **To adjust the airflow direction of the side air vents:** hold the centre of side air vent ① and move it up or down or to the left or right.
- ▶ **To adjust the airflow direction of the centre air vents:** hold the controller of centre air vent ② and move it up or down or to the left or right.

### Adjusting the rear air vents

**⚠ WARNING** Risk of burns or frostbite due to being too close to the air vents

Very hot or very cold air can flow from the air vents.

- ▶ Make sure that all vehicle occupants always maintain a sufficient distance from the air vents.
- ▶ If necessary, direct the airflow to another area of the vehicle interior.



- ▶ **To open or close the rear air vents:** hold the controller of rear air vent ① and move it inwards or outwards as far as it will go.
- ▶ **To set the airflow direction of the rear air vents:** hold controller ① and move it up or down or to the left or right.

## Driving

### Notes on Mercedes-AMG vehicles

Observe the notes on the following topics in the Supplement, otherwise you may fail to recognise dangers.

-  The availability of certain functions depends on the equipment and model of the vehicle.
- AMG Active Sound
- AMG ceramic high-performance composite brake system
- RACE START
- AMG RIDE CONTROL +
- AMG steering-wheel buttons

### Notes on electric mode

 **WARNING** Risk of chemical burns and poisoning from damaged high-voltage battery

If the housing of the high-voltage battery has been damaged, electrolyte and gases may leak out.

- ▶ Avoid contact with the skin, eyes or clothing.
- ▶ Immediately rinse electrolyte splashes off with water and seek medical attention straight away.

 **DANGER** Risk of fire and explosion from excessive internal pressure of the high-voltage battery

In the event of a vehicle fire, flammable gas can escape and ignite.

- ▶ Stop the charging process immediately in case of unusual odours, smoke or burn marks.
- ▶ Leave the danger zone immediately. Secure the danger zone at a sufficient distance.
- ▶ Call the fire service.

Observe the following notes on vehicle noise emissions and the acoustic vehicle warning system:

- The vehicle is equipped with a purely electric drive system and develops considerably lower vehicle noise emissions than vehicles with a combustion engine.  
It is for this reason that the vehicle is equipped with a sound generator, which serves as an acoustic vehicle warning system (AVAS).
- The sound generator generates speed-dependent vehicle noise emissions when driving forward or backing up at a speed of up to around 30 km/h.  
This helps other road users, particularly pedestrians and cyclists, to hear your vehicle better.
- When driving at speeds above 20 km/h The vehicle acoustic warning system gradually switches off.
- Despite the sound generator, the vehicle still may not be heard by other road users. Adapt your driving style accordingly.

- The sound generator is off when the vehicle is stationary.

### Manual disconnection of the high-voltage on-board electrical system

**⚠ DANGER** Risk of death and fire due to modified and/or damaged components of the high-voltage on-board electrical system

The vehicle's high-voltage on-board electrical system is under high voltage. If you modify component parts in the vehicle's high-voltage on-board electrical system or touch damaged component parts, you may be electrocuted. In addition, modified and/or damaged components may cause a fire.

In the event of an accident or impact to the vehicle underbody, components of the high-voltage electrical system may be damaged although the damage is not visible.

- ▶ Never make any modifications to the high-voltage on-board electrical system.

- ▶ Do not switch on or use the vehicle if its high-voltage on-board electrical system components have been modified or damaged.
- ▶ Never touch damaged components of the high-voltage on-board electrical system.
- ▶ After an accident, do not touch any components of the high-voltage on-board electrical system.
- ▶ After an accident, have the vehicle transported away.
- ▶ Have the components of the high-voltage on-board electrical system checked at a qualified specialist workshop and replaced if necessary.

### Requirements:

Only disconnect the high-voltage on-board electrical system manually in the following situations:


- The  restraint system warning lamp lights up in the driver's display, e.g. after an accident.

- The vehicle is badly damaged, e.g. after an accident, and the restraint system components have not been triggered.


### Operating the high-voltage disconnect device

Only disconnect the high-voltage on-board electrical system manually in the above-mentioned situations.

- ▶ Switch off the vehicle.
- ▶ Shift the transmission to position **P**.
- ▶ Apply the electric parking brake.
- ▶ Secure the vehicle against rolling away.



- ▶ Remove flap ① of the fuse box in the front passenger footwell.



- ▶ Press release tab ③ on high-voltage disconnect device ② in the direction of the arrow and pull it out.
- ▶ Pull connector ④ in the direction of the arrow until it engages. The high-voltage on-board electrical system is switched off.

All work on the drive system (including after disconnecting the high-voltage on-board electrical

system manually) may only be carried out in a qualified specialist workshop.

### Switching on the power supply or the vehicle

**⚠ WARNING** Risk of accident and injury due to leaving children unattended in the vehicle

If children are left unattended in the vehicle, they could, in particular:

- open doors, thereby endangering other persons or road users.
- get out and be struck by oncoming traffic.
- operate vehicle equipment and become trapped, for example.


In addition, the children could also set the vehicle in motion by, for example:

- releasing the parking brake.
- changing the transmission position.
- starting the vehicle.


- ▶ Never leave children unattended in the vehicle.
- ▶ When leaving the vehicle, always take the key with you and lock the vehicle.
- ▶ Keep the vehicle key out of the reach of children.

#### Requirements:

- the key is in the vehicle and is recognised.
- the brake pedal is not depressed.



Vehicles with central display



Vehicles with MBUX Hyperscreen

- ▶ **To switch on the power supply:** press button ① once.  
You can, for example, switch on the wind-screen wiper.

The power supply is switched off again if the following conditions are met:

- you open the driver's door.

- you press button ❶ twice more.

▶ **To switch on the vehicle:** press button ❶ twice.  
Indicator and warning lamps light up on the driver's display.

The vehicle is switched off again if one of the following conditions is met:

- you do not start the vehicle within 15 minutes and the transmission is in position **P** or the electric parking brake is applied.
- you press button ❶ once.

## Starting the vehicle

### Starting the vehicle with the start/stop button

#### Requirements:


- the key is in the vehicle and is recognised.
- ▶ Shift the transmission to position **P** or **N**.
- ▶ Depress the brake pedal and press button ❶ once.
- the vehicle is started.

- the **READY** display appears on the driver's display: the vehicle can be driven.
- ▶ If the vehicle does not start: switch off non-essential consumers and press button ❶ once.
- ▶ If the vehicle still does not start and the **Place the key in the marked space See Owner's Manual** display message appears on the driver's display: start the vehicle with the key in the marked space (emergency operation mode) (→ page 180).
- ❶ You can switch off the vehicle while driving. To do this, press button ❶ for about three seconds or press button ❶ three times within three seconds. The transmission will shift to neutral **N** automatically. When you press button ❶ again, the vehicle will start again and you can engage drive position **D** again. Be sure to observe the safety notes concerning this under "Driving tips" (→ page 181).

Observe any information regarding display messages that may be displayed on the driver's display.

### Starting the vehicle with the key in the marked space (emergency operation mode)

If the vehicle does not start and the **Place the key in the marked space See Owner's Manual** display message appears on the driver's display, you can start the vehicle in emergency operation mode.



- ▶ Make sure that marked space ❷ is empty.
- ▶ Remove key ❶ from the key ring.
- ▶ Place key ❶ in marked space ❷ on the symbol.
- The vehicle will start after a short time.

When you remove key ❶ from marked space ❷, the vehicle can still be driven. For further engine starts however, key ❶ must be located in marked space ❷ on the symbol during the entire journey.

- ▶ Have key ❶ checked at a qualified specialist workshop.

#### If the vehicle does not start:

- ▶ Place key ❶ in marked space ❷ and leave it there.
- ▶ Depress the brake pedal and start the vehicle using the start/stop button.

❶ You can switch on the power supply or the vehicle with the start/stop button.

Observe any information regarding display messages that may be displayed on the driver's display.

#### Running-in notes

- In certain driving and driving safety systems, the sensors adjust automatically while a certain distance is being driven after the vehicle

has been delivered or after repairs. Full system effectiveness is not reached until the end of this teach-in process.

- Brakepads, brake disks and tyres that are either new or have been replaced only achieve optimum braking effect and grip after several hundred kilometres of driving. Compensate for the reduced braking effect by applying greater force to the brake pedal.

#### Notes on driving

**⚠ WARNING** Risk of accident due to objects in the driver's footwell

Objects in the driver's footwell may impede pedal travel or block a depressed pedal.

This jeopardises the operating and road safety of the vehicle.

- ▶ Stow all objects in the vehicle securely so that they cannot get into the driver's footwell.

- ▶ Always fit the floor mats securely and as prescribed in order to ensure that there is always sufficient room for the pedals.
- ▶ Do not use loose floor mats and do not place floor mats on top of one another.

**⚠ WARNING** Risk of accident due to incorrect footwear

Incorrect footwear includes, for example:

- shoes with platform soles
- shoes with high heels
- slippers

There is a risk of an accident.

- ▶ Always wear suitable footwear so that you can operate the pedals safely.

**⚠ WARNING** Risk of accident if the vehicle is switched off while driving

If you switch off the vehicle while driving, safety functions are restricted or no longer available.



This may affect the power steering system and the brake force boosting, for example.

You will need to use considerably more force to steer and brake, for example.

- ▶ Do not switch off the vehicle while driving.

**⚠ WARNING** Risk of accident due to the brake system overheating

If you leave your foot on the brake pedal when driving, the brake system may overheat.

This increases the braking distance and the brake system can even fail.

- ▶ Never use the brake pedal as a footrest.
- ▶ Do not depress the brake pedal and the accelerator pedal at the same time while driving.

**! NOTE** Damage to the vehicle due to not observing the maximum permitted headroom clearance

If the vehicle height is greater than the maximum permitted headroom clearance, the roof and other parts of the vehicle may be damaged.

- ▶ Observe the signposted headroom clearance.
- ▶ If the vehicle height is greater than the permitted headroom clearance, do not enter.
- ▶ Observe the changed vehicle height with add-on roof equipment.

**Notes on driving with a roof load, trailer or fully laden vehicle**

When driving with a loaded roof luggage rack or trailer as well as with a fully laden or fully occupied vehicle, the vehicle's driving and steering characteristics change.

You should bear the following in mind:

- Do not exceed the permissible roof load and towing capacity. Also observe the technical data in the printed Owner's Manual.
- Evenly distribute the roof load, and place heavy objects at the bottom. Also comply with the notes on loading the vehicle (→ page 124).
- Drive attentively, and avoid suddenly pulling away, braking and steering as well as rapid cornering.

**Notes on driving on salt-treated roads**

The braking effect is limited on salt-treated roads.

Therefore, observe the following notes:

- due to salt build-up on the brake disks and brakepads, the braking distance can increase considerably or result in braking only on one side
- maintain a much greater safe distance to the vehicle in front

To remove salt build-up:

- brake occasionally while paying attention to the traffic conditions
- carefully depress the brake pedal at the end of the journey and when starting the next journey

### Notes on aquaplaning

Aquaplaning can take place once a certain amount of water has accumulated on the road surface.

Observe the following notes during heavy precipitation or in conditions in which aquaplaning may occur:

- reduce speed
- avoid tyre ruts
- avoid sudden steering movements
- brake carefully

**i** Also observe the notes on regularly checking wheels and tyres (→ page 396).

### Notes on driving through water on the road surface

Water which has entered the vehicle can damage the drive system, electrics and transmission.

Observe the following if you must drive through water:

- The water, when calm, may only reach the lower edge of the vehicle body.
- Drive at walking pace at most; water can otherwise enter the vehicle interior.
- Vehicles travelling in front, or oncoming vehicles, can create waves which may exceed the maximum permissible depth of the water.

The braking effect of the brakes is reduced after fording. Brake carefully while paying attention to the traffic conditions until braking power has been fully restored.

### Function of rear axle steering

**i** This function is an on-demand feature (→ page 24).


The rear axle steering is an electromechanical auxiliary steering on the rear axle which adjusts the steering of the rear wheels according to the position of the front wheels, depending on the speed. This results in greater manoeuvrability and improved driving stability, e.g. when cornering.

Rear axle steering has the following characteristics:

- reduced steering effort and turning circle resulting in reduced parking effort
- improved driving stability, e.g. when cornering
- more direct steering resulting in improved handling of the vehicle

Observe the notes on snow chains and snow chain mode (→ page 397).

### ECO display function



The ECO display shows an evaluation of your driving style on the driver's display depending on the situation. This enables you to check the efficiency of your driving style and adjust it if necessary. The **ECO display** menu shows a ball (2) that will roll forwards or backwards on a stylised road in the direction of travel according to the driving characteristics.

Above and below the road, lines mark the area for an efficient driving style (3). Ball (2) will light up in green if it is rolling within these lines. Outside the lines, the ball will light up in orange.

The ECO display assesses the following criteria for an economical driving style:

- coasting at the right time
- consistent speed
- moderate acceleration

The overall assessment of your driving style "from start" is indicated using stars (1). It starts with five empty stars, which you can fill one after the other if you drive efficiently. When all five stars are filled, a glow will appear in the background.

- (i) You can call up the **ECO display** function via the **Classic** menu (→ page 300).

### Recuperative brake system

#### Function of the recuperative brake system

Depending on the selected recuperation level, the electric motors are operated as an alternator when in overrun mode and during braking in order to charge the high-voltage battery while driving. As soon as you take your foot off the accelerator pedal when the vehicle is in motion and in transmission position **D**, recuperation in overrun mode is initiated.

The higher the recuperation, the more sharply the vehicle is braked when coasting and the more electrical energy is fed into the high-voltage battery.

The deceleration in overrun mode may not be sufficient depending on the driving conditions. Also brake with the service brake if necessary. Always adapt your speed to the driving conditions and keep a sufficient distance.

The recuperative brake system has the following characteristics:

- supports braking with electronically controlled brake force boosting
  - converts the kinetic energy of the vehicle into electric energy
- (i) If you brake hard, the mechanical brake is also used. This means that the maximum recuperative energy cannot be recovered. The more you drive and brake in an anticipatory manner, the more efficiently energy can be recuperated.

### System limits


The braking effect of the electric motor during recuperation in overrun mode may be reduced or may not be available at all in the following situations:

- when the high-voltage battery charge level increases
- if the high-voltage battery is not yet at a normal operating temperature

In these cases, the desired deceleration is set by the brake control system.

### Manually setting recuperative deceleration

You can use the steering wheel gearshift paddles to manually adjust the intensity of recuperation in overrun mode.



- i** When the vehicle is started again, **D** is automatically set as the recuperation level.

The following recuperation levels are available:

- **D AUTO** Intelligent and anticipatory recuperation with ECO Assist (→ page 185)
- **D +** No recuperation: the vehicle coasts, rolls freely
- **D** Normal recuperation (standard setting)

- **D -** Increased recuperation: increased deceleration in overrun mode

▶ **To increase recuperation:** briefly pull gearshift paddle ①.

▶ **To reduce recuperation:** briefly pull gearshift paddle ②.

▶ **To select **D AUTO**:** pull and hold gearshift paddle ① or ②.

The driver's display shows the currently selected recuperation level next to the transmission position display.

### ECO Assist

#### ECO Assist function

ECO Assist is only an aid. It is not a substitute for you paying attention to your surroundings and does not relieve you of your responsibility pertaining to road traffic law. The driver is responsible for keeping a safe distance from the vehicle in front, for vehicle speed and for braking in good time.

**⚠ WARNING** Risk of accident if ECO Assist does not provide sufficient deceleration

ECO Assist only brakes your vehicle when you take your foot off the gas pedal. If vehicles are detected late, e.g. after tight curves, or if you do not react immediately to the ECO Assist display, the deceleration may not be sufficient.

- ▶ React promptly to the ECO Assist recommendation and take your foot off the gas pedal.
- ▶ Adjust your speed to the driving conditions and maintain a suitable distance from the vehicle in front.
- ▶ Brake the vehicle yourself and/or take evasive action.

ECO Assist is active only in **D** **AUTO**  
(→ page 185).


Depending on the vehicle's equipment, ECO Assist analyses data for the vehicle's expected route. This allows the system to optimally adjust the driving style for the route ahead, use minimal energy and recuperate as much as possible. If the system has detected an event ahead or a vehicle

in front and the vehicle is approaching the event, ECO Assist calculates the optimised speed profile based on the distance, speed and available route information.

If you release the accelerator pedal in this case, intelligent recuperation starts in overrun mode. If ECO Assist has detected a vehicle travelling in front or a stationary vehicle ahead, it can brake your vehicle to a standstill. This may be the case, for example, at the end of a traffic jam or if the detected vehicle ahead stops in front of you.

If the deceleration provided by ECO Assist is not sufficient, you must also brake with the service brake.

At low speeds, e.g. in a multi-storey car park or on play streets, no adjustment is made for stationary vehicles and therefore there is no display.



- ① "Foot off the accelerator" recommendation
- ② Route event ahead
- i ECO Assist can also be shown on the head-up display.

If a route event ahead or a vehicle in front that requires an adjustment of your driving style is detected, corresponding symbol ② and the  symbol (grey) are displayed.

If you release the accelerator pedal, the  symbol turns green and recuperation in overrun mode is initiated.

The ECO Assist display is hidden again in the following cases:

- You do not react to the ECO Assist recommendation for a long time.
- ECO Assist cannot identify any further recommendations from the route ahead.

In addition to a vehicle in front , ECO Assist can detect the following route events  depending on the vehicle's equipment:

-  Roundabout
-  S-bend
-  Sharp bend
-  T-junction
-  Downhill gradient
-  Speed limit

ECO Assist can also react to other intersections or junctions if you activate the turn signal indicator in good time.

-  On roads with an obligation to drive in a lane as far to the right as possible, vehicles driving in the lane to your left are also recognised as vehicles ahead of you.

To enable ECO Assist to react to future route events, the equipment-dependent speed adaptation functions of Active Distance Assist must be active (→ page 238).

### System limits

If the calculated route is adhered to when route guidance is active, ECO Assist will operate with greater accuracy. The basic function is also available without active route guidance. Not all information and traffic situations can be foreseen. The quality depends on the map data.

-  ECO Assist is available after driving off, as soon as the sensor check is completed.

The system may be impaired or may not function in the following situations:

- If there is poor visibility, e.g. due to insufficient illumination of the road, highly variable shade conditions, rain, snow, fog or heavy spray.
- If there is glare, e.g. from oncoming traffic, direct sunlight or reflections.
- If the windscreen is dirty in the vicinity of the multifunction camera.

- If the multifunction camera is misted up, damaged or obscured.
- If road signs are hard to detect, e.g. due to dirt, snow or insufficient lighting, or because they are obscured.
- If the information in the navigation system's digital map is incorrect or out-of-date.
- If signs are ambiguous, e.g. road signs in roadworks or in adjacent lanes.
- If the radar sensors are dirty or obscured.
- When you drive on roads with steep uphill or downhill gradients.
- If there are narrow vehicles in front, such as bicycles or motorcycles.

### Activating or deactivating ECO Assist

Multimedia system:

   **Settings**  **Assistance**  
 **Driving**

-  Activate or deactivate the function.

### Function of the haptic accelerator pedal

The haptic accelerator pedal features an additional point of resistance to help you drive as efficiently as possible in drive program **E**.

### Range maximisation

#### Range maximisation function

The range maximisation function enables a maximum range gain. To achieve this, the function partially or completely switches off convenience systems that are not relevant to driving and activates efficiency-enhancing driving functions.

The range maximisation function controls the restrictions of the following function groups:

- **Climate control**
  - Restricting climate control functions and deactivating front windscreen, rear window and mirror heaters
- **Interior**
  - Switching off ambient lighting, displays and certain charging functions
- **Seating comfort**

- Deactivating the steering wheel heater, seat heating and ventilation and deactivating of the relaxation function

#### • ECO drive functions

- Changing to the **E** drive program, activating ECO Assist and the **D AUTO** recuperation level

If necessary, you can deactivate the restrictions of individual function groups again. This will reduce the maximum range gain by the value specified for the function group.

If you switch on a deactivated function while range maximization is activated, all restrictions of the corresponding function group will be removed and the maximum range gain will be reduced accordingly. For example, if you switch on the seat heating again, all restrictions of the "Seating comfort" function group will be deactivated.

This does not apply to the ECO driving functions group, as the range gain in this case depends mainly on your personal driving style. The activated ECO driving functions help you to drive in an energy-efficient manner. The specified range gain for the ECO drive functions can be achieved only

if you observe the driving instructions and recommendations displayed and drive without kickdown.

#### Activating/deactivating range maximisation

Multimedia system:

→  >> Settings >> EQ >> Range

▶ Activate or deactivate **Maximum range**. All function groups concerned are activated or deactivated.

or

▶ Individually activate or deactivate the individual subsystems of the four function groups **Climate control**, **Interior**, **Seat comfort** or **ECO drive functions**.

#### DYNAMIC SELECT button

#### Function of the DYNAMIC SELECT button

**!** **NOTE** Mercedes-AMG vehicles

▶ Observe the notes in the Supplement. You could otherwise fail to recognise dangers.

You can switch between the drive programs with the DYNAMIC SELECT button (→ page 190).

Depending on the drive program selected, the following vehicle characteristics will change:

- Drive
- **Vehicles with AIRMATIC:** Suspension (→ page 262)
  - Suspension and damping
  - Vehicle level (speed-dependent)
- Steering
- ESP®
- Sound of the drive system in the vehicle interior
- Pressure point in the haptic accelerator pedal

**i** In drive program **E**, an additional pressure point is activated in the haptic accelerator pedal.

- 1st pressure point: at approx. 60% pedal travel (only in **E**)
- 2nd pressure point: transition to kickdown (always available)

### Available drive programs

#### **I** (Individual)

- The following vehicle characteristics are individually adjustable:
  - Drive
  - Suspension
  - Steering
  - ESP®
  - Sound of the drive system in the vehicle interior

#### **S** (Sport)

- Sporty and dynamic driving characteristics
- Only suitable for good road conditions, a dry road surface and a clear stretch of road

#### **C** (Comfort)

- Comfortable driving characteristics
- Recommended for all road conditions
- Best balance between efficiency and performance for all driving situations


#### **E** (Eco)

- Economical setting of vehicle functions
- Recommended for all road conditions
- Additional 1st pressure point in the haptic accelerator pedal indicates an efficient, economical driving style

The ESP® settings in the drive programs **E** and **C** are designed for stability. Therefore, choose one of these drive programs especially when transporting roof loads, in trailer operation and when the vehicle is fully loaded or fully occupied.



## Selecting a drive program



- ▶ Press DYNAMIC SELECT button ① on the left or right.  
The drive program selected appears on the driver's display.

## Configuring DYNAMIC SELECT (multimedia system)

Multimedia system:

- ➞ ➞ Settings ➞ Vehicle
- ➞ DYNAMIC SELECT

### Setting drive program I

- ▶ Select Individual.
- ▶ Select and set a category.

### Switching the reset display on/off

- ▶ Activate or deactivate **Ask when starting**.
- ① This function must be activated for each user profile separately. The drive program for the respective user profile of the last driver is only stored if this function is activated.

**Function on:** the next time the vehicle is started a prompt appears asking whether the last active drive program should be restored.

- ① The prompt appears only if the previously active settings deviate from the standard settings.

**Function off:** the next time the vehicle is started the drive program is set automatically.

## Displaying vehicle data

Multimedia system:

- ➞ ➞ Info
- ▶ Select **Vehicle**.  
The vehicle data is displayed.

## Calling up the fuel consumption indicator

Multimedia system:

- ➞ ➞ EQ
- ▶ Select **Consumption**.  
The current and average fuel consumption is displayed.

## Transmission

### DIRECT SELECT lever

#### Function of the DIRECT SELECT lever

**⚠ WARNING** Risk of accident and injury due to leaving children unattended in the vehicle

If children are left unattended in the vehicle, they could, in particular:


- open doors, thereby endangering other persons or road users.
- get out and be struck by oncoming traffic.
- operate vehicle equipment and become trapped, for example.

In addition, the children could also set the vehicle in motion by, for example:

- releasing the parking brake.
- changing the transmission position.
- starting the vehicle.

- ▶ Never leave children unattended in the vehicle.
- ▶ When leaving the vehicle, always take the key with you and lock the vehicle.
- ▶ Keep the vehicle key out of the reach of children.

Use the DIRECT SELECT lever to switch the transmission position. The current transmission position is displayed on the driver's display.



- P** Park position
- R** Reverse gear
- N** Neutral
- D** Drive position

#### Engaging reverse gear R

- ▶ Depress the brake pedal and push the DIRECT SELECT lever upwards past the first point of resistance.

### Engaging neutral N

- ▶ Depress the brake pedal and push the DIRECT SELECT lever up or down to the first point of resistance, holding it there until the transmission position **N** is shown on the driver's display.

Subsequently releasing the brake pedal will allow you to move the vehicle freely, e.g. to push it or tow it away.

### If you want the transmission to remain in neutral N even if the vehicle is switched off:

- ▶ Start the vehicle.
  - ▶ Depress the brake pedal and engage neutral **N**.
  - ▶ Release the brake pedal.
  - ▶ Switch off the vehicle.
- ❗ If you then exit the vehicle leaving the key in the vehicle, the transmission will remain in neutral **N**.

### Engaging park position P

- ▶ Observe the notes on parking the vehicle (→ page 212).

- ▶ Depress the brake pedal until the vehicle comes to a standstill.
- ▶ When the vehicle is at a standstill, press button **P**.  
Park position is only engaged when the transmission position display **P** is shown in the driver's display. If no transmission position display **P** appears, secure the vehicle to prevent it from rolling away.

Park position **P** is engaged automatically if one of the following conditions is met:

- You switch the vehicle off in transmission position **D** or **R**.
  - You open the driver's door when the vehicle is at a standstill or when driving at a very low speed and the transmission is in position **D** or **R**.
- ❗ To manoeuvre with an open driver's door, open the driver's door while at a standstill and engage transmission position **D** or **R** again.
- ❗ If you have engaged park position **P** or switched off the vehicle and no transmission

position display is displayed, secure the vehicle from rolling away (→ page 215).

### Engaging drive position D

- ▶ Depress the brake pedal and push the DIRECT SELECT lever down past the first point of resistance.

### Function of the 4MATIC

The flexible all-wheel distribution of the 4MATIC means the drive is always ideally distributed between both axles. Depending on the situation, only the front axle or only the rear axle can be driven, or the drive can be distributed continuously between both axles.

This means that recuperation can be used even more effectively and the range of the vehicle can be increased (→ page 184).

Together with ESP® and 4ETS, 4MATIC improves the traction of your vehicle whenever a driven wheel spins due to insufficient traction.

If you fail to adapt your driving style, 4MATIC can neither reduce the risk of an accident nor override the laws of physics. It cannot take into account

road, weather or traffic conditions. 4MATIC is only an aid. You are responsible especially for maintaining a safe distance from the vehicle in front, for vehicle speed, for braking in good time and for staying in lane.

- i** In wintry road conditions, the maximum effect of the flexible all-wheel distribution can be achieved only if you use winter tyres (M+S tyres), with snow chains if necessary.

## Charging the high-voltage battery

### Notes on charging the high-voltage battery

- !** **NOTE** High-voltage battery damage due to leaving the vehicle idle for lengthy periods of time

Lithium-ion batteries experience a natural self-discharge.

Exhaustive discharging can therefore occur if the vehicle is idle for several months. This can damage the high-voltage battery.

- ▶** To avoid damage, please observe the following recommendations when handling the high-voltage battery.

- !** **NOTE** Accelerated ageing of the high-voltage battery due to not observing the following recommendations

As a result of its basic characteristics, the storage capacity of, and the amount of energy available from, the high-voltage battery decreases over the course of its life. As a result, the maximum electrical range that can be achieved by the vehicle is reduced and its maximum electrical output can be impaired.

The following factors could accelerate the ageing of the high-voltage battery:

- frequently fully charging (charge level 100%) the high-voltage battery, especially when this process is not directly followed by a journey
- frequent rapid charging with direct current (mode 4)

- leaving the vehicle idle for lengthy periods at high ambient temperatures
- ▶** To avoid accelerated ageing, please observe the following recommendations when handling the high-voltage battery.

Recommendations when handling the high-voltage battery:

- Every six months, when the outside temperature is above 10 °C, park the vehicle overnight with a charge level below 20%.
- Only charge the high-voltage battery with direct current (mode 4) if necessary.
- Charge the high-voltage battery on average to a charge level of 80%. Beyond a charge level of 80%, the charging time is considerably prolonged.
- If leaving the vehicle idle for lengthy periods, park up the vehicle with a high-voltage battery charge level between 30% and 50%. Do not keep the high-voltage battery continuously connected to power supply equipment.

- If leaving the vehicle idle for lengthy periods of time avoid, if possible, high ambient temperatures.
- Check the high-voltage battery's charge level every six weeks (→ page 210).
- Charge the high-voltage battery if the charge level is below 20%.
- Do not disconnect the 12 V battery even if the vehicle is left idle for a lengthy period. Otherwise, the condition of the vehicle's high-voltage battery cannot be monitored.


You can contribute to reducing the vehicle's energy consumption in the following ways:

- An anticipatory driving style (→ page 184)
- Reduced use of electrical consumers
- Having the vehicle regularly maintained


The charging time of the high-voltage battery may change over the course of its life.

- i** Depending on the national version, your vehicle is equipped with one of the following vehicle sockets.

You can charge the high-voltage battery with both alternating current (mode 2/3) and direct current (mode 4).



Combo 1 vehicle socket



Combo 2 vehicle socket

- 1** Type 1 or type 2 connection for charging with alternating current
- 2** Socket extension for charging with direct current

- ❗ When using a CCS (Combined Charging System) charging cable to charge with direct current at a combo vehicle socket, both vehicle socket connections ❶ and ❷ are used for charging.

Charging options for the high-voltage battery (mode 2, 3 or 4):

- Charging through recuperation while the vehicle is in motion
- Charging with alternating current when stationary:
  - at a mains socket (mode 2)
  - at a wallbox or charging station (mode 3)
- Charging with direct current when stationary:
  - at a rapid charging station (mode 4)

Depending on the country-specific vehicle equipment and your vehicle's charging cable, single phase AC charging is also possible.

Observe the different grid requirements of your current location when charging. Only use charging cables which conform to the grid requirements. Consult a qualified electrician or your local grid operator if you have any questions.

It is recommended that you charge the high-voltage battery at a wallbox or charging station due to the improved charging performance and better charging efficiency offered.

### Stowing the charging cable

Always stow the vehicle charging cable in the charging cable bag provided and attach its spring hook to the tie-down eye in the boot or the load compartment.

Otherwise, the charging cable is not sufficiently secured.

### System limits

The power output of the high-voltage battery may be impaired by the following:

- High or low outside temperatures
- Electrical auxiliary consumers in the vehicle being switched on, e.g. operating the air conditioning system
- Extended periods without charging

The charging time of the high-voltage battery may be increased by the following:

- High or low outside temperatures

- Extended periods without charging
- The maximum available charge current of the charging facility
- The settings of the charging process in the multimedia system (→ page 211)

### Notes on charging the high-voltage battery at the mains socket (mode 2)

**⚠ DANGER** Risk of fatal injury from incorrectly installed component parts

Connecting the charging cable to a mains socket using incorrectly installed component parts could cause a fire or an electric shock, for example.

➤ Only connect the charging cable to a mains socket that:

- Has been properly installed and
- Has been inspected by a qualified electrician

- ▶ For safety reasons, only use the charging cable supplied with the vehicle or an original Mercedes-Benz charging cable.
- ▶ Purchase these parts at a Mercedes-Benz Service Centre and obtain advice there.

Mercedes-Benz thoroughly tests these original charging cables for their suitability for high-voltage charging of your vehicle.

- ▶ Never use a damaged charging cable.
- ▶ Do not use:
  - Extension cables
  - Extension reels
  - Multiple sockets
- ▶ Never use socket adapters to connect the charging cable to the mains socket. The only exception being if the adapter has been tested and approved by the manufacturer for charging the high-voltage battery of an electric vehicle.

- ▶ Observe the safety notes in the operating instructions for the socket adapter.

Only the following charging cables may be used:

- The charging cable supplied with the vehicle.
- A charging cable that has been approved for the vehicle.

The charging process can vary depending on the power supply equipment. The charging times when charging the high-voltage battery at the mains socket are considerably longer than when charging at a wallbox or charging station.

When doing so, always observe the local information.

Do not leave the charging cable controls hanging loose from a mains socket.

Do not lift the controls by the following component parts:

- the charging cable connector
- the mains plug

When charging, protect the charging cable control element from excessive heat such as direct sun-

light. Otherwise, the charging process may be cancelled.

### Notes on charging the high-voltage battery at a wallbox or charging station (mode 3)

**⚠ DANGER** Risk of fatal injury from incorrectly installed component parts

Connecting the charging cable to a wallbox using incorrectly installed component parts could cause a fire or an electric shock, for example.

- ▶ Only connect the charging cable to a wallbox that:
  - Has been properly installed and
  - Has been inspected by a qualified electrician
- ▶ For safety reasons, only use charging cables that have been tested and approved by the manufacturer for charging the high-voltage battery in an electric vehicle.

- ▶ Never use damaged charging cables.
- ▶ Do not extend the charging cable.
- ▶ Do not use adapters.
- ▶ Observe the safety notes in the operating instructions for the wallbox.

If charging at a wallbox without pre-installed cable, use the optionally available charging cable for wallbox and charging station (mode 3). The charging cable is stowed in a bag in the boot/luggage compartment.

Only use charging cables that have been tested and approved by the manufacturer for charging the high-voltage battery in an electric vehicle.

**⚠ DANGER** Risk of fatal injuries due to damaged components

Connecting the charging cable to a charging station using a damaged component part could cause a fire or an electric shock, for example.

- ▶ For charging stations with a preinstalled charging cable:

- Perform a visual check of the charging station for obvious faults, such as massive damage to the housing or charging cable.
- ▶ For charging stations without a preinstalled charging cable:
  - For safety reasons, only use charging cables that have been tested and approved by the manufacturer for charging the high-voltage battery in an electric vehicle.
  - Never use damaged charging cables.
  - Do not extend the charging cable.
  - Do not use adapters.
- ▶ Make sure to observe the safety information on the charging station.

Most charging stations must be activated before the charging process, e.g. using an RFID card or via Plug & Charge. Observe the on-site operator's instructions for the charging station and the notes on Mercedes me Charge (see the vehicle's Digital Owner's Manual).

The amount of energy dispensed for the charging process, shown by the charging station, may be higher than the amount of energy actually absorbed by the high-voltage battery. This is the result of different levels of charging losses and is described as recharge efficiency. Charging losses occur, for example, due to heat that builds up when charging or from auxiliary consumers that are switched on. Further information on recharge efficiency can be obtained at a qualified specialist workshop.

**Notes on charging the high-voltage battery at a rapid charging station (mode 4)**

**⚠ DANGER** Risk of fatal injuries due to damaged components

Connecting the charging cable to a charging station using a damaged component part could cause a fire or an electric shock, for example.

- ▶ For charging stations with a preinstalled charging cable:



- Perform a visual check of the charging station for obvious faults, such as massive damage to the housing or charging cable.
- ▶ For charging stations without a preinstalled charging cable:
  - For safety reasons, only use charging cables that have been tested and approved by the manufacturer for charging the high-voltage battery in an electric vehicle.
  - Never use damaged charging cables.
  - Do not extend the charging cable.
  - Do not use adapters.
- ▶ Make sure to observe the safety information on the charging station.

**⚠ DANGER** Risk of fatal injuries when carrying out maintenance work during the charging process

During the charging process, the high-voltage on-board electrical system is under high voltage.

- ▶ Do not perform any maintenance work during the charging process.

Most charging stations must be activated before the charging process, e.g. using an RFID card or via Plug & Charge. Observe the on-site operator's instructions for the charging station and the notes on Mercedes me Charge (see the vehicle's Digital Owner's Manual).

The charging cable for the vehicle must not be longer than 30 m due to the legal requirements in some countries. This is to prevent the interference of signals being received by radio communication devices in the vehicle or in close proximity to the charging station. Be aware that parts of the charging cable may be routed underground. If in doubt, ask the charging station operator if this is the case before charging the high-voltage battery.

The amount of energy dispensed for the charging process, shown by the charging station, may be higher than the amount of energy actually absorbed by the high-voltage battery. This is the result of different levels of charging losses and is described as recharge efficiency. Charging losses occur, for example, due to heat that builds up when

charging or from auxiliary consumers that are switched on. Further information on recharge efficiency can be obtained at a qualified specialist workshop.

### Setting the maximum permissible charging current for charging at a mains socket

**!** **NOTE** Overloading the mains socket due to excessive charging current

If the charging current is too high, the fuse could be tripped or the external mains supply could overheat.

- ▶ Ensure that the external mains supply has been designed to handle the charging current provided.
- ▶ For safety reasons, only use the charging cable supplied with the vehicle or an original Mercedes-Benz charging cable. Mercedes-Benz thoroughly tests these original charging cables for their suitability for high-voltage charging of your vehicle. Purchase these parts at a Mercedes-

Benz Service Centre and obtain advice there.

- ▶ Check the maximum charging current using the charging capacity shown in the driver's display.


The charging cable supplied is set to a country-specific maximum charging current value. When charging abroad, the maximum value may exceed the permitted value for that country.

- ▶ Before charging at a mains socket, have the maximum permissible charging current for the relevant mains socket or the building inspected by a qualified electrician.
- ▶ When abroad, observe the country-specific laws when charging.

If you have questions concerning the charging current or if there is a malfunction, please contact a qualified specialist workshop.

### Overview of the charging cable control panel

The charging cable control panel shows the current status of the charging process.



- ① Supply voltage indicator
- ② Charging process indicator
- ③ Temperature monitor indicator
- ④ Safety system indicator

### Supply voltage indicator ①

| Display         | Meaning                          |
|-----------------|----------------------------------|
| Lights up white | The supply voltage is connected. |

### Charging process indicator ②

| Display       | Meaning                               |
|---------------|---------------------------------------|
| Flashes green | The high-voltage battery is charging. |

### Temperature control indicator ③

| Display       | Meaning                                                                                                                                                                              |
|---------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Lights up red | The green LED flashes simultaneously: overtemperature – the charging performance is reduced.<br><br>The green LED does not flash: overtemperature – the charging process is stopped. |
| Flashes red   | Overtemperature at the mains plug – the charging process is stopped.                                                                                                                 |

Safety system indicator ④

| Display       | Meaning                                                                                                                                                                                                                                            |
|---------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Flashes red   | Charging cable malfunction – cannot carry out the charging process, reset the charging cable operating unit.                                                                                                                                       |
| Lights up red | <p>White LED is off: power supply malfunction – cannot carry out the charging process, replace the mains socket.</p> <p>White LED is on: vehicle malfunction – cannot carry out the charging process, reset the charging cable operating unit.</p> |


When all four displays light up, the charging cable operating unit performs a self-test.

If temperature monitor ③ indicates a malfunction, it may help to protect the charging cable from direct sunlight.

**To reset the charging cable operating unit:** if safety system ④ indicates a charging cable malfunction or a vehicle malfunction, first reset the charging cable operating unit. To do this, disconnect the charging cable from the vehicle and from the mains socket and wait for approximately five seconds. If the malfunction persists after the charging cable is reconnected, charging at the mains socket is not possible. The charging cable must be replaced or the vehicle plug must be checked at a qualified specialist workshop, depending on the indicator.

Functions of the indicator lamp on the vehicle socket

The socket flap is centrally locked and unlocked together with the vehicle.



Example: Combo 2 vehicle socket

The colour and signalling of status display ① have the following meanings:

Locking status

- Lights up white: vehicle socket unlocked; insert or remove charging cable
- Flashes white: disconnection or malfunction during locking or unlocking

### Charge status

- Lights up blue: charging process completed
- Flashes blue: charging; active energy flow
- Lights up orange: charging paused
- Flashes orange: connection is being established
- Flashes red (for approx. 90s): malfunction in vehicle; charging not possible

**i Vehicles with active ambient lighting:** when the charging sequence is activated, the charge level is also accompanied by ambient lighting (→ page 153).

### Starting the alternating current charging process (mode 2/3)

**⚠ DANGER** Risk of death when charging at a damaged socket

The charging process uses high voltage.

If the charging cable, the vehicle socket or the mains socket are damaged, you could receive an electric shock.

- ▶ Only use an undamaged charging cable.
- ▶ Avoid mechanical damage such as crushing, abrading or driving over the cable.
- ▶ Have a damaged vehicle socket replaced at a qualified specialist workshop as soon as possible.
- ▶ Never connect the charging cable to a damaged vehicle socket.

**! NOTE** Damage due to overheating of charging cable and charging cable connector

During the charging process, the charging cable and charging cable connector can heat up within their permissible limit values.

The permissible limit values are influenced by the following factors:

- the power supply system and the charging cable are not damaged
- the instructions for handling the charging cable and the control element on the charging cable have been observed

- ▶ If the charging cable or charging cable connector becomes too hot, have the power supply system checked.

**! NOTE** Damaged or dirty vehicle socket when the socket flap is open

- ▶ Always keep the socket cover and the socket flap closed when there is no charging cable connected. This protects the vehicle socket from dirt and damage.
- ▶ Make sure that the socket cover is closed properly before closing the socket flap. This can otherwise result in damage which may prevent the socket flap from being opened again.

**! NOTE** Damage to the vehicle socket or the charging cable connector due to incorrect handling

Do not use excessive force (maximum 300 N) to insert the charging cable connector into the vehicle socket to the stop. You may otherwise


damage the vehicle socket, the charging cable connector or their contacts.

- ▶ If you feel there is increased resistance, pull the charging cable connector out of the socket and reinsert it.


### Requirements:

- The transmission is in position **P**.
- The vehicle is unlocked or the distance between the key and the vehicle does not exceed 1 m.
- The vehicle has not been started. The **READY** display in the driver's display is off.
- The charging cable is not taut.

- ❗ Depending on the national version, the vehicle is equipped with one of the following vehicle sockets.



Combo 1 vehicle socket



Combo 2 vehicle socket

- ▶ Open socket flap ❶ via the EQ module of the multimedia system (→ page 308).

or

- ▶ Press the centre rear section of socket flap ❶. Socket flap ❶ swings open and status display ❷ lights up white.

**Vehicles with an electric socket flap:** if an obstacle impedes the electric socket flap while it is opening, the socket flap closes again automatically and the driver's display shows a corresponding display message.

- ❗ When the vehicle is started (the READY display is lit in the driver's display), socket flap ❶ cannot be opened.
- ❗ Only upper connection ❸ is required for the charging cable connector.

- ▶ To charge at a mains socket, insert the mains plug into the mains socket of the external power source as far as it will go.
- ▶ Insert the charging cable connector into vehicle socket connection ❸ to the stop. If the wallbox/charging station is not equipped with a charging cable, insert the plug of the vehicle's charging cable into the wallbox/charging station socket to the stop.  
Make sure that the charging cable is not taut when inserted.

Status display ❷ flashes orange and, as soon as the high-voltage battery is charged, blue.

- ❗ When the charging sequence for the ambient lighting is activated, the ambient lighting lights up for approximately 30 seconds as with status display ❷ (→ page 153).  
When Sound Experience is activated, different situations, for example the charging cable connector being inserted and removed or the beginning of the charging process, are accompanied by selected sounds. For information on Sound Experience, please refer to the Digital Owner's Manual.

**Vehicles with an electric socket flap:** if a charging cable is not connected to the vehicle after the socket flap has been opened, the socket flap will close again automatically.

When the charging cable is connected to the vehicle, the vehicle cannot be started or moved.

At the start of the charging process, the charge level display is shown in the driver's display with a charging prediction. The charging prediction refers to the time at which the high-voltage battery will be fully charged.

- ❗ When the vehicle is switched on, a lightning symbol appears next to the charge level display

in the driver's display during the charging process.


- ❗ Depending on the temperature, the fan and battery cooling system may audibly switch on during the charging process.
- ❗ If the vehicle is idle for lengthy periods and connected to the mains supply, the high-voltage battery will be recharged automatically as needed or when electrical consumers are activated (e.g. the pre-entry climate control).

### Ending the alternating current charging process (mode 2/3)

#### Requirements:

- The distance between the key and the vehicle does not exceed 1 m.

## Combo 1 vehicle socket




- ▶ Press charging interruption button ②. The charging process is ended. Status display ① lights up white. The vehicle socket is unlocked.
- ▶ Press and hold button ③ on the charging cable connector and remove the charging cable connector from the vehicle socket.

❗ If you cannot remove the charging cable connector, repeat the unlocking procedure. If the charging cable connector is still locked, contact a qualified specialist workshop.

- ▶ Close the socket cover and the socket flap. For vehicles with an electric socket flap, observe the notes at the end of the section.
- ▶ Remove the charging cable connector from the mains socket, or from the socket on the wallbox/charging station, and stow the vehicle's charging cable safely in the vehicle (→ page 193).

## Combo 2 vehicle socket



- ▶ Press charging interruption button ②. The charging process is ended. Status display ① lights up white. The vehicle socket is unlocked.

- ▶ Remove charging cable connector ③ from the vehicle socket within 30 seconds. After the 30 seconds have elapsed, the vehicle socket will be locked again and the charging process will resume.
- ❗ If you cannot remove the charging cable connector, repeat the unlocking procedure. If the charging cable connector is still locked, contact a qualified specialist workshop.
- ❗ Status display ① indicator lamp remains lit for some time after the charging cable connector has been removed and then goes out.
- ▶ Close the socket flap.  
For vehicles with an electric socket flap, observe the following notes on closing the socket flap.
- ▶ Remove the charging cable connector from the mains socket, or from the socket on the wallbox/charging station, and stow the vehicle's charging cable safely in the vehicle (→ page 193).

The electric socket flap closes automatically in the following situations:

- shortly after the charging cable connector has been removed
- after the socket flap has been tapped in the direction to close it
- after transmission position **N**, **D** or **R** has been engaged

#### Automatic reversing function of the electric socket flap

If an obstacle impedes the electric socket flap during the closing process, the socket flap opens again automatically and the driver's display shows a corresponding display message. The automatic reversing function is only an aid and is not a substitute for your attentiveness.

- ▶ When closing the socket flap, make sure that no body parts or objects are in the closing area.

#### Starting the direct current charging process (mode 4)

**⚠ DANGER** Risk of death when charging at a damaged socket

The charging process uses high voltage.

If the charging cable, the vehicle socket or the mains socket are damaged, you could receive an electric shock.

- ▶ Only use an undamaged charging cable.
- ▶ Avoid mechanical damage such as crushing, abrading or driving over the cable.
- ▶ Have a damaged vehicle socket replaced at a qualified specialist workshop as soon as possible.
- ▶ Never connect the charging cable to a damaged vehicle socket.



**!** **NOTE** Damage due to overheating of charging cable and charging cable connector

During the charging process, the charging cable and charging cable connector can heat up within their permissible limit values.

The permissible limit values are influenced by the following factors:

- the power supply system and the charging cable are not damaged
- the instructions for handling the charging cable and the control element on the charging cable have been observed

► If the charging cable or charging cable connector becomes too hot, have the power supply system checked.

**!** **NOTE** Damaged or dirty vehicle socket when the socket flap is open

► Always keep the socket cover and the socket flap closed when there is no

charging cable connected. This protects the vehicle socket from dirt and damage.

► Make sure that the socket cover is closed properly before closing the socket flap. This can otherwise result in damage which may prevent the socket flap from being opened again.

**!** **NOTE** Damage to the vehicle socket or the charging cable connector due to incorrect handling

Do not use excessive force (maximum 300 N) to insert the charging cable connector into the vehicle socket to the stop. You may otherwise damage the vehicle socket, the charging cable connector or their contacts.


► If you feel there is increased resistance, pull the charging cable connector out of the socket and reinsert it.

#### Requirements:


- The transmission is in position **P**.

- The vehicle is unlocked or the distance between the key and the vehicle does not exceed 1 m.
- The vehicle has not been started. The **READY** display in the driver's display is off.
- The charging cable is not taut.

**i** Depending on the national version, the vehicle is equipped with one of the following vehicle sockets.



Combo 1 vehicle socket



Combo 2 vehicle socket

► Open socket flap ① via the EQ module of the multimedia system (→ page 308).

or

► Press the centre rear section of socket flap ①.  
Socket flap ① swings open and status display ② lights up white.

**Vehicles with an electric socket flap:** if an obstacle impedes the electric socket flap while it is opening, the socket flap closes again automatically and the driver's display shows a corresponding display message.

① When the vehicle is started (the **READY** display is lit in the driver's display), socket flap ① cannot be opened.

► Remove socket cover ④ from the lower connection of vehicle socket ③.

① The CCS charging cable connector requires both vehicle socket connections ③.

► Insert the charging cable connector into vehicle socket ③ to the stop.  
Make sure that the charging cable is not taut when inserted.

Status display ② flashes orange and, as soon as the high-voltage battery is charged, blue.

① When the charging sequence for the ambient lighting is activated, the ambient lighting lights up for approximately 30 seconds as with status display ② (→ page 153).

When Sound Experience is activated, different situations, for example the charging cable connector being inserted and removed or the beginning of the charging process, are accompanied by selected sounds. For information on Sound Experience, please refer to the Digital Owner's Manual.

**Vehicles with an electric socket flap:** if a charging cable is not connected to the vehicle after the socket flap has been opened, the socket flap will close again automatically.

When the charging cable is connected to the vehicle, the vehicle cannot be started or moved.

At the start of the charging process, the charge level display is shown in the driver's display with a charging prediction. The charging prediction refers to the time at which the high-voltage battery will be fully charged.

**i** When the vehicle is switched on, a lightning symbol appears next to the charge level display in the driver's display during the charging process.


- i** Depending on the temperature, the fan and battery cooling system may audibly switch on during the charging process.
- i** If the vehicle is idle for lengthy periods and connected to the mains supply, the high-voltage battery will be recharged automatically as needed or when electrical consumers are activated (e.g. the pre-entry climate control).

### Ending the direct current charging process (mode 4)

#### Requirements:

- The distance between the key and the vehicle does not exceed 1 m.


### Combo 1 vehicle socket



- ▶ Press charging interruption button **2**. The charging process is ended. Status display **1** lights up white. The vehicle socket is unlocked.
- ▶ Press and hold button **3** on the charging cable connector and remove the charging cable connector from the vehicle socket.

- ❗ If you cannot remove the charging cable connector, unlock the vehicle and repeat the procedure. If the charging cable connector is still locked, contact a qualified specialist workshop.
- ❗ Status display ❶ indicator lamp remains lit for some time after the charging cable connector has been removed and then goes out.
- Insert socket cover ❷ into the lower vehicle socket connection.
- Close the socket flap.  
For vehicles with an electric socket flap, observe the notes at the end of the section.

### Combo 2 vehicle socket



- Press charging interruption button ❷. The charging process is ended. Status display ❶ lights up white. The vehicle socket is unlocked.
- Remove charging cable connector ❸ from the vehicle socket.

- ❗ If you cannot remove the charging cable connector, unlock the vehicle and repeat the procedure. If the charging cable connector is still locked, contact a qualified specialist workshop.
- ❗ Status display ❶ indicator lamp remains lit for some time after the charging cable connector has been removed and then goes out.
- Insert socket cover ❷ into the lower vehicle socket connection.
- Close the socket flap.  
For vehicles with an electric socket flap, observe the following notes on closing the socket flap.

The electric socket flap closes automatically in the following situations:

- shortly after the charging cable connector has been removed
- after the socket flap has been tapped in the direction to close it
- after the transmission position **N**, **D** or **R** has been engaged


### Automatic reversing function of the electric socket flap

If an obstacle impedes the electric socket flap during the closing process, the socket flap opens again automatically and the driver's display shows a corresponding display message. The automatic reversing function is only an aid and is not a substitute for your attentiveness.

▶ When closing the socket flap, make sure that no body parts or objects are in the closing area.

### Function of the charge level display in the driver's display

i The data shown in the illustration is example data.



- ① Range at current charge level
- ② Current state of charge of the high-voltage battery
- ③ Maximum state of charge (depending on the setting)
- ④ Time remaining until completely charged (until the selected maximum charge level is reached)
- ⑤ Charge level recommended by Range Assistant to reach the next destination
- ⑥ Dynamic charge level display
- ⑦ Current charging capacity

i Specified remaining range ① may vary due to different factors, e.g. driving style or topography.

When the vehicle is connected to the mains supply and is switched off, the driver's display shows the charge level display for approximately two minutes.

i The value of current charging capacity ⑦ can differ from the display on the charging station. At a charging capacity of 10 kW or higher, the value in the charge level display is rounded off and shown without a decimal place.

The value in ④ varies depending on the setting of the charging process. It displays the charging prediction, e.g. the time at which the selected charge level will be reached or the charge level at the pre-selected departure time.

## Configuring the charging settings

Multimedia system:

→  » EQ » Charging

### Setting the charging program

- ▶ Select **Home**, **Work** or **Standard**.

### Opening the socket flap

- ▶ Press **Open socket flap**.

The socket flap opens.

- ① Further notes on charging with alternating current: (→ page 201) or direct current: (→ page 205).

### Unlocking the charging cable (mode 3 or 4)

When the function is active, the charging cable is unlocked when the maximum charge level is reached.

- ▶ Select **Home** or **Work**.
- ▶ Activate or deactivate **Unlock charging cable**.

### Activating or deactivating location-based charging

- ▶ Select **Charge at home** or **Charge at work**.

- ▶ Activate or deactivate **Select based on location**.

When the function is activated, the vehicle's current position is saved as one of the selected options. When the address is reached again, the charging program is automatically switched over as soon as parking position **P** is engaged.

### Activating or deactivating ECO charging

- ▶ Activate or deactivate the function.

The **ECO charging** function limits the charging voltage at charging stations to conserve the vehicle's battery.

### Setting the departure time

The set departure times are used for the vehicle's pre-entry climate control and for predictions regarding the approximate state of charge and range at the time selected. The charging process always starts immediately, irrespective of the next departure time.

- ▶ Select **Departure time**.

The following charging times can be selected:

- individual charging times

- On **Week profile**

### Setting an individual departure time

- ▶ Select **Add new time** and set a new departure time.

or

- ▶ Select  and adapt an existing departure time.

### Setting the repeat days

- ▶ Select **Add new time** and set a new departure time.

- ▶ Mark the relevant weekdays for which the departure time will apply and confirm with **OK**.

or

- ▶ Select  and edit existing repeat days.

### Setting a break in the charging process

Up to four breaks in the charging process can be set during which the vehicle is not charged, even if it is connected to a charging station.

- ▶ Select **Charging interruptions**.

- ▶ Select **Add new time** and then set and save the times for the beginning and end of the break.
- ▶ Activate or deactivate the charging breaks that have been set.

Set charging breaks can be edited with the  button or deleted with the  button.

## Parking

### Parking the vehicle

**⚠ WARNING** Risk of accident and injury caused by an insufficiently secured vehicle rolling away

If the vehicle is not securely parked sufficiently, it can roll away in an uncontrolled way even at a slight downhill gradient.

- ▶ On uphill or downhill gradients, turn the front wheels so that the vehicle rolls towards the kerb if it starts moving.
- ▶ apply the parking brake.
- ▶ Switch the transmission to position **P**.

**⚠ WARNING** Risk of accident and injury due to leaving children unattended in the vehicle

If children are left unattended in the vehicle, they could, in particular:

- open doors, thereby endangering other persons or road users.
- get out and be struck by oncoming traffic.
- operate vehicle equipment and become trapped, for example.

In addition, the children could also set the vehicle in motion by, for example:

- releasing the parking brake.
  - changing the transmission position.
  - starting the vehicle.
- ▶ Never leave children unattended in the vehicle.
  - ▶ When leaving the vehicle, always take the key with you and lock the vehicle.
  - ▶ Keep the vehicle key out of the reach of children.

**! NOTE** Damage to the vehicle due to it rolling away

- ▶ Always secure the vehicle against rolling away.

**! NOTE** Damage caused by vehicle being lowered

**Vehicles AIRMATIC:** The vehicle can be lowered due to differences in temperature or extended non-operational times. This can cause damage to parts of the body.


- ▶ When stopping the vehicle and when driving off, make sure that there are no obstacles such as kerbs under or in the immediate vicinity of the body.

**i** If you park the vehicle for a long period, observe the following notes:


- Make sure the high-voltage battery has a sufficient state of charge, especially at very low outside temperatures. In this way you can avoid any problems when the vehicle is subsequently started.

- If possible, avoid parking spaces in direct sunlight.

Observe the notes on charging the high-voltage battery (→ page 193).



Vehicles with central display



Vehicles with MBUX Hyperscreen

- ▶ Bring the vehicle to a standstill by pressing the brake pedal.
- ▶ On gradients, turn the front wheels so that the vehicle will roll towards the kerb if it starts moving.
- ▶ Apply the electric parking brake.

- ▶ Engage transmission position **P** in a stationary vehicle with the brake pedal depressed (→ page 192).
  - ▶ Switch off the vehicle by pressing button **1**.
  - ▶ Release the service brake slowly.
  - ▶ Get out of the vehicle and lock it.
- i** When you park the vehicle, you can still operate the side windows and the panoramic sliding sunroof for approximately four minutes if the driver's door is closed.



## Electric parking brake

### Function of the electric parking brake (applying automatically)

**⚠ WARNING** Risk of accident and injury due to leaving children unattended in the vehicle

If children are left unattended in the vehicle, they could, in particular:

- open doors, thereby endangering other persons or road users.
- get out and be struck by oncoming traffic.
- operate vehicle equipment and become trapped, for example.

In addition, the children could also set the vehicle in motion by, for example:

- releasing the parking brake.
- changing the transmission position.
- starting the vehicle.

▶ Never leave children unattended in the vehicle.

- ▶ When leaving the vehicle, always take the key with you and lock the vehicle.
- ▶ Keep the vehicle key out of the reach of children.

**The electric parking brake is applied if the transmission is in position **P** and one of the following conditions is fulfilled:**

- The vehicle is switched off.
- The seat belt tongue is not inserted in the seat belt buckle of the driver's seat and the driver's door is opened.

**i** To prevent application: pull the handle of the electric parking brake (→ page 215).

**In the following situations, the electric parking brake is also applied:**

- The HOLD function is keeping the vehicle stationary.
- Active Parking Assist is keeping the vehicle stationary.
- Active Distance Assist DISTRONIC is bringing the vehicle to a standstill.

• **In addition, one of the following conditions must be fulfilled:**

- The vehicle is switched off.
- The seat belt tongue is not inserted in the seat belt buckle of the driver's seat and the driver's door is opened.
- There is a system malfunction.
- The power supply is insufficient.
- The vehicle is stationary for a lengthy period.

When the electric parking brake is applied, the red **(P)** indicator lamp lights up in the driver's display.

**Function of the electric parking brake (releasing automatically)**

**The electric parking brake is released when the following conditions are fulfilled:**

- The driver's door is closed.
- The vehicle has been started.
- The transmission is in position **D** or **R** and you depress the accelerator pedal or you shift

from transmission position **P** to **D** or **R** when on level ground.

- If the transmission is in position **R**, the boot lid must be closed.
- The seat belt tongue is inserted into the seat belt buckle of the driver's seat.


If the seat belt tongue is not inserted into the seat belt buckle of the driver's seat, one of the following conditions must be fulfilled:

- You shift from transmission position **P**.  
or
- You have previously driven at speeds greater than 3 km/h.

When the electric parking brake is released, the red **(P)** indicator lamp in the driver's display goes out.

## Applying/releasing the electric parking brake manually

### Applying



- ▶ Push handle ①.  
The red **(P)** indicator lamp lights up in the driver's display.

- ① The electric parking brake is only securely applied if the red **(P)** indicator lamp is lit continuously.

### Releasing

- ▶ Switch on the vehicle.
- ▶ Pull handle ①.  
The red **(P)** indicator lamp in the driver's display goes out.

### Emergency braking

- ▶ Press and hold handle ①.  
As long as the vehicle is driving, the **Release parking brake** message is displayed and the red **(P)** indicator lamp flashes.  
When the vehicle has been braked to a standstill, the electric parking brake is applied. The red **(P)** indicator lamp lights up in the driver's display.

### Information on collision detection on a parked vehicle

If a collision is detected when the tow-away protection is primed on a locked vehicle, you will

receive a notification in the multimedia system when you switch the vehicle on.

You will receive information about the following points:

- The area of the vehicle that may have been damaged.
- The force of the impact.

The following situation can lead to inadvertent activation:

- The parked vehicle is moved, forexample, in a two-storey garage.

-  Deactivate tow-away protection in order to prevent inadvertent activation. If you deactivate tow-away protection, collision detection will also be deactivated.  
You can permanently deactivate collision detection via the multimedia system (→ page 216).

### System limits

Detection may be restricted in the following situations:

- the vehicle is damaged without impact, forexample, if an outside mirror is torn off or the paint is damaged by a key
  - an impact occurs at low speed
  - the electric parking brake is not applied
-  You are responsible for your vehicle. Therefore, always make sure that your vehicle is free of damage and is roadworthy.

### Setting collision detection on a parked vehicle

Multimedia system:

  **» Settings » Vehicle**  
**» Open/close » Vehicle protection**

-  Activate or deactivate the function via **Collision notification**.
-  A maximum of three incidents can be registered. Up to 15 photos are taken for every incident. In the event of another incident, the

photos of the first incident will be overwritten if they have not been deleted already.

### Activating or deactivating the collision photos function

Note possible legal restrictions in some countries regarding automatic recording of the vehicle surroundings.

-  Activate or deactivate **Take photos**.

### Transferring the collision photos with the Mercedes me App

-  Select **Upload to Mercedes me**.
-  Select **Upload automatically**.
-  Scan the generated QR code on the central display with the Mercedes me App.  
The encrypted collision photos will then be uploaded to Mercedes me.
-  Any device that can scan QR codes can be used to view the collision photos in the Mercedes me App.

### Copying the collision photos to a USB flash drive

-  Connect a USB flash drive .

- ▶ Select **Manage collision photos**.
- ▶ Select **Copy (USB)**.  
All collision photos are copied to the USB flash drive.
- ❶ To ensure secure operation, only use with FAT32 or exFAT formatted USB storage devices.

### Deleting collision photos

- ▶ Select **Manage collision photos**.
- ▶ Select **Delete**.  
All collision photos will be deleted.

## Driving and driving safety systems

### Driving systems and your responsibility



Your vehicle is equipped with driving systems which assist you in driving, parking and manoeuvring the vehicle. The driving systems are only aids. They are not a substitute for you paying attention to your surroundings and do not relieve you of your responsibility pertaining to road traffic law. The driver is always responsible for maintaining a safe distance to the vehicle in front, for vehi-

cle speed, for braking in good time and for staying in lane. Pay attention to the traffic conditions at all times and intervene when necessary. Be aware of the limitations regarding the safe use of these systems.

Driving systems can neither reduce the risk of accident if you fail to adapt your driving style nor override the laws of physics. They cannot always take into account road, weather or traffic conditions.

### Information on vehicle sensors and cameras

Some driving and driving safety systems use cameras as well as radar or ultrasonic sensors to monitor the area in front of, behind or next to the vehicle.



- ❶ Multifunction camera
- ❷ Cameras in the outside mirrors
- ❸ Front radar
- ❹ Front camera

- 5 Corner radars
- 6 Ultrasonic sensors
- 7 Reversing camera

**! WARNING** Risk of accident due to restricted detection performance of vehicle sensors and cameras

If the area around vehicle sensors or cameras is covered, damaged or dirty, certain driving and safety systems cannot function correctly. There is a risk of an accident.

- Keep the area around vehicle sensors or cameras clear of any obstructions and clean.
- Have damage to the bumper, radiator grille or stone chipping in the area of the front and rear windows repaired at a qualified specialist workshop.

Particularly, keep the areas around the sensors and cameras free of dirt, ice or slush (→ page 373). The sensors and cameras must not be covered and the detection ranges around them must be kept free. Do not attach additional

licence plate brackets, advertisements, stickers, foils or foils to protect against stone chippings in the detection range of the sensors and cameras. Make sure that there are no overhanging loads protruding into the detection range.

If there is damage to a bumper or the radiator grille, or after an impact, have the function of the sensors checked at a qualified specialist workshop. Have damage or stone chipping in the area of the cameras on the front and rear windows repaired at a qualified specialist workshop.

- i The reversing camera can extend and retract automatically for the purpose of calibration, even though there is no camera image in the display.

### Overview of driving systems and driving safety systems

- ABS (→ page 219)
- BAS (→ page 219)
- ESP® (→ page 220)
- ESP® Crosswind Assist (→ page 221)
- ESP® trailer stabilisation (→ page 221)
- EBD (→ page 222)
- STEER CONTROL (→ page 222)
- HOLD function (→ page 222)
- Hill Start Assist (→ page 223)
- Adaptive Brake Lights (→ page 224)
- Valet service mode (→ page 224)
- Beginner driver mode (→ page 225)
- ATTENTION ASSIST (→ page 225)
- Cruise control (→ page 227)
- Limiter (→ page 228)
- Speed Limit Assist (country-dependent) (→ page 250)
- Traffic Sign Assist (→ page 251)
- Traffic light view (→ page 255)
- AIRMATIC (→ page 262)

## Driving Assistance package

- ❗ The availability of some functions or sub-functions of the Driving Assistance Package is equipment- or country-specific. The functions of your Driving Assistance Package may differ from the functions listed here.  
Active Distance Assist DISTRONIC, Active Blind Spot Assist, Active Brake Assist, Active Lane Keeping Assist and Active Emergency Stop Assist are also available without the Driving Assistance Package, albeit with restricted functionality.
- Active Distance Assist DISTRONIC (→ page 230)
- Active Speed Limit Assist (→ page 235)
- Route-based speed adaptation (→ page 236)
- Active Brake Assist (→ page 245)
- Active Steering Assist (→ page 238)
- Active Emergency Stop Assist (→ page 241)
- Active Lane Change Assist (→ page 242)
- Active Stop-and-Go Assist (→ page 238)

- Active Blind Spot Assist with exit warning (→ page 255)
- Active Lane Keeping Assist (→ page 259)
- PRE-SAFE® Impulse Side (→ page 58)

## Parking Package

- ❗ The availability of individual functions is country and equipment-dependent.
- Reversing camera (→ page 264)
- 360° Camera (→ page 266)
- Parking Assist PARKTRONIC (→ page 271)
- Active Parking Assist (→ page 275)
- Remote Parking Assist (→ page 280)
- Memory Parking Assist (country-dependent) (→ page 287)

## Functions of ABS

The Anti-lock Brake System (ABS) regulates the brake pressure in critical driving situations:

- During braking, for instance, at maximum full-stop braking or if there is insufficient tyre traction, the wheels are prevented from locking.

- Vehicle steerability while braking is ensured.

If ABS intervenes when braking, you will feel a pulsing in the brake pedal. The pulsating brake pedal can be an indication of hazardous road conditions and can serve as a reminder to take extra care while driving.

## System limits

- ABS is active from speeds of approx. 5 km/h.
- ABS may be impaired or may not function if a malfunction has occurred and the yellow  ABS warning lamp lights up continuously after the vehicle is started.

## Function of BAS

**⚠ WARNING** Risk of an accident caused by a malfunction in BAS (Brake Assist System)

If BAS is malfunctioning, the braking distance in an emergency braking situation is increased.

- ▶ Depress the brake pedal with full force in emergency braking situations. ABS prevents the wheels from locking.

The Brake Assist System (BAS) supports your emergency braking situation with additional brake force.

If you depress the brake pedal quickly, BAS is activated:

- BAS automatically boosts the brake pressure.
- BAS can shorten the braking distance.
- ABS prevents the wheels from locking.

The brakes will function as usual once you release the brake pedal. BAS is deactivated.

### Function of ESP®

**⚠ WARNING** Risk of skidding if ESP® is deactivated

If you deactivate ESP®, ESP® cannot carry out vehicle stabilisation.

- ▶ ESP® should only be deactivated in the following situations.

#### **!** NOTE Mercedes-AMG vehicles

- ▶ Observe the notes in the Supplement. You could otherwise fail to recognise dangers.

The Electronic Stability Program (ESP®) can monitor and improve driving stability and traction in the following situations within physical limits:

- When pulling away on wet or slippery carriageways.
- When braking.
- **Vehicles with trailer hitch:** in trailer operation from speeds of 65 km/h, if the vehicle/trailer combination begins to sway from side to side.
- In strong side winds when you are driving faster than 80 km/h.

If the vehicle deviates from the direction desired by the driver, ESP® can stabilise the vehicle by intervening in the following ways:

- One or more wheels are braked.
- The drive system output is adapted according to the situation.

ESP® is deactivated if the  ESP® OFF warning lamp lights up continuously in the driver's display:

- Driving stability will no longer be improved.
  - **Vehicles with trailer hitch:** stabilisation of the vehicle/trailer combination is no longer active.
  - Crosswind Assist is no longer active.
  - The drive wheels could spin.
  - ETS/4ETS traction control is still active.
- i** When ESP® is deactivated, you are still assisted by ESP® when braking.

If the  ESP® warning lamp flashes in the driver's display, one or several wheels has reached its grip limit:

- Adapt your driving style to suit the current road and weather conditions.
- Do not deactivate ESP®.
- Only depress the accelerator pedal as far as is necessary when pulling away.

Deactivate ESP® in the following situations to improve traction:

- When using snow chains.
- In deep snow.
- On sand or gravel.

 Spinning the wheels results in a cutting action, which enhances traction.

If the  ESP® warning lamp lights up continuously, ESP® is not available due to a malfunction.

### ETS/4ETS (Electronic Traction System)

ETS/4ETS traction control is part of ESP® and makes it possible to pull away and accelerate on a slippery carriageway.

ETS/4ETS can improve the vehicle's traction by intervening in the following ways:

- The drive wheels are braked individually if they spin.
- More drive torque is transferred to the wheel or wheels with traction.

### Influence of drive programs on ESP®

The drive programs enable ESP® to adapt to different weather and road conditions as well as the driver's preferred driving style. Depending on the selected drive program, the appropriate ESP® mode will be activated. You can select the drive programs using the DYNAMIC SELECT button (→ page 190).

### Function of ESP® Crosswind Assist

ESP® Crosswind Assist detects sudden gusts of side wind and helps the driver to keep the vehicle in the lane:

- ESP® Crosswind Assist is active at vehicle speeds above approx. 80 km/h when driving straight ahead or cornering slightly.

- The vehicle is stabilised by means of individual brake application on one side.

### Function of ESP® trailer stabilisation

 **WARNING** Risk of accident in poor road and weather conditions

In poor road and weather conditions, the trailer stabilisation cannot prevent lurching of the vehicle/trailer combination. Trailers with a high centre of gravity may tip over before ESP® detects this.

► Always adapt your driving style to suit the current road and weather conditions.

When driving with a trailer, ESP® can stabilise your vehicle if the trailer begins to swerve from side to side:

- ESP® trailer stabilisation is active above speeds of 65 km/h.
- Slight swerving is reduced by means of a targeted, individual brake application on one side.



- In the event of severe swerving, the operating energy output is also reduced and all wheels are braked.

ESP® trailer stabilisation may be impaired or may not function if:

- The trailer is not connected correctly or is not detected properly by the vehicle.

### Activating/deactivating ESP® (Electronic Stability Program)

Multimedia system:



#### **NOTE** Mercedes-AMG vehicles

- ▶ Observe the notes in the Supplement. You could otherwise fail to recognise dangers.

- ▶ Select **ESP**.
- ▶ Select **On** or  **Off**.

ESP® is deactivated if the  ESP® OFF warning lamp lights up continuously in the driver's display.

Observe any information on warning lamps and display messages which may be shown in the driver's display.

### Function of EBD

Electronic Brakeforce Distribution (EBD) is characterised by the following:

- Monitoring and regulating the brake pressure on the rear wheels.
- Improved driving stability when braking, especially on bends.

### Function of STEER CONTROL

STEER CONTROL assists you by transmitting a noticeable steering force to the steering wheel in the direction required for vehicle stabilisation.

### System limits

STEER CONTROL may be impaired or may not function in the following situations:

- ESP® is deactivated.
- ESP® is malfunctioning.
- The steering is malfunctioning.

If ESP® is malfunctioning, you will be assisted further by the electric power steering.

### HOLD function

#### HOLD function

The HOLD function holds the vehicle at a standstill without requiring you to depress the brake pedal, e.g. while waiting in traffic.

The HOLD function is only an aid. The responsibility for the vehicle safely standing still remains with the driver.

### System limits

The HOLD function is only intended to provide assistance when driving and is not a sufficient means of safeguarding the vehicle against rolling away when stationary.

- The incline must not be greater than 30%.

### Activating/deactivating the HOLD function

**⚠ WARNING** Risk of an accident due to the HOLD function being active when you leave the vehicle

If the vehicle is only braked with the HOLD function it could, in the following situations, roll away:

- If there is a malfunction in the system or in the power supply.
- If the HOLD function is deactivated by depressing the accelerator pedal or brake pedal, e.g. by a vehicle occupant.

▶ Always secure the vehicle against rolling away before you leave it.

### Requirements:

- The vehicle is stationary.
- The driver's door is closed or the seat belt on the driver's side is fastened.
- The vehicle has been started.
- The electric parking brake is released.

- Active Distance Assist DISTRONIC is deactivated.
- The transmission is in position **D**, **R** or **N**.

### Activating the HOLD function

- ▶ Depress the brake pedal, and after a short time quickly depress further until the **HOLD** display appears in the driver's display.
- ▶ Release the brake pedal.

### Deactivating the HOLD function

- ▶ Depress the accelerator pedal to pull away.
- or
- ▶ Depress the brake pedal until the **HOLD** display disappears from the driver's display.

The HOLD function is deactivated in the following situations:

- Active Distance Assist DISTRONIC is activated.
- The transmission is shifted to position **P**.
- The vehicle is secured with the electric parking brake.

In the following situations, the vehicle is held by transmission position **P** and/or by the electric parking brake:

- The seat belt is unfastened and the driver's door is opened.
- The vehicle is switched off.
- There is a system malfunction.
- The power supply is insufficient.

In addition, the **Brake immediately** message may appear in the driver's display and a horn tone may sound at regular intervals.

- ▶ Immediately depress the brake pedal firmly until the warning message disappears. The HOLD function is deactivated.
- ▶ Additionally secure the vehicle against rolling away.

### Function of Hill Start Assist

Hill Start Assist holds the vehicle for a short time when pulling away on a hill under the following conditions:

- The transmission is in position **D** or **R**.

- The electric parking brake is released.

This gives you enough time to move your foot from the brake pedal to the accelerator pedal and depress it before the vehicle begins to roll away.

**⚠ WARNING** Risk of accident and injury due to the vehicle rolling away

After a short time, Hill Start Assist no longer holds the vehicle.

- ▶ Swiftly move your foot from the brake pedal to the accelerator pedal. Do not leave the vehicle when it is being held by Hill Start Assist.

### Function of Adaptive Brake Lights

Adaptive Brake Lights warn following traffic in an emergency braking situation with the following actions:

- flashing the brake lamps
- activating the hazard warning lights (→ page 144)

If the vehicle is braked sharply from speeds above 50 km/h, the brake lamps flash rapidly. This provides traffic travelling behind you with an even more noticeable warning.

### Valet service mode

#### Function of the valet service mode

In valet service mode, the vehicle acceleration is limited to reduce the risk of damage to and improper use of the vehicle when it is handed over to third parties.

Valet service mode is characterised by the following:

- The maximum speed that can be driven is limited to 80 km/h.
- Drive programs **[S<sup>+</sup>]** and **[I<sup>+</sup>]** are not available.
- ESP® cannot be deactivated.
- Profiles that are still logged in are logged out and unprotected profiles are secured.

### Activating or deactivating valet service mode

#### Requirements:

- For activation: the vehicle is stationary.
- For deactivation: park position **[P]** is engaged.

Multimedia system:

➔ **[Home]** ➔ **Apps** ➔ **Valet service mode**

- ⓘ This function is an on-demand feature (→ page 24).
- ▶ Activate or deactivate the function. If valet service mode is activated, an indicator lamp in the driver's display lights up.
- ⓘ Alternatively, valet service mode can be activated or deactivated via the Mercedes me connect App. Further information on Mercedes me connect (→ page 348)
- ⓘ Valet service mode is protected from deactivation by third parties only in combination with Mercedes me connect. If the vehicle is connected to Mercedes me connect, only the profile that activated the mode or the established main user can deactivate it again.

- ❗ Valet service mode remains active even following a change of profile or after the vehicle is switched on or off, and must be deliberately deactivated by the authorised user.

### Beginner driver mode

#### Function of the beginner driver mode

In beginner driver mode, the vehicle acceleration is limited to increase safety for inexperienced drivers.

Beginner driver mode is characterised by the following:

- The maximum speed that can be driven is limited to 120 km/h.
- Drive programs **S** and **I\*** are not available.
- ESP® cannot be deactivated.

#### Activating or deactivating beginner driver mode

##### Requirements:

- For activation: the vehicle is stationary.
- For deactivation: park position **P** is engaged.

Multimedia system:

→  » Apps » Beginner driver mode

- ❗ This function is an on-demand feature (→ page 24).
- ▶ Activate or deactivate the function.  
If beginner driver mode is activated, an indicator lamp in the driver's display lights up.
- ❗ Alternatively, beginner driver mode can be activated or deactivated via the Mercedes me connect app.  
Further information on Mercedes me connect (→ page 348)
- ❗ Beginner driver mode is protected from deactivation by third parties only in combination with Mercedes me connect. If the vehicle is connected to Mercedes me connect, only the profile that activated the mode or the established main user can deactivate it again.
- ❗ Beginner driver mode remains active even following a change of profile or after the vehicle is switched on or off, and must be deliberately deactivated by the authorised user.

### ATTENTION ASSIST

#### Function of ATTENTION ASSIST with microsleep detection

- ❗ The microsleep detection sub-function is only available in combination with the driver camera (→ page 315).

ATTENTION ASSIST assists you on long, monotonous journeys, e.g. on motorways and trunk roads. If indicators of fatigue or increasing lapses in concentration on the part of the driver are detected, the system suggests taking a break.

ATTENTION ASSIST is only an aid. It cannot always detect fatigue or lapses in concentration in time. The system is not a substitute for a well-rested and attentive driver. On long journeys, take regular breaks in good time that allow for adequate recuperation.

You can choose between two settings:

- **Standard:** normal system sensitivity.
- **Sensitive:** higher system sensitivity. The driver is warned earlier and the attention level detected by ATTENTION ASSIST is adapted accordingly.

If fatigue or increasing inattention is detected, the warning appears in the driver display: **ATTENTION ASSIST: Take a break!**. You can acknowledge the message and take a break if necessary. If you do not take a break and ATTENTION ASSIST continues to detect increasing lapses in concentration, you will be warned again after a minimum of 15 minutes.



The following information is displayed in the driver's display:

- The length of the journey since the last break
- The attention level determined by ATTENTION ASSIST:

- The more segments ② of the circle displayed, the higher the detected attention level.
- Fewer segments ② are displayed in the circle as the attention level decreases.
- Microsleep detection ① status:
  - Deactivated: display ① is hidden.
  - Activated but not operational: display ① is grey.
  - Activated and operational: display ① is green.

If ATTENTION ASSIST is unable to calculate the attention level and cannot issue a warning, the **System suspended** message appears.

If the system, which uses the driver camera, detects indicators of microsleep, the **ATTENTION ASSIST Microsleep Take a break!** warning message appears in the driver's display and a warning tone sounds simultaneously. This warning message must be confirmed by Touch Control. It is recommended that you take a break immediately.

If the driver display shows a warning, a service area search is offered in the multimedia system.

You can select a rest area and start navigation to this rest area.

If you restart the vehicle, ATTENTION ASSIST with microsleep detection is automatically activated. The last selected sensitivity level remains stored.

### System limits

ATTENTION ASSIST is active in the 60 km/h to 200 km/h speed range.

The microsleep detection function is available at a speed of 20 km/h and above.

Particularly in the following situations, ATTENTION ASSIST only functions in a restricted manner and warnings may be delayed or not occur:

- If you have been driving for less than approximately 30 minutes.
- If the road condition is poor (uneven road surface or potholes).
- If there is a strong side wind.
- If you adopt a sporty driving style (high cornering speeds or high rates of acceleration).
- If the Steering Assist function of Active Distance Assist DISTRONIC is active.

- If the clock is set to the incorrect time.
- If you change lanes and vary your speed frequently in active driving situations.

Microsleep detection also does not function when the driver camera cannot detect the driver's eyes, foreexample as a result of the following factors:

- The driver's eyes are covered due to the steering column position, foreexample.
- Poor lighting conditions.
- Some types of spectacles or sunglasses.
- The driver's line of vision is outside the driver camera's field of vision.

Also observe any information regarding display messages that can be displayed in the driver's display.

The tiredness and alertness assessment of ATTENTION ASSIST with microsleep detection is reset and restarted when continuing the journey in the following situations:

- If you switch off the vehicle.

- If you unfasten your seat belt and open the driver's door (e.g. to change drivers or take a break).

### Setting ATTENTION ASSIST

Multimedia system:

→  >> Settings >> Assistance  
>> Assistance >> ATTENTION ASSIST

### Setting the sensitivity

- ▶ Select  next to ATTENTION ASSIST.
- ▶ Select **Standard** or **Sensitive**.

### Cruise control and limiter

#### Function of cruise control

Cruise control regulates the speed to the value selected by the driver.

If you accelerate to overtake, foreexample, the stored speed is not deleted. If you remove your foot from the accelerator pedal after overtaking, cruise control will resume speed regulation back to the stored speed.

You can store any speed above 20 km/h up to the maximum design speed, up to the speed recom-

mended by range monitoring or up to the set winter tyre limit.

Observe the notes on driving systems and your responsibility; you may otherwise fail to recognise dangers (→ page 217).

**Mercedes-AMG vehicles:** cruise control is available up to a maximum speed of 250 km/h.

### Displays in the driver's display

-  (grey): cruise control is selected but not yet active, or temporarily passive.
-  (green): cruise control is active.

A stored speed appears under the  display and is indicated in the speedometer.

### System limits

Cruise control may be unable to maintain the stored speed on uphill gradients. The stored speed is resumed when the gradient evens out.

Increase recuperation in good time on long and steep downhill gradients. Take particular note of this when driving a laden vehicle. By doing so, you will make use of the electric motor's braking effect to charge the high-voltage battery. This

relieves the load on the brake system and prevents the brakes from overheating and wearing too quickly.

Do not use cruise control in the following situations:

- in traffic situations which require frequent changes of speed, e.g. in heavy traffic, on winding roads
- on slippery roads. Accelerating can cause the drive wheels to lose traction and the vehicle could then skid.
- when visibility is poor

### Function of the limiter

The limiter restricts the speed of the vehicle. To reduce the speed to the set speed, the limiter applies the brakes automatically.

You can limit the speed as follows:

- **Variable:** for a short-term speed restriction, e.g. in built-up areas
- **Permanent:** for a longer-term speed restriction, e.g. in winter tyre mode

You can store any speed above 20 km/h up to the maximum design speed or up to the set winter tyre limit. You can also perform settings while the vehicle is stationary if the vehicle has been started.

Observe the notes on driving systems and your responsibility; you may otherwise fail to recognise dangers (→ page 217).

**Mercedes-AMG vehicles:** the limiter is available up to a maximum speed of 250 km/h.

### Displays in the driver's display

-  (grey): variable limiter is selected but not yet activated.
-  (flashes grey): variable limiter is temporarily passive.
-  (green): variable limiter is activated.

A stored speed appears under the  display and is indicated in the speedometer.

If you depress the accelerator pedal beyond the pressure point (kickdown), the variable limiter switches to passive mode. The  **passive** message appears in the driver's display and the  display flashes.

The variable limiter is reactivated in the following situations:

- If the vehicle speed drops below the stored speed.
- If the stored speed is called up.
- If you store a new speed.

### Operating cruise control or the variable limiter



**WARNING** Risk of accident due to stored speed

If you call up the stored speed and this is lower than your current speed, the vehicle decelerates.



Take into account the traffic situation before calling up the stored speed.


### Requirements:

Cruise control

- Cruise control is selected.
- ESP® must be activated, but not intervening.
- The vehicle speed is at least 20 km/h.
- The transmission is in position .

## Variable limiter

- The variable limiter is selected.



Steering wheel control panel for cruise control and variable limiter

- RES/+** Adopts the stored/detected speed
- CANCEL** Deactivates cruise control/the variable limiter
- Selects cruise control

**LIM** Selects the variable limiter

- 1** Control panel to increase/decrease speed

## Operating cruise control and the variable limiter

- Press the corresponding button with only one finger or swipe on the control panel.

## Switching between cruise control and the variable limiter

- To select cruise control: press .
- To select the variable limiter: press **LIM**.

- i** Vehicles with Active Distance Assist DISTRONIC: the variable limiter is selected by a different button (→ page 233).

## Activating cruise control or the variable limiter

- Press **SET/+** or **SET/-** on control panel **1**. The current vehicle speed is stored and the vehicle maintains this speed (cruise control) or does not exceed it (variable limiter).

or

- Press **RES/+**.

The last stored speed is called up and the vehicle maintains this speed (cruise control) or does not exceed it (variable limiter).

If the last stored speed has previously been deleted, the current vehicle speed is stored.

- i** When you switch off the vehicle, the last speed stored is deleted. When you activate cruise control or Active Distance Assist DISTRONIC, the last speed stored for the variable limiter is deleted.

## Increasing/decreasing the stored speed

- To increase the stored speed: swipe upwards from the bottom of control panel **1**.
  - The stored speed is increased by 1 km/h.
- To decrease the stored speed: swipe downwards from the top of control panel **1**.
  - The stored speed is decreased by 1 km/h.

or



- ▶ Briefly press **SET/+** or **SET/-** on control panel **1**.  
The stored speed is increased or decreased to the next increment of ten (e.g. to 50 km/h or 60 km/h).

or

- ▶ Press and hold **SET/+** or **SET/-** on control panel **1**.  
The stored speed is increased or decreased to the next increment of ten and afterwards by increments of 10 km/h.

or

- ▶ Accelerate the vehicle to the desired speed.
- ▶ Press **SET/+** on control panel **1**.

- i** When the variable limiter is switched to passive mode, you cannot increase or decrease its stored speed in increments of 1 km/h.

### Adopting a detected speed

If cruise control/variable limiter is activated and Traffic Sign Assist has detected a speed restriction sign with a maximum permissible speed and this is displayed in the driver's display:

- ▶ Press **RES/Ⓢ**.  
The maximum permissible speed shown by the traffic sign is stored and the vehicle maintains or does not exceed this speed.

### Deactivating cruise control or the variable limiter

- ▶ Press **CANCEL**.
- i** If you brake, deactivate ESP® or if ESP® intervenes, cruise control is deactivated. The variable limiter is not deactivated.

### Information on the permanent limiter

If the vehicle should never exceed a specific speed (e.g. for driving in winter tyre mode), you can set this speed with the permanent limiter.

You do this by limiting the speed between 160 km/h and 240 km/h in the multimedia system (→ page 230).

Shortly before the set speed is reached, it appears in the driver's display. When you confirm the message, display messages no longer appear until you switch off the vehicle. The speed will only be displayed again once the vehicle has been restarted or if the set speed is changed.

The permanent limiter does not switch to passive mode even during kickdown and the driven speed remains below the set speed.

### Setting the limit speed for winter tyres

Multimedia system:

→  **» Settings » Vehicle » Driving**

- ▶ Activate or deactivate **Winter tyre limit**.

### Setting a speed

- ▶ Select  next to **Winter tyre limit**.
- ▶ Select a speed.

### Active Distance Assist DISTRONIC

#### Function of Active Distance Assist DISTRONIC

DISTRONIC Active Distance Assist maintains the set speed when driving freely. If vehicles are detected ahead, the set distance is maintained, if necessary until the vehicle comes to a standstill. The vehicle accelerates or brakes depending on the distance to the vehicle in front and the set speed. The speed and distance to the vehicle in front are set and saved using the steering wheel.

Available speed range:

- **Vehicles without Driving Assistance Package:**  
20 km/h - 160 km/h
- **Vehicles with Driving Assistance Package:**  
20 km/h - 210 km/h

**i** The adjustable set speed may differ if a limit speed (e.g. winter tyre limit) (→ page 230) is stored.

**i** If Active Distance Assist DISTRONIC is active and the range monitor recommends a lower driving speed, this is automatically adopted as the new set speed. If necessary, the setting speed can be increased again manually.

Other features of Active Distance Assist DISTRONIC:

- Adjusts the driving style depending on the selected drive program (energy-saving, comfortable or dynamic) (→ page 188)
- Initiates acceleration to the stored speed if the turn signal indicator is switched on to change to the overtaking lane
- **Vehicles with Driving Assistance Package:**


- Reacts to stationary vehicles detected in urban speed ranges (except bicycles and motorcycles)
- Takes one-sided overtaking restrictions into account on motorways or on multi-lane roads with separate carriageways (country-dependent)

**i** In the DYNAMIC SELECT menu, it is possible to set the driving mode of the Active Distance Assist DISTRONIC. Depending on which drive program is selected, the driving characteristics can be geared towards energy economy, comfort or dynamic performance. In the Active Distance Assist menu, the driving style can be permanently set to Comfort or Dynamic (→ page 238).

**Vehicles with Active Parking Assist and Driving Assistance Package:** if Active Distance Assist DISTRONIC has braked the vehicle to a standstill, it can automatically follow the vehicle in front when driving off again within 30 seconds. If a critical situation is detected in the surrounding area when driving off, such as a person in the vehicle path, a visual and acoustic warning is given indi-

cating that the driver must now take control of the vehicle. The vehicle is not accelerated any further. Observe the notes on driving systems and your responsibility; you may otherwise fail to recognise dangers (→ page 217).

**Display in the driver's display in the Assistance menu**



- 1** Vehicle in front
- 2** Distance indicator
- 3** Set specified distance

Vehicle detected in front **1** is highlighted in green. It may also be in the lane to the left of your

vehicle in situations where it is not permitted to overtake on the right, for example on motorways.

### Permanent status display

-  (grey): Active Distance Assist DISTRONIC selected but not yet active
-  (green speedometer, white vehicle): Active Distance Assist DISTRONIC active, speed set
-  (green): Active Distance Assist DISTRONIC active and vehicle detected

The stored speed is shown under the permanent status display and highlighted on the speedometer. When Active Distance Assist DISTRONIC is passive, the status display is greyed out.

If the speed of the vehicle in front or the speed adjustment is less than the stored speed due to the route event ahead, the segments in the speedometer light up.

When the set specified distance is increased or decreased, the  display briefly appears under the vehicle in the permanent status display.

-  On motorways or high-speed major roads, the green  vehicle symbol is displayed cyclically when the vehicle is ready to pull away.
-  If you depress the accelerator pedal beyond the setting of the Active Distance Assist DISTRONIC, the system is switched to passive mode. The following message appears briefly in the driver's display  **suspended**.

### System limits

The system may be impaired or may not function in the following situations, for example:

- In snow, rain, fog, heavy spray, if there is glare, in direct sunlight or in greatly varying light conditions.
- The windscreen in the area of the camera is dirty, misted up, damaged or covered.
- If the radar sensors are dirty or covered.
- In multi-storey car parks or on roads with steep uphill or downhill gradients.
- If there are narrow vehicles in front, such as bicycles or motorcycles.

In addition, on slippery roads, braking or accelerating can cause one or several wheels to lose traction and the vehicle could then skid.

Do not use Active Distance Assist DISTRONIC in these situations.

**⚠ WARNING** Risk of accident from acceleration or braking by Active Distance Assist DISTRONIC

Active Distance Assist DISTRONIC may accelerate or brake in the following cases, for example:

- If the vehicle pulls away using Active Distance Assist DISTRONIC.
- If the stored speed is called up and is considerably faster or slower than the currently driven speed.
- If Active Distance Assist DISTRONIC no longer detects a vehicle in front or does not react to relevant objects.

► Always carefully observe the traffic conditions and be ready to brake at all times.

- ▶ Take into account the traffic situation before calling up the stored speed.

**⚠ WARNING** Risk of accident due to insufficient deceleration by Active Distance Assist DISTRONIC

Active Distance Assist DISTRONIC brakes your vehicle with up to 50% of the possible deceleration. If this deceleration is not sufficient, Active Distance Assist DISTRONIC alerts you with a visual and acoustic warning.

- ▶ Adjust your speed and maintain a suitable distance from the vehicle in front.
- ▶ Brake the vehicle yourself and/or take evasive action.

**⚠ WARNING** Risk of accident if detection function of Active Distance Assist DISTRONIC is impaired

Active Distance Assist DISTRONIC does not react or has a limited reaction:

- when driving on a different lane or when changing lanes
- to pedestrians, animals, bicycles or stationary vehicles, or unexpected obstacles
- to complex traffic conditions
- to oncoming vehicles and crossing traffic

As a result, Active Distance Assist DISTRONIC may neither give warnings nor intervene in such situations.

- ▶ Always observe the traffic conditions carefully and react accordingly.

- ESP® is activated and is not intervening.
- The transmission is in position **D**.
- All the doors are closed.
- Check of the radar sensor system has been successfully completed.
- Snow chain mode is not active (→ page 397).

Variable limiter:


- The variable limiter is selected.

### Operating Active Distance Assist DISTRONIC and the variable limiter

#### Requirements:

Active Distance Assist DISTRONIC:

- The electric parking brake is released.



Adopts the stored/detected speed

Deactivates Active Distance Assist DISTRONIC/ the variable limiter

Increases/decreases the speed

Increases/decreases the specified distance

Switches between the variable limiter and Active Distance Assist DISTRONIC

▶ **To operate Active Distance Assist DISTRONIC or the variable limiter:** press the respective button with only one finger or swipe on the control panel.

**Switches between the variable limiter and Active Distance Assist DISTRONIC**

▶ Press .

**Activating the variable limiter or Active Distance Assist DISTRONIC**

▶ **To activate without a stored speed:**

press , or . **Active Distance Assist DISTRONIC:** remove your foot from the accelerator pedal.

The current vehicle speed is stored and maintained (Active Distance Assist DISTRONIC) or limited (variable limiter) by the vehicle.

or

▶ **To activate with a stored speed:** press .

**Active Distance Assist DISTRONIC:** remove your foot from the accelerator pedal. The last stored speed is called up and the vehicle maintains this speed (Active Distance

Assist DISTRONIC) or does not exceed it (variable limiter).

If the stored speed has been deleted, the current vehicle speed is stored.

When you switch off the vehicle, the stored speed is deleted. When you activate Active Distance Assist DISTRONIC, the last speed stored for the variable limiter is deleted.

**Increasing or reducing the speed**

▶ To increase the stored speed: swipe upwards from the bottom of control panel .

- The stored speed is increased by 1 km/h.

▶ To decrease the stored speed: swipe downwards from the top of control panel .

- The stored speed is decreased by 1 km/h.

or

▶ Briefly press on the upper section or on the lower section of control panel .

The stored speed is increased or reduced by 10 km/h.

or

- ▶ Press and hold **SET/+** on the upper section or **SET/-** on the lower section of control panel . The stored speed is increased or reduced in increments of 10 km/h.

or

- ▶ Accelerate the vehicle to the desired speed.
- ▶ Press **SET/+** on the upper section of control panel .

### Adopting the limit speed shown in the driver's display

- ▶ Activate Active Distance Assist DISTRONIC or the variable limiter: press **SET/+**, **SET/-** or **RES/Ⓢ**.
- ▶ Accept the displayed speed limit: press **RES/Ⓢ**. The limit speed displayed in the driver's display is adopted as the stored speed. The vehicle adapts its speed to that of the vehicle in front, but only up to the stored speed, or limits its speed accordingly.

-  A speed limit shown in the driver display is only adopted while driving, not when stationary.

### Pulling away with Active Distance Assist DISTRONIC

- ▶ Activate Active Distance Assist DISTRONIC and remove your foot from the brake pedal.
- ▶ Press **RES/Ⓢ**.

or

- ▶ Depress the accelerator pedal briefly and firmly. The functions of Active Distance Assist DISTRONIC continue to be carried out.

### Reducing or increasing the specified distance from the vehicle in front

- ▶ Press . The  display appears. The specified distance is reduced by one level. If the lowest level is already selected, the selection jumps to the highest level.

### Deactivating Active Distance Assist DISTRONIC or the variable limiter

 **WARNING** Risk of an accident due to Active Distance Assist DISTRONIC being active when you leave the driver's seat

If you leave the driver's seat while the vehicle is being braked by Active Distance Assist DISTRONIC only, the vehicle can roll away.

- ▶ Always deactivate Active Distance Assist DISTRONIC and secure the vehicle to prevent it from rolling away before you leave the driver's seat.

- ▶ Press **CANCEL**.

-  If you brake, deactivate ESP® or if ESP® intervenes, Active Distance Assist DISTRONIC is deactivated. The variable limiter is not deactivated.

### Function of Active Speed Limit Assist

If a change in the speed limit of 20 km/h or more is detected and automatic adoption of speed limits is activated, the new speed limit is automatically adopted as the stored speed (→ page 238).

The driven speed is adjusted when the vehicle is level with the traffic sign at the latest. In the case of signs indicating entry into an urban area, the speed is adapted according to the speed permitted within the urban area. The speed limit display in the driver's display is always updated when the vehicle is level with the traffic sign.

If you are driving on German motorways and there is no speed limit, the system uses the speed stored for a stretch of road with no speed limit as the set speed. If you do not alter the stored speed on a stretch of road with no speed limit, the recommended speed of 130 km/h is adopted.

If Active Distance Assist DISTRONIC has been put into passive mode by pressing the accelerator pedal, only speed limits which are higher than the set speed are adopted.

The maximum permissible speed does not take the road condition and current weather and traffic conditions into account. Adjust your speed accordingly, when necessary.

Observe the notes on driving systems and your responsibility; you may otherwise fail to recognise dangers (→ page 217).

### System limits

The system limits of Traffic Sign Assist apply to the detection of traffic signs (→ page 251).

Speed limits below 20 km/h are not automatically adopted by the system as the stored speed. Temporary speed restrictions (e.g. for a certain time or due to weather conditions) cannot be properly detected by the system. The maximum permissible speed applying to a vehicle with a trailer is not detected by the system.

Adjust the speed in these situations.

**⚠ WARNING** Risk of accident due to Active Speed Limit Assist adapting the vehicle's speed

The speed adopted by Active Speed Limit Assist may be too high or incorrect in some individual cases, such as:

- at speed limits below 20 km/h
- in wet conditions or in fog
- when towing a trailer

- ▶ Ensure that the driven speed complies with traffic regulations.
- ▶ Adjust the driving speed to suit current traffic and weather conditions.

### Function of route-based speed adaptation

When Active Distance Assist DISTRONIC is activated, the vehicle speed will be adapted accordingly to the route events ahead. Depending on the drive program selected, the vehicle negotiates a route event ahead in an energy-saving, comfortable or dynamic manner. When the route event has been passed, the vehicle accelerates again to the stored speed. The set distance to the vehicle in front, vehicles detected ahead and speed restrictions ahead are taken into account.

Route-based speed adaptation can be activated in the multimedia system (→ page 238).

The following route events are taken into account:

- Bends
- Roundabouts
- T-junctions
- Turns and exits

- Traffic jams ahead (only with Live Traffic )

Also, the speed is reduced if the turn signal indicator is switched on and one of the following situations is detected:

- Turning at junctions
- Driving on slowing-down lanes
- Driving on lanes adjacent to slowing-down lanes

The driver is responsible for choosing the right speed and observing other road users. This applies in particular to junctions, roundabouts and traffic lights, as route-based speed adaptation does not brake the vehicle to a standstill.

If a corresponding route event is detected while route guidance is active, the first speed adjustment is carried out automatically. If the turn signal indicator is switched on, the selected route is confirmed and further speed adjustment is activated.

Speed adaptation is cancelled in the following cases:

- If the turn signal indicator is switched off before the route event and it is therefore

assumed that the route event is not relevant to the driver.

- If the driver depresses the accelerator or brake pedal during the process.

### System limits

Route-based speed adaptation does not take right of way regulations into account. The driver is responsible for complying with road traffic regulations and driving at a suitable speed.

In difficult conditions, the speed selection made by the system may not always be suitable. This applies to the following situations, forexample:

- unclear roads
- Road narrowing
- varying maximum permissible speeds in individual lanes, forexample at toll stations
- wet road surfaces, snow or ice
- if transport equipment, forexample a trailer or bicycle rack, is attached to the trailer hitch and the electrical connection has been correctly established

In these situations the driver must intervene accordingly.

### **WARNING** Risk of accident in spite of route-based speed adaptation

Route-based speed adaptation can malfunction or be temporarily unavailable in the following situations:

- If the driver does not follow the calculated route
- If map data is not up-to-date or available
- In the event of roadworks
- In bad weather or road conditions
- If the accelerator pedal is depressed
- In the event of electronically displayed speed limitations

 Adapt the speed to the traffic situation.



## Setting Active Distance Assist DISTRONIC driving styles

### Requirements:

- Active Distance Assist DISTRONIC is activated.

Multimedia system:

→  » Settings » Assistance  
» Driving » Active Distance Assist

### Selecting a driving style

- ▶ Select **DYNAMIC SELECT based**, **Dynamic** or **Comfort**.

### Setting speed adaptation

- ▶ Select **For curves etc..**.  
When these functions are active, the vehicle speed is adjusted depending on the route events ahead.
- ❗ When one of the following systems is active, the detected speed can be manually adopted as the speed limit:
  - Active Distance Assist DISTRONIC
  - Variable limiter

Further information about Active Distance Assist DISTRONIC (→ page 233).

- ❗ Further information on speed adaptation (→ page 236).

### Function of Active Stop-and-Go Assist

Active Stop-and-Go Assist helps you when in traffic jams on multi-lane roads with separate carriageways by automatically pulling away within up to 60 seconds and with moderate steering manoeuvres. It orients itself using the vehicle in front and lane markings. Active Stop-and-Go Assist automatically maintains a safe distance from the vehicle in front and vehicles cutting in.

Active Stop-and-Go Assist requires you, as the driver, to keep your hands on the steering wheel at all times so that you are able to intervene at any time to correct the course of the vehicle and keep it in lane.

Observe the notes on driving systems and your responsibility; you may otherwise fail to recognise dangers (→ page 217).

Active Stop-and-Go Assist activates automatically when all of the following conditions are met:

- You are in a traffic jam on a motorway or high-speed major road.
- Active Distance Assist DISTRONIC is activated and active (→ page 233).
- Active Steering Assist is activated and active (→ page 240).
- You are travelling no faster than 60 km/h.

When Active Stop-and-Go Assist is active the  status display appears in the driver's display.

### System limits

The system limitations of Active Distance Assist DISTRONIC and Active Steering Assist apply to Active Stop-and-Go Assist (→ page 238).

## Active Steering Assist

### Function of Active Steering Assist

Active Steering Assist is only available up to a speed of 210 km/h. The system helps you to stay in the centre of the lane by means of moderate

steering interventions. Depending on the speed driven, Active Steering Assist uses the vehicles ahead and lane markings as a reference.

- ❗ Depending on the country, in the lower speed range Active Steering Assist can use the surrounding traffic as a reference. If necessary, Active Steering Assist can then also provide assistance when driving outside the centre of the lane.

If the detection of lane markings and vehicles ahead is impaired, Active Steering Assist switches to passive mode. The system provides no support in this case.

#### Permanent status display in the driver's display


-  **Grey:** activated and passive
-  **Green:** activated and active
-  **Red, flashing:** prompt to the driver to actively confirm or transition from active to passive status, system limit detected

- ❗ During the transition from active to passive status, the  symbol is shown as enlarged and flashing. Once the system is passive, the

 symbol is shown as grey in the driver's display.

#### Contact detection

The driver is required to keep their hands on the steering wheel at all times and be able to intervene at any time to correct the course of the vehicle and keep it in lane. The driver must expect a change from active to passive mode or vice versa at any time.



If the system detects that the driver has not steered the vehicle for a considerable period of time or has removed their hands from the steering wheel, an optical warning is given first. Display  appears in the driver's display. If the driver still

does not steer the vehicle, or gives no confirmation to the system, a warning tone sounds in addition to the visual warning message.

If the driver does not react to this warning for a considerable period, an emergency stop is initiated (→ page 241).

The warning is not issued or is stopped as soon as the system detects that the driver has touched the steering wheel.

Touch detection may be limited or inoperative in the following situations:

- The driver is wearing gloves.
- There is a steering wheel cover on the steering wheel.

If Active Steering Assist detects that a system limit has been reached, a visual warning is issued and a warning tone sounds.

Observe the notes on driving systems and your responsibility; you may otherwise fail to recognise dangers (→ page 217).

#### System limits

Active Steering Assist has a limited steering torque for lateral guidance. In some cases, the steer-

ing intervention is not sufficient to keep the vehicle in the lane.

The system may be impaired or may not function in the following instances:

- There is poor visibility, e.g. due to snow, rain, fog, heavy spray, greatly varying light conditions or strong shadows on the carriageway.
- There is glare, e.g. from oncoming traffic, direct sunlight or reflections.
- Insufficient road illumination.
- The windscreen is dirty, misted up, damaged or covered in the vicinity of the camera, e.g. by a sticker.
- No, or several, unclear lane markings are present for one lane, or the markings change quickly, for example, in a construction area or junctions.
- The lane markings are worn away, dark or covered up, e.g. by dirt or snow.
- If the distance to the vehicle in front is too short and thus the lane markings cannot be detected.
- The road is narrow and winding.

- There are obstacles on the lane or projecting out into the lane, such as object markers.
- If transport equipment, for example a trailer or bicycle rack, is attached to the trailer hitch and the electrical connection has been correctly established

The system does not provide assistance in the following conditions:

- On very tight bends and when turning.
- When crossing junctions.
- At roundabouts or toll stations.
- When actively changing lane without switching on the turn signal indicator.
- When the tyre pressure is too low.

**⚠ WARNING** Risk of accident if Active Steering Assist unexpectedly stops functioning

If the system limits of Active Steering Assist are reached there is no guarantee that the system will remain active or will keep the vehicle in lane.

- ▶ Always keep your hands on the steering wheel and observe the traffic carefully.
- ▶ Always steer the vehicle paying attention to traffic conditions.

**⚠ WARNING** Risk of accident if Active Steering Assist unexpectedly intervenes

The detection of lane markings and objects may malfunction and cause unexpected steering interventions.

- ▶ Steer according to traffic conditions.

### Activating/deactivating Active Steering Assist

#### Requirements:

- ESP® is activated, but is not intervening.
- Active Distance Assist DISTRONIC is activated.

Multimedia system:

➔  ➔ [Settings](#) ➔ [Assistance](#)  
➔ [Driving](#)

▶ Activate or deactivate [Active Steering Assist](#).

### Function of Active Emergency Stop Assist

Active Emergency Stop Assist monitors the steering wheel and the accelerator and brake pedals. If the system detects a lack of driver activity and the vehicle threatens to leave the lane, a warning can be issued and an emergency stop initiated.


**Vehicles without Driving Assistance Package:** The system is available from a speed of approx. 60 km/h.

**Vehicles with Driving Assistance package:** If Active Steering Assist is switched off, the system is available from a speed of approx. 60 km/h.

If the system detects that the vehicle is threatening to leave the lane, a warning can be issued and an emergency stop initiated.

- The driver does not touch the steering wheel for a longer period of time or no steering movement can be measured for a longer period of time (depending on the vehicle equipment).
- Neither the accelerator nor the brake pedal is depressed.

- ❗ **Vehicles with Driving Assistance package:** if Active Steering Assist is switched on and active, only the steering wheel is monitored by the system. If the driver does not touch the steering wheel for a longer period of time, a warning may be given despite pedal actuation. Also observe the instructions on the contact detection of Active Steering Assist (→ page 238).



Active Emergency Stop Assist issues the following warnings in order:

- Display message ❶ appears in the driver's display.

- In addition to display ❶ a warning tone sounds.
- The message **Beginning emergency stop** will appear in the driver's display, a continuous warning tone will sound, the vehicle will no longer accelerate and, if necessary, slight belt tensioning will be produced.
- The vehicle speed is reduced in increments until it is at a standstill. Sharp brake impulses are also produced.

- ❗ **Vehicles with Driving Assistance Package:** If Active Distance Assist DISTRONIC is active and the driver unfastens the seat belt and driver's door, an emergency stop can be initiated immediately.

### Vehicles with Driving Assistance Package:

Depending on the country, a lane change to the adjacent right-hand lane is carried out, if possible. It is only possible to change across one lane and only into the right-hand lane, and not onto the hard shoulder.

When automatic braking is initiated, Active Distance Assist DISTRONIC is deactivated. Depend-

ing on the country, the hazard warning light system is switched on.

When the vehicle is stationary, the following actions are carried out:

- The vehicle is secured with the electric parking brake.
- The vehicle is unlocked.
- If possible, an emergency call is placed to the Mercedes-Benz emergency call centre.

Before automatic braking is initiated, you can cancel Active Emergency Stop Assist by steering.

You can cancel the intervention by Active Emergency Stop Assist after automatic braking is initiated by one of the following actions:

- Accelerating or braking: the emergency stop is cancelled, but the warning message, warning tone and power steering remain active
- Steering: power-assisted steering is cancelled, the warning message and warning tone remain active and the vehicle continues to be braked

 Active Emergency Stop Assist can initiate an emergency stop a maximum of three times

within one driving cycle. Subsequently, Active Steering Assist and Active Emergency Stop Assist are deactivated for that driving cycle.

### System limits

For the detection of vehicles and other obstacles, observe the system limits of the following functions:

- Active Distance Assist DISTRONIC (→ page 230)
- Active Steering Assist (→ page 238)
- Active Lane Change Assist (→ page 242)
- Active Brake Assist (→ page 245)

### Vehicles without Driving Assistance Package:

Active Emergency Stop Assist is inactive in the following cases:

- Active Lane Keeping Assist has reached a system limit.
- Active Lane Keeping Assist is not operational (grey status display) or deactivated (white status display) (→ page 259).

## Active Lane Change Assist

### Function of Active Lane Change Assist

Active Lane Change Assist supports the driver when changing lanes and is activated by indicating briefly.

For this, the following conditions must be fulfilled:


- You are on a motorway or high-speed major road.
- The vehicle speed is between approximately 80 km/h and 180 km/h.
- The neighbouring lane is separated by a broken lane marking.
- No vehicle or obstacle is detected in the adjacent lane.
- Since the last time the vehicle was started, the sensors have detected a vehicle at a suitable distance behind your vehicle.
- Active Lane Change Assist is selected in the multimedia system.
- Active Distance Assist DISTRONIC and Active Steering Assist are activated on motorways.

The system is not available and must be reactivated in the following situations:

- Active Distance Assist DISTRONIC and Active Steering Assist were already activated before entering the motorway.
- The system briefly does not detect the road you are on as a motorway or a motorway-like road, e.g. on a motorway junction.

As soon as Active Lane Change Assist detects a suitable road, you can reactivate it with **RES** , **SET/+** or **SET/-**.

### Display in the driver's display in the Assistance menu



- ① Green arrow: lane change initiated
- ② Red arrow: lane change cancelled

When Active Lane Change Assist is available, the  display appears along with green arrows in the driver's display. If the system has been activated but is not currently available, the  display

appears along with grey arrows in the driver's display.

If no vehicle or obstacle is detected in the adjacent lane and a lane change is permitted, the lane change begins after the driver has indicated briefly. The lane change is shown to the driver with a flashing green arrow next to the  steering wheel symbol. Green arrow **Assistance** is displayed in the appropriate adjacent lane in the ① menu in the driver's display. The message, for **Lane change to the left** example, also appears.

Active Lane Change Assist can be cancelled in various situations, including the following:

- Change in the surrounding conditions (e.g. detected obstacle).
- The driver removes their hands from the steering wheel.
- The driver steers with too much force or in the opposite direction.
- The driver moves the turn signal indicator in the opposite direction.
- Active Distance Assist DISTRONIC or Active Steering Assist is deactivated.

- The vehicle cannot make the lane change as planned.

Cancellation of Active Lane Change Assist is displayed as follows:

- The arrow in the selected direction of travel turns red.
- A corresponding message will also appear in the driver's display.
- In certain circumstances a warning tone sounds.

**⚠ WARNING** Risk of accident when changing lane to an occupied adjacent lane

Lane Change Assist cannot always clearly detect if the adjacent lane is free.

The lane change might be initiated although the adjacent lane is not free.

- ▶ Before changing lanes, make sure that the neighbouring lane is free and there is no danger to other road users.
- ▶ Monitor the lane change.

**⚠ WARNING** Risk of accident if Lane Change Assist unexpectedly stops functioning

If the system limitations for Lane Change Assist have been reached, there is no guarantee that the system will remain active.

Lane Change Assist cannot then assist you by applying steering torque.

- ▶ Always monitor the lane change and keep your hands on the steering wheel. Observe the traffic conditions and steer and/or brake if necessary.

### System limits

The system limitations of Active Steering Assist apply to Active Lane Change Assist (→ page 238).

The system may also be impaired or may not function in the following situations:

- The sensors are damaged, covered or dirty (→ page 217).
- The exterior lighting shows a defect.

- The system does not detect a suitable road, for example, in tight bends or shortly after a slip road.
- The vehicle is on a construction site.

- ⓘ The Active Lane Change Assist sensors adjust automatically while a certain distance is being driven after the vehicle has been delivered. Active Lane Change Assist is unavailable or only partially available during this teach-in process, and no arrows are displayed next to the  Active Steering Assist symbol.

Observe the notes on driving systems and your responsibility; you may otherwise fail to recognise dangers (→ page 217).

### Selecting Active Lane Change Assist

Multimedia system:

→  » Settings » Assistance  
» Driving

- ▶ Select **Aktiver Spurwechsel-Assistent** (Active Lane Change Assist).

## Active Brake Assist


### Function of Active Brake Assist

Active Brake Assist consists of the following functions:

- Distance warning function
- Collision warning
- Autonomous braking function
- Situation-dependent braking assistance
- **Vehicles with Driving Assistance Package and Active Steering Assist:** Evasive Steering Assist

Active Brake Assist can help you to minimise the risk of a collision with vehicles, cyclists or pedestrians or to reduce the effects of such a collision.

If Active Brake Assist has detected a risk of collision, a warning tone sounds and the  distance warning lamp lights up.



In the **Assistance** menu, an insufficient distance ① to the vehicle in front is displayed in red. If you further reduce the distance, the vehicle in front is also highlighted in red. When the system detects a risk of collision, red radar waves ② appear in front of the vehicle.

- ① **Vehicles with PRE-SAFE®:** depending on the country, an additional haptic warning occurs in the form of slight, repeated tensioning of the seat belt.
- ② **Vehicles with active ambient lighting:** if **Warning assistance** is activated, the Active Brake Assist warning is also accompanied by ambient lighting (→ page 153).

If you do not react to the warning, autonomous braking can be initiated in critical situations.

In particularly critical situations, Active Brake Assist can also initiate autonomous braking directly. In this case, the warning lamp and warning tone occur simultaneously with the braking application.

If you apply the brake yourself in a critical situation or apply the brake during autonomous braking, situation-dependent braking assistance occurs. The brake pressure increases up to maximum full-stop braking if necessary.



If autonomous braking or situation-dependent braking assistance has occurred, pop up ①



appears in the driver's display and then automatically goes out after a short time.

If the autonomous braking function or the situation-dependent braking assistance is triggered, additional preventive measures for occupant protection (PRE-SAFE®) may also be initiated.

**⚠ WARNING** Risk of an accident caused by limited detection performance of Active Brake Assist

Active Brake Assist cannot always clearly identify objects and complex traffic situations.

In such cases, Active Brake Assist might:

- Give a warning or brake without reason
- Not give a warning or not brake

Active Brake Assist is only an aid. The driver is responsible for maintaining a sufficiently safe distance to the vehicle in front, vehicle speed and for braking in good time.

- Always pay careful attention to the traffic situation; do not rely on Active Brake Assist alone.

- Be prepared to brake or swerve if necessary.

If Active Brake Assist is deactivated or the functions are restricted, e.g. due to activation of another driving system, the  display message appears in the driver's display.

If the system is unavailable due to dirty or damaged sensors or due to a fault, or if the functions are restricted, the  warning lamp appears in the driver's display.

Also observe the system limits of Active Brake Assist.

The individual subfunctions are available in the following speed ranges:

### Distance warning function

You are warned by the distance warning function from approximately 30 km/h if, over several seconds, the distance maintained to the vehicle travelling in front is insufficient for the driven speed. In this case, the  warning lamp in the driver's display lights up. If the distance to the vehicle in front continues to decrease at higher speeds, the  warning lamp begins to flash.

### Collision warning

Collision warning can assist you in the following situations from approximately 7 km/h with an intermittent warning tone and the  warning lamp.

Vehicles without Driving Assistance Package:

- At speeds up to approximately 250 km/h when approaching vehicles ahead.
- At speeds up to approximately 80 km/h when approaching stationary vehicles, pedestrians walking in the direction of travel and cyclists ahead.
- At speeds up to approximately 70 km/h when approaching crossing pedestrians and cyclists.
- At speeds up to approximately 60 km/h when approaching stationary pedestrians and cyclists.

Vehicles with Driving Assistance Package:

- At speeds up to approximately 250 km/h when approaching vehicles ahead.

- At speeds up to approximately 120 km/h when approaching crossing vehicles, pedestrians and cyclists.
- At speeds up to approximately 100 km/h when approaching stationary vehicles.
- At speeds up to approximately 80 km/h when approaching cyclists ahead.
- At speeds up to approximately 70 km/h when approaching stationary pedestrians and cyclists.

### **Autonomous braking function**

If the vehicle is travelling at speeds above approximately 7 km/h, the autonomous braking function may intervene in the following situations:

Vehicles without Driving Assistance Package:

- At speeds up to approximately 250 km/h when approaching vehicles ahead.
- At speeds up to approximately 80 km/h when approaching cyclists ahead, pedestrians walking in the direction of travel and stationary vehicles.

- At speeds up to approximately 70 km/h when approaching crossing pedestrians and cyclists.

Vehicles with Driving Assistance Package:

- At speeds up to approximately 250 km/h when approaching vehicles ahead.
- At speeds up to approximately 120 km/h when approaching crossing vehicles, pedestrians and cyclists.
- At speeds up to approximately 100 km/h when approaching stationary vehicles.
- At speeds up to approximately 80 km/h when approaching cyclists ahead.
- At speeds up to approximately 70 km/h when approaching stationary pedestrians and cyclists.

### **Situation-dependent braking assistance**

If the vehicle is travelling at speeds above approximately 7 km/h, situation-dependent braking assistance may intervene in the following situations.

Vehicles without Driving Assistance Package:

- At speeds up to approximately 250 km/h when approaching vehicles ahead.
- At speeds up to approximately 80 km/h when approaching cyclists ahead, pedestrians walking in the direction of travel and stationary vehicles.
- At speeds up to approximately 70 km/h when approaching crossing pedestrians and cyclists.
- At speeds up to approximately 60 km/h when approaching stationary pedestrians and cyclists.

Vehicles with Driving Assistance Package:

- At speeds up to approximately 250 km/h when approaching vehicles ahead.
- At speeds up to approximately 120 km/h when approaching crossing vehicles, pedestrians and cyclists.
- At speeds up to approximately 100 km/h when approaching stationary vehicles.
- At speeds up to approximately 80 km/h when approaching cyclists ahead.

- At speeds up to approximately 70 km/h when approaching stationary pedestrians and cyclists.

### Cancelling a brake application of Active Brake Assist

You can cancel a brake application of Active Brake Assist at any time by:

- Fully depressing the accelerator pedal or with kickdown.
- Releasing the brake pedal.

Active Brake Assist may cancel the brake application when one of the following conditions is fulfilled:

- You manoeuvre to avoid the obstacle.
- There is no longer a risk of collision.
- An obstacle is no longer detected in front of your vehicle.

### Reaction to oncoming road users (only vehicles with Driving Assistance Package)

Active Brake Assist can also react to detected oncoming road users:

- Reaction up to speeds of approximately 100 km/h
- Warning for oncoming road users through acoustic warning and warning lamp
- Autonomous braking application in order to reduce the severity of an accident

### Evasive Steering Assist

**⚠ WARNING** Risk of accident despite Evasive Steering Assist

Evasive Steering Assist cannot always recognise objects or complex traffic situations clearly.

Moreover, the steering support provided by Evasive Steering Assist is not sufficient to avoid a collision.

- ▶ Always pay careful attention to the traffic situation; do not rely on Evasive Steering Assist alone.
- ▶ Be prepared to brake or swerve if necessary.
- ▶ End the support by actively steering in non-critical situations.
- ▶ Drive at an appropriate speed if there are pedestrians close to the path of your vehicle.

Evasive Steering Assist has the following characteristics:

- Detection of pedestrians, cyclists and vehicles.
- Assistance through power-assisted steering if it detects a swerving manoeuvre.
- Activation by an abrupt steering movement during a swerving manoeuvre.
- Assistance during swerving and straightening of the vehicle.

- Reaction from a speed of approximately 20 km/h up to a speed of approximately 110 km/h.

The steering support of Evasive Steering Assist can be cancelled at any time by counter steering.

### System limits

Full system performance is not yet available for a short time after switching on the vehicle or after driving off. As long as the functions are restricted, the  warning lamp can also be shown in the driver's display. Depending on the environmental conditions, it may take a few minutes before full system performance is available.

The system may be impaired or may not function, particularly in the following situations:

- In snow, rain, fog, heavy spray, if there is glare, in direct sunlight or in greatly varying light conditions.
- If the sensors are dirty, misted up, damaged or covered. (→ page 217)
- If the sensors are impaired due to interference from other radar sources, e.g. strong radar reflections in multi-storey car parks.

- If a loss of tyre pressure or a defective tyre has been detected and displayed.
- In complex traffic situations where objects cannot always be clearly identified.
- If pedestrians, cyclists or vehicles move quickly into the sensor detection range.
- If road users are hidden by other objects or are located close to other objects.
- If the typical outline of a pedestrian or cyclist cannot be distinguished from the background.
- If a pedestrian or cyclist is not detected as such, e.g. due to special clothing or other objects.
- If the driver's seat belt is not fastened.
- On bends with a tight radius.

### Setting Active Brake Assist

#### Requirements:

- The vehicle is switched on.

Multimedia system:

→  >> Settings >> Assistance  
>> Avoid contact

▶ Activate or deactivate the function.

 It is recommended that you always leave Active Brake Assist activated.

When Active Brake Assist is deactivated, the distance warning function, the autonomous braking function and Evasive Steering Assist are deactivated.

 If Active Brake Assist is deactivated, the  symbol appears in the status bar of the driver's display, and the system is reactivated the next time the vehicle is started.

### Setting the time of the brake application warnings

▶ Select  next to Active Brake Assist.

▶ Select Early, Medium or Late.

## Speed Limit Assist

### Function of Speed Limit Assist

- ① Speed Limit Assist uses OpenStreetMap data, which is made available under the conditions of the Open Database License (ODbL). For more information, see: <https://www.osmfoundation.org/wiki/licence>.

Speed Limit Assist detects speed limits with multi-function camera and displays them in the driver's display and optionally in the head-up display. The camera also detects speed limits with a restriction indicated by an additional sign (e.g. when wet).


Observe the notes on driving systems and your responsibility; you may otherwise fail to recognise dangers (→ page 217).

### Warning when the maximum permissible speed is exceeded

The system can warn you if you unintentionally exceed the maximum permissible speed. To do this, you can specify in the multimedia system by how much the maximum permissible speed can be exceeded before a warning is issued. You can

specify whether the warning is to be just a visual warning or an acoustic one as well (→ page 251).

### Display in the driver's display



- ① Permissible speed
  - ② Permissible speed when there is a restriction
  - ③ Additional sign with restriction
- ① Traffic signs which have an impact on the maximum permissible speed, e.g. signs indicating the beginning or end of dual carriageways, can also be detected.

The system can show up to two traffic signs in the driver's display simultaneously. The system always prioritises displaying speed limits. Up to one traf-

fic sign with a maximum permissible speed can be shown in the head-up display. If two speed signs are shown in the driver's display, for example when speed limits are detected, the value of left-hand speed limit ① is transmitted to the limiter, cruise control or Active Distance Assist DISTRONIC for adoption and is shown in the head-up display.

If Speed Limit Assist cannot determine the current maximum permissible speed (e.g. due to missing signs), the following display appears in the driver's display:



This is displayed continuously if the vehicle is in a country where Speed Limit Assist is not supported. Speed Limit Assist is not available in all countries.

### System limits

The system may be impaired or may not function particularly in the following situations:

- If visibility is poor, e.g. due to insufficient illumination of the road, highly variable shade

conditions, rain, snow, fog, swirling dust or heavy spray.

- If there is glare, e.g. from oncoming traffic, direct sunlight or reflections.
- If there is dirt on the windscreen in the vicinity of the multifunction camera or if the camera is misted up, damaged or obscured.
- If traffic signs are difficult to detect, e.g. due to dirt, snow, ice, insufficient lighting or driving too close to the vehicle in front, or because they are covered, faded, damaged, badly positioned or twisted.
- Digital LED traffic signs may not be detected correctly or at all due to technical factors, such as transmission frequency.
- If signs or the road layout is ambiguous, e.g. traffic signs in roadworks, at exits and ramps, in neighbouring lanes or parallel roads.
- If signs do not conform to the standard.
- If signs or road layouts are specific to the country, for example, at or beyond construction sites.

- After sharp turns and tight bends, when traffic signs are outside the camera's field of vision.
- If you overtake vehicles with traffic signs which are affixed or attached to them.
- If you are using transport equipment secured with a trailer coupling, such as a bicycle rack, the system may react to restrictions for car/trailer combinations.

### Setting Speed Limit Assist

Multimedia system:

  **» Settings » Assistance**  
**» Assistance » Speed Limit Assist**

### Setting an additional audible indication

 Activate or deactivate the function.

### Setting the warning threshold

This value determines the speed at which a warning is issued when exceeded.

-  Select **Warning threshold**.
-  Set the desired speed.

 When one of the following systems is active, the detected speed can be manually adopted as the speed limit:

- Active Distance Assist DISTRONIC
- Cruise control
- Variable limiter

Further information (→ page 233).

## Traffic Sign Assist

### Function of Traffic Sign Assist

 This function is an on-demand feature (→ page 24).

Traffic Sign Assist detects traffic signs with the multifunction camera and compares this with information in the digital navigation map. It assists you by displaying detected speed limits and overtaking restrictions in the driver's display and in the head-up display. The system can issue a warning when you exceed the maximum permissible speed.

In some countries, the system can provide you with further functions and can warn you when you

are approaching pedestrian crossings or when you are about to drive past stop signs or red lights unintentionally.

The camera also detects and analyses traffic signs with a restriction indicated by an additional sign (e.g. when wet).


Traffic Sign Assist portrays only selected signs in the driver's display. Actual traffic signs and speed limits have priority over traffic signs and speed limits shown in the driver's display.

Also observe the following information:

- select a speed adapted to the traffic, surroundings and weather conditions
- observe actual traffic signs
- observe applicable traffic rules and regulations


Observe the notes on driving systems and your responsibility; you may otherwise fail to recognise dangers (→ page 217).

### Displays in the driver's display



- ① Permissible speed
- ② Permissible speed when there is a restriction
- ③ Additional sign with restriction

The system can show up to two traffic signs in the driver's display simultaneously. The system always prioritises displaying speed limits. Up to one traffic sign with a maximum permissible speed can be shown in the head-up display. If two speed signs are shown in the driver's display, for example when speed limits are detected, the value of left-hand speed limit ① is transmitted to the limiter, cruise control or Active Distance Assist DISTRONIC for adoption and is shown in the head-up display.



Examples of traffic signs which can be displayed

Traffic Sign Assist can detect and display following traffic signs ①:

- speed limits
- end of the speed limit
- overtaking restrictions
- play streets
- depending on the country: signs showing the start or end of motorways and dual carriageways

Traffic Sign Assist can detect following additional signs ③ and, if necessary, analyse the relevance of the restrictions using other vehicle sensors:

- when wet
- slippery road surfaces
- in fog
- temporary restrictions
- exits
- restrictions for car/trailer combinations

Traffic Sign Assist also uses data from the digital street map in the navigation system. When you leave or enter a municipality or change roads, on a motorway exit or slip road for example, or after you turn at a junction, the display in the driver's display can thus be updated without a traffic sign having been detected.

Depending on vehicle equipment and country, the system can also display speed restrictions ahead in the driver's display and in the head-up display. The driver's display can also show the distance to an upcoming lower limit speed. For this purpose, information from the digital road map of the navigation system is used. The **Assistance** menu can

also display a dynamic visualisation of the speed limits ahead.

If Traffic Sign Assist cannot determine the currently applicable maximum permissible speed (e.g. due to missing signs), the following display appears in the driver's display:



Traffic Sign Assist is not available in all countries. If the vehicle is in a country where Traffic Sign Assist is not supported, this is displayed continuously.

④ Also observe the information on display messages in Traffic Sign Assist (→ page 424).

### **Warning when the maximum permissible speed is exceeded**

The system can warn you if you unintentionally exceed the maximum permissible speed. To do this, you can specify in the multimedia system by how much the maximum permissible speed can be exceeded before a warning is issued. You can set the warning to visual only (the traffic sign

flashes three times in the driver's display) or visual and acoustic, including a warning tone.

### **Additional functions of Traffic Sign Assist (country-specific)**

**Warning for no-entry signs:** Traffic Sign Assist can warn you if you drive the wrong way down a section of road, for example on motorway slip roads or one-way streets.

**Warning at pedestrian crossings:** if you approach pedestrian crossings, provided that pedestrians are in the danger zone or are moving towards it, Traffic Sign Assist can warn you up to a speed of approximately 70 km/h.

**Warning at stop signs:** Traffic Sign Assist can warn you up to a speed of approximately 70 km/h if you are about to drive past a stop sign unintentionally. For this to be possible, the signs must be clear, for example if the system detects more than one stop sign, or a stop sign can be confirmed using the digital navigation map. No warning can be issued if several different signs are detected.

**Warning at red lights:** Traffic Sign Assist can warn you up to a speed of approximately 70 km/h if



you are about to drive through a red light unintentionally.

The following conditions must be fulfilled:

- Several traffic lights have been detected.
- All traffic lights detected are red.
- At least one of the red traffic lights detected is on the front passenger side beside the vehicle's own lane.
- The traffic lights are in the following sequence (from top to bottom): red, yellow, green.

 If the function is available, you can activate or deactivate the warnings at pedestrian crossings, stop signs and red lights in the Traffic Sign Assist menu under [Further warnings](#) (→ page 254).

### System limits

The system may be impaired or may not function particularly in the following situations:

- If visibility is poor, e.g. due to insufficient illumination of the road, highly variable shade conditions, rain, snow, fog, swirling dust or heavy spray.
- If there is glare, e.g. from oncoming traffic, direct sunlight or reflections.
- If there is dirt on the windscreen in the vicinity of the multifunction camera or if the camera is misted up, damaged or obscured.
- If traffic signs are difficult to detect, e.g. because they are dirty, covered, faded, covered with ice, damaged, badly positioned, poorly lit or twisted.
- Active traffic signs with LED displays may not be detected correctly or at all due to technical factors, such as transmission frequency.
- If the information on the navigation system's digital map is incorrect, incomplete or out of date.
- If signs or the road layout is ambiguous, e.g. traffic signs in roadworks, at exits and ramps, in neighbouring lanes or parallel roads.
- If signs do not conform to the standard.
- If signs or road layouts are specific to the country and deviate from the route guidance in the navigation system, e.g. at or beyond construction sites.

- After sharp turns and tight bends, when traffic signs are outside the camera's field of vision.
- If you overtake vehicles with traffic signs which are affixed or attached to them.
- If you are using transport equipment secured to the vehicle with a trailer coupling, such as a bicycle rack, restrictions for car/trailer combinations may be considered valid if applicable.

### Setting Traffic Sign Assist

Multimedia system:

  [» Settings](#) [» Assistance](#)  
[» Assistance](#) [» Traffic Sign Assist](#)

### Activating or deactivating the speed warning

 Activate or deactivate [Speed limit warning](#).

### Activating or deactivating further functions of Traffic Sign Assist

 Switch [Further warnings](#) or [Additional warning tone](#) on or off.

### Setting the warning threshold

This value determines the speed at which a warning is issued when exceeded.

- ▶ Set the desired speed under [Warning threshold](#).

 This function is an on-demand feature (→ page 24).

## [Traffic light view](#)

### Information about the traffic light view

The traffic light view supports the driver when waiting in front of a red light by displaying the camera image on the central display. The camera image is displayed when the driver is the first vehicle in front of the red light and faded out when the vehicle drives off.

### Displaying traffic light view

#### Requirements:

- The [Traffic light view](#) option is switched on .
- A traffic light view is available.

Multimedia system:

   [Settings](#)  [Assistance](#)  
 [Assistance](#)  [Traffic light view](#)

 This function is not available in all countries.

If the vehicle is in first position at a traffic light, the camera image with traffic light view is shown on the central display.

When the vehicle pulls away, the camera image is faded out.

- ▶ Activate  or deactivate  [Traffic light view](#).

### Using other available functions

- ▶ Select .
- ▶ Select [On request](#) or [Automatic](#).  
 If [On request](#) is set and a traffic light view is available, the [Please tap here for traffic light view](#) message is displayed. The camera image is shown after confirmation of the message.  
 When [Automatic](#) is set, the camera image is automatically displayed when the traffic light view is available.

## [Blind Spot Assist and Active Blind Spot Assist](#)

### Function of Blind Spot Assist and Active Blind Spot Assist with exit warning

Blind Spot Assist and Active Blind Spot Assist use radar sensors to monitor the area up to 40 m behind and 3 m next to your vehicle.

The system can detect vehicles travelling from speeds of approximately 12 km/h and issue a warning if they move into the monitoring range.


Status display in the driver's display



**Grey:** the system is activated but inoperative.



**Green:** the system is activated and operational.



Display in the driver's display in the **Assistance** menu

If a vehicle is detected at speeds above approximately 12 km/h and this vehicle enters the warning range immediately afterwards, the warning lamp in the corresponding outside mirror lights up red. In the **Assistance** menu, the lamp in outside mirror ① also lights up red, and the lane in which the vehicle is detected is hatched out.

If a vehicle is detected in the warning range and you switch on the turn signal indicator in the corresponding direction, a double warning tone sounds once, and the warning lamp flashes red in the corresponding outside mirror. Red radar

waves ② are displayed next to your vehicle in the assistance graphic.

If the turn signal indicator remains on, the display in the outside mirror flashes for all other detected vehicles, but no further warning tone sounds. If you overtake a vehicle quickly, no warning is given.

Observe the notes on driving systems and your responsibility; you may otherwise fail to recognise dangers (→ page 217).

**⚠ WARNING** Risk of accident despite Blind Spot Assist

Blind Spot Assist does not react to vehicles approaching and overtaking you at a greatly different speed.

Blind Spot Assist cannot warn drivers in this situation.

- ▶ Always pay careful attention to the traffic situation and maintain a safe distance at the side of the vehicle.

### Exit warning

The exit warning is an additional function of Blind Spot Assist and Active Blind Spot Assist and can warn vehicle occupants attempting to leave a stationary vehicle about approaching vehicles.

**⚠ WARNING** Risk of accident despite exit warning

The exit warning neither reacts to stationary objects nor to persons or road users approaching you at a greatly differing speed. The exit warning cannot warn drivers in these situations.

- ▶ Always pay particular attention to the traffic situation when opening the doors and make sure there is sufficient clearance.

If a vehicle is detected in the monitoring range, the red warning lamp lights up in the corresponding outside mirror.

If a vehicle occupant pulls the door handle on the side of the warning, a warning tone sounds twice and the ambient lighting in the respective door

and the warning lamps in the corresponding outside mirror flash red.

- ① **Vehicles with ambient lighting:** the **Warning assistance** of the ambient lighting can be activated and deactivated (→ page 153).
- ① The warning assistance can differ depending on the equipment and may vary according to the setting.

The exit warning is only available when Blind Spot Assist is activated and up to a maximum of three minutes after the vehicle has been switched off. The exit warning is no longer available once the warning lamp in the outside mirror flashes three times.

The exit warning is only an aid and not a substitute for the attention of vehicle occupants. The responsibility for opening and closing the doors and for leaving the vehicle remains with the vehicle occupants.

### System limits

Blind Spot Assist and Active Blind Spot Assist may be limited in the following situations, in particular:

- if there is dirt on the sensors or the sensors are obscured
- in poor visibility, e.g. due to fog, heavy rain or snow
- if there are narrow vehicles, e.g. bicycles or motorbikes
- if the road has very wide or narrow lanes
- if vehicles are not driving in the middle of their lane

Warnings may be issued in error when driving close to crash barriers or similar continuous lane borders. Always make sure that there is sufficient distance to the side for other traffic or obstacles.

Warnings may be interrupted when driving alongside long vehicles, for example lorries, for a prolonged time.

Blind Spot Assist and Active Blind Spot Assist are not operational when reverse gear is engaged.

Blind Spot Assist and Active Blind Spot Assist are not operational if transport equipment, for example a trailer or bicycle rack, is attached to the trailer hitch and the electrical connection has been correctly established.

Additionally, the exit warning may be limited in the following situations:

- when the sensors are covered by adjacent vehicles in narrow parking spaces
- when people approach the vehicle
- in the event of stationary or slowly moving objects

### Function of the brake application of Active Blind Spot Assist

- ① The brake application function is only available for vehicles with a Driving Assistance Package.

If Active Blind Spot Assist detects a risk of a side impact in the monitoring range, a course-correcting brake application is carried out. This is designed to help you avoid a collision.

The course-correcting brake application is available in the speed range between approximately 30 km/h and 200 km/h.

**⚠ WARNING** Risk of accident despite brake application of Active Blind Spot Assist

A course-correcting brake application cannot always prevent a collision.

- ▶ Always steer, brake or accelerate yourself, especially if Active Blind Spot Assist warns you or makes a course-correcting brake application.
- ▶ Always maintain a safe distance at the sides.

**⚠ WARNING** Risk of accident despite Active Blind Spot Assist

Active Blind Spot Assist does not react in the following situations:

- If you overtake vehicles at a high speed.
- If vehicles approach and overtake you at a greatly different speed.

Active Blind Spot Assist may not give warnings or intervene in such situations.

- ▶ Always pay careful attention to the traffic situation and maintain a safe distance at the side of the vehicle.



If a course-correcting brake application occurs, the red warning lamp flashes in the outside mirror and a warning tone sounds. In addition, a display **1** indicating the danger of a side collision appears in the driver's display.

In rare cases, the system may make an inappropriate brake application. This brake application

may be interrupted at any time if you steer slightly in the opposite direction or accelerate.

### System limits

Either a course-correcting brake application appropriate to the driving situation, or none at all, may occur especially in the following situations:

- Vehicles or obstacles, e.g. crash barriers, are located on both sides of your vehicle.
- A vehicle approaches too closely on the side.
- You have adopted a sporty driving style with high cornering speeds.
- You brake or accelerate significantly.
- A driving safety system intervenes, e.g. ESP® or Active Brake Assist.
- ESP® is deactivated.
- A loss of tyre pressure or a defective tyre is detected.
- Transport equipment, for example a trailer or bicycle rack, is attached to the trailer hitch and the electrical connection has been correctly established.

## Activating/deactivating Blind Spot Assist or Active Blind Spot Assist

Multimedia system:

→  » Settings » Assistance

» Avoid contact

▶ Activate or deactivate **Active Blind Spot Assist**.

## Active Lane Keeping Assist

### Function of Active Lane Keeping Assist

Active Lane Keeping Assist monitors the area in front of your vehicle by means of the multifunction camera (→ page 217) and can warn you before you leave your lane unintentionally. The system can guide you back into your lane through a course-correcting steering intervention and additionally warns you with vibration pulses in the steering wheel. Active Lane Keeping Assist is available in the speed range between 60 km/h and 200 km/h.

The system can intervene in the following situations:

- Active Lane Keeping Assist detects a lane marking.
- One of your front wheels goes over a lane marking.

If you activate the turn signal indicator, a steering intervention does not occur on the corresponding side.

If you leave the lane without activating the turn signal indicator, but danger of a collision with a moving obstacle is detected in your lane, a steering intervention does not occur.

**Vehicles with Blind Spot Assist or Driving Assistance Package:** if the system detects an obstacle, such as another vehicle in the adjacent lane, a steering intervention will occur regardless of the turn signal indicator.



Display ❶ will appear in the driver's display and a warning tone will sound in the following situations:

- A steering intervention by Active Lane Keeping Assist lasts longer than approximately ten seconds.
- The system carries out two or more steering interventions within approximately three minutes without any steering intervention from the driver.

In the Active Lane Keeping Assist settings, you can set the sensitivity of the system and set the level of support. Additionally, you can set whether the system should react to discontinuous lane

markings or only continuous lane markings (→ page 261).

### Status displays for Active Lane Keeping Assist



**White:** Active Lane Keeping Assist is deactivated.



**Yellow:** there is a malfunction. Please also observe the display messages.



**Grey:** Active Lane Keeping Assist is activated, but not operating.



**Green:** Active Lane Keeping Assist is activated and operating. If the system is operational on only one side, the lane marking is shown in green on the corresponding side.



**Red:** Active Lane Keeping Assist has guided you back into your lane with a course-correcting steering intervention. The status display will flash if there is also a haptic warning in the steering wheel. The lane marking is shown in red only on the side for which there is a warning.

**Vehicles without Driving Assistance Package:** if both lane markings are simultaneously shown in red in the status display,

Active Lane Keeping Assist has initiated an emergency stop (→ page 241).

### Active Lane Change Assist display in the "Assistance" menu



If the front wheel of the vehicle drives over a detected lane marking, this will be highlighted red in the **Assistance** menu in the driver's display.

**ⓘ Vehicles with active ambient lighting:** if **Warning assistance** is activated, the Active Lane Keeping Assist warning is also accompanied by ambient lighting (→ page 153).

### System limits

In the following situations, no lane-correcting steering intervention occurs but rather a warning in the steering wheel, depending on the situation:

- You clearly and actively steer, brake or accelerate.
- If a driving safety system intervenes, such as ESP®, Active Brake Assist or Active Blind Spot Assist.
- You have adopted a sporty driving style with high cornering speeds or high rates of acceleration.
- When ESP® is deactivated.
- If transport equipment, for example a trailer or bicycle rack, is attached to the trailer hitch and the electrical connection has been correctly established.
- If a loss of tyre pressure or a defective tyre has been detected and displayed.

The system may be impaired or may not function particularly in the following situations:

- If there is poor visibility, e.g. due to insufficient illumination of the road, highly variable shade conditions, rain, snow, fog or heavy spray.
- If there is glare, e.g. from oncoming traffic, the sun or reflections.
- If there is dirt on the windscreen in the vicinity of the multifunction camera or if the camera is misted up, damaged or obscured.
- If there is dirt on the bumper in the area of the radar sensors, or if they are damaged or covered.
- If there are no lane markings, or several unclear lane markings are present for one lane, e.g. around roadworks.
- If the lane markings are worn, dark or covered.
- If the distance to the vehicle in front is too short and thus the lane markings cannot be detected.
- If the lane markings change quickly, e.g. lanes branch off, cross one another or merge.

- If the carriageway is very narrow and winding.

Observe the notes on driving systems and your responsibility; you may otherwise fail to recognise dangers (→ page 217).

### Activating/deactivating Active Lane Keeping Assist

Multimedia system:

→  >> Settings >> Assistance

>> Avoid collision

>> Active Lane Keeping Assist

▶ Activate or deactivate the function.

Alternatively, Active Lane Keeping Assist can be activated and deactivated via quick-access.

- ⓘ After starting the vehicle, the settings are country-specific.

### Setting Active Lane Keeping Assist

Multimedia system:

→  >> Settings >> Assistance

>> Avoid collision

>> Active Lane Keeping Assist

### Setting the sensitivity

▶ Select .

▶ Select Early, Med. or Late.

The last selected setting will be adopted the next time the vehicle is started.

- ⓘ The standard setting for this function is dependent on the country.

### Activating or deactivating assistance on discontinuous lane markings

▶ Select Advanced support.

The last selected setting will be adopted the next time the vehicle is started.

- ⓘ The standard setting for this function is dependent on the country.



- i** This function must be activated in vehicles without Driving Assistance Package, so that Emergency Stop Assist is fully available. Further information on Emergency Stop Assist (→ page 241)

## AIRMATIC

### Function of AIRMATIC

AIRMATIC is an air suspension system with variable damping for improved driving comfort. The all-round level control system ensures the best possible suspension and constant ground clearance, even with a laden vehicle. When driving at speed, the vehicle is lowered automatically to improve driving safety and to reduce energy consumption. You also have the option of manually adjusting the vehicle level.

AIRMATIC includes the following components and functions:

- air suspension with automatic all-round level control
- ADS PLUS (Adaptive Damping System with constant damping force adjustment)

- speed-dependent lowering of the vehicle level
- increased vehicle level for greater ground clearance, selected via the multimedia system
- a comfortable suspension setting in drive programs **C** and **E**
- a firmer, sporty suspension setting in drive program **S**
- lowering the vehicle at speeds above 120 km/h in order to reduce energy consumption

When driving at speeds below 80 km/h, the vehicle is raised again to the normal level.

- i** **Operation with a trailer or bicycle rack:** if transport equipment, such as a trailer or a bicycle rack, is attached to the trailer hitch and the electrical connection has been correctly established, the vehicle remains at normal level irrespective of speed or the drive program selected.

### Setting the vehicle level

**⚠ WARNING** Risk of accident because vehicle level is too high

Driving characteristics may be impaired.

The vehicle can drift outwards, for example, when steering or cornering.

- Choose a vehicle level which is suited to the driving style and the road surface conditions.

**⚠ WARNING** Risk of entrapment from vehicle lowering

When lowering the vehicle, other people could become trapped if their limbs are between the vehicle body and the tyres or underneath the vehicle.

- Make sure no one is underneath the vehicle or in the immediate vicinity of the wheel arches when the vehicle is being lowered.

**⚠ WARNING** Risk of becoming trapped due to the vehicle lowering

**Vehicles with AIRMATIC or level control:** when you unload luggage or leave the vehicle, the vehicle first rises slightly and then returns to the set level shortly afterwards.

You or anyone else in the vicinity of the wheel arches or the underbody could thus become trapped.

The vehicle can also be lowered after being locked.

- ▶ When leaving the vehicle, make sure that nobody is in the vicinity of the wheel arches or the underbody.

**! NOTE** Damage due to vehicle lowering

Parts of the body could be damaged when the vehicle is lowered.

- ▶ Make sure that there are no obstacles such as kerbs underneath or in the immediate vicinity of the body when the vehicle is being lowered.

### Requirements:

- The vehicle has been started.
- The vehicle is not moving faster than 40 km/h.
- When the trailer socket is contacted (trailer/ bicycle rack): the vehicle is not moving faster than 30 km/h.

Multimedia system:



### Raising the vehicle

- ▶ Select . The indicator lamp lights up continuously. The vehicle is raised to high level +1.

Your selection is saved. High level +1 set remains stored even after the vehicle has been switched off.

The vehicle is lowered again in the following situations:

- When driving faster than 50 km/h.

- When the trailer socket is contacted (trailer/ bicycle rack): the vehicle is moving faster than 30 km/h.

### GPS-based raising

If the function is activated, it is possible to save the vehicle position when the vehicle level is raised.

- ▶ Confirm the prompt. The position of the vehicle is stored. When the previously stored position is reached again, a prompt appears in the Zero Layer as to whether the vehicle level should be raised again.

- ① Settings for GPS-based raising (→ page 264)
- ① Zero Layer function (→ page 305)

### Lowering the vehicle

- ▶ Select . The indicator lamp goes out. The vehicle is adjusted to the normal level.
- ① Use the normal level in trailer operation. High level driving is not permitted in trailer operation on public roads.

## Setting GPS-based raising of the vehicle

Multimedia system:

→  » Settings » Vehicle » Driving  
» GPS-based raising

▶ Select **Positions saved on request**, **Always save positions** or **Delete all saved positions**.


## Reversing camera

### Function of the reversing camera

The reversing camera monitors the area behind your vehicle. If you have activated the function (→ page 271), the image from the reversing camera is automatically displayed in the central display when reverse gear is engaged.

The reversing camera is only an aid. It is not a substitute for your attention to the surroundings. The responsibility for safe manoeuvring and parking remains with you. Make sure that there are no persons, animals or objects etc., in the manoeuvring area while manoeuvring and parking.


**i** The area behind the vehicle is displayed as a mirror image, as in the inside rear view mirror.




Camera views menu (top view)

- ① **Parking Assistance** menu
- ② Reversing camera with top view
- ③ Wide-angle view
- ④ Trailer view
- ⑤ Activates/deactivates Parking Assist PARKTRONIC (→ page 275)

- ⑥ Warning display of Parking Assist PARKTRONIC (→ page 271)
- ⑦ Guide lines at a distance of approximately 0.5 m, 1.0 m, 1.5 m and 3.0 m from the rear area
- ⑧ Path marking the course the tyres will take with the current steering wheel angle (dynamic)
- ⑨ Driven surface depending on the current steering wheel angle (dynamic)
- ⑩ Guide line at a distance of approximately 0.3 m from the rear area
- i** When Active Parking Assist is active, lanes ⑧ are displayed in green (→ page 275).



Wide-angle view



Trailer view

- ① Yellow guide line, locating aid
- ② Red guide line at a distance of approximately 0.3 m from the ball head of the trailer hitch
- ③ Ball head of the trailer hitch

### System limits

If the system is not ready for operation, the **System inoperative** message appears in the central display.

The reversing camera will not function or will only partially function in the following situations:

- You are driving forwards at a speed greater than approximately 16 km/h.
- The tailgate is open.
- The weather conditions are poor, e.g. heavy rain, snow, fog, storm or spray.
- The light conditions are poor, e.g. at night or if light is shining into the camera.
- The camera lens is obstructed, dirty or misted up. Observe the notes on cleaning the reversing camera (→ page 373).
- The camera or rear of your vehicle is damaged. In this case, have the camera and its position and setting checked at a qualified specialist workshop.
- The detection range is limited by additional vehicle attachments at the rear, such as a licence plate bracket or bicycle rack.

Also observe the information on vehicle sensors and cameras (→ page 217).

- ❗ Do not use the reversing camera in these types of situations. You could otherwise injure others or collide with objects when parking the vehicle.
- ❗ The contrast of the display may be impaired by direct sunlight or by other light sources, e.g. when driving out of a garage. In this case, pay particular attention.
- ❗ Have the display repaired or replaced if, for example, pixel errors considerably restrict its use.

## 360° Camera

### Function of the 360° Camera

The 360° Camera is a system that consists of four cameras which cover the immediate surroundings of the vehicle. The cameras assist you when you are parking, for example, or at exits with reduced visibility.

If you have activated the function, the image from the reversing camera is automatically displayed in


the central display when reverse gear is selected (→ page 271).

The 360° Camera includes the following cameras and evaluates their images:

- Reversing camera
- Front camera
- Two side cameras in the outside mirrors

The cameras are only an aid and may show a distorted view of obstacles, show them incorrectly or not show them at all. They are not a substitute for your attention to the surroundings. The responsibility for safe manoeuvring and parking remains with you. Make sure that there are no persons, animals or objects etc., in the manoeuvring area while manoeuvring and parking.


## Menu overview **Camera views**



- ① Menu **Parking Assistance**
- ② Top view with image from the front camera
- ③ Top view with image from the reversing camera
- ④ 3D view, left-hand side of the vehicle
- ⑤ 3D view, right-hand side of the vehicle
- ⑥ 3D auto view

- ⑦ To activate/deactivate Parking Assist PARKTRONIC (→ page 275)
- ⑧ To set the GPS activation point (→ page 271)
- ⑨ To switch between standard and wide-angle view
- ⑩ To switch between standard and trailer view
- ① In all views, the Parking Assist PARKTRONIC warning display is shown (→ page 271).

### Function of the guide lines




- ① Guide lines at a distance of approximately 0.5 m, 1.0 m, 1.5 m and 3.0 m from the rear area
- ② Path marking the course the tyres will take with the current steering wheel angle (dynamic)
- ③ Driven surface depending on the current steering wheel angle (dynamic)
- ④ Guide line at a distance of approximately 0.3 m from the rear area

- ① When Active Parking Assist is active, lanes and guide lines are displayed in green instead of yellow (→ page 275).

### Top view with image from the front or reversing camera

If you have activated the function, the image from the reversing camera is automatically displayed in the central display when reverse gear is selected (→ page 271).



- ① Warning display of Parking Assist PARKTRONIC (→ page 271)
- ② Your vehicle from above
- ③ Lane indicating the route the vehicle will take at the current steering angle

## 3D view, left/right-hand side of the vehicle

**!** **NOTE** Risk of accident due to objects being severely distorted in the display or not displayed at all

Due to the projection of the cameras, objects in the 3D views may be severely distorted when displayed or not displayed at all.

▶ Make sure that there are no persons, animals or objects etc. in the manoeuvring area while manoeuvring and parking.




- ① Display of Parking Assist PARKTRONIC (→ page 271)

In the 3D view, left-/right-hand side of the vehicle, the virtual camera moves to the respective side of the vehicle. When you change the transmission position, the view is automatically adapted.

## 3D auto view

- ① The area behind the vehicle is **not** displayed as a mirror image as is usual in the 3D views.



- ① Display of Parking Assist PARKTRONIC (→ page 271)  
② Guide lines

In the 3D auto view, the virtual camera moves to the standard perspective, facing forward from the rear above the roof. The view changes automatically when approaching obstacles.

If you touch the touchscreen, the view changes to 3D view with free rotation. You can turn, tilt and zoom the views by touch.

## Wide-angle view




- ① Display of Parking Assist PARKTRONIC (→ page 271)
- ② To switch between standard and wide-angle view

## Trailer view

- ① In trailer mode, the guide lines are shown at the level of the trailer hitch.


If you select trailer view and no trailer is coupled to the vehicle, the following display appears:



Trailer view: locating aid

- ① To switch between standard and trailer view
- ② Yellow locating aid
- ③ Ball head of the trailer hitch
- ④ Red guide line at a distance of approximately 0.3 m from the ball head of the trailer hitch

When the electrical connection is established between the vehicle and the trailer, the display changes to the side camera view.



Trailer view: side view of the mirror cameras

- ① To switch between standard and trailer view

## System limits

If the system is not ready for operation, the **System inoperative** message appears in the central display.

The 360° Camera will not function or will only partially function in the following situations:

- You are driving forwards at a speed greater than approximately 16 km/h.
- The doors are open.
- An outside mirror is not completely folded out.
- The boot lid is open.



- The weather conditions are poor, e.g. heavy rain, snow, fog, storm or spray.
  - The light conditions are poor, e.g. at night or if light is shining into the camera.
  - The camera lens is obstructed, dirty or misted up.
  - If cameras or vehicle components in which the cameras are fitted are damaged. In this event, have the cameras, their positions and their setting checked at a qualified specialist workshop.
- i** Do not use the 360° Camera under such circumstances. You could otherwise injure others or collide with objects when parking the vehicle.


For technical reasons, the standard height of the vehicle may be altered if the vehicle is carrying a heavy load and can result in inaccuracies in the guide lines and in the display of the generated images.

The field of vision and other functions of the camera system may be restricted due to additional attachments on the vehicle (e.g. licence plate bracket, bicycle rack).

- i** The contrast of the display may be impaired by abrupt, direct sunlight or by other light sources, e.g. when driving out of a garage. In this case, pay particular attention.
- i** Have the display repaired or replaced if, foreexample, pixel errors considerably restrict its use.

See the notes on cleaning the 360° Camera (→ page 373).

### Calling up the 360° Camera views using the button



- i** Depending on the vehicle's equipment, button **1** may also be located at a different position in the centre console.

- ▶ Press button **1**.
- ▶ Select the **Camera views** menu.

- ▶ In the multimedia system, select the desired view (→ page 266).

### Selecting a view for the 360° Camera (reverse gear)

#### Requirements:

- The [Activation in R](#) setting is activated in the multimedia system (→ page 271).

- ▶ Engage reverse gear.
- ▶ Select the desired view in the multimedia system (→ page 266).

### Setting the reversing camera or 360° Camera

The reversing camera is only an aid. It is not a substitute for your attention to the surroundings. The responsibility for safe manoeuvring and parking remains with you. Make sure that no persons, animals or objects etc. are in the manoeuvring range. Pay attention to your surroundings and be ready to brake at all times.

Multimedia system:

- ▶  ▶ Settings ▶ Assistance
- ▶ ▶ Camera

- ▶ Activate or deactivate [Activation in R](#).

- ❗ The settings for deactivating the reversing camera are not available in every country.

### 360° Camera with GPS - managing activation positions

Multimedia system:

- ▶  ▶ Settings ▶ Assistance
- ▶ ▶ Camera

### Renaming an activation position

- ❗ You can determine activation positions in the [Camera views](#) menu. (→ page 266)

- ▶ Select an activation position.
- ▶ Select .
- ▶ Enter a name and confirm.  
The activation position is saved under the new name.

### Deleting an activation position

- ▶ Select [Manage activation positions](#).
- ▶ Select an activation position.
- ▶ Select .
- ▶ Confirm the prompt.  
The activation position is deleted.

### Opening the camera cover

Multimedia system:

- ▶  ▶ Settings ▶ Assistance
- ▶ ▶ Camera

- ▶ Select [Open camera cover](#).

- ❗ The camera cover closes automatically after some time or after the vehicle is switched on or off.

## Parking Assist PARKTRONIC

### Function of Parking Assist PARKTRONIC

Parking Assist PARKTRONIC is an electronic parking assistance system which monitors the area surrounding your vehicle and shows you the distance between the vehicle and a detected obstacle visually and audibly.


The passive side impact protection also warns you of obstacles to the side. These must be detected beforehand by the sensors in the front or rear bumper while driving by them. If you steer in the direction of a detected obstacle and there is a risk of a lateral collision, a warning is issued. The pas-

sive side impact protection can be activated and deactivated via the multimedia system.


In order for front or rear obstacles to the side to be displayed, the vehicle must first travel a distance of at least half a vehicle length. Once the vehicle has travelled one vehicle length, obstacles on all sides can be shown.

Parking Assist PARKTRONIC is only an aid. It is not a substitute for your attention to the surroundings. The responsibility for safe manoeuvring and parking remains with you. Make sure that there are no persons, animals or objects in the manoeuvring area while manoeuvring and parking in/exiting parking spaces.

### Displays in the central display



Vehicles with 360° Camera



Vehicles with reversing camera

As soon as Parking Assist PARKTRONIC is operational, the respective areas of the display are shown in blue.

- ① Operational, front and rear
- ② Operational, all around
- ③ Operational, all around and obstacle detected

The colour of the display changes depending on the distance to the detected obstacle:

- **Blue:** > 1 m (no obstacles detected)
- **Yellow:** approx. 1 m - 0.7 m
- **Orange:** approx. 0.7 m - 0.4 m
- **Red:** < 0.4 m

**Vehicles with 360° Camera:** the boundary line shifts dynamically depending on the position and distance of the obstacles detected.

Depending on the distance to the obstacle detected, an intermittent warning tone also sounds. You can set the timing of the warnings in the multimedia system. In the **Warn early** setting, the system warns you from a distance of 1 m, in the standard setting only from 0.4 m.



Vehicles with 360° Camera




Vehicles with reversing camera

If you are not in the **Camera & parking** menu and an obstacle in the vehicle path is detected, pop-up window ① appears in the central display if the following requirements are met:

- **Vehicles without Active Parking Assist:** when driving no faster than 12 km/h.

- **Vehicles with Active Parking Assist:** when driving no faster than 18 km/h.



Optionally, obstacles detected by Parking Assist PARKTRONIC from a distance of approximately 1.0 m in front ② and 0.7 m on sides ③ can also be displayed in the head-up display.

#### Vehicles with active ambient lighting and Parking Package with remote parking functions

When **Warning assistance** is activated, the Parking Assist PARKTRONIC display is also accompanied by ambient lighting. If an obstacle is detected, the ambient lighting lights up in the same colour as the display in the central display.

The ambient lighting which accompanies the Parking Assist PARKTRONIC display is only intended to accentuate the display in the central display and does not replace it.

More information on ambient lighting:  
(→ page 153)

- ❗ A display message for the ambient lighting does not occur in the area of the driver's display or in the rear compartment.
- ❗ Depending on the selected setting, other functions may supersede the ambient lighting effects of Parking Assist PARKTRONIC. In this case, the ambient lighting effects of Parking Assist PARKTRONIC do not occur.

### System limits

Parking Assist PARKTRONIC does not necessarily take into account the following obstacles:

- Obstacles below the detection range, e.g. persons, animals or objects.
- Obstacles above the detection range, e.g. overhanging loads, overhangs or loading ramps of lorries.

- Pedestrians or animals approaching the vehicle from the side.
- Objects placed next to the vehicle

Obstacles on the sides are not shown in the following situations, for example:

- You park the vehicle and switch it off.
- You open the doors.

After the engine is restarted, obstacles must be detected again by driving past them before a new warning can be issued.

Also observe the system limits of the following systems:

- Reversing camera (→ page 264)
- 360° Camera (→ page 266)

Observe the information on vehicle sensors and cameras; the system otherwise cannot function properly (→ page 217).

**Vehicles with trailer hitch:** Parking Assist PARKTRONIC is deactivated for the rear zone when you establish an electrical connection between your vehicle and a trailer.

### Problems with Parking Assist PARKTRONIC

If the Parking Assist PARKTRONIC display lights up red for approximately three seconds then goes out, and the  symbol appears in the driver's display, the system may have been deactivated due to signal interference. Start the vehicle again and check if Parking Assist PARKTRONIC is working at a different location.

If a warning tone also sounds, it may be due to one of the following causes:

- **The sensors are dirty:** clean the sensors and observe the notes on care of vehicle parts (→ page 373).
- **Parking Assist PARKTRONIC has been deactivated due to a malfunction:** restart the vehicle. If the problem persists, consult a qualified specialist workshop.

## Activating/deactivating Parking Assist PARKTRONIC

**!** **NOTE** Risk of an accident from objects at close range

Parking Assist PARKTRONIC may not detect certain objects at close range.

- ▶ When parking or manoeuvring the vehicle, pay particular attention to any objects which are above or below the sensors, e.g. flowerpots or drawbars. The vehicle or other objects could otherwise be damaged.

### Requirements:

- The camera menu is open.
  - Or: Active Parking Assist is active.
  - Or: the PARKTRONIC pop-up window appears.
- ▶ Press  in the central display.

If the indicator lamp is lit, Parking Assist PARKTRONIC is active. If the indicator lamp does not light up or the symbol  is displayed, PARKTRONIC Parking Assist is not active.

 Parking Assist PARKTRONIC is automatically activated when the vehicle is started.

Alternatively, Parking Assist PARKTRONIC can be activated or deactivated in the quick access menu.

### Setting the warning tones of Parking Assist PARKTRONIC

Multimedia system:

  ▶ Settings ▶ Assistance  
▶ Parking

### Adjusting warning tones

- ▶ Select **Set warning tones**.
- ▶ Set the desired level under **Volume** or **Tone pitch**.

### Activating/deactivating audio fadeout

- ▶ **Audio fadeout** select and **Audio fade for warnings** switch it on or off. The volume of the currently playing media source is reduced during a Parking Assist PARKTRONIC warning tone.

or

- ▶ **Audio fadeout** select and **Audio fadeout in trans. position R** switch it on or off. The volume of the currently playing media source is reduced when reverse gear is engaged.

### Setting the time of the warnings

- ▶ Selecting **Time of warning**
- ▶ Activate or deactivate **Side warning**.
- ▶ Set the desired warning time for **Front** or **Rear**.

## Active Parking Assist

### Function of Active Parking Assist

Active Parking Assist is an electronic parking assistance system, which uses ultrasound with the assistance of the reversing camera and 360° Camera. When you are driving forwards up to approximately 35 km/h, the system automatically measures parking spaces on both sides of the vehicle.

Active Parking Assist offers the following functions:

### Vehicles with reversing camera

- Parking in parking spaces parallel to the road
- Reversing into parking spaces perpendicular to the road

### Vehicles with 360° Camera

- Parking in parking spaces parallel to the road
- Parking in parking spaces perpendicular to the road (optionally either forwards or reverse)
- Parking in parking spaces that can only be detected as such due to markings (forexample at the roadside)
- Exiting a parking space parallel to the road
- Exiting a parking space perpendicular to the road (optionally either left or right)

Active Parking Assist is only an aid. It is not a substitute for your attention to the surroundings. The responsibility for safe manoeuvring and parking remains with you. Make sure that no persons, animals or objects etc. are in the manoeuvring range.

If Active Parking Assist is available, the  message appears in the driver's display. When the

system detects parking spaces,  appears. The arrows show on which side of the road free parking spaces are located. These are then shown in the central display.

When Active Parking Assist is activated, the turn signal indicators are activated based on the calculated path of your vehicle. When you are entering or exiting a parking space, the procedure is assisted by acceleration, braking, steering and gear changes.

To start the parking procedure, press the  button (→ page 277).

Active Parking Assist will be cancelled in the following situations:

- You deactivate Parking Assist PARKTRONIC.
- You press the  button again.
- You begin steering.
- You engage transmission position .
- ESP® intervenes.
- You open the driver's door.

### System limits

If the exterior lighting is malfunctioning, Active Parking Assist is not available.

Also observe the system limits of the following systems:

- Reversing camera (→ page 264)
- 360° Camera (→ page 266)

Objects located above or below the detection range of Active Parking Assist, such as overhanging loads, overhangs or loading ramps of goods vehicles or the borders of parking spaces, are not detected during measurement of the parking space. These are also then not taken into account when calculating the parking procedure. In some circumstances, Active Parking Assist may therefore guide you into the parking space prematurely or brake too late.

Certain environmental conditions, such as snowfall or heavy rain, may lead to a parking space being measured inaccurately. Parking spaces that are partially occupied by trailer drawbars might not be identified as such or be measured incorrectly. Only use Active Parking Assist on level, high-grip ground.

**⚠ WARNING** Risk of accident due to objects located above or below the detection range of Active Parking Assist

If there are objects above or below the detection range, the following situations may arise:

- Active Parking Assist may steer too early.
- The vehicle may not stop in front of these objects.

There is a danger of collision!

- ▶ In these situations, do not use Active Parking Assist.


Active Parking Assist can also display unsuitable parking spaces, e.g. parking spaces in which parking is not permitted or parking spaces on unsuitable surfaces.

Do not use Active Parking Assist in the following situations:

- In extreme weather conditions such as ice, packed snow or in heavy rain.
- When transporting a load that protrudes beyond the vehicle.

- If the parking space is on a steep downhill or uphill gradient.
- When snow chains are fitted.
- When a trailer or bicycle rack is attached.
- Directly after a tyre change or when spare tyres are fitted.
- If the tyre pressure is too low or too high.
- If the suspension is out of alignment, e.g. after bottoming out on a kerb.
- On steep inclines of more than approximately 15 %.


## Parking with Active Parking Assist



**i** Depending on the vehicle's equipment, button **1** may also be located at a different position in the centre console.


▶ Press button **1**.





- ▶ Select ② menu **Parking Assistance**.

Parking spaces ③ detected by the system are shown in the central display.



When the vehicle is stationary, indicated vehicle path ④ into currently selected parking space ⑤ also appears.

- ▶ If a parking space is displayed: stop the vehicle.
- ▶ If necessary, select another parking space.

- ▶ **Vehicles with 360° Camera:** to change the parking direction, tap the selected parking space again.

- ▶ **To start the parking procedure:** press button ① again.  
The vehicle drives into the selected parking space.

The turn signal indicator is switched on automatically when the parking procedure begins. You are responsible for selecting the turn signal indicator in accordance with the traffic conditions. If necessary, select the turn signal indicator accordingly.

**⚠ WARNING** Risk of accident due to vehicle swinging out while parking or pulling out of a parking space

While parking or exiting a parking space, the vehicle swings out and can drive onto areas of the oncoming lane.

This could cause you to collide with objects or other road users.

- ▶ Pay attention to objects and other road users.

- ▶ Where necessary, stop the vehicle or cancel the parking procedure with Active Parking Assist.

On completion of the parking procedure, the **Active Parking Assist finished** display message appears.

- ▶ Secure the vehicle against rolling away. When required by legal requirements or local conditions: turn the wheels towards the kerb.

- ① You can stop the vehicle and change the transmission position during the parking procedure. The system then calculates a new vehicle path. If no new vehicle path is available, the transmission position can be changed again, or the process can be cancelled.

### Immediate parking via the **Camera views** menu



- ▶ Select the **Camera views** menu.
- ▶ When the vehicle is stationary and in transmission position **[R]**, and symbol ⑥ appears in the camera image: press button ① again. The parking procedure is initiated for the detected parking space.
- ① The parking space and parking direction cannot be changed in immediate parking.


### Exiting a parking space with Active Parking Assist

#### Requirements:

- The vehicle is equipped with a 360° Camera.

- The vehicle has been parked with Active Parking Assist.

- ▶ Start the vehicle.
- ▶ Press button ①.



- ▶ Select **Parking Assistance** menu ②.
- ▶ If necessary, change direction of exit ③.

- ▶ **To start exiting the parking space:** press button ① again.
- ▶ If necessary, change the gearbox setting. Observe any messages displayed in the driver's display and central display. The vehicle moves out of the parking space.

The turn signal indicator is automatically switched on when exiting a parking space begins and switched off when it is completed. You are responsible for selecting the turn signal indicator in accordance with the traffic conditions. If necessary, select the turn signal indicator accordingly.

After the parking space has been exited, a warning tone and the  **Active Parking Assist finished, take control of vehicle** message prompt you to take control of the vehicle. You have to accelerate, brake, steer and change gear yourself again.

If you do not react to the prompt to take control of the vehicle, the system will brake the vehicle to a standstill.

### Pausing Active Parking Assist

You can interrupt the parking or exiting procedure of Active Parking Assist by performing one of the following actions, foreexample:

- ▶ Depress the brake pedal.
- ▶ Open the front passenger door, a rear door or the load compartment.
- ▶ Apply the electric parking brake or activating the HOLD function.
- ▶ **To resume the parking or exiting procedure:** gently depress the accelerator pedal.

❗ If the electric parking brake was applied before Active Parking Assist was activated, depress the accelerator pedal lightly to start the parking or exiting procedure.

Check the area around your vehicle again before resuming a paused parking procedure. Make sure that persons, animals or objects are no longer in the manoeuvring range. Also observe the system limitations of Active Parking Assist.

### Automatic braking function of Active Parking Assist

Persons or objects detected in the manoeuvring range could cause the vehicle to brake sharply and interrupt the parking or exiting procedure. The vehicle will then be held at a standstill. If you depress the accelerator pedal, the parking or exiting procedure is resumed.

Check the area around your vehicle again before resuming the parking or exiting procedure. Make sure that persons, animals or objects are no longer in the manoeuvring range. Also observe the system limitations of Active Parking Assist.

### Remote Parking Assist

#### Function of Remote Parking Assist

- ❗ Remote Parking Assist is an additional function of Active Parking Assist. Comply with local traffic laws and regulations when using Remote Parking Assist on public roads. If it is required to turn the wheels toward the kerb, you cannot use Remote Parking Assist.

Please note that you can only use Remote Parking Assist if you have a valid driving licence and are in a fit state to drive.

Remote Parking Assist parks your vehicle or exits the parking space while you are outside of your vehicle. You can monitor the manoeuvring and parking procedure on your mobile phone.

With Remote Parking Assist, you can carry out all the parking procedures of Active Parking Assist. You can also position the vehicle directly in front of a garage or a driveway entrance and then use Remote Parking Assist to enter or exit a parking space.

Remote Parking Assist manages pulling away, braking and steering. While Remote Parking Assist is active, the vehicle is locked.

Remote Parking Assist is only an aid. It is not a substitute for your attention to the surroundings. The responsibility for safe manoeuvring and parking remains with you. Interrupt or terminate the parking procedure if necessary. Make sure that no persons, animals or objects etc. are in the manoeuvring range. Make sure to also pay attention to other vehicles.

### System limits

If the system detects a malfunction or a system limit during the manoeuvring or parking procedure, the procedure will be cancelled:

- The vehicle is brought to a standstill.
- Transmission position **P** is selected and the electric parking brake is applied automatically.
- The vehicle is switched off.
- The vehicle remains locked.

If the parking manoeuvre is cancelled, a corresponding message is displayed on the mobile phone.

Depending on the situation, you can then take control of the procedure, manoeuvre the vehicle back to the starting position or manually take control of the vehicle.

The system limits of Active Parking Assist apply (→ page 275).

Certain environmental conditions, such as snowfall or heavy rain, may lead to a parking space being measured inaccurately or to connection problems with the mobile phone. Only use Remote Parking Assist on level, high-grip ground.

During the parking procedure, you should not stand more than approx. 3.0 m away from the vehicle. At greater distances, the procedure will be interrupted and a corresponding message will be displayed on the mobile phone. If you move closer to the vehicle, you will be able to continue the procedure.

### Operating Remote Parking Assist

#### Requirements:

For the Remote Parking Assist function, you require a mobile phone and the current Remote Parking Assist App for your vehicle type.

 A list of compatible phones can be found at: <https://www.mercedes-benz-mobile.com/>

The following operating systems are supported:

- Android™
- Apple® iOS

 **WARNING** Danger due to insufficient view of the vehicle surroundings

If you manoeuvre, park or exit a parking space with the vehicle using Remote Parking Assist, observe the following:


- ▶ Make sure that you have the best view possible of the vehicle and the vehicle's surroundings.
- ▶ Make sure that no persons, animals or objects are in the path of your vehicle.
- ▶ Make sure that you maintain a suitable distance to the vehicle and that neither you nor other road users could be endangered.
- ▶ Be aware of the vehicle's surroundings at all times and identify possible dangers.
- ▶ If necessary, cancel the parking procedure.

No persons or pets are permitted to remain in the vehicle during the parking procedure. Observe the system limits at all times. If necessary, cancel the parking procedure. Always make sure that others can access their vehicles.


- ▶ Activate the "Remote Parking Assist" service e.g. via the Mercedes me homepage.
- ▶ Authorise the mobile phone using the Remote Parking Assist App in the vehicle (→ page 284).

### Selecting the parking manoeuvre in advance while inside the vehicle

- ▶ Stop the vehicle and select transmission position **P**.



- ❗ Depending on the vehicle's equipment, button ① may also be located at a different position in the centre console.
- ▶ Press button ①.



- ▶ Select ② menu **Parking Assistance**.
- ▶ For further information on Remote Parking Assist: select ③.
- ▶ If necessary, select another parking space ④ or select ⑤ to drive straight ahead into a garage, forexample.
- ▶ If necessary, change parking direction ⑥.

- ❗ Alternatively, you can begin parking with Active Parking Assist (→ page 277) and continue with the Remote Parking Assist from any vehicle position. To do this, stop the parking process and adjust the gearbox setting **P**.

- ▶ Switch off the vehicle and exit it with the key.

### Starting the parking procedure without selecting in advance

- ▶ Stop the vehicle and select transmission position **P**.
- ▶ Switch off the vehicle and exit it with the key.

### Starting the parking procedure while outside the vehicle

- ▶ Unlock the vehicle.

### Carrying out a parking procedure with Remote Parking Assist

- ❗ Keep the vehicle key with you during the parking procedure. You can cancel the parking procedure and bring the vehicle to a standstill by pressing a button on the key.
- ❗ On completion of the parking procedure, the vehicle is locked.

If you have started the parking procedure as described above, the vehicle is ready to connect to your mobile phone for a limited time.

- ▶ Start the Remote Parking Assist App on the mobile phone and connect to the vehicle.
- ▶ Follow the instructions of the Remote Parking Assist App.

- ❗ The turn signal indicator is automatically switched on when starting parking and switched off when it is completed.
- ❗ If the connection between the vehicle and the mobile phone is interrupted while a parking manoeuvre is being performed, the manoeuvre can be continued if the connection is re-established within a short time.

**⚠ WARNING** Risk of accident due to vehicle swinging out while parking or pulling out of a parking space

While parking or pulling out of a parking space, the vehicle swings out and can drive onto areas of the oncoming lane.

This could cause you to collide with objects or other road users.

- ▶ Pay attention to objects and other road users.
- ▶ Where necessary, stop the vehicle or cancel the parking procedure with Remote Parking Assist.

- ▶ After ending the parking procedure, ensure that all vehicle doors, windows and the boot are closed. Secure the vehicle against rolling away.

### Cancelling the parking procedure

You can cancel the parking procedure of Remote Parking Assist at any time and bring the vehicle to a standstill.

- ▶ Cancel the parking procedure in the Remote Parking Assist App.
- or
- ▶ Press a button on the vehicle key.
- or
- ▶ Pull a door handle.

## Authorising/de-authorising a mobile phone for Remote Parking Assist

Multimedia system:

→  » Settings » Assistance  
» Parking

### Authorising a new mobile phone

In order to be able to use the Remote Parking Assist function, you must authorise your mobile phone. You can authorise up to ten mobile phones.

- ▶ Select **Remote Parking Assist**.
- ▶ Select **Authorise a new device**.  
Remote Parking Assist is ready to connect.
- ▶ Start the Remote Parking Assist App and additionally start the authorisation process.  
A connection prompt is displayed.
- ▶ Scan the QR code on the central display.  
The mobile phone is authorised.

### De-authorising mobile phones

- ▶ Select **Remote Parking Assist**.
- ▶ Select **Deauthorise devices**.

- ▶ **To de-authorise a mobile phone:** select a mobile phone.  
The mobile phone is deleted from the device list.
- ▶ **To de-authorise all mobile phones:** select **Deauthorise all devices**.  
All mobile phones are deleted from the device list.

## Manoeuvring assistant

### Function of Drive Away Assist

Drive Away Assist can reduce the severity of an impact when pulling away. If the system detects an obstacle in the direction of travel, the vehicle's speed is briefly reduced to approximately 2 km/h.

A risk of collision may occur in the following situations, for example:

- If the driver mixes up the accelerator and brake pedals.
- If the driver engages an incorrect gear.
- If the driver depresses the accelerator pedal with too much force.

Drive Away Assist is active under the following conditions:

- If the vehicle was stationary and the transmission position was changed to **R** or **D**.
- If the vehicle has rolled less than approximately 1.0 m since being at a standstill.
- If the detected obstacle is less than approx. 1.0 m away.

The **Drive-away Assist** can be deactivated or activated in the **Manoeuvring assistance** menu (→ page 287).

If a critical situation is detected, the following symbol appears in red in the selected view in the **Camera & parking** menu:



- ❗ If Drive Away Assist is not available, the same symbol appears in grey. If the **Camera & parking** menu is not opened in the central display, the symbol and pop-up of Parking Assist PARKTRONIC both appear.

Drive Away Assist is only an aid. It is not a substitute for your attention to the surroundings. The responsibility for safe manoeuvring and parking remains with you. Make sure that no persons, animals or objects etc. are in the manoeuvring range.

**⚠ WARNING** Risk of accident caused by limited detection performance of Drive Away Assist

Drive Away Assist cannot always clearly identify objects and traffic situations.

- ▶ Always pay careful attention to the traffic situation; do not rely on Drive Away Assist alone.
- ▶ Be prepared to brake or swerve as necessary, provided the traffic situation permits and that it is safe to take evasive action.

### System limits

The system limits of Active Parking Assist apply (→ page 275).

On uphill gradients, the performance of Drive Away Assist is restricted.

If transport equipment is secured to the trailer hitch, such as a trailer or bicycle rack, Drive Away Assist is not available when you are reversing.

### Function of cross traffic warning

The cross traffic warning can warn you of crossing traffic when you are exiting a parking space. The radar sensors in the bumper also monitor the area adjacent to the vehicle.

The cross traffic warning is active under the following conditions:

- **Warning for crossing traffic behind:** the vehicle is driving in reverse at a speed slower than approx. 10 km/h.
- **Warning for crossing traffic ahead:** the vehicle is driving forwards at a speed slower than approx. 10 km/h and the camera image is shown in the central display (→ page 270).

The **Warning for crossing traffic ahead** can be deactivated or activated in the **Manoeuvring assistance** menu.

Depending on the country, the **Warning for crossing traffic behind** can also be deactivated or activated (→ page 287).

If a critical situation is detected, the following symbol appears in red in the selected view in the **Camera & parking** menu:



### Warning for crossing traffic behind

- The vehicle can be braked automatically when crossing traffic is detected.
- If the menu **Camera & parking** is not open and a critical situation is detected, a warning appears in the central display together with the PARKTRONIC Parking Assist pop-up.

### Warning for crossing traffic ahead

- If Active Parking Assist is active, the vehicle can be braked automatically when crossing traffic is detected.



- If Active Parking Assist is not active but the menu **Camera & parking** is open, a warning appears.
- If the menu **Camera & parking** is not open, the system cannot react to crossing traffic.

The cross traffic warning is only an aid and not a substitute for your attention to the surroundings. The responsibility for safe manoeuvring and parking remains with you. Make sure that no persons, animals or objects etc. are in the manoeuvring range.

**⚠ WARNING** Risk of accident caused by limited detection performance of the cross traffic warning

The cross traffic warning cannot always clearly identify objects and traffic situations.

- ▶ Always pay careful attention to the traffic situation; do not rely on the cross traffic warning alone.
- ▶ Be prepared to brake or swerve as necessary, provided the traffic situation per-

mits and that it is safe to take evasive action.

### System limits

- ❗ If the cross traffic warning is not available, the  symbol appears in grey.

The system limits of Active Parking Assist apply (→ page 275).

If the radar sensors are obstructed by vehicles or other objects, detection is not possible.

In the following situations, the cross traffic warning is not available:

- on inclines
- **Warning for crossing traffic behind:** if transport equipment, for example a trailer or bicycle rack, is attached to the trailer hitch and the electrical connection has been correctly established

### Manoeuvring brake function

The manoeuvring brake function can prevent collisions with pedestrians when the vehicle is reversing at slow speeds. If the reversing camera

detects a person in the vehicle path, the vehicle can be braked to a standstill.

The manoeuvring brake function can intervene under the following conditions:

- The vehicle is reversing at a speed slower than 10 km/h.
- The camera image is shown in the central display (→ page 270).

Depending on the country, you can activate and deactivate the manoeuvring brake function in the **Manoeuvring assistance** menu (→ page 287).

If the manoeuvring brake function is triggered, the following symbol appears in red in the selected view in the **Camera & parking** menu:



- ❗ If the manoeuvring brake function is not available, the same symbol appears in grey.

The manoeuvring brake function is only an aid. It is not a substitute for your attention to the surroundings. The responsibility for safe manoeuvring

and parking remains with you. Make sure that no persons, animals or objects etc. are in the manoeuvring range.

**⚠ WARNING** Risk of accident caused by limited detection by the manoeuvring brake function

The manoeuvring brake function cannot always clearly detect people. Other obstacles are not detected by the function.

In these cases, the function may brake unnecessarily or not brake at all.

- ▶ Always pay careful attention to the traffic situation; do not rely on the manoeuvring brake function alone.
- ▶ Be ready to brake.

### System limits

Observe the system limits of the following functions:

- Active Parking Assist (→ page 275)
- 360° Camera (→ page 266)
- Reversing camera (→ page 264)

The manoeuvring brake function is not available in the following situations:

- on inclines
- if transport equipment, for example a trailer or bicycle rack, is attached to the trailer hitch and the electrical connection has been correctly established

### Activating/deactivating manoeuvring assistance

Multimedia system:

→  >> Settings >> Assistance  
>> Parking

 This function is available on demand (→ page 24).

- ▶ Select **Manoeuvring assistance**.
- ▶ Activate or deactivate the desired manoeuvring assistance.

### Memory Parking Assist

#### Function of Memory Parking Assist

Memory Parking Assist can park your vehicle using a previously stored parking space. You can store parking procedures with a total distance of

up to 500 m (100 m per parking or exiting procedure).

During parking or exiting, the system can travel a previously stored path of up to approximately 100 m to or out of the desired parking space, for example, from the driveway entrance into the garage.

Within a radius of approx. 150 m, only one parking or exiting procedure can be recorded.

Only use Memory Parking Assist on private property. Use on public roads, e. g. in public parking spaces, is not permitted.

Memory Parking Assist is only an aid. It is not a substitute for your attention to the surroundings. The responsibility for safe manoeuvring and parking remains with you. Make sure that no persons, animals or objects etc. are in the manoeuvring range.

### System limits

Observe the system limitations of Active Parking Assist (→ page 275).

**⚠ WARNING** Risk of accident due to objects located above or below the detection range of Memory Parking Assist

If there are objects above or below the detection range, the following situations may arise:

- Memory Parking Assist may steer too early.
- The vehicle may not stop in front of these objects.

This result in a collision.

- ▶ In these situations, do not use Memory Parking Assist.

Objects located above or below the detection range of Memory Parking Assist may not be detected during the parking procedure.

Drawbars of parked trailers, among other objects, that protrude into the parking space may not be detected.


Do not use Memory Parking Assist in the following situations, for example:

- In extreme weather conditions such as ice, packed snow or in heavy rain.
- When transporting a load that protrudes beyond the vehicle.
- If the parking space is on a steep downhill or uphill gradient.
- When snow chains are fitted.

### Recording a parking procedure using Memory Parking Assist

#### Requirements:

- The entire route is, for example, within your own property and not on public roads.
- The system needs reference points in the surroundings to orient itself, such as fences, walls or trees. Therefore, after starting the vehicle, a certain distance must first be driven. If not enough reference points are detected in the surrounding area, no new route can be recorded.



- ▶ Press button ①. The **Camera & parking** view opens in the central display.



- ▶ Select ② menu **Memory Parking Assist**.
  - ▶ Brake the vehicle to a standstill at the desired starting point of the assisted parking procedure, e.g. a driveway entrance.
  - ▶ **To start recording:** press ③.
- ❗ If not all conditions for a recording are met, symbol ③ is greyed out.

- ▶ Park the vehicle in the desired parking space. Do not exceed 8 km/h.
- ▶ **To end recording:** stop the vehicle and press ③ again. The recording is stored.
- ❗ In the Memory Parking Assist settings you can delete and rename stored parking procedures.

### Parking with Memory Parking Assist

#### Requirements:

- A parking procedure has been recorded.
- ▶ Press button ①. The **Camera & parking** view opens in the central display.



- ▶ Select **Memory Parking Assist** menu ②.
- ▶ Brake the vehicle to a standstill at the starting point of the stored parking procedure.
- ▶ **To start the parking procedure:** press .
- ▶ Select the stored parking procedure from the list.

- ▶ Follow the instructions on the central display. The vehicle drives into the selected parking space.

❗ The turn signal indicator is not switched on automatically. You are responsible for selecting the turn signal indicator in accordance with the traffic conditions.

- ▶ After completion of the parking procedure, safeguard the vehicle against rolling away.

### Exiting a parking space with Memory Parking Assist

#### Requirements:

- The exiting procedure was recorded together with the respective parking procedure and stored separately within one driving cycle.
- The vehicle was parked using Memory Parking Assist.

- ▶ Press button ❶.
- ▶ The **Camera & parking** view opens in the central display.
- ▶ Select **Memory Parking Assist** menu ❷.

### Starting the exiting procedure

- ▶ Press .
- ▶ Confirm the saved exiting procedure.
- ▶ Follow the instructions on the central display. The vehicle drives the recorded route.
- ❗ The turn signal indicator is not switched on automatically. You are responsible for selecting the turn signal indicator in accordance with the traffic conditions.
- ▶ Take control of the vehicle after the exiting procedure has been completed.

### Setting Memory Parking Assist

Multimedia system:

- ▶  ▶ **Settings** ▶ **Assistance**
- ▶ **Camera & parking** ▶ **Parking Assistance**
- ▶ **Memory Parking Assist**

### Renaming a recording

- ▶ Select **Manage lanes**.
- ▶ Select  next to the desired recording.
- ▶ Enter a name and confirm with **OK**.

### Deleting a recording

- ▶ Select **Manage lanes**.
- ▶ Select  next to the desired recording.
- ▶ Confirm the message prompt with **Yes**.

### Deleting all recordings

- ▶ Select **Manage lanes**.
- ▶ Select **Delete all lanes**.
- ❗ Alternatively, you can delete all data in Memory Parking Assist by resetting the multimedia system (→ page 324).

## Trailer hitch

### Notes on trailer operation

❗ **NOTE** The operating permit may be invalidated due to the illegal installation of trailer hitches

The installation – including retrofitting – of a non-folding or non-removable trailer hitch that even partially conceals the license plate or the lighting system is prohibited.

- ▶ Observe the applicable legal regulations for the installation of trailer hitches.

Observe the following notes on the tongue weight:

- Do not use a tongue weight that exceeds or falls below the permissible tongue weight
- Use a tongue weight as close as possible to the maximum tongue weight

Do not exceed the following values:

- Permissible towing capacity
- Permissible rear axle load of the towing vehicle
- Permissible gross weight of the towing vehicle
- Permissible gross weight of the trailer
- Maximum permissible speed of the trailer

Ensure the following before starting a journey:

- The tyre pressure on the rear axle of the towing vehicle is set for a maximum load
- The lighting of the connected trailer is operational

In the event of increased rear axle load, the car/trailer combination must not exceed a maximum speed of 100 km/h for reasons concerning the operating permit. This also applies in countries in which the permissible maximum speed for car/trailer combinations is above 100 km/h.

### Folding the ball neck out and in

**⚠ WARNING** Risk of accident due to the ball neck not being engaged

If the ball neck is not engaged, the trailer may come loose.

- ▶ Always engage the ball neck as described.

**⚠ WARNING** Risk of injury from ball neck swinging outwards

The ball neck may swing outwards when unlocking or when it has not been properly engaged.

There is a risk of injury within the ball neck's range of movement!

- ▶ Unlock the ball neck only when its range of movement is unobstructed.
- ▶ Always be sure the ball neck is engaged when folding inwards.

**! NOTE** Increased risk of damage to property due to folded-out ball neck

- ▶ When the trailer is not coupled or the bicycle rack is attached, fold in the ball neck or, in the case of a fully electric trailer hitch, retract the ball neck.

**! NOTE** Damage to the vehicle due to incorrect use of the trailer hitch

When a trailer hitch is used to recover a vehicle, the vehicle may be damaged in the process.


- ▶ Use the trailer hitch only for pulling a trailer or attaching approved carrier systems (e.g. a bicycle rack).

### Requirements:


- The vehicle is secured against rolling away.

- The swivel range is clear.
- The trailer cables or adapter plugs have been removed.

### Folding the ball neck out



- ▶ Pull switch ② until the ball neck unlocks. The ball neck will fold out from under the rear bumper. Indicator lamp ① will flash.



- ▶ Pull the ball neck in the direction of the arrow until it engages audibly in a vertical position. Indicator lamp ① on the ball neck release switch will go out.
- If the ball neck is not securely locked in place, the **Check trailer hitch lock** message will appear on the driver display.
- ▶ Remove the cover cap from the ball head and store it in a safe place.

Make sure that the ball on the ball neck is clean. Check that it is either greased or dry (grease-free), depending on the instructions for the trailer.

### Folding the ball neck in

- ▶ Pull switch ② until the ball neck unlocks. The ball neck will fold up under the rear bumper. Indicator lamp ① will flash.
- ▶ Push the ball neck in the direction of the arrow until it engages audibly behind the bumper. Indicator lamp ① will go out and the message on the driver display will disappear.

Observe the information about the displays on the driver's display:

- Indicator and warning lamps (→ page 489)
- Display messages (→ page 424)

## Coupling up/uncoupling a trailer

**⚠ WARNING** Risk of injury due to a change in vehicle level

**Vehicles with AIRMATIC:** the vehicle level may be changed unintentionally, e.g. by other people. If you couple or uncouple the trailer during this time, you may become trapped. In addition, other people could become trapped if parts of their body are between the vehicle body and the tyres or underneath the vehicle.

Observe the following when coupling or uncoupling:

- ▶ Do not open or close any doors or the boot lid.
- ▶ Do not initiate the level control and do not operate the DYNAMIC SELECT switch.
- ▶ Do not lock or unlock the vehicle.

### Requirements:

- The ball neck is extended and engaged in a securely locked position.

- **Vehicles with AIRMATIC:** ensure the vehicle is at the normal level (→ page 262).

Use the normal level in trailer operation. High-level driving is not permitted in trailer operation on public roads.

Trailers with a 7-pin plug can be connected to the vehicle with the following adapters:

- Adapter plug
- Adapter cable

The trailer will be correctly detected by the vehicle only if the following conditions are met:

- The trailer is connected correctly.
- The trailer lighting system is in working order.

The functions of the following systems will be affected by a correctly connected trailer:

- ESP® trailer stabilisation
- Active Lane Keeping Assist
- Parking Assist PARKTRONIC
- Active Parking Assist
- Blind Spot Assist or Active Blind Spot Assist

- Drive Away Assist
- Cross traffic warning
- Manoeuvring brake function
- Reversing camera
- 360° camera
- AIRMATIC

## Coupling up a trailer

**! NOTE** Damage to the starter battery due to full discharge

Charging the trailer battery using the power supply of the trailer can damage the starter battery.

- ▶ Do not use the vehicle's power supply to charge the trailer battery.

- ▶ Remove the cover cap from the ball head and store it in a safe place.
- ▶ Position the trailer on a level surface behind the vehicle and couple it up to the vehicle.





- ▶ Open the socket cap.
- ▶ Insert the plug with lug ① in groove ③ on the socket.
- ▶ Turn bayonet coupling ② to the right as far as it will go.
- ▶ Let the cap engage.
- ▶ Secure the cable to the trailer with cable ties (only if you are using an adapter cable).
- ▶ Make sure that the cable is always slack for ease of movement during cornering.

Under the following conditions, a message may appear on the driver's display even if the trailer has been connected correctly:

- LEDs have been installed in the trailer lighting system.
- The current has fallen below the trailer lighting system's minimum current (50 mA).

① Accessories can be connected to the permanent power supply up to 180 W and to the power supply that is switched on via the ignition lock.

### Uncoupling a trailer

**⚠ WARNING** Risk of being crushed and becoming trapped when uncoupling a trailer

When uncoupling a trailer with an engaged inertia-activated brake, your hand may become trapped between the vehicle and the trailer drawbar.

- ▶ Do not uncouple trailers with an engaged overrun brake.

**! NOTE** Damage during uncoupling with an engaged overrun brake

The vehicle may be damaged if you uncouple with an engaged overrun brake.

- ▶ Do not uncouple trailers with an engaged overrun brake.

- ▶ Secure the trailer against rolling away.
- ▶ Disconnect the electrical connection between the vehicle and the trailer.
- ▶ Uncouple the trailer.
- ▶ Place the cover cap on the ball head.

① **Trailers with LED lighting:** after uncoupling the trailer, switch the vehicle on and then off again.

## Bicycle rack function

**⚠ WARNING** Risk of an accident if the bicycle rack is used incorrectly

The bicycle rack may become detached from the vehicle in the following cases:

- the permissible load capacity of the trailer hitch is exceeded.
- the bicycle rack is used incorrectly.
- the bicycle rack is secured to the ball neck beneath the ball head.

Observe the following for your own safety and that of other road users:

- always adhere to the permissible load capacity of the trailer hitch.
- always observe the permissible rear axle load of the towing vehicle.
- use the bicycle rack only to transport bicycles.

- always mount the bicycle rack properly by attaching to the ball head and the ball neck guide pin, if possible.
- when transporting four bicycles, always use bicycle racks which have additional support on the ball neck guide pin.
- use only bicycle racks approved by Mercedes-Benz.
- always observe the bicycle rack operating instructions.

**! NOTE** Damage to or breakage of the trailer hitch due to unsuitable or improperly used bicycle rack.

► Only use bicycle racks approved by Mercedes-Benz properly as described below.

**! NOTE** Increased risk of damage to property due to folded-out ball neck


► When the trailer is not coupled or the bicycle rack is attached, fold in the ball

neck or, in the case of a fully electric trailer hitch, retract the ball neck.

**! NOTE** The operating permit may be invalidated due to the illegal installation of trailer hitches

The installation – including retrofitting – of a non-folding or non-removable trailer hitch that even partially conceals the license plate or the lighting system is prohibited.

► Observe the applicable legal regulations for the installation of trailer hitches.



Trailer hitch (example with additional guide pin)

Depending on the bicycle rack's design, different numbers of bicycles can be transported.

The following bicycle rack designs are possible:

- When mounted by attaching to ball head ①, the maximum load capacity is 75 kg. You can transport up to three bicycles.

- When mounted on ball head ① and guide pin ②, the maximum load capacity is 100 kg. You can transport up to four bicycles.

The maximum load capacity is calculated from the weight of the bicycle rack and the bicycle rack load.

Observe the notes on driving with a roof load, trailer or fully laden vehicle (→ page 181).

When using a bicycle rack, set the tyre pressure for increased load on the rear axle of the vehicle. Further information on the tyre pressure can be found in the tyre pressure table (→ page 398).

### Notes on loading

The larger the distance between the load's centre of gravity and the ball head, the greater the load on the trailer hitch.


Observe the following notes:

- mount heavy bicycles as close to the vehicle as possible
- always distribute the load on the bicycle rack as evenly as possible across the vehicle's longitudinal axis

Mercedes-Benz recommends removing all detachable parts from bicycles (e.g. baskets, child seats, batteries) before loading them onto the bicycle rack. This will improve the aerodynamic resistance and centre of gravity of the bicycle rack.

Always secure the bicycles to prevent them from moving around and check them at regular intervals to ensure that they are secure.

Do not use tarpaulins or other covers. The driving characteristics and rear view may be impaired. In addition, aerodynamic resistance and the load on the trailer hitch will increase.



Load distribution on the bicycle rack

- ① Vertical distance between centre of gravity and ball head
- ② Horizontal distance between centre of gravity and ball head
- ③ The centre of gravity is on the vehicle's central axis

Observe the following information when loading the bicycle rack:

### Loading the bicycle rack

|                                       | 3 bicycles  | 4 bicycles   |
|---------------------------------------|-------------|--------------|
| Total weight of bicycle rack and load | Up to 75 kg | Up to 100 kg |
| Max. distance<br>①                    | 420 mm      | 420 mm       |
| Max. distance<br>②                    | 300 mm      | 400 mm       |

When transporting four bicycles or a total weight between 75 kg and 100 kg, always use bicycle racks with additional support on the trailer hitch guide pin.

### Vehicle towing instructions

The vehicle is not suitable for the use of tow bar systems that are used for flat towing or dinghy towing, for example. Attaching and using tow bar systems can result in damage to the vehicle. When you are towing a vehicle with tow bar systems, safe driving characteristics cannot be guar-

anteed for the towing vehicle or the towed vehicle. The vehicle-trailer combination may swerve from side to side.

Observe the following information:

- Permitted towing methods (→ page 388)
- The notes on towing the vehicle with both axles on the ground (→ page 388)

### Notes on the driver's display

**⚠ WARNING** Risk of accident if the driver display fails

If the driver display has failed or is malfunctioning, function restrictions in systems relevant to safety cannot be detected.

The operating safety of your vehicle may be impaired.

- ▶ Drive on carefully.
- ▶ Have the vehicle checked immediately at a qualified specialist workshop.

**! NOTE** Mercedes-AMG vehicles

- ▶ Observe the notes in the Supplement. You could otherwise fail to recognise dangers.

If the operating safety of your vehicle is impaired, park the vehicle immediately and safely. Contact a qualified specialist workshop.

The driver's display shows the following basic information:

- Speed and power meter level
- Range according to average consumption, personal driving style or high-consumption driving style
- State of charge of the high-voltage battery
- Indicator and warning lamps

Additional functions available include the following:

- Different menus, e.g. for assistance and navigation
- Status displays for the driving systems
- Display messages

The menu contents and settings can be individually adapted and set.

### Notes on the range

The range in general

- All ranges shown are assumptions based on various calculation bases. The actual range achieved may differ from the range displayed.
- Outside temperatures, climate control settings, vehicle interior temperatures, road conditions, driving style etc. directly influence the achievable range.
- Pay attention to the charging prompts at all times.

Range according to personal driving style

- Your previous individual consumption will be taken into account when the range is being calculated.
- While the navigation system or commuter route is active, additional information about the route ahead can be included in the range calculation.

Range with low consumption

- The maximum range shows the potential range when consumption is low, e.g. as a result of

economical driving or having the air conditioning system turned off.

#### Range with high consumption

- The minimum range shows the range when consumption is high, e.g. as a result of a sporty driving style or having the air conditioning system turned on.
- This range is determined based on past and current consumption figures.

#### Electrical consumption

- The consumption figures **From start** and **From reset** take into account all active consumer equipment when it comes to the drive system's operational readiness **READY**.

- i** When the range maximisation function is switched on, the range display on the speedometer will increase automatically (→ page 188).

### Operating the driver's display


**⚠ WARNING** Risk of distraction from information systems and communications equipment

If you operate information systems and communication devices integrated in the vehicle when driving, you could be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- ▶ Only operate this equipment when the traffic situation permits.
- ▶ If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.

Observe the legal requirements for the country in which you are currently driving when operating the driver's display.

### Scrolling on the menu bar



- ① Back button
- ② Main menu button
- ③ Touch Control

The content on the driver's display is controlled using the control elements on the left side of the steering wheel. You can use Touch Control ③ to navigate vertically and horizontally by swiping with

one finger. Confirm the selection by pressing the Touch Control.

**i** To operate Touch Control **3** in the most effective way, use the tip of your thumb if possible. You can also set the sensitivity of the Touch Control on the central display.

▶ Briefly press main menu button **2**.

▶ Select a menu by swiping to the left or right on Touch Control **3**.

▶ Press Touch Control **3** to confirm.

## Driver display menus

### Notes on menus on the driver's display

**⚠ WARNING** Risk of distraction from information systems and communications equipment

If you operate information systems and communication devices integrated in the vehicle when driving, you could be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

▶ Only operate this equipment when the traffic situation permits.

▶ If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.

Observe the legal requirements for the country in which you are currently driving when operating the driver's display.

The following menus can be called up via the menu bar on the driver's display:

- Understated
- Sport
- Classic
- Navigation
- Assistance
- Service

On some of these menus, you can choose between different display content on the centre display area.

On most of the menus, you can use **Options** to configure further settings for the menu-specific display content.

You can find further information about the possible settings and selections on the menus in the Digital Owner's Manual.

## Head-up display

### Function of the head-up display


The head-up display projects various content into the driver's field of vision, for example.

You can use the head-up display menu bar to select different contexts, e.g.:

- Minimal
- Sport
- Standard
- ECO display
- Settings
- Head-up display on/off

The following image shows an example of the head-up display. You can choose what content is displayed (→ page 301).

### Head-up display content with navigation (9x3°)



- ① Navigation instructions
- ② Navigation instructions (distance to the next route event)
- ③ Steer Assist status
- ④ Current speed
- ⑤ Set speed in the driving system (e.g. cruise control)
- ⑥ Detected traffic signs (Traffic Sign Assist)

When you receive a call, the  **Call waiting** message will appear on the head-up display and the driver's display.

### System limits


Visibility is particularly influenced by the following conditions:

- Seat position
- Image position setting
- Light conditions
- Wet road surfaces
- Objects on the display cover
- Polarisation in sunglasses

### Operating the head-up display

#### Selecting display content of the head-up display via the menu bar of the driver's display

- ▶ Press the main menu button  on the left.
- ▶ **To select the menu bar of the head-up display:** swipe upwards on the left-hand Touch Control.



#### Switching between display contents on the head-up display

- ▶ Swipe to the left or right on the left-hand Touch Control. A preview of the selected display content will appear on the head-up display.
- ▶ Press the  button to confirm the desired content.

#### Switching back to the driver's display

- ▶ Press the  or  button.



### Setting the position and brightness

- ▶ Swipe to the left or right on the left-hand Touch Control and select **Settings** on the menu bar of the head-up display.
- ▶ Press the left-hand Touch Control. The current position and brightness settings will be displayed graphically on the head-up display as well as on the driver's display.
- ▶ **To adjust the position:** swipe up or down on the left-hand Touch Control.
- ▶ **To adjust the brightness:** swipe to the left or right on the left-hand Touch Control. The settings configured for position and brightness will be saved automatically.
- ▶ Press the  or  button to exit the settings.

### Switching the head-up display on/off

Driver's display:



### Switching on

- ▶ Swipe up on left-hand Touch Control.


- ▶ Press  on the left-hand Touch Control.

### Switching off

- ▶ Swipe up on left-hand Touch Control.
- ▶ Swipe on left-hand Touch Control and select **Head-up display**.
- ▶ Press  on the left-hand Touch Control.

### Overview of status displays on the driver's display

The status displays for the driving and driving safety systems can be found in display sections ① to ④.



- ① The number, position and presentation of the status indicators on the driver's display depend on which systems are activated or deactivated.

-  Pedestrian detection (only on assistant display)
-  Active Parking Assist available (→ page 277)

-  Active Parking Assist has detected a parking space (→ page 277)
-  Parking Assist PARKTRONIC deactivated (→ page 275)
-  Cruise control (→ page 227)
-  Limiter (→ page 228)
-  Active Distance Assist DISTRONIC (→ page 230)
-  Specified distance for Active Distance Assist DISTRONIC (→ page 230)
-  Active Brake Assist switched off (→ page 249)
-  Active Brake Assist impaired or not functioning (→ page 249)
-  Active Steering Assist (→ page 238)
-  Active Lane Change Assist (→ page 242)
-  Active Lane Keeping Assist (→ page 259)
-  Active Blind Spot Assist (only on assistant display) (→ page 257)
-  Haptic accelerator pedal (→ page 185, 188)

-  HOLD function (→ page 222)
-  Adaptive Highbeam Assist (→ page 149)  
Adaptive Highbeam Assist Plus (→ page 150)
-  Maximum permissible speed exceeded (for certain countries only)
-  Active Stop-and-Go Assist (→ page 238)
-  Slippery road surface warning

**Vehicles with Speed Limit Assist:** detected instructions and traffic signs (→ page 250).

**Vehicles with Traffic Sign Assist:** detected instructions and traffic signs (→ page 251).

-  Acoustic presence indicator inoperative (→ page 436)

## Overview and operation

### Notes on the MBUX multimedia system

**⚠ WARNING** Risk of distraction from information systems and communications equipment

If you operate information systems and communication devices integrated in the vehicle when driving, you could be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- ▶ Only operate this equipment when the traffic situation permits.
- ▶ If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.

You must observe the legal requirements for the country in which you are currently driving when operating the multimedia system. Depending on the equipment, the scope of function and product designation of your MBUX multimedia system may differ from the description and


images in this Owner's Manual. For example, route guidance with augmented reality is not available in all equipment variants.

**! NOTE** Increased surface temperature due to direct sunlight on the central display

The surface of the central display is very dark. If the display is exposed to direct sunlight, the surface can become very hot.

- ▶ If the central display has been exposed to direct sunlight, allow it to cool down before touching it for a long time.


### Overview of the MBUX multimedia system



Vehicles with central display

- ① Touch Control and control panel for the MBUX multimedia system  
MBUX stands for Mercedes-Benz User Experience.
  - Operating Touch Control
- ② Central display with touch functionality
  - Home screen overview
  - Operating the touchscreen
- ③ Switch panel with:
  -  Fingerprint sensor

-  Switches the MBUX multimedia system on or off
-  Switches sound on or off
-  Adjusts the volume



Vehicles with MBUX Hyperscreen

- ① Touch Control and control panel for the MBUX multimedia system
  - Operating Touch Control
- ② Central display with touch functionality for the driver
  - Home screen overview
  - Operating the touchscreen

- ③ Front passenger display with touch functionality
  - Home screen overview
  - Operating the touchscreen
- ④ Switch panel with:
  -  Fingerprint sensor
  -  Switches the MBUX multimedia system on or off
  -  Switches sound on or off
  -  Adjusts the volume

Further operating options:

- Conducting a dialogue with the MBUX voice assistant.
- ① You can find further information about operation as well as about applications and services in the Digital Owner's Manual.

### Anti-theft protection

This device is equipped with technical provisions to protect it against theft. More detailed information about anti-theft protection can be obtained at a qualified specialist workshop.

## Zero Layer

### Function of the Zero Layer

The Zero Layer provides you with dynamic content from the MBUX multimedia system and is used to quickly access and control the applications you use. When you select  on the central display, the digital map with the applications appears in the lower display area. Compared to the home screen with a classic menu, the steps required to call up the applications are reduced. You can switch between the Zero Layer and the home screen with a classic menu.

The applications can be hidden from the display area and shown again.

The Zero Layer provides the following modules and applications:

- EQ module and navigation module
 

The EQ module is always shown on the digital map. In the expanded view, charging settings and navigation functions are offered.
- Entertainment (media, radio) and telephone
 

When the lower display area is shown, the entertainment sources are always displayed.

A mobile phone must be connected to the MBUX multimedia system for the phone to be displayed.

- Active applications

The lower display area shows an active message programme, for example.

- Suggestions

Suggestions are displayed on the lower display area based on context and your user behaviour. These are, for example, dialled phone numbers, active message programmes or vehicle functions.

- Online voice applications

In the lower display area, context-dependent services that can be executed via voice are available for direct access.


The applications are first displayed in a reduced view. By tapping on them, you can operate them or open the associated menu (expanded view).

A long press on a suggestion opens a context menu in which further functions are available.

The learning function can be switched on and off for the options (→ page 317).

## Overview of the Zero Layer

### Digital map and user-specific applications (example)



- ❶ EQ module (reduced view)
- ❷ Enters a destination
- ❸ Calls up the Control Centre
- ❹ Calls up user profile settings
- ❺ Content sharing menu
- ❻ Status line
- ❼ Suggestions

Requirement: suggestions are activated (→ page 317).

- ❽ Active application, e.g. message programme



Press briefly: displays all applications and the global search (→ page 308)

Press and hold: calls up the home screen with classic menu

- ❿ Entertainment sources (media, radio) and telephone

Requirement for phone: the mobile phone is connected to the MBUX multimedia system.

The Zero Layer shows the digital map and the user-specific applications.

The following user-specific applications are displayed in the lower display area:

- Suggestions ❼
- Active applications ❽
- Entertainment sources and telephone ❿
- Online voice applications

The lower display area can be hidden and shown (→ page 308).

### Information about entertainment sources

You can operate the applications in the reduced view or in the menu (expanded view) (→ page 308).

Examples:

- Control a media source, e.g. pause/play, next track, set a station
- Select tracks from the current playlist or stations from the station list
- Select a media source

The media source must be connected to the MBUX multimedia system.

### Information about the telephone

To use the functions, your mobile phone must be connected with the MBUX multimedia system.

Requirement for suggestions: the [Calls & messages](#) option is activated in the suggestions.

Examples:

- Answer a call and calling a missed call  
The missed calls are displayed for the mobile phone currently connected to the MBUX multimedia system.

- Display contacts and call list and calling a contact
- Use voice functions
- Suggest contacts

The contacts are suggested for the mobile phone connected to the MBUX multimedia system. No contacts are suggested for a mobile phone that is linked to another user profile.

- Write messages to contacts (suggestion)
- Connect a device via the device manager (suggestion)

### Information about active applications

The following functions are available:

- Operating massage programmes
- Raising or lowering the vehicle level

### Suggestions for comfort and vehicle functions as well as navigation

Requirement: the [Comfort](#), [Vehicle](#) and [Navigation](#) options are activated in the suggestions.

- Operating massage programmes

For example, the multimedia system suggests a programme at a certain time.

- Opening and closing the tailgate  
Requirement: the vehicle is equipped with boot lid convenience closing.
- Opening and closing the comfort doors  
Requirement: the vehicle is equipped with comfort doors.
- Setting the vehicle level
- Making heating settings
- Activating/deactivating Parking Assist PARKTRONIC
- Selecting previous destinations and destinations from favourites

### Information on online voice applications

Requirement: the [Online voice services](#) option is activated in the suggestions.

The suggested voice applications are made available online and are based on your previous voice inputs.

Examples:

- What will the weather be like tomorrow?

- Play the messages.
- Start Geoquiz.
- Open the garage door.

### Calling up and operating the Zero Layer

#### Calling up the Zero Layer

When the vehicle has been switched on, the Zero Layer is displayed with the digital map. Navigation is active.

- ▶ **From another application:** press the  button on the right side of the steering wheel.

or

- ▶ Tap on .

#### Operating applications in the reduced view (examples)


- ▶ **Media:** to play the previous or next track, tap  or .
- ▶ **To answer a call or call a missed call:** tap on the contact.  
After the connection has been established, the call functions are available.
- ▶ **To end a call:** tap on the contact again.

- ▶ **To reply to message:** tap on a message and dictate the message via the MBUX voice assistant.
- ▶ **To start a massage program:** tap on the application and start the massage programme.
- ▶ **To select a previous destination:** tap on the application and select one of the previous destinations.
- ▶ **To select a destination from the favourites:** tap on the application and select the destination.

#### Hiding and showing the display area with applications

- ▶ **To hide:** pull the applications down.
  - ▶ **To show:** pull the bar above  upwards.
- or
- ▶ Select .
- or
- ▶ Press the  button on the steering wheel on the right.

### EQ module (expanded view)



- ① Sets the charging program (→ page 211)
- ② Current state of charge of the high-voltage battery
- ③ Maximum state of charge (depending on the setting)
- ④ Sets the next charging break (to use a less expensive tariff)

- ⑤ Setting the departure time
- ⑥ Opens the socket flap
- ⑦ Activates or deactivates ECO charging


▶ Tap on the EQ module (→ page 306).  
The charging settings are displayed.

Additional EQ and navigation functions are available in the lower menu bar:

- Symbol 
  - Enters a destination
- **Route**
  - The route shows charging stops and the destination.
- **Range**
  - Switches range maximisation on or off (→ page 188).
- **Consumption**
  - The current and average fuel consumption is displayed.
- Symbol 
  - Makes settings for **View**, **Messages & tones** and **Route**.

▶ To close the menu: select .

### Navigation module (expanded view)




Example: navigation module with active route guidance

- ① Arrival time at charging stop, type of charging station

- ② Charging stop shows the charging time recommended by the navigation with Electric Intelligence as well as states of charge on arrival and onward journey for an optimal travel time
  - ③ Distance from current vehicle position and remaining driving time
  - ④ Searches for an additional charging station
- ▶ Tap on the EQ module (→ page 306).  
▶ Select **Route** in the lower menu bar.



### Operating a menu in the lower display area (example: active massage programme)



- ❶ Selects a massage programme
- ❷ Starts/stops a massage programme for the driver
- ❸ Starts/stops a massage programme for the front passenger
- ❹ Sets the massage programme intensity for the driver's or front passenger seat

- ▶ Tap on the application.  
The expanded view of the application is displayed.
- ▶ **To close the menu:** select

### Opening and closing the context menu for a suggestion

- ▶ Press and hold on a suggestion.  
The context menu opens and shows the **Do not suggest** option, for example.
- ▶ **To close:** swipe downwards.

### Removing a suggestion from the display area

- ▶ Swipe the suggestion upwards.

### Showing all applications




- ▶ Press briefly.  
Available applications ❶ are displayed. The global search is available.

- ▶ **To hide applications:** briefly press again.

### Switching between Zero Layer and home screen with classic menu

- ▶ Long press on .  
The home screen with classic menu is shown.
- ▶ **To return to the Zero Layer:** press and hold on .

## Home screen overview




- ① Status line
- ② Calls up user profile settings and switches user
- ③ Uses the global search
- ④ Calls up the Control Centre (pull down)
- ⑤ Calls up favourites
- ⑥ Displays in the status line

- ⑦ Calls up applications
- ⑧ Quick-access to application
- ⑨ Global menu
  - ⏮ Calls up previous menu
  - 🏠 Press and hold: switches between home screen and zero layer
  - ⏪ Previous track or previous radio station
  - ⏩ Next track or next radio station
- ⓘ During a telephone call, the call duration is displayed in global menu ⑨.

The following functions are called up in the Control Center:

- Notifications Centre
- Content sharing menu
- Favourites
- Vehicle quick-access

## Content sharing menu in the Control Center



Example: Content sharing menu

- ① Calls up a menu
- ② Central display with active content (cover display)
- ③ Front passenger display


- ④ Displays animation for content sharing
- ⑤  Bluetooth® headphones connected to the front passenger display on the right

To share content, drag a display and drop it over another display.

To control media playback, tap a display.

## Operating the MBUX multimedia system

### Using Touch Control



- ①  Shows the home screen
- ② Touch Control

    swipe in the direction of the arrow (navigate)


 Press (confirm)

- ③  Returns to the previous display
- ④  Makes or accepts a call
- ⑤  Rejects or ends a call
- ⑥ Increase volume: swipe upwards  
Reduce volume: swipe down
-  Switch off the sound: press
- ⑦  Calls up favourites (press briefly) or adds favourites (press and hold)
- ⑧  Starts the MBUX voice assistant

You can navigate through menus and lists via the touch-sensitive surface of Touch Control ② using a **single-finger swipe**, for example:

- ▶ **To enter a character:** select a character using the keyboard and press on Touch Control ②.
- ▶ **To select a menu option:** scroll in a list and press Touch Control ②.
- ▶ **To move the digital map:** swipe in any direction.


### Using the touchscreen



Example: control elements for vehicles with a central display

- ① Fingerprint sensor
- ② Switches the MBUX multimedia system on or off
- ③ Switches the mute function on/off

- ④ Adjusts the volume  
Press **-** or **+** or swipe over the button



Example: control elements for vehicles with an MBUX Hyperscreen

- ① Adjusts the volume  
Press **-** or **+**.
- ② Fingerprint sensor

- ③ Switches the MBUX multimedia system on or off
- ④ Switches the mute function on/off

- ▶ **To select a menu item or entry:** tap on a symbol or an entry.
- ▶ **To increase the map scale:** tap twice quickly with one finger.
- ▶ **To reduce the map scale:** tap with two fingers.
- ▶ **To enter characters with the keypad:** tap on a button.
- ▶ **To navigate in menus:** swipe up, down, left or right.
- ▶ **To use handwriting to enter characters:** write the character with one finger on the touchscreen.
- ▶ **To zoom in and out of the map:** move two fingers together or apart.
- ▶ **To enlarge or reduce the size of a section of a website:** move two fingers together or apart.
- ▶ **To turn the digital map:** turn anti-clockwise or clockwise using two fingers.

▶ **To move the digital map:** touch the touchscreen and move your finger in any direction.

▶ **To save the destination in the digital map:** touch the touchscreen and hold until a message is shown.

▶ **To set the volume on a scale:** touch the touchscreen and move the finger to the left or right.

▶ **To call up a global menu in the applications:** touch the touchscreen and hold until the **Options** menu appears.

### Function of the MBUX voice assistant

**⚠ WARNING** Risk of distraction from information systems and communications equipment

If you operate information systems and communication devices integrated in the vehicle when driving, you could be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- ▶ Only operate this equipment when the traffic situation permits.
- ▶ If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.

For your own safety, always observe the following points when operating mobile communications equipment and especially your voice control system:

- Observe the legal requirements for the country in which you are driving.
- If you use the voice control system in an emergency your voice can change and your telephone call, e.g. an emergency call, can thereby be unnecessarily delayed.
- Familiarise yourself with the voice control system functions before starting the journey.

Using the MBUX voice assistant, vehicle functions and various areas of the MBUX multimedia system can be operated by voice input. The MBUX voice assistant is operational approximately half a minute after switching on the ignition and can be

operated from all seats. Further information and examples of voice commands can be found in the Digital Owner's Manual.

You can use the MBUX voice assistant to operate the following functions depending on the vehicle equipment:

- Telephone
- Text message and e-mail
- Navigation
- Radio and media
- Vehicle functions
- Online functions

Full functionality of the voice control system is only available for you with activation of online voice control.

### Conducting a dialogue

#### Starting a dialogue

- ▶ Say "Hey Mercedes" to activate the MBUX Voice Assistant. Voice activation must be switched on in the multimedia system.

or

- ▶ Press the  button on the multifunction steering wheel. A blue line appears in the MBUX multimedia system. The dialogue can be started. For the dialogue with the MBUX Voice Assistant, you can use complete sentences of colloquial language as voice commands. Voice activation can also be directly combined with a voice command, e.g. "Hey Mercedes, how fast can I drive?".

#### Calling up help

- ▶ **For information about the MBUX Voice Assistant:** say "Hey Mercedes, what can you do?"
- ▶ **Digital Owner's Manual:** "Show me the Owner's Manual". The full extent of the Digital Owner's Manual is available when the vehicle is stationary.

#### Operating functions (examples)

- ▶ **To operate the navigation:** "Search for an Asian restaurant, but not Japanese, in South London."
- ▶ **To operate the phone:** "Call my father."

- ▶ **To change the system language to English (short command):** "Change language to English".
- ▶ **To operate the radio:** "Show me the list of radio stations."
- ▶ **To operate media:** "Switch on random playback."
- ▶ **To operate vehicle functions:** "Switch the seat heating to level 2."
- ▶ **To operate online functions:** "What's the time in Sydney?"
- ▶ **To ask a question about the vehicle:** "Do I have Blind Spot Assist?"

### Function of the driver camera

The driver camera is located in the driver display.

The driver camera detects the following characteristics:

- Head position
- Viewing direction
- Eyelid closure characteristics

- Driver's face

- ❗ The driver camera records image data for applications such as ATTENTION ASSIST and facial recognition, for example. The camera converts the image data directly into meta data. No image data is saved in the process. The data is only processed in the vehicle and is not transmitted from the vehicle. The driver camera is automatically activated each time the vehicle is opened with the key.

The driver camera must be set up for face detection before use. Teaching-in biometric data (→ page 317).

### System limits

The system may be impaired or may not function in the following situations:

- The camera is covered or dirty, misted up or scratched.
- The driver's face and/or eyes are covered.
- The driver is wearing glasses that block infrared.

### Display messages

In the following situations display messages may be shown:

- The driver camera is inoperative.  
The camera is faulty.  
The [Driver camera inoperative See Owner's Manual](#) message appears.
- The driver camera cannot capture the position of your head.  
The [Change steering wheel/ seat position until 6 dots are visible on the upper edge of the screen](#) message appears.
- The view of the driver camera is reduced or restricted.  
The [Driver camera view currently restricted See Owner's Manual](#) message appears.

### Notes on care

Please comply with the notes on caring for the interior (→ page 375).

## Switching the driver camera on or off

Multimedia system:

→  >> Settings >> System

>> Intelligent assistants

▶ Select **On** or **Off**.

When the driver camera is switched off, the following functions are not available or limited:

- The microsleep detection of ATTENTION ASSIST (→ page 225)

- The facial recognition

This function serves as sensor input for authentication and unlocking of the user profile and protected applications. (→ page 317)

## Information on users, suggestions and favourites

**⚠ WARNING** Risk of becoming trapped during adjustment of the driver's seat after calling up a driver profile

Selecting a user profile may trigger an adjustment of the driver's seat to the position saved

under the user profile. You or other vehicle occupants could be injured in the process.

- ▶ Make sure that when the position of the driver's seat is being adjusted via the multimedia system, no people or body parts are in the seat's range of movement.

If there is a risk of someone becoming trapped, stop the adjustment process immediately:

- ▶ a) Tap the warning message on the central display.

or

- ▶ b) Press a memory function position button or a seat adjustment switch on the driver's door.

The adjustment process will be stopped.

The driver's seat is equipped with an access preventer.

If the driver's door is open, the driver's seat will **not** be set after calling up the driver's profile.

## User profiles and user-specific content

Prerequisites for the vehicle owner:

- You have a Mercedes me user account.
- You have a Mercedes me PIN.
- You have agreed to the terms of use.
- The vehicle is linked to a Mercedes me user account.

**i** If one of the pre-requisites listed is missing or if no user profile has been selected, the data described in the following section will be saved in the vehicle as the standard setting. Standard settings can be changed by all vehicle users.

User profiles save personal settings. If the vehicle is used by several people, a person can change their profile settings without changing the settings of other users.

You can individualise a user profile in the vehicle using the set-up assistant or using the settings in your user profile. Some settings, e.g. the Mercedes me PIN and a profile photo are made in the Mercedes me app or in the Mercedes me Portal.

User-specific content and applications with personal data are protected by different levels of security. To access protected content, the Mercedes me PIN and, depending on the vehicle equipment, biometric sensors can be used.

**i** The security level is set by the multimedia system and calculated from the combination of all sensor inputs. Some security levels cannot be turned off.

**i** When a user profile is activated, the following personalised comfort systems, for example, can be adjusted or their settings loaded:

- Seat
- Ambient light
- Outside mirrors
- Blinds
- Climate control settings

If the user profile is activated when driving then the driver's seat position will not be adjusted.

Depending on the vehicle equipment you can, as a user, save the following settings, for example:

- Driver's seat, steering wheel and mirror settings
- Climate control
- Ambient lighting
- Radio (including station list)
- Suggestions and favourites

### Suggestions

The vehicle can learn the habits of the driver. It then makes suggestions regarding navigation destinations, phone numbers and music preferences. The requirements for that are the selection of a user, your consent to the recording of data and sufficient collected data.

### Favourites

Favourites offer you quick access to frequently used applications. 100 favourites are available in total.

## Configuring users, suggestions and favourites

### Requirements:

- To use the set-up assistant: the vehicle is stationary.

Multimedia system:

   **Change user**

### Adding a user

- ▶ Select  **Add user** .  
A QR code is loaded.
- ▶ Scan the displayed QR code with the Mercedes me app or any QR code scanner on a mobile device. If the Mercedes me app is not yet installed on your mobile device, you will be directed to the store of your mobile device.
- ▶ Follow the directions in the app.  
The vehicle is connected with your Mercedes me user account. This automatically creates your user profile in the vehicle.  
  
If only your user profile is available, it will be loaded automatically.



If more than one user profile is available, you will be directed to the user selection.

When the vehicle is stationary, the set-up assistant starts automatically after user selection.

### Protecting user-specific content and applications

If you add a new user, access protection is already activated for the user profile. The Mercedes me PIN and, depending on the vehicle equipment, biometric sensors are available for access. Biometric sensors must be taught in the vehicle. The authentication process then takes all taught-in and available sensors into account.

The following user-specific content and applications are protected, for example:

- User selection and user profile settings
- Biometric sensors

The teaching-in of biometric sensors is protected.

- Suggestions

The data and determination of the most probable navigation destinations, media sources,

radio stations, contacts and messages are protected.

- ENERGIZING COACH

The recorded health data and their evaluation are protected.

- Mercedes me connect store

The purchase of services is protected.

▶ Switch **Protect content** on or off.

▶ Switch **Access protection** on or off.

❗ When access protection is switched off, your user profile can be viewed from any seat and changes can be made.

❗ Access protection is switched on or off on a vehicle-specific basis.

### Teaching in, editing and deleting biometric data

The biometric data models are saved in the sensors in the vehicle. If recognition has been taught-in, this sensor serves as a contributory factor for authentication on the multimedia system.

▶ Select **Protect content**.

▶ Select **Facial recognition**, **Fingerprint recognition** or **Voice recognition**.

❗ If necessary, authenticate yourself on the multimedia system.

### Authenticating using face recognition

▶ Close the driver's door or fasten the driver's seat belt.

▶ Look at the driver's display for about five seconds.

Your face is scanned. A message in the driver's display shows whether facial recognition was successful or not. You can unlock your user profile and protected applications with the facial scan.

### Authenticating using fingerprints

▶ Place and lift your finger several times on the fingerprint sensor under the touchscreen (→ page 304).

The finger is scanned. If the scanning procedure is successful, a message appears on the central display. You can unlock your user profile and protected applications with your fingerprint.

### Authenticating using voice recognition

- ▶ Speak the sentence shown on the central display and follow the voice assistant's instructions.
- If the voice recognition was successful, a message appears on the central display. You can unlock your user profile.
- ❗ Avoid background or disturbing noises during voice recognition.

### Deleting biometric data

- ▶ Tap on  , for example, behind **Facial recognition**.
- ▶ Select **Yes**.

### Teaching in the vehicle key for profile selection

- ▶ Select **Protect content**.
  - ▶ Select **Key recognition**.
  - ▶ Have the key ready and follow the set-up assistant's prompts.
- The user profile is linked to the selected key. If you open the vehicle with the key, the light, mirror and seat settings for your user profile

are pre-activated. The key you are currently using for unlocking is used.

The key is only stored for the driver and for one user profile.

### Selecting a user

- ❗ When you call up your driver profile, the driver's seat and the steering wheel can be set. You can cancel the setting process with the following actions:
    - Press **Tap here to cancel**. message on the central display.
    - Press one of the seat operating buttons in the driver's door.
  - ▶ Select **Change user**.
  - ▶ Select a user.
  - ▶ When requested to do so, authenticate with the Mercedes me PIN or a taught-in biometric characteristic.
- The user profile is loaded and activated.
- ❗ If you select **Continue without selecting user**, no specific settings for the user profile are loaded.

### Configuring and deleting suggestions

- ▶ Select .
  - ▶ Select **Settings**.
  - ▶ Select **System**.
  - ▶ Select **Suggestions**.
  - ▶ Select .
  - ▶ Switch the options on or off individually.
- If an option is switched on and sufficient data has been gathered, personalised suggestions based on your user behaviour will be offered to you on the zero layer. These are, for example, visited navigation destinations, dialled phone numbers as well as suggestions based on your music preferences.
- ▶ **To delete collected suggestions:** select .
  - ▶ Select **Ja** (Yes).
- The suggestions are reset.

### Adding favourites from categories

- ▶ Select .
- ▶ Select .
- ▶ Select .

- ▶ Select  [Create new favourite.](#)
- ▶ Select the category.
- ▶ Select a favourite.

## System settings

### Overview of the system settings menu

In the system settings menu, you can make settings in the following menus and control elements:

- Display:
  - Display brightness
  - Screensaver for the front passenger display (vehicles with MBUX Hyperscreen)
- Control elements:
  - Keyboard language and handwriting recognition
  - Sensitivity of the Touch Controls
  - Haptic operation for the touchscreen
- MBUX voice assistant
- MBUX Interior Assistant

- Sound
  - Entertainment
  - Navigation and traffic announcements
  - Telephone
  - Voice amplification
- Data protection
- Connectivity:
  - Wi-Fi, Bluetooth®, NFC
- Time & date
- Language
- Units for distance
- System PIN
- Software update
- System reset

### Overview of software updates

Important software updates may be necessary for the security of your multimedia system's data. Install these updates, or else the security of your multimedia system cannot be ensured.

The multimedia system displays a corresponding message when a software update is available.

If the [Automatic online update](#) option is active, software updates are downloaded automatically. If the option is deactivated, you will be informed of new software updates once. The software updates are available for downloading for a limited period of time.

Carrying out a software update:

- You can start software updates via the communication module.
  - You can start software updates via a Wi-Fi hotspot.
  - You can start map updates from an external medium.
-  Online software updates cannot be performed via external Wi-Fi hotspots that are encrypted using TKIP.
-  To complete software updates via the communication module, the vehicle must be connected with the Internet and a Mercedes me user account.

- ❗ To complete software updates via Wi-Fi, the vehicle must be connected to an external Wi-Fi hotspot.

A software update consists of three steps:

- Downloading or copying of the data required for installation
  - Installation of the downloaded software update
  - Activation of the downloaded software update.
- ❗ It may be necessary to restart the MBUX multimedia system after completion of a software update.
  - ❗ While some software updates are being downloaded, the multimedia system cannot be operated and the vehicle functions may be restricted.
  - ❗ Some software updates require a safe vehicle status for the installation to be completed. They can only be carried out in a safely parked vehicle with the vehicle switched off.


**For software updates requiring a safe vehicle status:** when the last installation step is reached, a message appears on the central display after the

vehicle is switched off. Follow the step-by-step instructions on the central display to complete the installation.

There are software updates that can only be installed when the vehicle is safely parked, there are no more people in the vehicle and the vehicle is locked.

#### Availability of the driver and central display

During the installation of software updates, it is not possible to use the vehicle, central display and driver's display. You may receive the following display message when an installation is running:



- ❗ The display message does not appear every time a software update is installed.

In rare cases, an error can occur during the installation. The multimedia system automatically attempts to restore the previous version.

If it is not possible to restore the previous version, the display message shown above appears every time the vehicle is started.

#### Failure of the driver's display

If the driver's display fails or there is a malfunction, you may not recognise limitations in the functions of systems relevant to safety or the speed display, for example. The operating safety of the vehicle may be impaired. Drive on carefully and have the vehicle checked at a qualified specialist workshop immediately (→ page 445).

Further information about software updates can be found at <https://me.secure.mercedes-benz.com>.

#### Failure of the central display

If the central display fails or the display message shown above is shown continuously, several systems such as the reversing camera, PARKTRONIC or climate control are no longer available. Drive on carefully and consult a specialist workshop as soon as possible.

### Front passenger display failure (only vehicles with MBUX Hyperscreen)

If the front passenger display has failed or a display message appears permanently, functions and systems are no longer available via the front passenger display. Visit a qualified specialist workshop.

### Setting up a Wi-Fi hotspot

#### Requirements:

- The Wi-Fi function is activated on the multimedia system and the communication device to be connected.
- The communication device to be connected supports at least one of the types of connection described.

The connection types shown depend on the device to be connected. The function must be supported by the multimedia system and by the device to be connected. The type of connection established must be selected on the multimedia system and on the device to be connected.

- ❗ Some functions may first need to be activated on the communication device being connected. More detailed information can be found in the manufacturer's operating instructions.
- ❗ The use of the vehicle data tariff by external devices is not available in all countries.

Multimedia system:

➔  ➔ Settings ➔ System  
➔ Internet and Bluetooth

- ❗ The availability of the functions is dependent on the country.

▶ Select **Wi-Fi**.  
The controller is to the right: Wi-Fi is switched on.

When the Wi-Fi function is switched on, you can connect the multimedia system with external hotspots or make it available as a hotspot for external devices.

When the Wi-Fi function is switched off, it is not possible to establish a hotspot connection.

- ❗ Depending on the vehicle equipment, you can purchase a data package directly from a mobile phone network provider via the

Mercedes me Store. To be able to use the data package, you conclude a separate contract with a mobile phone network provider via the Mercedes me Store, which can be terminated at any time and for which there are no costs. This contract is a prerequisite for using the services from the previously purchased package. The availability of this option is dependent on the country. If the data package option is not available or can be upgraded, you can purchase data volume directly from the mobile phone network provider for a fee.

- ❗ The use of the vehicle data tariff by external devices is not available in all countries.

#### Using the multimedia system as a Wi-Fi hotspot

- ▶ Select **MBUX hotspot**.
- ▶ Select one of the following connection options.

#### Connecting using a QR code

Requirement: an app for scanning the QR code is installed on the device being connected.

Alternatively: the device being connected has an integrated QR code scanner (see manufacturer's operating instructions).

- ▶ Scan the QR code shown.  
The Wi-Fi connection is established.

### Connecting using NFC

- ▶ Activate NFC on the device to be connected.
- ▶ When the NFC icon is displayed in the **MBUX hotspot** menu, hold the device to be connected to the NFC interface.
- ▶ Follow the instructions on the device.  
The Wi-Fi connection is established.

### Connecting using a security key

- ▶ Select the vehicle from the device to be connected. The vehicle is displayed with the **MBUX XXXXX** network name.
- ▶ Enter the security key which is shown in the central display on the device to be connected.
- ▶ Confirm the entry.

### Generating a new security key

- ▶ Select the hotspot name **MBUX XXXXX** in the **MBUX hotspot** menu.
- ▶ Confirm the prompt with **Yes**.  
A new security key is generated.

A connection will be established with the newly created security key.

- ❗ When a new security key is generated, all existing Wi-Fi connections are then disconnected. If the Wi-Fi connections are being re-established, the new security key must be entered.

### Using a mobile communication device as a Wi-Fi hotspot (tethering)

- ❗ This function is country-dependent.
- ▶ Select the **Connect to the Internet** option in the **Internet and Bluetooth** menu.
- ❗ The Wi-Fi function on the mobile phone and Internet access via Wi-Fi must be activated (see the manufacturer's operating instructions).
- ▶ Select **Search for access**.

- ▶ Select the network.
- ▶ Log in to the Wi-Fi network.  
or

- ▶ Select the mobile phone with the  Wi-Fi symbol.

- ❗ With external Wi-Fi hotspots, which are encrypted via TKIP, online software updates cannot be carried out via the external Wi-Fi hotspot.

## System language

### Notes on the system language

This function allows you to determine the language for the menu displays and the navigation announcements. The selected language affects the characters available for entry. The navigation announcements are not available in all languages. If a language is not available, the navigation announcements will be in English.

## Setting the language

Multimedia system:

→  » Settings » System  
» Language

## Setting the system language

A list of the available system languages is shown.

- ▶ Select a language.  
The system language is switched to the selected language.

## Resetting the multimedia system (reset function)

**⚠ WARNING** Risk of accidents due to failure of the central display functions

While the multimedia system is being reset, its functions such as the reversing camera are not available.

- ▶ Only reset the multimedia system when the vehicle is stationary.

## Requirements:

- The vehicle is switched on.

- Some settings can only be reset when the vehicle is stationary.

Multimedia system:

→  » Settings » System » Reset

When resetting the system, personal data and settings are deleted, for example:

- Connected devices
- Individual user profiles
- Biometric data
- Vehicles with rear telephony: handset connection

- ❗ The data used and saved in the multimedia system by the driver assistance systems is deleted.
- ❗ Vehicles with rear telephony: The handset must be in the cradle while the system is reset.
- ▶ Select **Reset**.  
A query appears asking if the system should really be reset.

- ▶ Select **Yes**.

The multimedia system is reset to the factory settings. The multimedia system is restarted after the system reset.

- ❗ Due to data protection, as well as the function of individual driving systems and driving safety systems, it is a requirement to carry out a complete system reset before selling the vehicle or transferring it to a third party, or after use as a hire car.

## AMG TRACK PACE

### Function of AMG TRACK PACE

- ❗ This function is an on-demand feature and can be subsequently activated after vehicle purchase via Mercedes me. The Digital Owner's Manual contains further information on Mercedes me and on-demand features.

With AMG TRACK PACE, the driving characteristics on race tracks can be analysed and optimised. You can drive previously stored race tracks (e.g. Hockenheimring), or new tracks can be recorded and stored. The driven lap times are

stored for every track. These can be analysed and compared to other lap times to achieve the best possible race results. Additionally, acceleration and braking procedures can be measured and stored.

**Note:** Use AMG TRACK PACE only on closed-off routes outside the public traffic area. Adapt your driving style to your personal performance and environmental conditions. As the driver, you are solely responsible for driving your vehicle. Park your vehicle safely before operating the application.

## Setting Track Race

Multimedia system:

→ TRACK PACE → Track Race

### Recording a new track

- ▶ Select  **New track.**
- ▶ Select  **Start Record.** at the desired starting point.  
The track recording starts at this point.

During track recording, sectors can be set to divide up the track.

- ▶  Select **Set Sector.**
- ▶ Select  **Stop Recording** to end track recording or cross the starting line again.
- ▶ Confirm the prompt with **Yes.**
- ▶ Select the weather.
- ⓘ The temperature is determined automatically.
- ▶ Enter a name.
- ▶ Press  to confirm.  
The track is saved under the name entered.

### Searching by track name

- ▶ Select  **Search.**
- ▶ Enter the track name.  
Tracks with the searched name are displayed.

### Measuring time on a saved track

- ▶  Select **All tracks.**
- ▶ Select the desired track.

- ▶ Select .
- ▶ Select **Start timing** if you are already at the starting line.

or

- ▶ Select **Navigate to** for navigation to the starting line.

Timekeeping begins automatically when the starting line has been crossed.

- ⓘ When  is selected, the track display can be switched to AR. In addition, it is possible to switch to the telemetry display by selecting .
- ▶ Select  **Stop timekeeping** to end timekeeping.
- ▶ Confirm the prompt with **OK.**
- ▶ Select the weather.
- ▶ Select **Yes** to save the times driven for this track.

### Showing displays during Track Race

The following displays can be shown:

- Tyre temperature



- Mini map
- Sector overview
- Engine data
- G-force display
- Lap overview

▶ Select  **Start timing**.

▶ Select .

▶ Pull the desired display from the grid on the left or right edge of the central display.  
The displays are shown during the Track Race.

By selecting  on the active display, you can deactivate this.

### Displaying the analysis

▶  Select **All tracks**.

An overview of all the driven tracks appears.

▶ Select a track.

▶ Select a session.

The following data is displayed:

- Lap and sector times
- Average and maximum permissible speed
- Driver
- Vehicle
- Date
- Weather

▶ Select **Add recording** to use a different session as a reference value.

▶ Select  to return to the overview.

▶ Select **Diagram**.

▶ Set the desired parameters.  
The analysis is displayed.



- 1 Lap overview
- 2 Parameter overview
- 3 Editing parameters
- 4 Deleting parameters
- 5 Adding new parameters

**i** The following values can be set for the parameters, for example:

- Speed

- Longitudinal/lateral acceleration
- Steering angle
- Engine speed
- Engine oil/tyre temperature

Based on the analysis you can check and optimise driving characteristics for any position on the track.

### Exporting tracks (USB)

- ▶ Select  **Tracks**.  
An overview of all stored tracks appears.
- ▶ Select the desired track.
- ▶ Select options  for the desired track.
- ▶ Select **Export track to...**  
The selected track can be exported to a USB storage device connected to the vehicle.

### Editing tracks and recordings

- ▶ Select  **Tracks**.
- ▶ Select the desired track.
- ▶ Select options  for the desired track.
- ▶ Select **Rename** or **Delete**.

or

- ▶ Select a track.
- ▶ Highlight the desired recording.
- ▶ Select  options.
- ▶ Select **Exporting to...** or **Delete**.

### Setting Drag Race

Multimedia system:

↩ TRACK PACE ▶▶ Drag Race

### Measuring acceleration

- ▶ Select  **Drag race options**.
- ▶ Select **Acceleration**.
- ▶ Set a starting speed or select **Automatic**.  
Measurement begins as soon as the specified starting speed has been reached.
- ▶ Set a target speed.  
Measurement stops as soon as the specified target speed has been reached.
- ▶ Pull away and start the measurement.  
Measurement begins when the vehicle accelerates.

Measurement can be stopped early by interrupting the acceleration procedure.

### Quarter-mile race

- ▶ Select  **Drag race options**.
- ▶ Select **Quarter-mile**.
- ▶ Set a target distance.  
Measurement stops as soon as the specified target distance has been reached.
- ▶ Pull away and start the measurement.  
Measurement begins when the vehicle accelerates. Timing runs until the target distance or a maximum of one mile has been travelled.

Measurement can be stopped early by interrupting the acceleration procedure.

### Measuring braking

- ▶  **Drag race options**
- ▶ Select **Braking**.
- ▶ Set a starting speed or select **Automatic**.
- ▶ Pull away and start the measurement.

- ▶ Brake to a standstill.  
Measurement is incremental, in steps of 10 km/h to a standstill. If the braking procedure is started e.g. at a speed of 157 km/h, measurement starts as soon as 150 km/h has been reached.

### Storing and calling up measurement values

If measurement is completed or cancelled, a prompt appears asking whether the measurement should be saved.

- ▶ Confirm the prompt with **OK** to save.

### Calling up saved measurements

- ▶  Select **History**.
  - ▶ Select **Acceleration**, **Quarter-mile** or **Braking**.
  - ▶ Select a measurement.  
The desired measurement is displayed in detail.
- or
- ▶ Delete a measurement.

### Calling up the telemetry display

Multimedia system:



The telemetry display shows current vehicle data as a digital value and as a diagram. Up to four parameters can be selected that are to be shown in the display.

For example:

- Engine speed
  - Wheel angle
  - Speed
  - Steering angle
- ▶ Set the desired parameters.
  - ▶ Set the time.  
The set parameters are evaluated in the diagram for the time set.

### Configuring AMG TRACK PACE

**Requirements:**

To connect a mobile device to the TRACK PACE app:

- The TRACK PACE app is installed on the mobile end device.
- The mobile end device is connected to the multimedia system via Wi-Fi.  
The mobile end device is connected to the multimedia system via Wi-Fi .

Multimedia system:



### Connecting a mobile device via the TRACK PACE app

The TRACK PACE app makes it possible to record videos and to synchronise them with stored tracks.

- ▶ Select **TRACK PACE App**.
- ▶ Select **Authorise new device**.
- ▶ Start the TRACK PACE app on the device to be connected.
- ▶ Select **Continue** and confirm the authorisation prompt.  
A four-digit code is shown in the central display.

- ▶ Enter the code in the smartphone.  
The device is authorised.

### De-authorising the mobile device

- ▶ Select **TRACK PACE App**.
- ▶ Select a device.
- ▶ Confirm the message prompt with Yes.  
The device is de-authorised.

### Setting the TRACK PACE display in the head-up display and driver's display

- ▶ Select **IC and HUD contents**.
- ▶ Activate or deactivate the desired contents.  
The contents in the head-up display and the driver's display are adapted.
- ① For further information on the Head-up Display (→ page 300).
- ① Further information about the driver's display (→ page 298).

### Setting acoustic feedback

- ▶ Select **Acoustic feedback**.  
A scale with values from 0 to 10 is shown.
- ▶ Select a setting.

### Displaying statistics

- ▶ Select **TRACK PACE statistics**.  
Statistics on the current user profile are displayed.  
The following data is displayed:
  - Driving time
  - Track driven
  - Tracks recorded
  - Track Races recorded
  - Laps recorded
  - Drag Races recorded
  - Maximum design speed

### Activating the ambient light

If this function is active, the vehicle interior is lit red or green depending on Delta Time.

- ▶ Select **Ambient lighting**.
- ▶ Activate or deactivate the function.

### Adjusting the dashcam

If the vehicle is equipped with a dashcam, this can be used in AMG TRACK PACE.

- ▶ Select **Dashcam**.
- ▶ Select **Track Race** or **Drag Race** and activate **Activate recording**.
- ▶ You can set which overlay is to be used in the recorded video under **Video overlay contents**.

### Drive system settings

#### Calling up the energy flow display

Multimedia system:



- ▶ Select **Energy flow**.  
The energy flow in the vehicle is displayed.

## Navigation and traffic

### Notes on navigation

#### Route guidance with augmented reality

**⚠ WARNING** Risk of accident and injury as a result of distraction, incorrect depiction or wrong interpretation of the display

The camera image of the augmented reality display is not suitable as a guide for driving.

- ▶ Always keep an eye on the actual traffic situation.
- ▶ Avoid extended observation of the camera image.

**⚠ WARNING** Risk of accident and injury due to imprecise positioning of additional information

The additional information from the augmented reality display may be inaccurate and is not a substitute for observing and assessing the actual driving situation.

- ▶ Always keep an eye on the actual traffic situation when carrying out all driving manoeuvres.

### Switching navigation on

Multimedia system:



- ▶ Alternatively, press the  button on the steering wheel on the right (→ page 312). The Zero Layer with the digital map is displayed.

### Navigation overview

#### Digital map and user-specific applications



- ① Navigation module (reduced view) or EQ module (reduced view)

Route guidance active:

Navigation module shows in the reduced view the information relevant to the route, e.g. the next charging stop, the destination and a traffic delay

 ends the current route guidance

Tapping opens the navigation module in the expanded view with the [Route](#)

Route guidance not active:

EQ module is shown in the reduced view

Tapping opens the EQ module in the expanded view with the charging functions

- ② Enters a destination
- ③ Calls up the Control Center in the status line
- ④ Current vehicle position (vehicle symbol or arrow)
- ⑤ Display area with entertainment sources, phone, active applications and suggestions
- ⑥ Searches for POIs, e.g. charging stations  and parking facilities , as well as sets map orientation and map type
- ⑦ Navigation window shows the next manoeuvre (zoomed out view) or the route monitor (zoomed in view)

For example, with active route guidance, route sections of the route list, displays for upcoming driving manoeuvres, lane recommendations



Switches off navigation announcements



Switches on navigation announcements

The following map orientations ⑥ are available:

- 2D and to the north


- 2D and direction of travel
- 3D and direction of travel
- Map with complete route

❗ If the map is moved, the map switches between 3D direction of travel and 2D north orientation.

The following map types ⑥ are available:

- Daytime display
- Night-time display
- Satellite map


## Navigation module (expanded view)



- ① Arrival time at charging stop, type of charging station
- ② Charging stop shows the charging time recommended by the navigation with Electric Intelligence as well as states of charge on arrival and onward journey for an optimal travel time

- ③ Distance from current vehicle position and remaining driving time
- ④ Searches for an additional charging station

### EQ module (expanded view)



- ① Sets the charging program (→ page 211)
- ② Current state of charge of the high-voltage battery

- ③ Maximum state of charge (depending on the setting)
- ④ Sets the next charging break (to use a less expensive tariff)
- ⑤ Setting the departure time
- ⑥ Opening the socket flap
- ⑦ Activating or deactivating ECO charging

### Entering a destination


#### Requirements:

- **For online search:** an Internet connection is established.
- Mercedes me connect is available.
- You have set up a user account in the Mercedes me Portal.
- The vehicle is connected with the user account and you have accepted the terms of use.

Further information can be found at: <https://www.mercedes.me>

- The service is available and has been activated.

Multimedia system:



Example: entering a POI or address

- ① Input line with current entry
- ② Search result
- ③ Selects destination input, displays further destination inputs with double arrow
- ④ Deletes an entry

- ⑤ Adopts the search result in the input line and continues the search
- ⑥ Deletes the last character entered
- ⑦ Hides the keypad
- ⑧ Switches to handwriting recognition
- ⑨ Starts the MBUX voice assistant
- ⑩ Sets the written language
- ⑪ Switches to digits and special characters
- ⑫ Switches to upper-case or lower-case letters

▶ Enter the destination in ①. The entries can be made in any order.  
The search results are displayed in a list.

① Online search results for POIs may contain additional information, for example opening times and prices. The information is provided by an online map service.  
This online function is not available in all countries.

① You can enter a destination as a 3 word address from what3words.  
This option is not available in all countries.

▶ Hide the keyboard with **OK**.

▶ Select the destination in the list.  
The route is calculated.

① Observe the notes on the MBUX multimedia system (→ page 304).

### Calculating a route with Electric Intelligence and using settings for route guidance

#### Requirements:

- The destination has been entered.
- The destination address is shown.
- **For navigation with Electric Intelligence:**
  - Mercedes me connect is available.
  - You have a Mercedes me connect user account and the vehicle is connected with the account.
  - The "Navigation with Electric Intelligence" service is available and activated in the Mercedes me Portal.

The services "Navigation with Electric Intelligence", "Display of charging stations" and "Mercedes me Charge" are required for optimal function.

- The **Schedule charging stops** route option is switched on.



Example: detailed display

- ① Saves destination as a favourite (**Schedule charging stops** is switched on)  
Calls up alternative routes (**Schedule charging stops** is switched off)



- ② Calculates the route and starts route guidance
- ③ Selects a point of interest in the vicinity of the destination
- ④ Destination information, online content (e.g. pictures, opening hours), three-word address from what3words

After selecting a destination, Electric Intelligence automatically and intelligently calculates the route to the destination. This is updated during route guidance. The route with Electric Intelligence contains the required charging stations as intermediate destinations. The charging stations are determined taking account of the driving distance and the estimated charging times.

- ▶ Select one of the options.
- ① When the **Schedule charging stops** route option is switched off, a route without charging stations is calculated.
- ① If the destination is located in a multi-storey car park, for example, and corresponding data is available, the parking levels are displayed.

### Saving a destination as a favourite

- ▶ Select  **Favourite**.
- ▶ Select an option.

### Calling up the route overview

- ① When **Schedule charging stops** is switched off, this option is available instead of the favourites function.
- ▶ Select **Routes**.
- ▶ Select an alternative route.

### Starting route guidance

- ▶ Select  **Let's go!**.

### Calling up the detailed display with destination address

- ▶ Pull the bar above the  **Let's go!** symbol upwards.  
Depending on the destination selection and availability, online content, for example ratings, prices and weather information, is shown.
- If the destination is in a different time zone, a message is displayed.

- ▶ **To share a destination:** select  **Share**.  
This option allows you to scan the displayed QR code.

- ▶ **To call up an Internet address:** if a web address is available, select **www**.

- ▶ **To call the destination:** if a telephone number is available, select **Call**.

### Searching for POIs in the vicinity of the destination shown

- ▶ Select **In the vicinity**.
- ▶ Search using categories, enter a search entry or search for a personal POI.

### Switching on the Electric Intelligence route option

- ▶ Select  in the navigation module (→ page 330).
- ▶ Select **Route**.
- ▶ Activate **Schedule charging stops**.  
If the route has been calculated and the state of charge of the high-voltage battery is not sufficient to reach the destination, charging stations are set automatically as intermediate destinations.

### Setting the state of charge of the high-voltage battery when the charging station and destination are reached

- ▶ Select  in the navigation module (→ page 330).
- ▶ Select **Route**.
- ▶ Select **Charge level at destination** or **Charge level at charging stations**.
- ▶ Move the control knob to the left or right and set the preferred state of charge in percent (%).  
The destination or charging station along the route is reached with the set state of charge.

To reach a charging station, the system uses the battery capacity, e.g. up to 10 % residual energy content (state of charge). You can increase this state of charge on arrival at the charging station and destination, e.g. to 25 % at the charging station and 50 % at the destination.

- ❗ In the event of increased energy consumption while driving, e.g. with headwind, the following options are available on the system side:
  - The charging station is safely reached even at states of charge of less than 10 %.
  - Navigation with Electric Intelligence selects a closer charging station for the route.
- ❗ If a charging facility is available at the destination, the state of charge can be lowered below 10 %. The **Min.** message appears on the central display. Make sure that the range monitor is switched on.

### Selecting a provider for charging stations

- ▶ Select  in the navigation module (→ page 330).
- ▶ Select **Route**.
- ▶ Activate or deactivate **Mercedes me Charge**. If the option is activated, only charging stations payable with Mercedes me Charge are taken into account when selecting the charging station.

or


- ▶ Activate **All**.  
All charging stations known to the navigation system are taken into account when calculating routes with Electric Intelligence, regardless of the type of payment.  
It may be necessary to register with the provider.

### Switching the range monitor on or off

The activated range monitoring assists with messages on the driver and central display to ensure safe arrival at the destination.

- ▶ Select  in the navigation module (→ page 330).
- ▶ Select **Route**.
- ▶ Activate or deactivate **Range monitoring**.  
To reach the destination with the state of charge set by the driver, the range is permanently monitored when the option is switched on.
- ❗ This function is not available in all countries.

## Displaying a route overview with charging station



- ① Arrival time at charging stop, type of charging station
- ② Charging stop shows the charging time recommended by the navigation with Electric Intelligence as well as states of charge on arrival and onward journey for an optimal travel time

- ③ Distance from current vehicle position and remaining driving time
- ④ Searches for an additional charging station

You can influence the route calculated by the navigation with Electric Intelligence using options ① and ④.

- ▶ Select one of the options.

### Ignoring a charging station

If you do not want to drive to the selected charging station, it can be removed for the current route guidance. The navigation with Electric Intelligence tries to plan the best possible alternative charging station for the route.

- ▶ Select ①.  
The expected charging power, the dynamic charge level display as well as the current state of charge and the predicted charging target are displayed, for example.
- ▶ Select **Ignore**.
- ▶ Select **Ignore during this journey**.  
The charging station is removed from the current route.

- ① After selecting **Details**, the detailed information about the charging station is displayed.

### Adding a charging station

If you want to drive to a charging station earlier on the route, for example, you can search for an additional charging station. If the charging station is suitable for the route, it will be accepted by the navigation with Electric Intelligence.

- ▶ Select ④.
- ▶ Select a charging station.
- ① You can also search for a charging station using the  symbol on the digital map or next to  **Where to?**

### Selecting a route type

- ▶ Select  in the navigation module (→ page 330).
- ▶ Select **Route**.  
The route is calculated as a fast route with a short journey time. Trailer mode is available if a trailer has been coupled with the vehicle. If available, you can select online routes. Traffic announcements for the route are taken into account via **Dynamic route guidance** .

- ❗ Trailer mode and online routes are not available in all countries and for all vehicles.

### Activating a commuter route

- ❗ A user profile has been created and **Allow destination suggestions** has been activated in the user options (→ page 317). Route guidance is not active.

- ▶ Select  in the navigation module.
- ▶ Select **Route**.
- ▶ Activate **Activate commuter route**.  
The navigation system automatically detects that the vehicle is on a commuter route.  
For the daily commuter route, traffic events on the route are also reported when driving without active route guidance.
- ▶ **To select or delete a commuter route:**  
select **Start** or .

### Avoiding or using route sections, e.g. motorways or ferries

- ▶ Select  in the navigation module.
- ▶ Select **Route**.

- ▶ Select **Avoid options**.
- ▶ Activate or deactivate the avoid option.

### Activating route guidance with augmented reality

- ▶ Select  in the navigation module.
- ▶ Select **View**.
- ▶ Select **Augmented reality video**.
- ▶ Activate or deactivate **Augmented reality video**.  
The AR camera's video image is shown on the central display before a turning manoeuvre. The video image includes additional information.

### Showing property information for route guidance with augmented reality

Road guidance with augmented reality is activated.

- ▶ Select  in the navigation module.
- ▶ Select **View**.
- ▶ Select **Augmented reality video**.

- ▶ Activate **Street names** and **House numbers**.  
During route guidance, the activated options are shown as additional information in the camera image.

### Using map functions

Multimedia system:



#### Increasing map scale

- ▶ When the map is shown, tap twice quickly with one finger on the central display.
- or

- ▶ Move two fingers apart on the central display.

#### Decreasing map scale

- ▶ Tap with two fingers on the central display.
- or

- ▶ Move two fingers together on the central display.

#### Moving the map

- ▶ When the map is displayed, swipe in any direction with one finger on the central display.

- ▶ **To reset the map to the current vehicle position:** select  **Centre**.

### Selecting map orientation

- ▶ Tap repeatedly on the  compass symbol on the map.

The map orientation changes in this order:

- The 3D map view is aligned to the direction of travel.
- The 2D map view is aligned to the direction of travel.
- The 2D map view is displayed so that north is always at the top.
- The map shows the complete route.

### Using services

#### Requirements:

- There is an Internet connection.
- Mercedes me connect is available.
- You have set up a user account in the Mercedes me Portal.

- The vehicle is connected to a user account and you have accepted the conditions of use for the service.

Further information can be found at: <https://www.mercedes.me>

- The service is available and has been activated.

Multimedia system:



### Showing traffic information

- ▶ Select  in the navigation menu (→ page 330).
- ▶ Select **View**.
- ▶ Activate **Traffic**.
- ▶ Activate **Traffic incidents** and **Free-flowing traffic**.  
Traffic incidents, for example roadworks, local area reports (e.g. fog) and warning messages, are shown on the route.

The traffic delay is displayed for the current route. The smallest value for the display for traffic delays is a minute.

### Displaying hazard warnings

If hazard warnings are available these can be shown as symbols on the map. The display depends on the settings for the **Traffic incidents** option.

- ▶ Set the option via .  
If the option is activated, all of the symbols are shown.

If the option is deactivated, the symbols are only shown when there is a hazard warning.

The following hazards may be shown on the map:

- Accidents and breakdowns
- Slippery roads, fog, crosswinds and heavy rain
- Hazards reported manually
- Vehicle with active hazard warning light
- Roadworks
- Additional hazards (if available)

### Displaying online map contents

- ▶ Select  in the navigation menu.

- ▶ Select **View**.
  - ▶ Switch on an online service, e.g. **Weather**. Current weather information is displayed on the navigation map, e.g. temperature or cloud cover.
- The service information is not shown in all map scales, e.g. weather symbols.

### Parking service

**!** **NOTE** Damage to the vehicle due to not observing the maximum permitted headroom clearance

If the vehicle height is greater than the maximum permitted headroom clearance, the roof and other parts of the vehicle may be damaged.

- ▶ Observe the signposted headroom clearance.
- ▶ If the vehicle height is greater than the permitted headroom clearance, do not enter.
- ▶ Observe the changed vehicle height with add-on roof equipment.

**!** **NOTE** Vehicle damage due to failure to observe local information and parking conditions

The data is based on the information provided by the respective service providers.

Mercedes-Benz does not guarantee the accuracy of the information provided in relation to the car park or parking area.

- ▶ Always observe the local information and conditions.

**i** This service is not available in all countries.

- ▶ Select  in the navigation menu and activate **Parking**.
- ▶ Tap on **P** in the map.
- ▶ Select a parking option.  
The map shows the parking options in the vicinity.

The following information is displayed (if available):

- Destination address, distance from current vehicle position and arrival time

- Information on the multi-storey car park/car park  
For example, opening times, parking charges, current occupancy, maximum parking time, **maximum access height**.  
The maximum access height shown by the parking service does not replace the need for observation of the actual circumstances.
  - Available payment options (Mercedes pay, coins, bank notes, cards)
  - Details on parking tariffs
  - Number of available parking spaces
  - Payment method (e.g. at parking meters)
  - Services/facilities at the parking option
  - Telephone number
- ▶ Calculate the route (→ page 333).

## Notes on the dashcam

**!** **NOTE** Observe legal regulations and data protection provisions

You are legally responsible for operation and use of the dashcam functions.

The legal requirements relating to operation and use of the dashcam can vary depending on the country in which the dashcam is operated.

This function is not permitted in all countries.

► Before using the dashcam, inform yourself about the content of the legal regulations, in particular the data protection regulations in the respective country of use.

► Observe the legal regulations, in particular the data protection regulations.

- ① To ensure secure operation, only use FAT32 or exFAT formatted USB storage devices.
- ① The file size and therefore the duration of single recording is limited by the limitations of the USB flash drive format. So FAT32 format-

ted USB flash drives do not allow files larger than 4 GB, for example.

When the file size is reached, the recording stops and you receive a notification.

① The following functions are available in the Gallery app:

- Switching write protection on or off
- Deleting video files

## Selecting a USB device for a video recording with the dashcam

### Requirements:

- At least one USB device is connected with the multimedia system .

Multimedia system:

→  ► Apps ► Dashcam

► Select the USB symbol.

► Select the USB device.

① When USB devices contain multiple partitions, recorded video files are not always displayed in the recording list.

Mercedes-Benz recommends that you use USB devices with one partition.

## Starting or stopping video recording with the dashcam

### Requirements:

- For recording and saving a video file: a USB device is connected with the multimedia system.
- The vehicle is switched on.

Multimedia system:

→  ► Apps ► Dashcam

► If several USB devices are connected with the multimedia system, select a USB device (→ page 340).

If no USB device is selected, a selection is made automatically when recording starts.

► **To select a recording mode:** select **Loop recording** or **Individual recording**. **Loop recording** records several short video files. When the memory is full, recording is continued automatically. In doing so, other

files will be overwritten starting with the oldest file.

**Individual recording** stops recording when the memory limit is reached. An individual recording is automatically protected against being overwritten.

► **To start:** select **Start recording**.

The length of the recording is shown. The **Please do not remove the storage medium** message appears. The video file is stored on the USB device.

► **To end:** select **End recording**.

- ❗ In some countries, geo-coordinates (longitude and latitude) are shown in the video image. For technical reasons, the geo-coordinates may show greater inaccuracies.

A report may appear in the following cases:

- **Individual recording:** the memory is full or there are only a few minutes recording time available. The video recording stops or will be stopped imminently.  
Change the USB device or delete a video file.

- The camera is not functional, the **Camera unavailable** message appears.

Have the camera checked in a Mercedes-Benz service centre.

- If the country border indication has been switched on.
- If an outdoor recording is started with the camera app during a dashcam recording, the dashcam recording pauses and resumes automatically after the camera recording is finished. A notification to this effect is displayed.

## Telephone

### Telephony

#### Notes on telephony

⚠ **WARNING** Risk of distraction from operating integrated communication equipment while the vehicle is in motion

If you operate communication equipment integrated in the vehicle when driving, you could be distracted from the traffic situation. This

could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.

⚠ **WARNING** Risk of accident from operating mobile communication equipment while the vehicle is in motion

Mobile communication devices distract the driver from the traffic situation. This can also cause the driver to lose control of the vehicle.

- As a driver, only operate mobile communication devices when the vehicle is stationary.
- As a vehicle occupant, use mobile communication devices only in the designated area, e.g. in the rear passenger compartment.



You must observe the legal requirements for the country in which you are currently driving when operating mobile communication equipment in the vehicle.

**⚠ WARNING** Risk of injury due to objects being stowed incorrectly

If objects in the vehicle interior are stowed incorrectly, they can slide or be thrown around and hit vehicle occupants. In addition, cup holders, open stowage spaces and mobile phone receptacles cannot always retain all objects within.

There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

- ▶ Always stow objects so that they cannot be thrown around in such situations.
- ▶ Always make sure that objects do not protrude from stowage spaces, luggage nets or stowage nets.
- ▶ Close the lockable stowage spaces before starting a journey.

- ▶ Always stow and secure heavy, hard, pointed, sharp-edged, fragile or bulky objects in the boot/load compartment.

Observe the additional information on stowing mobile communications devices correctly:

- Loading the vehicle (→ page 124)

**Bluetooth® connection:**

The menu view and the available functions in the telephone menu are in part dependent on the Bluetooth® profile of the connected mobile phone. If the mobile phone supports all the following Bluetooth® profiles, the full range of features is available:

- PBAP (Phone Book Access Profile)
  - The contacts on the mobile phone are shown automatically on the multimedia system.
- MAP (Message Access Profile)
  - The mobile phone message functions can be used on the multimedia system.
- HFP (hands-free profile)

- Wireless telephony is available on the multimedia system.
- SAP (SIM Access Profile)
  - The car telephone has access to the SIM card data and dials into the mobile phone network via the exterior aerial.

Irrespective of this, Bluetooth® audio functionality can be used with any mobile radio unit.

For information on the range of functions of the mobile radio unit to be connected, see the manufacturer's operating instructions.

**Network connection:**

The following cases can lead to the call being disconnected while the vehicle is in motion:

- You switch into a transmission/reception station, in which no communication channel is free.
- The SIM card used is not compatible with the network available
- A mobile phone with "Twincard" is logged into the network with the second SIM card at the same time

The multimedia system supports calls in HD Voice® for improved speech quality. A requirement for this is that the mobile phone and the mobile phone network provider of the person you are calling support HD Voice®.

Depending on the quality of the connection, the voice quality may fluctuate.

Further information can be obtained from a Mercedes-Benz service centre or at: <https://www.mercedes-benz.com/connect>

### Telephone menu overview



- ① Bluetooth® device name of the currently connected mobile phone/of the mobile phone
- ② Bluetooth® device name of the currently connected mobile phone/of the mobile phone (two phone mode)
- ③ Signal strength of the mobile phone network
- ④ Battery status of the connected mobile phone

- ⑤ Options
- ⑥ Messages
- ⑦ Calls up my devices
- ⑧ Numerical pad
- ⑨ Starts contact search

### Telephony operating modes overview

Depending on your equipment, the following telephony operating modes are available:

- A mobile phone is connected to the multimedia system via Bluetooth®.
- Two mobile phones are connected with the multimedia system via Bluetooth® (two phone mode).
  - You can use all the functions of the multimedia system with both mobile phones.

### Connecting a mobile phone

#### Requirements:

- Bluetooth® is activated on the mobile phone (see the manufacturer's operating instructions).

- Bluetooth® is activated on the multimedia system.

Multimedia system:

➔  ➔ Phone ➔  ➔ Devices  
➔ My devices

### Searching for a mobile phone

- ▶ Select **Connect new device**.

### Connecting a mobile phone

- ▶ Select a mobile phone.  
A code is displayed in the multimedia system and on the mobile phone.
- ▶ If both codes match, confirm the code on the mobile phone.

### Functions in the telephony menu

In the telephony menu you have the following functions, for example:

- Making calls, e.g.:
  -  Accepting a call
  -  **End call**
  - Answering a call with a message


-  **Conference**
  - Accepting or rejecting a waiting call
- Managing contacts, e.g.:
  - Downloading mobile phone contacts
  - Managing the format of a contact's name
  - Deleting favourites
- Receiving and sending messages, e.g.:
  - Using the read-aloud function
  - Dictating a new message

### Mercedes me app

#### Mercedes me calls

#### Making a call via the overhead control panel

- ❗ Mercedes me calls are not possible in every country. Find out at a Mercedes-Benz service centre if these functions are available in your country.



- ① me button for service or information calls
- ② SOS button cover
- ③ SOS button (emergency call system)

#### Making a Mercedes me call

- ▶ Press me button ①.

### Making an emergency call

- ▶ To open the cover of SOS button ②, press it briefly.
- ▶ Press and hold SOS button ③ for at least one second.

If a Mercedes me call is active, an emergency call can still be triggered. This has priority over all other active calls.

### Information about the Mercedes me call using the me button

A call to the Mercedes-Benz Customer Centre has been initiated via the me button in the overhead control panel or the multimedia system (→ page 344).

Using the voice dialogue system you access the desired service:

- Accident and Breakdown Management
- Mercedes-Benz Customer Centre for general information about the vehicle

You can find information on the following topics:

- Activation of Mercedes me connect
- Operating the vehicle

- Nearest Mercedes-Benz service centre
- Other products and services from Mercedes-Benz

Data is transferred during the connection to the Mercedes-Benz Customer Centre (→ page 347).

### Calling the Mercedes-Benz Customer Centre using the multimedia system

#### Requirements:

- Access to a GSM network is available.
- The contract partner's GSM network coverage is available in the respective region.
- The vehicle must be switched on so that vehicle data can be transferred automatically.

Multimedia system:



- ▶ Call **Mercedes me connect**. After confirmation, the multimedia system sends the required vehicle data. The data transfer is shown on the central display.

Then, you can select a service and be connected to a specialist at the Mercedes-Benz Customer Centre.

### Calling the Mercedes-Benz Customer Centre after automatic accident or breakdown detection

#### Requirements:

- The vehicle has detected an accident or breakdown situation.
- The vehicle is stationary.
- The hazard warning lights are switched on.

 This function is not available in all countries.

The vehicle can detect accident or breakdown situations under certain circumstances.

In the event an accident or breakdown is detected, the emergency guide shows safety notes in the multimedia system display.

After quitting the emergency guide display on the multimedia system, a prompt appears asking whether you would like to get support from the Mercedes-Benz Customer Centre.

► Select **Call**.

- After your agreement, or if the Mercedes me connect service "Accident and Breakdown Management" is active, the vehicle data is transferred automatically (→ page 349).
- The Mercedes-Benz Customer Centre takes your call and organises the breakdown and accident assistance.

You may be charged for these services.

- ① Depending on the severity of the accident, an automatic emergency call can be initiated. This has priority over all other active calls.
- ① In addition, if the Mercedes me connect service "Telediagnosics" is active, a similar prompt can appear after a delay in the event of a breakdown. If you are already in contact with the Mercedes-Benz Customer Centre or have already received support, this prompt can be ignored or declined.
- ① If you answer the prompt for support from the Mercedes-Benz Customer Centre with **Call later**, the message will be hidden and appear again later.

The prompt triggered by the Mercedes me connect service "Telediagnosics", can either be confirmed or declined. After being declined, this will not be shown again.

### Arranging a service appointment via a Mercedes me call

If you have activated the maintenance management service, relevant vehicle data is transferred automatically to the Mercedes-Benz Customer Centre. You will then receive individual recommendations regarding the maintenance of your vehicle.

Regardless of whether you have consented to the maintenance management service, the multimedia system reminds you after a certain amount of time that a service is due. A prompt appears asking if you would like to make an appointment.

- **To arrange a service appointment:** select **Call**. After your agreement, the vehicle data is transferred and the Mercedes-Benz customer centre takes your preferred appointment date. The information is then sent to your desired service outlet.

This will contact you to confirm the appointment and if necessary consult about the details.

- ① If you select **Call later** after the service message appears, the message is hidden and reappears at a later time.

### Giving consent to data transfer during a Mercedes me call

#### Requirements:

- There is an active Mercedes me call via the multimedia system or the me button in the overhead control panel (→ page 344).
- ① The prompt to confirm data transfer does not appear in all countries.

If the Accident and Breakdown Management services are not activated on Mercedes me, the **Do you want to transfer your vehicle data and the vehicle's position to the Mercedes-Benz Customer Centre to improve the processing of your request?** message is shown.

- Select **Yes**.  
Relevant identification data is transmitted automatically.

More information on Mercedes me: <https://www.mercedes.me>

### Transferred data during a Mercedes me call

If you initiate a service call using Mercedes me, data is transferred to enable targeted advice and an efficient service.

The following requirements must be fulfilled for the transfer of the data:

- The vehicle is switched on.
- The required data transfer technology is supported by the mobile phone network provider.
- The quality of the mobile connection is sufficient.

Multi-stage transfer depends on the following factors:

- Reason for the initiation of the call
- The available mobile phone transmission technology.
- The activated Mercedes me connect services.
- The service selected in the voice control system.

-  A prompt for consent to the data transfer only occurs if the corresponding Mercedes me connect service is not activated.

### Data transfer if Mercedes me connect services are not activated

If no Mercedes me connect services are activated and the data protection prompt has been confirmed the following data is transmitted:

- Vehicle identification number
- Time of the call
- Reason for the initiation of the call
- Confirmation of the data protection prompt
- Country indicator of the vehicle
- Set language for the multimedia system
- Telephone number of the communication platform installed in the vehicle

If a call is made for a service appointment via the service reminder, the following data is also transmitted:

- Current mileage and maintenance data

If a call is made after automatic accident or breakdown detection using the multimedia system, the following data is also transmitted:

- Current mileage and maintenance data
- Current vehicle location

If Accident and Breakdown Management is called via the voice control system and no service has been activated, but the data protection query has been confirmed, the following data can also be called up from the vehicle by the Mercedes-Benz Customer Centre:

- Current vehicle location

If the data protection prompt has been rejected, the following data is transmitted to enable targeted advice and an efficient service:

- Reason for the initiation of the call
- Rejection of the data protection prompt
- Country indicator of the vehicle
- Set language for the multimedia system
- Telephone number of the communication platform installed in the vehicle

### Data transfer if Mercedes me connect services are activated

Only if the respective service is activated will additional incident-specific data be transmitted in the second stage to enable an optimal service.

An overview of the data transferred is contained in the data protection information for the Mercedes me connect services. You can find these in your Mercedes me user account.

### Data processing

The data transmitted within the scope of the call is deleted from the processing system after the call is finished, in so far as this data is not being used for other activated Mercedes me connect services.

The incident-specific data is processed and stored in the Mercedes-Benz Customer Centre and, if required to process the incident, forwarded to the service partner authorised by the Mercedes-Benz Customer Centre. Take note of the data protection information on the Mercedes me Internet page <https://www.mercedes.me> or in the recorded message immediately after calling the Mercedes-Benz Customer Centre.

- ❗ The recorded message is not available in every country.

### Mercedes me connect

#### Information on Mercedes me connect

- ❗ Mercedes me connect or individual Mercedes me connect services are not available in every country. Find out at a Mercedes-Benz service centre if these functions are available in your country.

Mercedes me connect consists of multiple services.

You can use the following services via the multimedia system and the overhead control panel, for example:

- Accident and Breakdown Management (me button or situation-dependent display in the multimedia system)
- Mercedes-Benz emergency call system (automatic emergency call and SOS button)

The Mercedes me connect Accident and Breakdown Management and the Mercedes-Benz emer-

gency call centre are available to you around the clock.

The me button and the SOS button can be found on the vehicle's overhead control panel (→ page 344).

You can also call the Mercedes-Benz Customer Centre using the multimedia system (→ page 345).

Please note that Mercedes me connect is a Mercedes-Benz service. In emergencies, first call the national emergency services using the standard national emergency service telephone numbers. In emergencies, you can also use the Mercedes-Benz emergency call system (→ page 355).

Please note the Mercedes me connect terms of use and the data protection information for Mercedes me connect. You can find these in your Mercedes me user account.

Further information about Mercedes me connect, the provided service scope and operation: [https://moba.i.daimler.com/markets/ece-row/baix/cars/connectme/en\\_GB/#emotions/Startseite.html](https://moba.i.daimler.com/markets/ece-row/baix/cars/connectme/en_GB/#emotions/Startseite.html)

## Information on Mercedes me connect Accident and Breakdown Management

The Accident and Breakdown Management can include the following functions:

- Supplement to the Mercedes-Benz emergency call system (→ page 355)

If necessary, the contact person at the Mercedes-Benz emergency call centre forwards the call to Mercedes me connect Accident and Breakdown Management. Forwarding the call is however not possible in all countries.

- Breakdown assistance by a technician on location and/or the towing away of the vehicle to the nearest Mercedes-Benz service centre  
You may be charged for these services.

- Addition to the emergency guide after automatic accident or breakdown detection (→ page 345)

In the event of a breakdown or accident, further vehicle data is sent which enables optimal support by the Mercedes-Benz Customer

Centre and the authorised service partner or breakdown assistance.

- Addition to the Mercedes me connect service Telediagnosics

With the Telediagnosics function, specific wear and failure reports are recorded by the service provider, in so far as these can be clearly interpreted and are available through the monitoring of components that are subject to diagnostics.

If your vehicle detects a breakdown or threat of a breakdown, you may be prompted via the multimedia system to contact the Mercedes-Benz Customer Centre for further help. This prompt in the multimedia system only appears when the vehicle is stationary.

- ❗ These services are subject to technical restrictions such as the mobile phone coverage, mobile network quality and the ability of the processing systems to interpret the transferred data. In some circumstances, this can result in delays or the failure of the information to appear in the multimedia system.

More information about Mercedes me connect services can be obtained in the Mercedes me Portal: <https://me.secure.mercedes-benz.com>

## Data transferred during Mercedes me connect call services

The data transferred during a Mercedes me connect call depends on:

- The reason for initiation of the call
- The service that is selected in the voice control system
- The activated Mercedes me connect services

You can find out which data is transferred when using the services in the currently valid Mercedes me connect terms of use and the data protection information for Mercedes me connect. You can find these in your Mercedes me user account.

## Overview of the Mercedes me & Apps menu

When you log in with a user account to the Mercedes me Portal, then services and offers from Mercedes-Benz will be available to you.



For more information consult a Mercedes-Benz service centre or visit the Mercedes me portal: <https://me.secure.mercedes-benz.com>

- ❗ Make sure you always keep the Mercedes me apps updated.

You can call up the menu using **Apps** in the multimedia system.

In the **Apps** menu, the following options can be available:

- Connecting the vehicle with the **Mercedes me** user account
- Deleting a connection between a **Mercedes me** user account and the vehicle
- Calling up the Mercedes me services
- Calling up apps such as, In-Car Office or the web browser depending on availability

### In-Car Office functions

Using In-Car Office, you can connect your online services with the multimedia system.

The following functions are available:

- Calendar

Showing appointments and triggering actions, e.g. reading aloud, placing a call, navigating

- E-mail

Reading, reading aloud, creating, answering and forwarding e-mails

- Tasks and calls

Managing tasks and pre-booked calls

- Voice input

Creating appointments/reminders and tasks

- ❗ Alternatively, you can record text contents via the MBUX voice assistant or via the dictation function.

Further information on the MBUX voice assistant .

- ❗ The Zero Layer displays notifications or reminders from In-Car Office, such as birthdays or calls due (→ page 305).

- ❗ Please note that certain functions are only available when the vehicle is stationary.

### Overview of In-Car Office

Using In-Car Office, you can connect your online services with the multimedia system.

Requirements for In-Car Office:

- The In-Car Office service is activated in your Mercedes me user account.
- You have a Mercedes me user account.
- You have set a Mercedes me PIN.
- You have synchronised your Mercedes me user account in the vehicle and via Mercedes me.
- You have a user account with an online service, e.g. with Office 365 or Gmail, and have connected the user account with In-Car Office.

Alternatively you can link this user account from the multimedia system to your Mercedes me user account. You will be offered a QR code that will take you to the website from which you can make the link.


In-Car Office functions

- Display pending appointments in the calendar

- Reading out calendar entries
- Calling (requirement being that a telephone is connected and a telephone number is saved)
- Navigating to appointments (requirement being that the appointment contains a navigable destination)
- Deleting a calendar entry
- Display and selection of tasks and calls to complete
  - Reading aloud
  - Calling (requirement being that a telephone is connected and a telephone number is saved)
  - Deletes
- Marking entry in **Tasks & calls** as completed ☒
- Managing e-mails
  - Showing or reading e-mails
  - Writing, answering and forwarding e-mails

- ❗ Alternatively, you can record text contents for your e-mail via the MBUX voice assistant or via the dictation function. Further information on the MBUX voice assistant (→ page 313).
- ❗ The Zero Layer displays notifications or reminders from In-Car Office, such as birthdays or calls due (→ page 305).
- ❗ You can start the In-Car Office function using the **Apps** menu. Please note that certain functions are only available when the vehicle is stationary.

## Web browser overview



- ❶ Search
- ❷ To refresh/stop
- ❸ Previous website
- ❹ Options
- ❺ Settings

❗ Under  you have the following options:

- [Bookmarks](#)
- [Browsing history](#)
- [Request mobile website](#)
- [Entered URLs](#)
- [Tabs](#)

❗ Websites cannot be shown while the vehicle is in motion.

### [Overview of smartphone integration](#)

With Smartphone Integration, you can use certain functions on your mobile phone via the multimedia system display.

Only one mobile phone at a time can be connected via Smartphone Integration to the multimedia system. Also for use with two phone mode with smartphone integration, only one additional mobile phone can be connected using Bluetooth® with the multimedia system.

The full range of functions for Smartphone Integration is only possible with an Internet connection. The appropriate application must be down-

loaded on the mobile phone to use Smartphone Integration. The mobile phone must be switched on and connected to the multimedia system via the USB port using a suitable cable.

Apps for Smartphone Integration:

- Apple CarPlay® (wireless connection via Bluetooth® also possible)
- Android Auto (wireless connection via Bluetooth® also possible)

❗ For safety reasons, the first activation of Apple CarPlay® or Android Auto on the multimedia system must be carried out when the vehicle is stationary with the parking brake.

You can start Smartphone Integration using the [My devices](#) menu.

You can end Smartphone Integration via the [My devices](#) or by disconnecting the connecting cable between the mobile phone and multimedia system.

❗ Mercedes-Benz recommends disconnecting the connection via the device manager or the connecting cable only when the vehicle is stationary.

### **Overview of transferred vehicle data**

When using Smartphone Integration, certain vehicle data is transferred to the mobile phone. This enables you to get the best out of selected mobile phone services. Vehicle data is not directly accessible.

The following system information is transmitted:

- Software release of the multimedia system
- System ID (anonymised)

The transfer of this data is used to optimise communication between the vehicle and the mobile phone.

To do this, and to assign several vehicles to the mobile phone, a vehicle identifier is randomly generated.

This has no connection to the vehicle identification number (VIN) and is deleted when the multimedia system is reset (→ page 324).

The following driving status data is transmitted:

- Transmission position engaged
- Distinction between parked, standstill, rolling and driving

- Day/night mode of the driver's display
- Drive type

The transfer of this data is used to alter how content is displayed to correspond to the driving situation.

The following position data is transmitted:

- Coordinates
- Speed
- Compass direction
- Acceleration direction

The mobile phone uses this data to improve the accuracy of navigation, for example, when driving through a tunnel.

### Mercedes-Benz emergency call system

#### Information on available emergency call systems

Two types of emergency call system are available to you in the vehicle:

- Mercedes-Benz emergency call system
- 112 emergency call system (EU eCall)

The Mercedes-Benz Emergency Call System is not available in all countries. You can find more information on the regional availability of the Mercedes-Benz Emergency Call System at: <https://www.mercedes-benz-mobile.com/extra/ecall/>

The following applies for both emergency call systems:

- The transfer of specific data is required for the intended function of both emergency call sys-

tems. This will be explained in the "Data transfer" section (→ page 356).

- Both emergency call systems are included as standard equipment in your vehicle and are activated at the factory.
- The use of both emergency call systems is exempt from charges.
- Both emergency call systems only function in areas in which the mobile phone network providers offer mobile phone coverage.

For both systems, insufficient network coverage from the mobile phone network providers can result in an emergency call not being transmitted.

Differences between the Mercedes-Benz emergency call system and the 112 emergency call system (EU eCall)

| Mercedes-Benz emergency call system                                                                                                                                                                                                                                                                                                                                                                                                                                                   | 112 emergency call system (EU eCall)                                                                                                                                                                                                                                                                                                                                                |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"><li>• The Mercedes-Benz emergency call system is permanently logged in to the mobile phone network.</li><li>• Automatic and manual Mercedes-Benz emergency calls are transmitted to a Mercedes-Benz emergency call centre.</li></ul> <p>In the event that the emergency call centre of the Mercedes-Benz emergency call system cannot be reached (e.g. due to a lack of network coverage), the 112 emergency call is carried out automatically.</p> | <ul style="list-style-type: none"><li>• If you decide on the 112 emergency call system (EU eCall) only, then the system only logs in to the mobile phone network after the triggering of a manual or automatic emergency call.</li><li>• The 112 emergency call system (EU eCall) transmits automatic and manual emergency calls directly to public coordination centres.</li></ul> |

- i** The 112 emergency call system (EU eCall) in your vehicle meets the delegated regulation EU 2017/79. Proper and full functionality of the 112 emergency call system (EU eCall) depends on circumstances beyond the influence of Mercedes-Benz AG. This includes mobile network coverage and the technical infrastructure of the public reception centres in the respective countries.
- i** Please observe that in the event of a repair genuine Mercedes-Benz batteries must be used which have been certified pursuant to the delegated regulation EU 2017/79 (Appen-

dix I). Other manufacturers are also permitted provided their batteries are certified according to the delegated regulation EU 2017/79.

There is the option of deactivating the Mercedes-Benz emergency call system and using only the 112 emergency call system (EU eCall). Contact address for carrying out deactivation of the Mercedes-Benz emergency call system are the local dealers.

Mercedes-Benz recommends the activation of the Mercedes-Benz emergency call system for the following reasons:

- In emergency situations when abroad, you can also get support in a language you speak.
- Several transmission technologies are used to accelerate the transfer of the accident data and improve reliability of the transmission.
- The Mercedes-Benz emergency call system is permanently logged in to the mobile phone network, which ensures faster placement of

the emergency call and faster transfer of the accident data.

Measures for rescue, recovery or towing away can then be initiated quickly.

- With a Mercedes-Benz emergency call, the accident data is only transferred to the public coordination centre with the approval of the customer.

In the event of an automatically triggered emergency call in which there is no voice contact, the accident data is transmitted immediately to the public emergency call centre.

- If the Mercedes-Benz emergency call centre is not available, the 112 emergency call is carried out automatically.

### Overview of emergency call systems

Both the Mercedes-Benz emergency call system as well as the 112 emergency call system (EU eCall) can help to reduce the time between an accident and the arrival of emergency services at the site of the accident. They help locate an accident site in places that are difficult to access.

Both emergency call systems can initiate an emergency call automatically (→ page 355) or manually (→ page 356).

Only make emergency calls if you or others are in need of rescue. Do not make an emergency call in the event of a breakdown or a similar situation.

### Indicators in the displays

The following messages appear on the central display for both emergency call systems:

- **SOS NOT READY**: the vehicle is not switched on or the emergency call system is malfunctioning. This does not necessarily indicate complete failure of the emergency call system. Emergency calls can still be transmitted.

The display only refers to the vehicle and does not take account of the availability of mobile phone networks and the Mercedes-Benz emergency call centre.

The functional readiness of the emergency call system on the vehicle can be seen when the **SOS NOT READY** display disappears once the vehicle is switched on.

- : The icon appears in the display during an active emergency call.
- ❗ If there is a malfunction of the emergency call system, the loudspeakers, microphone, airbag or the SOS button, for example, are faulty. You can recognise a fault in the emergency call system by the following displays:
  - A corresponding message will also appear in the driver's display.
  - The SOS button lights up red continuously.

### Triggering an automatic emergency call

#### Requirements:

- The vehicle is switched on.
- The starter battery is sufficiently charged.

Both the Mercedes-Benz emergency call system as well as the 112 emergency call system (EU eCall) automatically initiate an emergency call:

- After activation of the restraint systems such as airbags or seat belt tensioners after an accident

- After an automatically initiated emergency stop by Active Emergency Stop Assist

The emergency call has been made:

- A voice connection is established with the emergency call centre.
- A message with accident data is transmitted to the emergency call centre.

The SOS button in the overhead control panel flashes until the emergency call is finished.

If no connection can be made to the public emergency services, a corresponding message appears in the display.

- ▶ Dial the emergency number 112 or the appropriate local emergency call number on your mobile phone.

If an emergency call has been initiated:

- Remain in the vehicle if the road and traffic conditions permit you to do so until a voice connection is established with the emergency call centre.
- On the basis of the call, the emergency call centre decides whether it is necessary to call

rescue teams and/or the police to the accident site.

- If no vehicle occupant answers, an ambulance is sent to the vehicle immediately.

### Triggering a manual emergency call

- ▶ **To use the SOS button in the overhead control panel:** press the SOS button at least one second long (→ page 344).

or

- ▶ **To use voice control:** use the voice commands of the MBUX voice assistant.

The emergency call has been made:

- A voice connection is established with an emergency call centre.
- Remain in the vehicle if the road and traffic conditions permit you to do so until a voice connection is established with the emergency call centre.
- On the basis of the call, the emergency call centre decides whether it is necessary to call

rescue teams and the police to the accident site.

- A message with accident data is transmitted to the emergency call centre.

If no connection can be made to the public emergency services, a corresponding message appears in the display.

- ▶ Dial the emergency number 112 or the appropriate local emergency call number on your mobile phone.

### Emergency call system data transfer

For both the Mercedes-Benz emergency call system as well as the 112 emergency call system (EU eCall) data is transferred to the Mercedes-Benz emergency call centre or the public emergency services call centre.

Depending on the emergency call system (→ page 353) activated different data is transmitted to the appropriate emergency call centre.

**Transmitted data according to activated emergency call system:**

| Mercedes-Benz emergency call                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | 112 emergency call                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>• Position data of the vehicle</li> <li>• Position data on the route (a few 100 m before the incident)</li> <li>• Direction of travel</li> <li>• Vehicle identification number</li> <li>• Drive type of the vehicle (e.g. petrol, diesel, CNG, LPG, electric or hydrogen)</li> <li>• Number of people determined to be in the vehicle</li> <li>• Whether the emergency call was initiated manually or automatically</li> <li>• Time of the accident</li> <li>• Language setting on the multimedia system</li> <li>• Whether Mercedes me connect is available or not</li> </ul> <p>This is a requirement for the option of forwarding the call to the Mercedes-Benz Customer Centre if necessary.</p> | <ul style="list-style-type: none"> <li>• Position data of the vehicle</li> <li>• Position data on the route (a few 100 m before the incident)</li> <li>• Direction of travel</li> <li>• Vehicle identification number</li> <li>• Drive type of the vehicle (e.g. petrol, diesel, CNG, LPG, electric or hydrogen)</li> <li>• Number of people determined to be in the vehicle</li> <li>• Whether the emergency call was initiated manually or automatically</li> <li>• Time of the accident</li> </ul> |

 If only the 112 emergency call system (EU eCall) is activated in the vehicle, the accident data is transmitted directly to the public emergency call centre.



For accident clarification purposes, the following measures can be taken up to an hour after the emergency call has been initiated:

- The current vehicle position can be determined.
- A voice connection to the vehicle occupants can be established.
- Emergency call data can be called up.

**i** For Russia: various functions, e.g. receiving traffic information, cannot be performed for up to two hours after sending an emergency call.

### Self diagnosis function of the emergency call system

Your car verifies the operability of the emergency call system each time the vehicle is ON. In case of system failure, you will be informed with text message on the instrument cluster and with red indicator SOS NOT READY on the display.

Please, make sure, that during 30 seconds after switching vehicle ON the red indicator SOS NOT READY in the upper right corner of display is

switched OFF, this means the emergency call system passed diagnostics successfully.

### Starting/ending ERA-GLONASS test mode

#### Requirements:

- The starter battery is sufficiently charged.
- The vehicle is switched on.
- The vehicle has been stationary for at least one minute.

**i** The test mode is currently available in the following countries, for example:

- Russia
- Belarus
- Kazakhstan
- Armenia
- Kyrgyzstan

► **To start the test mode:** press and hold the  button on the multifunction steering wheel for at least five seconds.

The test mode is started and automatically ends after the language test has been performed.

► **To stop manual test mode:** switch off the vehicle.  
The test mode is ended.

### Information on data processing

#### Processing of personal data via the Mercedes-Benz emergency call system

All processing of personal data via the Mercedes-Benz emergency call system corresponds with the specifications in the EU Regulation 2016/679 "on the protection of natural entities with regard to the processing of personal data (GDPR)".

The data is solely used by the Mercedes-Benz emergency call system for rescue and recovery in the event of an accident.

The owner of a vehicle, that is equipped with a Mercedes-Benz emergency call system in addition to the 112 emergency call system (EU eCall), has

the right to use the 112 emergency call system instead of the Mercedes-Benz emergency call system.

Contact address for carrying out deactivation of the Mercedes-Benz emergency call system are the local dealers.

### **Processing of personal data via the 112 emergency call system (EU eCall)**

All processing of personal data via the 112 emergency call system (EU eCall) corresponds with the specifications in the EU Regulation 2016/679 "on the protection of natural entities with regard to the processing of personal data (GDPR)" and is based particularly on the necessity of upholding the vital interests of the affected person in accordance with Article 6, Clause 1, Letter d of the GDPR.

The processing of this type of data is strictly limited to the purpose of operating the emergency calls to the standard European emergency call number 112.

### **Data recipient**

The recipients of data that is processed using the 112 emergency call system (EU eCall) are the rel-

evant emergency call inquiry terminals that are specified to first receive and handle emergency calls to the standard European emergency call number 112 by the respective country authorities in whose territory you are located.

### **Arrangements for data processing**

Both emergency call systems are designed so that the following requirements are fulfilled:

- The data contained in the system memory is not accessible outside the system prior to the initiation of an emergency call.
- Both emergency call systems cannot be traced and there is no continuous tracking in normal operation.
- The data in the system's internal memory is automatically and continuously deleted.
- The location data of the vehicle is continuously overwritten in the system's internal memory, so that no more than the last three current locations required for the normal function of the system are available.
- The record of the activity data of both emergency call systems is only kept for as long as

is required to fulfil the purpose of handling the emergency call, and under no circumstances for more than 13 hours after the time that an emergency call is initiated.

### **Rights of persons affected by the data processing**

The person affected by the data processing (the vehicle owner) has the right to access the data and if applicable can demand the correction, deletion or barring of data that affects him or her and that the processing of which does not correspond with the GDPR regulations. Each correction, deletion or barring carried out according to this regulation must be shared with the third party to which the data has been transmitted, provided this does not prove to be infeasible and does not incur disproportionate expenditure.

The person affected by the data processing has the right to complain to the appropriate data protection authority should they be of the opinion that their rights have been infringed by the processing of their personal data.

Responsible contact point for the processing of access rights: Konzernbeauftragter für den Daten-

schutz, Daimler AG, HPC G353, D-70546 Stuttgart, Germany

Radio, media & TV

Overview of the symbols and functions in the media menu

| Symbol                                                                           | Designation        | Function                                                                                                                                                                                                                                                                     |
|----------------------------------------------------------------------------------|--------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | Play               | Select to start or continue playback.                                                                                                                                                                                                                                        |
|  | Rest               | Select to pause the playback.                                                                                                                                                                                                                                                |
|  | Repeat a track     | Select to repeat the current track or the active playlist. <ul style="list-style-type: none"><li>• Select once: the active playlist is repeated.</li><li>• Select twice: the current track is repeated.</li><li>• Select three times: the function is deactivated.</li></ul> |
|  | Random playback    | Select to play back the tracks in random order.                                                                                                                                                                                                                              |
|  | Skip forwards/back | Select to skip to the next or to the previous track.                                                                                                                                                                                                                         |
|  | Additional options | Select to show additional options.                                                                                                                                                                                                                                           |

| Symbol                                                                            | Designation | Function                                                                                            |
|-----------------------------------------------------------------------------------|-------------|-----------------------------------------------------------------------------------------------------|
|  | Categories  | Select to show or search through available categories (e.g. playback lists, albums, artists, etc.). |
|  | Search      | Select to search in the active menu. You can search for artists, genres or moods, for example.      |
|  | Settings    | Select to make settings.                                                                            |
|  | Home        | Select to return to the home screen.                                                                |
|  | Messaging   | Select to call up messaging.                                                                        |
|  | Full screen | Select to switch to full screen mode.                                                               |

The following functions and settings are available in the media menu:

- Connecting external data storage media with the multimedia system (e.g. using USB or Bluetooth®)
- Playing back audio or video files
- Streaming online music
- Looking at TV programmes in the TV menu

Additional functions in the TV menu

| Symbol                                                                           | Designation  | Function                                                                                                                                                                                                                                                                                              |
|----------------------------------------------------------------------------------|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | Settings     | Select to make settings in the TV menu. The following functions can be switched on/off or configured: <ul style="list-style-type: none"><li>• Channel fix</li><li>• Country-specific character set</li><li>• Audio language</li><li>• Subtitles</li><li>• Teletext</li><li>• Picture format</li></ul> |
|  | EPG          | Select to show current programme information for the channel.                                                                                                                                                                                                                                         |
|  | Channel list | Select to show a list of available channels with the current programme.                                                                                                                                                                                                                               |

## Receiving TV channels in HD quality

**!** **NOTE** Damage to the CI+ capable CA module (Conditional Access module) and the Smart Card due to sustained high heat

The CI+ capable CA module is designed for home use. The CI+ capable CA module can overheat and be damaged at continuously high outside temperatures.

▶ Make sure that the CI+ enabled CA module is not exposed to prolonged high temperatures. If the CI+ capable CA module is damaged, no encrypted channels can be received.

**i** The CI+ module is not available in all countries.

A CI+ module (CA module), which is not included in the scope of delivery, is used to decrypt HD programmes according to the CI+ standard.

In some countries, an additional smart card is required, which is inserted into the CI+ module (see the manufacturer's operating manual).

The CI+ module is connected in the CI+ box in the glove compartment.

▶ **To insert the smart card in the CI+ module:** if required (country-dependent), insert the smart card into the CI+ module slot.

**i** The CI+ box is designed for operating temperatures between 0 °C and 65 °C. At operating temperatures that are higher or too low a message appears in the multimedia system and the CI+ module is switched off automatically. If the CI+ module is switched off, no encrypted channels can be received.

### Overview of the symbols and functions in the radio menu

| Symbol                                                                           | Designation                 | Function                                                                                                                        |
|----------------------------------------------------------------------------------|-----------------------------|---------------------------------------------------------------------------------------------------------------------------------|
|  | Home                        | Select to return to the home screen.                                                                                            |
|  | Messaging                   | Select to call up messaging.                                                                                                    |
|  | Skip forwards/back          | Select to skip to the next or to the previous station.                                                                          |
|  | Settings                    | Select to have further options shown.<br>The setting options are country-dependent.                                             |
|  | Additional options          | Select to show additional options.                                                                                              |
|  | Traffic information service | Select to switch on the traffic information service.<br>When the traffic information service is switched on, <b>TA</b> is blue. |
|  | Station list                | Select to have the station list shown.                                                                                          |
|  | Search                      | Select to search in the active menu. You can search for artists, genres or moods, for example.                                  |

### Additional functions of TuneIn Radio

-  A relatively large volume of data can be transmitted when using TuneIn Radio.

| Symbol                                                                            | Designation | Function                                                                                                                                                                                             |
|-----------------------------------------------------------------------------------|-------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | Settings    | The following additional settings are available in the TuneIn Radio menu: <ul style="list-style-type: none"> <li>• Selecting stream</li> <li>• Logging on to or out of the TuneIn account</li> </ul> |
|  | Favourites  | Select during playback to save the station currently set as a favourite.                                                                                                                             |
|  | Play/Pause  | Select to start, stop or continue playback.                                                                                                                                                          |
|  | Browse      | Select to choose a category and then a radio station.                                                                                                                                                |

Depending on the frequency band selected, different functions are available to you.

Select the desired frequency band in the radio menu head runner.

### Calling up TuneIn Radio

#### Requirements:

- There is a user account at <https://www.mercedes.me>.

- The vehicle is linked to the Mercedes me user account.
- The TuneIn Radio service is activated in the Mercedes me portal.
- The data volume is available.



Depending on the country, data volume may need to be purchased.

- A fast Internet connection for data transmission free of interference.
- ❶ Data volume can be purchased **directly from a mobile phone network provider** via the Mercedes me Portal.
- ❷ The functions and services are country-dependent. For more information, consult a Mercedes-Benz service centre.

Multimedia system:



▶ Select **TuneIn Radio**.

The TuneIn menu appears. The last station set starts playing.

- ❶ The connection quality depends on the local mobile phone reception.

## Sound settings

### Overview of functions in the sound menu

The setting options and functions available depend on the sound system fitted. You can find

out which sound system is fitted in your vehicle in the Digital Owner's Manual.

### Standard sound system

The following functions are available:

- Equaliser:
  - Treble, mid-range and bass
- Balance and fader
- Volume:
  - Automatic adjustment

### Burmester® 3D-surround sound system and Burmester® high-end 3D surround sound system

The following functions are available:

- Equaliser:
  - Treble, mid-range and bass
- Balance and fader
- Sound focus
- VIP seat (Burmester® high-end 3D surround sound system only)
- Sound profiles
- Volume:

- Automatic adjustment

## ASSYST PLUS service interval display

### Function of the ASSYST PLUS service interval display

The ASSYST PLUS service interval display on the driver's display informs you of the next regular service due date.

Depending on the operating conditions of the vehicle, the remaining time or distance until the next service due date will be displayed.

You can hide this service display using the back button  on the steering wheel.

You can obtain information concerning the servicing of your vehicle from a qualified specialist workshop, e.g. a Mercedes-Benz service centre.

### Displaying the service due date

Driver's display:



The next service due date is displayed.

▶ **To exit the display:** press the back button  on the steering wheel.

Bear in mind the following related topic:

- Operating the driver display (→ page 299).

### Information on regular maintenance work

**!** **NOTE** Premature wear through failure to observe service due dates

Maintenance work which is not carried out at the right time or incompletely can lead to increased wear and damage to the vehicle.

- ▶ Adhere to the prescribed service intervals.
- ▶ Always have the prescribed maintenance work carried out at a qualified specialist workshop.

**!** **NOTE** Irreparable damage to the high-voltage battery due to maintenance work not being carried out

The high-voltage battery is subject to wear. Maintenance work which is not carried out in time can lead to irreparable damage to the high-voltage battery.

- ▶ Always observe the warning messages about the high-voltage battery and immediately consult a qualified specialist workshop.
- ▶ Have the necessary maintenance work on the high-voltage battery carried out at a qualified specialist workshop.

### Notes on special service requirements

The prescribed service interval is based on normal operation of the vehicle. Have the maintenance work carried out more often than prescribed if operating conditions are difficult or the vehicle is subject to increased stress. This is the case for frequent operation in mountainous terrain or on poor road surfaces, for example.

In these or similar operating conditions, have the interior air filter changed more frequently. Check the tyres more frequently if the vehicle is operated under increased stress. Further information can be obtained at a qualified specialist workshop.

The ASSYST PLUS service interval display is only an aid. It is the responsibility of the driver of the vehicle to have maintenance work carried out more often than prescribed due to actual operating conditions and/or stresses.

### Battery disconnection periods

The ASSYST PLUS service interval display can calculate the service due date only when the battery is connected.

- ▶ Display and note down the service due date on the driver display before disconnecting the battery (→ page 367).

## Engine compartment

### Active bonnet (pedestrian protection)

#### Operation of the active bonnet (pedestrian protection)

In certain accident situations, the actuation of the active bonnet reduces the risk of injury to pedestrians. The rear area of the bonnet is raised by approximately 80 mm.

After being triggered, the active bonnet remains in the raised position. Limited visibility due to the raised bonnet cannot be ruled out.

After the active bonnet has been actuated, pedestrian protection may be limited.

Have the full functionality of the active bonnet restored immediately in a qualified specialist workshop.

If necessary, adjust your seat position and drive carefully to a qualified specialist workshop. If a safe continued journey is not possible, contact a qualified specialist workshop.

### Notes on the bonnet

Only the specialist personnel of a qualified specialist workshop should open the bonnet. Access by the customer is not permitted.

To open the bonnet, consult a qualified specialist workshop.

**⚠ DANGER** Risk of fatal injuries when carrying out maintenance work during the charging process

During the charging process, the high-voltage on-board electrical system is under high voltage.

- ▶ Do not perform any maintenance work during the charging process.

**⚠ WARNING** Risk of accident due to driving with the bonnet unlocked

The bonnet may open and block your view.

- ▶ Never release the bonnet when driving.
- ▶ Before every trip, ensure that the engine bonnet is locked.

**⚠ WARNING** Risk of accident and injury when opening and closing the bonnet

The bonnet may suddenly drop into the end position.

There is a risk of injury for anyone in the engine bonnet's range of movement.

- ▶ Do not open or close the bonnet if there is a person in the bonnet's range of movement.

**⚠ WARNING** Risk of injury due to overheated vehicle

If you open the bonnet in the event of an overheated vehicle or fire in the engine compartment, the following situations may occur:

- You may come into contact with hot gases.
- You may come into contact with other escaping hot operating fluids.
- ▶ In the event of overheating or fire in the engine compartment, keep the bonnet closed and call the fire service.
- ▶ Allow the overheated vehicle to cool down first if you need to open the bonnet.

**⚠ WARNING** Risk of injury due to moving parts

Components in the engine compartment may continue to run or start unexpectedly even when the drive system is switched off.

Observe the following if you must open the bonnet:

- ▶ Switch off the vehicle.
- ▶ Never touch the danger zones surrounding moving components, e.g. the rotation area of the fan.
- ▶ Remove jewellery and watches.
- ▶ Keep items of clothing and hair away from moving parts.

**⚠ WARNING** Risk of injury from using the windscreen wipers when the bonnet is open

If the windscreen wipers start moving when the bonnet is open, you could be trapped by the wiper linkage.

- ▶ Always switch off the windscreen wipers and the vehicle first if you need to open the bonnet.

### Notes on the coolant level

Checking or topping up coolant should be carried out only by the trained personnel of a qualified specialist workshop. Access by the customer is not permitted.

To check or top up coolant, use a qualified specialist workshop.

**⚠ WARNING** Risk of scalding from hot coolant

You may scald yourself if you open the cap when the drive system is at normal operating temperature.

- ▶ Let the vehicle cool down before opening the cap.
- ▶ When opening the cap, wear protective gloves and safety glasses.
- ▶ Open the cap slowly to release pressure.

### Keeping the air/water duct free

- ▶ Keep the area between the bonnet and the windscreen free of deposits, e.g. ice, snow or leaves.

### Topping up the windscreen washer system


**⚠ WARNING** Risk of fire and injury from windscreen washer concentrate

Windscreen washer concentrate is highly flammable.

- ▶ Avoid fire, naked flames, smoking and the creation of sparks when using windscreen washer concentrate.

#### Requirements:

- The vehicle is unlocked.



- ▶ Press on the back area of washer fluid filler flap ①.  
Washer fluid filler flap ① will open.
- ▶ Top up the washer fluid.
- ▶ Close washer fluid filler flap ①.
- ① Further information about the windscreen washer fluid (→ page 418)

### Cleaning and care

#### Information on washing the vehicle in a car wash

**⚠ WARNING** Risk of an accident due to reduced braking power after washing the vehicle

Braking efficiency is reduced after washing the vehicle.

- ▶ After the vehicle has been washed, brake carefully while paying attention to the traffic conditions until braking power has been fully restored.

**! NOTE** Damage from automatic braking

If one of the following functions is activated, the vehicle brakes automatically in certain situations:

- Active Brake Assist
- Active Distance Assist DISTRONIC
- HOLD function
- Active Parking Assist

To avoid damage to the vehicle, deactivate these systems in the following or similar situations:

- ▶ During towing.
- ▶ In a car wash.

**! NOTE** Damage due to unsuitable car wash

- ▶ Before driving into a car wash make sure that the car wash is suitable for the vehicle dimensions.
- ▶ Ensure there is sufficient ground clearance between the underbody and the guide rails of the car wash.
- ▶ Ensure that the clearance width of the car wash, in particular the width of the guide rails, is sufficient.

To avoid damage to your vehicle when using a car wash, ensure the following beforehand:

- Active Distance Assist DISTRONIC is deactivated.
- The HOLD function is switched off.

- The 360° Camera or the reversing camera is switched off.
- The vehicle is locked and the door handles retracted.
- The side windows and sliding sunroof are completely closed.
- The blower for the ventilation and heating is switched off.
- The windscreen wiper switch is in position **0**.
- The key is at a minimum distance of 6 m away from the vehicle. Otherwise the boot lid or a door could open unintentionally.
- For car washes with a conveyor system:
  - Neutral **N** is engaged.
  - The vehicle is locked from inside.

**i** If, after the car wash, you remove the wax from the windscreen and wiper rubbers, this will prevent smearing and reduce wiper noise.

### Information on using a high-pressure cleaner

**⚠ WARNING** Risk of an accident when using high-pressure cleaners with round-spray nozzles

The water jet can cause externally invisible damage.

Components damaged in this way may unexpectedly fail.

- ▶ Do not use a high-pressure cleaner with round-spray nozzles.
- ▶ Have damaged tyres or chassis parts replaced immediately.

To avoid damage to your vehicle, observe the following when using a high-pressure cleaner:

- The key is at a minimum distance of 3 m away from the vehicle. Otherwise the boot lid or a door could open unintentionally.
- Maintain a distance of at least 30 cm to the vehicle.
- **Vehicles with decorative foil:** Parts of your vehicle are covered with a decorative foil.

Maintain a distance of at least 70 cm between the foil-covered parts of the vehicle and the nozzle of the high-pressure cleaner. Move the high-pressure cleaner nozzle around whilst cleaning. The water temperature of the high-pressure cleaner must not exceed 60°C.

- Observe the information on the correct distance in the equipment manufacturer's operator manual.
- Do not direct the nozzle of the high-pressure cleaner directly at sensitive parts such as tyres, gaps, electrical component parts, batteries, illuminants and louvres.

### Washing the vehicle by hand

Observe the relevant legal requirements (e.g. in some countries, washing by hand is permitted only in specially designated wash bays).

- ▶ Use a mild cleaning agent (e.g. car shampoo).
- ▶ Wash the vehicle with lukewarm water using a soft car sponge. When doing so, do not expose the vehicle to direct sunlight.

▶ Carefully hose the vehicle off with water and dry using a chamois.

❗ Observe the notes on the care of car parts (→ page 373).

### Notes on paintwork/matt finish paintwork care

To avoid damaging the paintwork and interfering with the driving assistance systems, please observe the following notes:

#### Paint

- Insect remains: Soak with insect remover and rinse off the treated areas afterwards.
- Bird droppings: Soak with water and rinse off afterwards.
- Tree resin, oils, fuels and greases: remove by rubbing gently with a cloth soaked in petroleum ether or lighter fluid.
- Coolant and brake fluid: remove with a damp cloth and clean water.
- Tar stains: use tar remover.
- Wax: use silicone remover.

- Do not attach stickers, films or similar materials. Only have film attached to the bumper at a qualified specialist workshop.
- Remove dirt immediately, where possible.

#### Matt finish

- Only use care products approved for Mercedes-Benz.
- Do not attach stickers, films or similar materials. Only have film attached to the bumper at a qualified specialist workshop.
- Do not polish the vehicle and light-alloy wheels.
- Only use car washes that correspond to the latest engineering standards.
- Do not use car wash programmes with a final hot wax treatment.
- Do not use paint cleaners, buffing or polishing products, gloss preservers, e.g. wax.

In the event of paintwork damage:

- Always have paintwork repairs carried out at a qualified specialist workshop.

- Make sure the radar sensors function (→ page 217).

### Notes on cleaning decorative foils

Observe the notes on matt finish care in the chapter "Notes on paintwork/matt finish paintwork care" (→ page 372). They also apply to matt decorative foils.

Observe the notes on cleaning decorative foils to avoid damage.

### Cleaning

- For cleaning, use plenty of water and a mild cleaning agent without additives or abrasive substances (e.g. a car shampoo approved for Mercedes-Benz).
- Remove dirt as soon as possible. Avoid rubbing too hard in order to not irreparably damage the decorative foil.
- If there is dirt on the finish or if the decorative foil is dull: Use the Paint Cleaner recommended and approved for Mercedes-Benz.
- Insect remains: Soak with insect remover and rinse off the treated areas afterwards.
- Bird droppings: Soak with water and rinse off afterwards.
- To prevent water stains, dry a foil-wrapped vehicle with a soft, absorbent cloth after every car wash.

### Avoiding damage to the decorative foil

- The service life and colouring of decorative foils are impaired by:
  - Sunlight
  - Temperature (e.g. hot air blower)
  - Weather conditions
  - Stone chippings and dirt
  - Chemical cleaning agents
  - Oily products
- Do not use polish on matt decorative foil. Polishing will have the effect of shining the foil-wrapped surface.
- Do not treat matt or structured decorative foils with wax. Permanent stains may occur.

Scratches, corrosive deposits, areas affected by corrosion and damage caused by incorrect care

cannot always be completely repaired. In this case, contact a qualified specialist workshop.

You can obtain more information on care and cleaning agents from the manufacturer.

In the case of foil-wrapped surfaces, optical differences may occur between the surfaces that were not protected by a decorative foil after removing a decorative foil.

- ① Have work or repairs to decorative foils carried out at a qualified specialist workshop (e.g. in a Mercedes-Benz Service Centre).

### Notes on care of car parts

**⚠ WARNING** Risk of entrapment if the windscreen wipers are switched on while the windscreen is being cleaned

If the windscreen wipers are set in motion while you are cleaning the windscreen or wiper blades, you can be trapped by the wiper arm.



- ▶ Always switch off the windscreen wipers and the drive system before cleaning the windscreen or wiper blades.

To avoid damage to the vehicle, observe the notes on cleaning and care of the following car parts:

### Wheels and rims

- Use water and acid-free alloy wheel cleaners.
- Do not use acidic alloy wheel cleaners to remove brake dust. This could damage wheel bolts and brake components.
- To avoid corrosion of the brake disks and brakepads, drive the vehicle for a few minutes after cleaning before parking it. The brake disks and brakepads warm up and dry out.

### Windows

- Clean the windows inside and outside with a damp cloth and with a cleaning agent recommended for Mercedes-Benz.
- Do not use dry cloths or abrasive or solvent-based cleaning agents to clean the inside of windows.

- ❗ After changing the wiper blades or treating the vehicle with wax, clean the windscreen thoroughly with cleaning agents recommended for Mercedes-Benz. Failure to observe the application instructions may result in damage, smear marks or dazzling spots.
- ❗ Remove external fogging or dirt on the windscreen in front of the multifunction camera. Otherwise, driving systems and driving safety systems may be impaired or not available (→ page 217).

### Wiper blades

- Move the wiper arms into the replacement position (→ page 155).
- With the wiper arms folded out, clean the wiper blades with a damp cloth.
- ❗ Make sure that the wiper blades are coated. The coating can leave residues on a cloth. Do not rub the wiper blades excessively or clean them too often.

### Exterior lighting

- Clean the lenses with a wet sponge and mild cleaning agent (e.g. car shampoo).

- Only use cleaning agents or cleaning cloths that are suitable for plastic lenses.

### Vehicle socket (high-voltage battery)

- Use clean water and a soft cloth to clean the vehicle socket.
- Do not use high-pressure cleaners or cleaning agents such as soap.

### Sensors

- Clean the sensors in the front and rear bumpers with a soft cloth and car shampoo (→ page 217).
- When using a high-pressure cleaner, maintain a minimum distance of 30 cm.

### Reversing camera and 360° Camera

- Open the camera cover with the multimedia system (→ page 271).
- Use clean water and a soft cloth to clean the camera lens.
- Do not use a high-pressure cleaner.

### Trailer hitch

- Observe the notes on care in the trailer hitch manufacturer's operator manual.

- Do not clean the ball neck with a high-pressure cleaner or solvent.
  - Remove traces of rust on the ball (e.g. using a wire brush).
  - Remove dirt with a lint-free cloth.
  - After cleaning, lightly oil or grease the ball head.
-  Before using trailers with anti-torsional coupling, observe the manufacturer's operator manual.

### Notes on care of the interior

 **WARNING** Risk of injury from plastic parts breaking off after the use of solvent-based care products

Care and cleaning products containing solvents can cause surfaces in the cockpit to become porous. When the airbags are deployed, plastic parts may break away.

 Do not use any care or cleaning products containing solvents to clean the cockpit.

 **WARNING** Risk of injury or fatal injuries from bleached seat belts

Bleaching or dyeing seat belts can severely weaken them.

This can, for example, cause seat belts to tear or fail in an accident.

 Never bleach or dye seat belts.

To avoid damage to the vehicle, observe the following notes on cleaning and care:

#### Seat belts

- Clean with lukewarm and soapy water.
- Do not use chemical cleaning agents.
- Do not dry by heating them to over 80°C or exposing them to direct sunlight.

#### Display

- Switch off the display and let it cool down.
- Clean the surface carefully with a microfibre cloth and a suitable display care product (TFT-LCD).
- Do not use any other agents.

#### Head-up display

- Clean with a soft, non-static, lint-free cloth.
- Do not use cleaning agents.

#### Plastic trim

- Clean with a damp microfibre cloth.
- For heavy soiling: Use a cleaning agent recommended for Mercedes-Benz.
- Do not attach stickers, films or similar materials.
- Do not allow cosmetics, insect repellent or sun cream to come in contact with the plastic trim.

#### Real wood and trim elements

- Clean with a microfibre cloth.
- Black piano-lacquer look: Clean with a damp cloth and soapy water.
- For heavy soiling: Use a cleaning agent recommended for Mercedes-Benz.
- Do not use solvent-based cleaning agents, polishes or waxes.

#### Roof lining

- Clean with a brush or dry shampoo.

**Carpet**

- Use a carpet and textile cleaning agent recommended for Mercedes-Benz.

**Steering wheel made of genuine leather or DINAMICA****! NOTE** Damage caused by wrong cleaners

▶ Do not use solvent-based cleaning agents such as tar remover or wheel cleaner; neither should you use polishes or waxes. Otherwise you may damage the finish.

- Clean with a damp cloth and 1% soapy water solution and then wipe with a dry cloth.
- For heavy soiling: Use a cleaning agent recommended for Mercedes-Benz.
- Leather care: Use a leather care agent that has been recommended for Mercedes-Benz.
- Do not allow the leather to become too damp.
- Do not use a microfibre cloth.

**i** Leather is a natural product. It exhibits natural surface properties such as differences in

structure, marks caused by growth and injury or subtle colour differences. These surface properties are characteristics of leather and not material faults. What's more, leather is subject to a natural ageing process during which the surface properties change.

**Genuine leather seat covers**

- Vacuum away dirt (e.g. crumbs or dust) and then clean the seat covers with a damp cotton cloth and wipe down with a dry cloth. Regularly clean the seat covers.
- For heavy soiling: use a leather care agent recommended for Mercedes-Benz aftercare.
- Leather care: Use a leather care agent that has been recommended for Mercedes-Benz.
- Do not use a microfibre cloth.
- Do not allow the leather to become too damp.
- Do not use oil-based cleaning and care products.

**i** Leather is a natural product. It exhibits natural surface properties such as differences in structure, marks caused by growth and injury or subtle colour differences. These surface

properties are characteristics of leather and not material faults. What's more, leather is subject to a natural ageing process during which the surface properties change. Regular cleaning and care of the leather reduces soiling, wear marks and ageing damage and thus significantly extends its life span. Clothing that can leave stains (e.g. jeans) can discolour the leather.

**DINAMICA seat covers**

- Clean with a damp cloth.
- Do not use a microfibre cloth.

**Imitation leather seat covers**

- Vacuum up dirt such as crumbs or dust and then use a damp cotton cloth and a 1% soap-suds solution to clean the entire seat cover. Do not spot clean.
- Use cleaning and care products recommended for Mercedes-Benz.
- Do not use a microfibre cloth.
- Do not use oil-based cleaning and care products.


**Fabric seat covers**

- Vacuum up dirt such as crumbs or dust and then use a damp microfibre cloth and a 1% soapsuds solution to clean the entire seat cover. Do not spot clean.
- Use cleaning and care products recommended for Mercedes-Benz.
- Do not use oil-based cleaning and care products.

## Emergency

### Removing the safety vest


The safety vests are located in stowage spaces in the front door.



▶ Take the safety vest bag out of stowage space ①.

▶ Open the safety vest bag and pull out the safety vest.

❗ Safety vests can also be stored in the rear door stowage spaces.



- ① Maximum number of washes
- ② Maximum wash temperature
- ③ Do not bleach
- ④ Do not iron
- ⑤ Do not tumble dry
- ⑥ Do not dry clean
- ⑦ This is a class 2 vest

The requirements defined by the legal standard are only fulfilled in the following cases:


- the safety vest is the correct size
- the safety vest is fully closed whilst being worn

Replace the safety vest in the following cases:

- the reflective strips are damaged or dirt on the reflective strips can no longer be removed
- the maximum number of washes is exceeded
- the fluorescence has faded


### Warning triangle

#### Removing the warning triangle




▶ Remove warning triangle ①.

## Setting up the warning triangle



- ▶ Fold side reflectors ① upwards to form a triangle and attach at the top using upper press-stud ②.
- ▶ Fold legs ③ down and out to the side.

## First-aid kit (soft sided)



First-aid kit (soft sided) ① is located on the right-hand side of the boot in the as-delivered condition.

## Removing the fire extinguisher


**⚠ WARNING** Risk of accident due to an incorrectly secured fire extinguisher in the driver's footwell

A fire extinguisher may impede pedal travel or block a depressed pedal.

This jeopardises the operating and road safety of the vehicle.

The fire extinguisher can be flung around and injure the driver or other vehicle occupants.

- ▶ Always store and secure the fire extinguisher in the bracket.
- ▶ Do not remove the fire extinguisher while driving.



- ▶ **Left-hand drive vehicle:** pull tab ① upwards.
- ▶ **Right-hand drive vehicle:** pull tab ① downwards.
- ▶ Remove fire extinguisher ②.

## Flat tyre

### Notes on flat tyres

**⚠ WARNING** Risk of accident due to a flat tyre

A flat tyre severely affects the driving characteristics as well as the steering and braking of the vehicle.

#### Tyres without run-flat characteristics:

- ▶ Do not drive with a flat tyre.
- ▶ Change the flat tyre immediately with an emergency spare wheel or spare wheel. Alternatively, consult a qualified specialist workshop.

#### Tyres with run-flat characteristics:

- ▶ Observe the information and warning notes on MOExtended tyres (run-flat tyres).

In the event of a flat tyre, the following options are available depending on your vehicle's equipment:

- **Vehicles with MOExtended tyres:** it is possible to continue the journey for a short period of time. Make sure you observe the notes on MOExtended tyres (run-flat tyres) (→ page 380).
- **Vehicles with a TIREFIT kit:** you can repair the tyre so that it is possible to continue the journey for a short period of time. To do this, use the TIREFIT kit (→ page 382).
- **Vehicles with Mercedes me connect:** you can make a call for breakdown assistance via the overhead control panel in the case of a breakdown (→ page 344).
- **All vehicles:** change the wheel (→ page 405).

### Notes on MOExtended tyres (run-flat tyres)

**⚠ WARNING** Risk of accident when driving in limp-home mode

Driving in emergency mode impairs the handling characteristics of the vehicle.

- ▶ Do not exceed the permissible maximum speed of the MOExtended tyres.
- ▶ Avoid any abrupt steering and driving manoeuvres as well as driving over obstacles (kerbs, pot holes, off-road). This applies, in particular, to a loaded vehicle.
- ▶ Stop driving in the emergency mode if you notice:
  - banging noise
  - vehicle vibration
  - smoke which smells like rubber
  - continuous ESP® intervention
  - cracks in the tyre sidewalls
- ▶ After driving in emergency mode, have the rims checked by a qualified specialist workshop with regard to their further use.
- ▶ The defective tyre must be replaced in every case.

With MOExtended tyres (run-flat tyres), you can continue to drive your vehicle even if there is a total loss of pressure in one or more tyres. However, the tyre affected must not show any clearly visible damage.

You can recognise MOExtended tyres by the MOExtended marking which appears on the side wall of the tyre.

#### **Vehicles with tyre pressure monitoring system:**

MOExtended tyres may only be used in conjunction with an activated tyre pressure monitoring system.

If a pressure loss warning message appears in the driver's display, proceed as follows:

- Check the tyre for damage.
- If driving on, observe the following notes.

#### **Driving distance possible in emergency mode after the pressure loss warning:**


| Load condition  | Driving distance possible in emergency mode |
|-----------------|---------------------------------------------|
| Partially laden | 80 km                                       |
| Fully laden     | 30 km                                       |

The driving distance possible in emergency mode may vary depending on the driving style. Observe the maximum permissible speed of 80 km/h.

If a tyre has gone flat and cannot be replaced with an MOExtended tyre, you can use a standard tyre as a temporary measure.

#### **TIREFIT kit storage location**

The TIREFIT kit is located under the load compartment floor.



- ① Tyre inflation compressor
- ② Tyre sealant bottle

Depending on the model, the TIREFIT kit may also be located in other places under the load compartment floor.

- ① You can find information on the power category (LK) and/or electrical data on the back of the tyre inflation compressor:
  - LK3 – 12 V/20 A, 240 W, 1 kg



At a distance of approximately 1 m to the tyre inflation compressor and approximately 1.6 m above the ground, the following sound pressure levels apply:

- Emission sound pressure level  $L_{pA}$  84 dB(A)
- Sound power level  $L_{WA}$  92 dB(A)

The tyre inflation compressor is maintenance-free. If there is a malfunction, please contact a qualified specialist workshop.

### Using the TIREFIT kit

#### Requirements:

- Tyre sealant bottle and tyre inflation compressor (→ page 381)
- TIREFIT sticker
- Gloves

You can use TIREFIT tyre sealant to seal perforation damage of up to 4 mm, particularly those in the tyre contact surface. You can use TIREFIT in outside temperatures down to -20 °C.

#### **WARNING** Risk of accident when using tyre sealant

The tyre sealant may be unable to seal the tyre properly, especially in the following cases:

- there are large cuts or punctures in the tyre (larger than damage previously mentioned)
  - the wheel rims have been damaged
  - after journeys with very low tyre pressure or with flat tyres
- Do not continue driving.
- Consult a qualified specialist workshop.

#### **WARNING** Risk of injury and poisoning from tyre sealant

Tyre sealant is hazardous to health and causes irritation. Do not allow it to come into contact with your skin, eyes or clothing, and do not swallow it. Do not inhale any vapours. Keep the tyre sealant away from children.

Observe the following if you come into contact with the tyre sealant:

- Rinse off the tyre sealant from your skin using water immediately.
- If tyre sealant gets into your eyes, thoroughly rinse them using clean water immediately.
- If tyre sealant has been swallowed, thoroughly rinse out your mouth immediately and drink plenty of water. Do not induce vomiting and seek medical attention immediately.
- Change out of clothing which has come into contact with tyre sealant immediately.
- If an allergic reaction occurs, seek medical attention immediately.


#### **NOTE** Overheating due to the tyre inflation compressor running too long

- Do not run the tyre inflation compressor for longer than ten minutes without interruption.


Comply with the manufacturer's safety notes on the sticker on the tyre inflation compressor.

Have the tyre sealant bottle replaced in a qualified specialist workshop every five years.

- ▶ Do not remove any foreign objects which have entered the tyre.



- ▶ Affix part ① of the TIREFIT sticker to the instrument cluster within the driver's field of vision.
- ▶ Affix part ② of the TIREFIT sticker near the valve on the wheel with the defective tyre.



- ▶ Pull plug ④ with the cable and hose ⑤ out of the tyre inflation compressor housing.
- ▶ Push the plug of hose ⑤ into flange ⑥ of tyre sealant bottle ① until the plug engages.
- ▶ Place tyre sealant bottle ① head downwards into recess ② of the tyre inflation compressor.



- ▶ Remove the valve cap from valve ⑦ on the faulty tyre.
- ▶ Screw filling hose ⑧ onto valve ⑦.
- ▶ Insert plug ④ into a 12-V-socket in your vehicle.
- ▶ Switch on the vehicle.
- ▶ Switch on the tyre inflation compressor using On/Off switch ③. The tyre is inflated. First, tyre sealant is pumped into the tyre. The pressure may briefly rise to approximately 500 kPa (5.0 bar/73 psi).

**Do not switch off the tyre inflation compressor during this phase!**

- ▶ Let the tyre inflation compressor run for a maximum of ten minutes.  
The tyre should then have attained a tyre pressure of at least 200 kPa (2.0 bar/29 psi).

If tyre sealant leaks out, make sure you clean the affected area as quickly as possible. It is preferable to use clean water.

If you get tyre sealant on your clothing, have it cleaned as soon as possible with perchloroethylene.

**If, after ten minutes, a tyre pressure of 200 kPa (2.0 bar/29 psi) has not been attained:**

- ▶ Switch off the tyre inflation compressor.
- ▶ Unscrew the filling hose from the valve of the defective tyre.

Please note that tyre sealant may leak out when unscrewing the filling hose.

- ▶ Drive forwards or in reverse very slowly for approximately 10 m.

- ▶ Pump up the tyre again.  
After a maximum of ten minutes the tyre pressure must be at least 200 kPa (2.0 bar/29 psi).

**⚠ WARNING Risk of accident due to the specified tyre pressure not being attained**

If the specified tyre pressure is not attained after the specified time, the tyre is too badly damaged. The tyre sealant cannot repair the tyre in this instance.

The braking and driving characteristics may be greatly impaired.

- ▶ Do not continue driving.
- ▶ Consult a qualified specialist workshop.

**If, after ten minutes, a tyre pressure of 200 kPa (2.0 bar/29 psi) has been attained:**

- ▶ Switch off the tyre inflation compressor.
- ▶ Unscrew the filling hose from the valve of the defective tyre.

**⚠ WARNING Risk of accident from driving with sealed tyres**

A tyre temporarily sealed with tyre sealant impairs the handling characteristics and is not suitable for higher speeds.

- ▶ Adapt your driving style accordingly and drive carefully.
- ▶ Do not exceed the maximum speed limit with a tyre that has been repaired using tyre sealant.

- ▶ Observe the maximum permissible speed of 80 km/h for a tyre sealed with tyre sealant.

**! NOTE Staining from leaking tyre sealant**

After use, excess tyre sealant may leak out from the filling hose.

- ▶ Therefore, place the filling hose in the plastic bag that contained the TIREFIT kit.

 **ENVIRONMENTAL NOTE** Environmental pollution caused by environmentally irresponsible disposal

Tyre sealant contains pollutants.

- ▶ Have the tyre sealant bottle disposed of professionally, e.g. at a Mercedes-Benz Service Centre.

- ▶ Stow the tyre sealant bottle and the tyre inflation compressor.
- ▶ Pull away immediately.
- ▶ Stop driving after approximately ten minutes and check the tyre pressure using the tyre inflation compressor. The tyre pressure must now be at least 130 kPa (1.3 bar/19 psi).

 **WARNING** Risk of accident due to the specified tyre pressure not being attained


If the specified tyre pressure is not reached, the tyre is too badly damaged. The tyre sealant cannot repair the tyre in this instance.

The braking and driving characteristics may be greatly impaired.

- ▶ Do not continue driving.
- ▶ Consult a qualified specialist workshop.

**Countries that have Mercedes-Benz Service24h:** you will find a sticker with the telephone number, e.g. on the B-pillar on the driver's side.

- ▶ Correct the tyre pressure if it is still at least 130 kPa (1.3 bar/19 psi). See the tyre pressure table on the socket flap for values.
- ▶ **To increase the tyre pressure:** switch on the tyre inflation compressor.



- ▶ **To reduce the tyre pressure:** press pressure release button ① next to manometer ②.

- ▶ When the tyre pressure is correct, unscrew the filling hose from the valve of the sealed tyre.
- ▶ Screw the valve cap onto the valve of the sealed tyre.
- ▶ Pull the tyre sealant bottle out of the tyre inflation compressor. The filling hose stays on the tyre sealant bottle.
- ▶ Drive to the nearest qualified specialist workshop and have the tyre, tyre sealant bottle and filling hose replaced there.

## Battery (vehicle)

### Notes on the 12 V battery

 **WARNING** Risk of explosion due to electrostatic charge

Electrostatic charge can ignite the highly explosive gas mixture in the battery.

- ▶ To discharge any electrostatic charge that may have built up, touch the metal vehicle body before handling the battery.

The highly flammable gas mixture is created while the battery is charging and during starting assistance.

For safety reasons, Mercedes-Benz recommends that you only use batteries which have been tested and approved for your vehicle by Mercedes-Benz.

**⚠ WARNING** Danger of chemical burns from the battery acid

Battery acid is caustic.

- ▶ Avoid contact with the skin, eyes or clothing.
- ▶ Do not lean over the battery.
- ▶ Do not inhale battery gases.
- ▶ Keep children away from the battery.
- ▶ Immediately rinse battery acid off thoroughly with plenty of clean water and seek medical attention immediately.



**ENVIRONMENTAL NOTE** Environmental damage due to improper disposal of batteries



Batteries contain pollutants. It is illegal to dispose of them with the household rubbish.



Dispose of batteries in an environmentally responsible manner. Take discharged batteries to a qualified specialist workshop or to a collection point for used batteries.

If you have to disconnect the 12 V battery, contact a qualified specialist workshop.

Comply with safety notes and take protective measures when handling batteries.



Risk of explosion.



Fire, naked flames and smoking are prohibited when handling the battery. Avoid creating sparks.



Electrolyte or battery acid is corrosive. Avoid contact with the skin, eyes or clothing. Wear suitable protective clothing, in particular gloves, an apron and a face mask. Immediately rinse electrolyte or acid splashes off with clean water. Consult a doctor if necessary.



Wear safety glasses.



Keep children away.



Observe this Owner's Manual.

If you do not want to use the vehicle for a long period of time, consult a qualified specialist workshop.

### Notes on the high-voltage battery

**⚠ DANGER** Risk of explosion from excessive internal pressure of the high-voltage battery

Flammable gas may escape and ignite in the event of a vehicle fire.

- ▶ Stop the charging process immediately in case of unusual odours, smoke or burn marks.
- ▶ Leave the danger zone immediately. Secure the danger zone at a sufficient distance.
- ▶ Call the fire brigade.

Observe the notes on charging the high-voltage battery (→ page 193).

Risk of explosion.



Fire, naked flames and smoking are prohibited when handling the battery. Avoid creating sparks.



Electrolyte or battery acid is corrosive. Avoid contact with the skin, eyes or clothing. Wear suitable protective clothing, in particular gloves, an apron and a face mask. Immediately rinse electrolyte or acid splashes off with clean water. Consult a doctor if necessary.



Wear safety glasses.



Keep children away.



Observe this Owner's Manual.

### Starting assistance and charging the 12 V battery

- ▶ Only have starting assistance provided by a qualified specialist workshop, e.g. a Mercedes-Benz Service Centre.
- ▶ Only have the battery charged at a qualified specialist workshop, e.g. a Mercedes-Benz Service Centre.

### Replacing the 12 V battery

- ▶ Only have the battery replaced at a qualified specialist workshop, e.g. at a Mercedes-Benz Service Centre.

Tow-starting or towing away

Overview of the permitted towing methods

**NOTE** Damage from automatic braking

If one of the following functions is activated, the vehicle brakes automatically in certain situations:

- Active Brake Assist
- Active Distance Assist DISTRONIC
- HOLD function
- Active Parking Assist

To avoid damage to the vehicle, deactivate these systems in the following or similar situations:

- ▶ During towing.
- ▶ In a car wash.

Mercedes-Benz recommends transporting your vehicle in the case of a breakdown, rather than towing it away.  
For towing, use a tow rope or tow bar with both axles on the ground. Do not use tow bar systems.

If you notice that the vehicle has lost coolant, do not have it towed away. Have the vehicle transported instead.

**NOTE** Damage to the vehicle due to towing away incorrectly

- ▶ Observe the instructions and notes on towing away.

Vehicles with rear wheel drive

| Permitted towing methods |                                                                             |
|--------------------------|-----------------------------------------------------------------------------|
| Both axles on the ground | Yes, maximum 50 km at 50 km/h, only forwards with the driver in the cockpit |
| Front axle raised        | No                                                                          |
| Rear axle raised         | Yes, maximum 50 km at 50 km/h                                               |

4MATIC vehicles

| Permitted towing methods |                                                                             |
|--------------------------|-----------------------------------------------------------------------------|
| Both axles on the ground | Yes, maximum 50 km at 50 km/h, only forwards with the driver in the cockpit |
| Front axle raised        | No                                                                          |
| Rear axle raised         | No                                                                          |

Towing the vehicle with both axles on the ground

- ▶ Observe the notes on the permitted towing methods (→ page 388).
- ▶ Make sure that the 12 V battery is connected and charged.

Observe the following points when the 12 V battery is disconnected or discharged:

- the drive system cannot be started
- the electric parking brake cannot be released or applied

- the transmission cannot be shifted to position **N** or **P**

In the following situations, only transporting the vehicle is permitted:

- if the transmission cannot be shifted to **N**
- if the 12 V battery is disconnected or discharged
- if the display in the instrument cluster is not working
- if the  **Towing not permitted See Owner's Manual** message is displayed
- if the  **Top up coolant See Owner's Manual** message is displayed
- if the  **Stop Switch off the vehicle** message is displayed

▶ In such cases, transport the vehicle (→ page 390).



**NOTE** Damage due to towing away at excessively high speeds or over long distances

The drivetrain could be damaged when towing at excessively high speeds or over long distances.

- ▶ A towing speed of 50 km/h must not be exceeded.
- ▶ A towing distance of 50 km must not be exceeded.



**WARNING** Risk of accident when towing a vehicle which is too heavy

If the vehicle to be tow-started or towed away is heavier than the permissible gross mass of your vehicle, the following situations can occur:

- the towing eye may become detached.
- the vehicle/trailer combination may swerve or overturn.
- ▶ Before tow-starting or towing away, check if the vehicle to be tow-started or

towed away exceeds the permissible gross mass.

If a vehicle must be tow-started or towed away, its permissible gross mass must not exceed the permissible gross mass of the towing vehicle.

▶ Information on the permissible gross mass of the vehicle can be found on the vehicle identification plate (→ page 415).

### Towing away the vehicle

- ▶ Fit the towing eye (→ page 393).
- ▶ Fasten the towing device.



**NOTE** Damage due to incorrect connection of the tow bar

- ▶ Only connect the tow rope or tow bar to the towing eyes.

- ▶ Deactivate the automatic locking mechanism (→ page 87).
- ▶ Do not activate the HOLD function.



- ▶ Deactivate tow-away protection (→ page 109).
- ▶ Deactivate Active Brake Assist (→ page 249).
- ▶ Shift the transmission to position **N**.
- ▶ Release the electric parking brake.
- ▶ Remain in the cockpit during towing and observe the display messages.
- ▶ Do not switch off the vehicle while it is being towed.
- ▶ Do not open the driver's door or front passenger door; the transmission will otherwise automatically shift to **P**.

**⚠ WARNING** Risk of accident due to limited safety-related functions during the towing process

Safety-related functions are limited or no longer available in the following situations:

- the vehicle is switched off.
- the brake system or power steering system is malfunctioning.

- the energy supply or the on-board electrical system is malfunctioning.

▶ In such cases, do not tow the vehicle.

▶ Transport the vehicle (→ page 390).

**!** **NOTE** Damage to the drive system due to incorrect towing

The vehicle may not be towed in the following situations:

- the vehicle is switched off.
- the brake system or power steering system is malfunctioning.
- the energy supply or the on-board electrical system is malfunctioning.

▶ In such cases, do not tow the vehicle.

**!** **NOTE** Damage due to excessive tractive power

If you pull away sharply, the tractive power may be too high and the vehicles could be damaged.

▶ Pull away slowly and smoothly.

### Loading the vehicle for transport

Requirements:

- The vehicle is stationary.
- The vehicle is switched off.
- The driver's display is in the initial state with no menus open (→ page 299). Transport is also possible with a warning message visible.
- The 12 V battery is charged.

- ▶ If necessary, set the system language (→ page 324).
- ▶ Observe the notes on towing away (→ page 388).
- ▶ Connect the towing device to the towing eye in order to load the vehicle.

**i** **Vehicles with trailer hitch:** you can also attach the tow bar to the trailer hitch.

- ▶ Switch on the power supply (→ page 178).
- ▶ Shift the transmission to position **N**.

- ❗ The transmission may be locked in position **P** in the event of damage to the electrics. To shift to **N**, provide the on-board electrical system with power (→ page 387).

## Vehicles with AIRMATIC

**!** **NOTE** Possible damage to the vehicle when loading or unloading

When loading or unloading, the vehicle must be raised to transport level.

If the transport settings are not shown or the **Vehicle not ready for loading** message is displayed, the vehicle may not be loaded or unloaded.

- ▶ If required, raise the vehicle to transport level again.
- ▶ A vehicle that cannot be raised to transport level may not be loaded or unloaded using a ramp. Consult a qualified specialist workshop.



**!** **WARNING** Risk of accident due to activated transport level

If the vehicle is raised to transport level, driving and driving safety systems have only limited availability and the view from the vehicle is restricted.

Driving safety is severely restricted and there is a risk of an accident!

- ▶ Do not use transport level in normal road operation.
- ▶ Only activate and use transport level to load the vehicle and when not on public roads.

- ▶ Ensure that no persons or obstacles are located in the area surrounding the vehicle.

## Raising the vehicle to transport level Vehicles with AIRMATIC

- ▶ Press the  button for at least five seconds.
- ▶ Immediately press and hold the **OK** button for at least one second. The **For transport level, switch vehicle on** message is displayed.
- ▶ Switch on the vehicle (→ page 180). The transport settings are displayed.
- ▶ Swipe downward to select **Transport level** and press **OK**. The vehicle is raised and the **Vehicle rising... Do not drive on ramp** message is displayed for 5 seconds. The raising process can last up to 60 seconds and can be cancelled with the  button.
- ▶ When raising, do not switch off the vehicle.

While the vehicle is being raised, you can manoeuvre at a maximum speed of 40 km/h.



- ▶ Before loading the vehicle, wait until transport level has been reached and the **Transport level** status is shown.

**i** If the vehicle is raised to transport level, the transport settings will continue to be shown even after a restart. Operation of the driver's display is meanwhile restricted.

When the vehicle is at transport level, it is lowered again in the following situations:


- When driving faster than 40 km/h.
- The 12 V battery is discharged.

The vehicle is adjusted to the height of the last active level.

### Transporting the vehicle

- ▶ Load the vehicle onto the transporter.
- ▶ Shift the transmission to position **P**.
- ▶ Use the electric parking brake to secure the vehicle against rolling away.
- ▶ Switch off the vehicle and the power supply.
- ▶ Only secure the vehicle by the wheels.

### 4MATIC vehicles



- ▶ Make sure that the front and rear axles come to rest on the same transportation vehicle.

**!** **NOTE** Damage to the drive train due to incorrect positioning of the vehicle

- ▶ Do not position the vehicle above the connection point of the transport vehicle.


### Unloading the vehicle Vehicles with AIRMATIC

- ▶ Make sure that the vehicle is raised to transport level before unloading (→ page 262).

### Lowering the vehicle after unloading



- ▶ Switch on the power supply.
- ▶ Switch on the vehicle.
- ▶ Swipe upward in the transport settings to select **Standard level** and press **OK**. The vehicle is adjusted to the height of the last active level and the **Lowering vehicle** message is displayed.
- ▶ After the vehicle has been lowered, press the **↩** button for at least two seconds. The transport settings are closed.

### Towing eye storage location



Towing eye ① is located under the boot floor.

### Fitting and removing the towing eye



- ▶ Press cover ① at top ② inwards and remove.
- ▶ Screw in the towing eye clockwise as far as it will go and tighten.

**Vehicles with a trailer hitch:** vehicles with a trailer hitch do not have a rear bracket for the towing eye. Fasten the tow bar to the trailer hitch.

- ▶ Make sure that cover ① engages in the bumper when you remove the towing eye.

**! NOTE** Damage to the vehicle due to incorrect use of the towing eye or trailer hitch

When a towing eye or trailer hitch is used to recover a vehicle, the vehicle may be damaged in the process.

- ▶ Only use the towing eye or trailer hitch to tow away or tow start the vehicle.
- ▶ Do not use the towing eye or trailer hitch to tow the vehicle during recovery.

### Tow-starting the vehicle

- ▶ If the drive system does not start, have the vehicle transported to a qualified specialist workshop, e.g. a Mercedes-Benz Service Centre.
- ▶ The drive system cannot be started by tow-starting the vehicle. Do not perform any attempts to tow-start the vehicle.

## Electrical fuses

### Notes on electrical fuses

**! WARNING** Risk of accident and injury due to overloaded lines

If you manipulate or bridge a faulty fuse or if you replace it with a fuse with a higher amperage, the electric line could be overloaded. This could result in a fire.

- ▶ Always replace faulty fuses with specified new fuses containing the correct amperage.

**! NOTE** Damage due to incorrect fuses

Using incorrect fuses can result in damage to electrical components or systems or their functions being considerably restricted.

- ▶ Use only fuses approved for Mercedes-Benz with the respective specified fuse rating.

Blown fuses must be replaced with fuses of the same rating, which you can recognise by the col-

our and the label. The fuse ratings and further information to be observed can be found in the fuse assignment diagram.

**Fuse assignment diagram:** on the fuse box in the rear passenger compartment (→ page 395).

**! NOTE** Damage or malfunctions caused by moisture

Moisture may cause damage to the electrical system or cause it to malfunction.

- ▶ When the fuse box is open, make sure that no moisture can enter the fuse box.
- ▶ When closing the fuse box, make sure that the seal of the lid is positioned correctly on the fuse box.

If the newly inserted fuse also blows, have the cause traced and rectified at a qualified specialist workshop.

Ensure the following before replacing a fuse:

- The vehicle is secured against rolling away.
- All electrical consumers are switched off.
- The vehicle is switched off.

The electrical fuses are located in various fuse boxes:

- Fuse box on the driver's side of the cockpit (→ page 395)
- Fuse box in the front passenger footwell (→ page 395)
- Fuse box in the rear passenger compartment (→ page 395)

### Opening and closing the fuse box in the cockpit

- Observe the notes on electrical fuses (→ page 394).

The fuse box is on the driver's side on the side of the cockpit under a cover.


- ▶ To open and close it, consult a Mercedes-Benz Service Centre.

### Opening and closing the fuse box in the front passenger footwell

#### Requirements:

- Observe the notes on electrical fuses (→ page 394).

**Right-hand drive vehicles:** the fuse box is on the left side.



- ▶ To open the fuse box: remove cover ①.
- ▶ To close the fuse box: reinsert cover ①.

### Opening and closing the fuse box in the rear

#### Requirements:

- Observe the notes on electrical fuses (→ page 394).

The fuse box is located in the centre of the vehicle under the seat.

- ▶ To open and close it, consult a Mercedes-Benz Service Centre.

### Notes on noise or unusual handling characteristics

Make sure there are no vibrations, noises or unusual handling characteristics when the vehicle is in motion. This may indicate that the wheels or tyres are damaged. Hidden tyre damage could also be causing the unusual handling characteristics.

If you suspect that a tyre is defective, reduce your speed immediately and have the tyres and wheels checked at a qualified specialist workshop.

### Notes on regularly inspecting wheels and tyres

**⚠ WARNING** Risk of injury due to damaged tyres

Damaged tyres can cause tyre pressure loss.

- ▶ Check the tyres regularly for signs of damage and replace any damaged tyres immediately.

**⚠ WARNING** Risk of aquaplaning due to insufficient tyre tread

Insufficient tyre tread will result in reduced tyre grip.

The risk of aquaplaning is increased on wet roads, especially when the speed of the vehicle is not adapted to suit the conditions.

- ▶ Thus, you should regularly check the tread depth and the condition of the tread across the entire width of all tyres.

Minimum tread depth for:

- Summer tyres: 3 mm
- M+S tyres: 4 mm
- ▶ For safety reasons, replace the tyres before the legally-prescribed limit for the minimum tread depth is reached.

Carry out the following checks on all wheels regularly, at least once a month or as required, for example, prior to a long journey or driving off-road:

- Check the tyre pressure (→ page 397).

- Visually inspect wheels and tyres for damage.
- Check the valve caps.
- Visual check of the tyre tread depth and the tyre contact surface across the entire width.  
The minimum tread depth for summer tyres is 3 mm and for winter tyres 4 mm.

### Notes on snow chains

**⚠ WARNING** Risk of accident due to incorrectly fitted snow chains

If you have fitted snow chains to the front wheels, they may drag against the vehicle body or chassis components.

- ▶ Never fit snow chains to the front wheels.
- ▶ Only fit snow chains on the rear wheels in pairs.

**!** **NOTE** Damage to components of the vehicle body or chassis due to fitted snow chains

If you fit snow chains to the front wheels of 4MATIC vehicles, you may damage components of the vehicle body or chassis.

- ▶ Only fit snow chains to the rear wheels of 4MATIC vehicles.

Observe the following notes when using snow chains:

- Snow chains are only permissible for certain wheel/tyre combinations. You can obtain information about this from a Mercedes-Benz Service Centre.
- For safety reasons, only use snow chains that have been specifically approved for your vehicle by Mercedes-Benz, or snow chains with the same quality standard.
- Comply with the installation instructions of the snow chain manufacturer.
- If snow chains are fitted, the maximum permissible speed is 50 km/h.

- **Vehicles with Active Parking Assist:** do not use Active Parking Assist when snow chains are fitted.
- **Vehicles with rear axle steering:** if snow chains are fitted, only drive with snow chain mode active (→ page 397).

- ① You can permanently limit the maximum speed for driving with winter tyres (→ page 230).
- ① You can deactivate ESP® to pull away (→ page 222). This allows the wheels to spin, achieving an increased driving force.

### Activating or deactivating snow chain mode

Multimedia system:



- ▶ Activate or deactivate **Snow chain mode**.

When the function is active, the vehicle behaves as if snow chains were mounted. For example, the maximum steering movement of the rear wheels is limited.

Additionally, parts of the driving and driving safety systems are not available when snow chain mode is active.

### Tyre pressure

#### Notes on tyre pressure

**⚠ WARNING** Risk of accident due to insufficient or excessive tyre pressure

Underinflated or overinflated tyres pose in particular the following risks:

- The tyres can burst.
- The tyres can wear excessively and/or unevenly.
- The driving characteristics as well as the steering and braking characteristics may be greatly impaired.

- ▶ Comply with the recommended tyre pressure and check the tyre pressure of all tyres, including the spare wheel, regularly:



- monthly
- when the load changes
- before embarking on a longer journey
- if operating conditions change, e.g. off-road driving

▶ Adjust the tyre pressure, if necessary.

Tyre pressure which is too high or too low can:

- Shorten the service life of the tyres.
- Cause increased tyre damage.
- Adversely affect driving characteristics and thus driving safety, e.g. due to aquaplaning.

**⚠ WARNING** Risk of accident due to repeated pressure drop in the tyres

The wheels, valves or tyres could be damaged. Too low a tyre pressure can lead to the tyres bursting.

- ▶ Examine the tyres for foreign objects.
- ▶ Check whether the tyre has a puncture or the valve has a leak.

▶ If you are unable to rectify the damage, contact a qualified specialist workshop.

Information on the recommended tyre pressure for the vehicle's factory-fitted tyres can be found on the tyre pressure table on the inside of the socket flap (→ page 398).

Use a suitable pressure gauge to check the tyre pressure. The outer appearance of a tyre does not permit any reliable conclusion about the tyre pressure.

Only correct tyre pressures when the tyres are cold. Conditions for cold tyres:

- The vehicle has been parked with the tyres out of direct sunlight for at least three hours.
- The vehicle has travelled less than 1.6 km.

The vehicle's tyres heat up when driving. As the temperature of the tyres increases, so too does the tyre pressure.


**Vehicles with a tyre pressure monitoring system:** you can also see the tyre pressure in the driver's display (→ page 399).

### Notes on trailer operation

Always inflate the rear axle tyres to the recommended tyre pressures on the tyre pressure table for increased load.

### Tyre pressure table

The tyre pressure table is on the inside of the socket flap.



|                |            | kPa |    | psi |    | kPa |    | psi |    |
|----------------|------------|-----|----|-----|----|-----|----|-----|----|
| Normal load    | Front axle | 230 | 33 | 230 | 33 | 230 | 33 | 230 | 33 |
|                | Rear axle  | 230 | 33 | 230 | 33 | 230 | 33 | 230 | 33 |
| Increased load | Front axle | 230 | 33 | 230 | 33 | 230 | 33 | 230 | 33 |
|                | Rear axle  | 230 | 33 | 230 | 33 | 230 | 33 | 230 | 33 |

A 213 584 37 03 1234567

The tyre pressure table shows the recommended tyre pressure for all tyres approved for this vehicle. The recommended tyre pressures apply for cold tyres under various operating conditions, i.e. loading and/or speed of the vehicle.

If one or more tyre sizes precede a tyre pressure, the tyre pressure information following is only valid for those tyre sizes.

If the preceding tyre sizes are complemented by the  symbol, the tyre pressure information following shows alternative tyre pressures. These tyre pressures may improve your vehicle's ride comfort. Energy consumption may then increase slightly.

The load conditions "partially laden" and "fully laden" are defined in the table for different numbers of passengers and amounts of luggage. The actual number of seats may differ from this.

Be sure to also observe the following further related subjects:

- Notes on tyre pressure (→ page 397)

## Tyre pressure monitoring system

### Function of the tyre pressure monitoring system

The system checks the tyre pressure and the tyre temperature of the tyres fitted to the vehicle by means of a tyre pressure sensor.

The tyre pressure and the tyre temperature appear in the driver's display.

If there is a substantial pressure loss or if the tyre temperature is excessive, you will be warned with display messages (→ page 486) or the  warning lamp in the driver's display (→ page 503).

The tyre pressure monitoring system is only an aid. It is the driver's responsibility to set the tyre pressure to the recommended cold tyre pressure suitable for the operating situation.

In most cases, the tyre pressure monitoring system will automatically update the new reference values after you have changed the tyre pressure. You can, however, also update the reference values by restarting the tyre pressure monitoring system manually (→ page 400).

### System limits

The system may be impaired or may not function particularly in the following situations:

- incorrect reference values were taught in
- sudden pressure loss caused by a foreign object penetrating the tyre, for example
- there is a malfunction caused by another radio signal source

### Checking the tyre pressure with the tyre pressure monitoring system

#### Requirements:

- The vehicle is switched on.


Driver's display:

   [Service](#)

 Press  to confirm.

One of the following displays appears:

- Current tyre pressure of each wheel:



- **Tyre pressures will be displayed after a few minutes of driving:** current values are not yet known to the system. The pressure/temperature values of each tyre are displayed as soon as they are known to the system.
  - **Tyre pressure monitor active:** the teach-in process of the system is not yet complete. The tyre pressures are already being monitored.
- ▶ Compare the current tyre pressure with the recommended tyre pressure for the current operating condition (→ page 398). Additionally, observe the notes on cold tyres (→ page 397).

- ❗ The values displayed in the driver's display may deviate from those of the tyre pressure gauge as they refer to sea level. At high elevations, the tyre pressure values indicated by a tyre pressure gauge are higher than those shown in the driver's display.

Bear in mind the following related topic:

- Notes on tyre pressure (→ page 397)

### Restarting the tyre pressure monitoring system

#### Requirements:

- The recommended tyre pressure is correctly set for the respective operating status on each of the four wheels (→ page 397).

Restart the tyre pressure monitoring system in the following situations:

- The tyre pressure has changed.
- The wheels or tyres have been changed or newly fitted.

Driver's display:



- ▶ Select **Tyre pressure** and confirm with **OK**.

- ▶ Swipe downwards on Touch Control on the steering wheel.  
The **Use current tyre pressures as new reference values?** message is shown in the driver's display.

- ▶ Select **Yes** and confirm the restart with **OK**.  
The **Tyre pressure monitor restarted** message is shown in the driver's display.

Current warning messages are deleted and the yellow  warning lamp goes out.

After you have been driving for a few minutes, the system checks whether the current tyre pressures are within the specified range. The current tyre pressures are then accepted as reference values and monitored.

If the tyre pressure levels are not within the specified range, the **Please correct tyre pressure** message appears.

Bear in mind the following related topic:

- Notes on tyre pressure (→ page 397)

## Wheel change

### Notes on selecting, fitting and replacing tyres

#### **!** NOTE Mercedes-AMG vehicles

- ▶ Observe the notes in the Supplement. You could otherwise fail to recognise dangers.

#### **!** WARNING Risk of accident due to incorrect wheel and tyre dimensions

If wheels and tyres of the wrong size are fitted, the service brakes or components in the brake system and in the wheel suspension may be damaged.

- ▶ Always replace wheels and tyres with those that fulfil the specifications of the original part.

For wheels, pay attention to the following:

- Designation
- Type

For tyres, pay attention to the following:

- Designation
- Manufacturer
- Type

#### **!** WARNING Risk of injury through exceeding the specified tyre load-bearing capacity or the permissible speed rating

Exceeding the load-bearing capacity of the tyres can lead to tyre damage and could cause the tyres to explode.

- ▶ Therefore, only use tyre types and sizes approved for your vehicle model.
- ▶ Observe the tyre load-bearing capacity rating and speed rating required for your vehicle.

#### **!** NOTE Vehicle and tyre damage caused by non-approved tyre types and sizes

For safety reasons, only use tyres, wheels and accessories which have been specially approved by Mercedes-Benz for your vehicle.

These tyres are specially adapted to the active safety systems, such as ABS, ESP® and 4MATIC, and marked as follows:

- MO = Mercedes-Benz Original
- MOE = Mercedes-Benz Original Extended (run-flat tyres only for certain wheels)
- MO1 = Mercedes-Benz Original (only certain AMG tyres)

Otherwise, certain properties, such as handling characteristics, vehicle noise emissions, consumption, etc. could be adversely affected. Furthermore, other tyre sizes could result in the tyres rubbing against the body and axle components when loaded. This could result in damage to the tyre or the vehicle.

Only use tyres, wheels and accessories that have been checked and recommended by Mercedes-Benz.

**!** **NOTE** Risk to driving safety from retreaded tyres

Retreaded tyres are neither tested nor recommended by Mercedes-Benz, since previous damage cannot always be detected on retreaded tyres.

For this reason driving safety cannot be guaranteed.

- ▶ Do not use used tyres if you have no information about their previous usage.

**!** **NOTE** Possible wheel and tyre damage when driving over obstacles

Large wheels have a smaller section width. As the section width decreases, the risk of wheels and tyres being damaged when driving over obstacles increases.

- ▶ Avoid obstacles or drive especially carefully.
- ▶ Reduce your speed when driving over kerbs, speed bumps, manhole covers and potholes.
- ▶ Avoid particularly high kerbs.

**!** **NOTE** Possible wheel and tyre damage when parking on kerbs or in potholes

Parking on kerbs or in potholes can damage the wheels and tyres.

- ▶ Only park on level surfaces if possible.
- ▶ Avoid kerbs and potholes when parking.

**!** **NOTE** Damage to electronic component parts due to the use of tyre-fitting tools

**Vehicles with tyre pressure monitoring system:** there are electronic component parts in the wheel.

If tyre-fitting tools are positioned in the area of the valve, the electronic components could be damaged.

- ▶ Tyre-fitting tools should not be applied in the area of the valve.
- ▶ Always have tyres changed at a qualified specialist workshop.

**!** **NOTE** Damage to summer tyres at low ambient temperatures

At low ambient temperatures, tears could form when driving with summer tyres, causing permanent damage to the tyre.

- ▶ At temperatures below 7 °C use  M+S tyres.

Accessory parts which are not approved for your vehicle by Mercedes-Benz, or which are not used correctly, can impair the operating safety.

Before purchasing and using non-approved accessories, visit a qualified specialist workshop and enquire about:

- Suitability
- Legal stipulations
- Factory recommendations

**⚠ WARNING** Risk of accident with high performance tyres

The special tyre tread in combination with the optimised tyre compound means that the risk of skidding and hydroplaning on wet roads is increased.

In addition, the tyre grip is greatly reduced at a low outside temperature and tyre running temperature.

- ▶ Switch on the ESP® and adapt your driving style accordingly.
- ▶ Use  M+S tyres at outside temperatures of less than 10 °C.
- ▶ Only use the tyres for their intended purpose.

Observe the following when selecting, fitting and replacing tyres:

- Country-specific requirements for tyre approval that define a specific tyre type for your vehicle.

- Furthermore, the use of certain tyre types in certain regions and areas of operation can be highly beneficial.
- Only use tyres and wheels of the same type (summer tyres, winter tyres, MOExtended tyres) and the same make.
- Only fit wheels of the same size on one axle (left and right).

It is only permissible to fit a different wheel size in the event of a flat tyre in order to drive to the specialist workshop.

- Do not make any modifications to the brake system, the wheels or the tyres.

The use of shims or brake dust shields is not permitted and may invalidate the vehicle's general operating permit.

- **Vehicles with a tyre pressure monitoring system:** all fitted wheels must be equipped with functioning sensors for the tyre pressure monitoring system.
- At temperatures below 7 °C use winter tyres or all-season tyres marked  M+S for all wheels.

Winter tyres provide the best possible grip in wintry road conditions.

- For M+S tyres, only use tyres with the same tread.
- Observe the maximum permissible speed for the M+S tyres fitted.

If the tyre's maximum speed is below that of the vehicle, this must be indicated by an appropriate label in the driver's field of vision.

- Run in new tyres at moderate speeds for the first 100 km.
- Replace the tyres after six years at the latest, regardless of wear.
- **When replacing with tyres that do not feature run-flat characteristics:** vehicles with MOExtended tyres are not equipped with a TIREFIT kit at the factory. Equip the vehicle with a TIREFIT kit after replacing with tyres that do not feature run-flat characteristics, e.g. winter tyres.

**i** You can permanently limit the maximum speed for driving with winter tyres (→ page 230).

For more information on wheels and tyres, contact a qualified specialist workshop.

Be sure to also observe the following further related subjects:

- Notes on tyre pressure (→ page 397)
- Tyre pressure table (→ page 398)
- Notes on the emergency spare wheel (→ page 410)

### Notes on interchanging wheels

**⚠ WARNING** Risk of injury through different wheel sizes

Interchanging the front and rear wheels can severely impair the driving characteristics.

The disk brakes or wheel suspension components may also be damaged.

- Only interchange the front and rear wheels if the wheels and tyres have the same dimensions.

Interchanging the front and rear wheels if the wheels or tyres have different dimensions can render the general operating permit invalid. Observe the instructions and safety notes on "Changing a wheel" (→ page 401)

The wear patterns on the front and rear wheels differ:

- front wheels wear more on the tyre shoulder
- rear wheels wear more in the centre of the tyre

Do not drive with tyres that have too little tread depth. This significantly reduces traction on wet roads (aquaplaning).

On vehicles with the same front and rear wheel size, you can interchange the wheels every 5,000 to 10,000 km, depending on the wear. Ensure the direction of rotation is maintained for the wheels.

### Notes on storing wheels

When storing wheels, observe the following notes:

- After removing wheels, store them in a cool, dry and preferably dark place.
- Protect the tyres from contact with oil, grease or fuel.

### Overview of the tyre-change tool kit

**! NOTE** Mercedes-AMG vehicles

- Observe the notes in the Supplement. You could otherwise fail to recognise dangers.

Apart from some country-specific variants, vehicles are not equipped with a tyre-change tool kit. For more information on which tyre-changing tools are required and approved for performing a wheel change on your vehicle, consult a qualified specialist workshop.


You require the following tools, for example, to change a wheel:

- Jack

- Chock
- Wheel wrench
- Centring pin

**i** The jack weighs approximately 3.4 kg. The maximum load capacity of the jack can be found on the sticker affixed to the jack. The jack is maintenance-free. If there is a malfunction, please contact a qualified specialist workshop.

The tyre-change tool kit is located in tool bag **1** in the boot.



The tool bag contains:

- Jack

- Gloves
- Wheel wrench
- Centring pin
- Folding chock
- Ratchet for jack

### Preparing the vehicle for a wheel change

#### Requirements:

- The vehicle is not on a slope.
- The vehicle is on solid, non-slippery and level ground.
- The required tyre-change tool kit is available.

**i** If your vehicle is not equipped with the tyre-change tool kit, consult a qualified specialist workshop to find out about suitable tools.

- ▶ Apply the electric parking brake manually.
- ▶ Move the front wheels to the straight-ahead position.
- ▶ Shift the transmission to position **P**.

▶ **Vehicles with AIRMATIC:** set the raised vehicle level for greater ground clearance (→ page 262).

▶ Switch off the vehicle.

▶ Make sure that the vehicle cannot be started.

▶ Place chocks or other suitable items under the front and rear of the wheel that is diagonally opposite the wheel you wish to change.

▶ Unload the vehicle.

### Raising the vehicle when changing a wheel

#### Requirements:

- There are no persons in the vehicle.
- The vehicle has been prepared for a wheel change (→ page 405).



Important notes on using the jack:

- Use only a vehicle-specific jack that has been approved by Mercedes-Benz to raise the vehicle.
- The jack is only designed for raising and holding the vehicle for a short time while a wheel




is being changed and not for maintenance work under the vehicle.

- The jack must be placed on a firm, flat and non-slip surface. If necessary, use a large, flat, load-bearing, non-slip underlay.
- The foot of the jack must be positioned vertically under the jack support point.




Rules of conduct when the vehicle is raised:

- Never place your hands or feet under the vehicle.
- Never lie under the vehicle.
- Do not start the vehicle and do not release the electric parking brake.
- Do not open or close any doors or the boot lid.



- ▶ Using the wheel wrench, loosen the wheel bolts on the wheel you wish to change by about one full turn. Do not unscrew the screws completely.



Position of the jack support points

**! NOTE** Mercedes-AMG vehicles

- ▶ Observe the notes in the Supplement. You could otherwise fail to recognise dangers.

**! WARNING** Risk of injury from incorrect positioning of the jack

If you do not position the jack correctly at the appropriate jacking point of the vehicle, the jack could tip with the vehicle raised.

- ▶ Only position the jack at the appropriate jacking point of the vehicle. The base of

the jack must be positioned vertically under the jacking point of the vehicle.

**! NOTE** Damage to the vehicle due to using an unsuitable jack

You can damage the vehicle and, in particular, the high-voltage battery if you use a jack that is not specifically designed for the jack support points of the vehicle.


- ▶ Only use jacks that are specifically designed for the jack support points, or use an appropriate adapter.

**! NOTE** Risk of damage to the vehicle due to incorrect positioning of the jack

If you do not position the jack at the designated jack support points, you could damage your vehicle and, in particular, the high-voltage battery.

- ▶ Only position the jack at the designated jack support points.

- ▶ Take the ratchet out of the tyre-change tool kit and place it on the hexagon nut of the jack so that the letters "AUF" are visible.



- ▶ Position support ② of jack ④ on jack support point ①.
- ▶ Turn ratchet ③ clockwise until support ② sits completely on jack support point ① and the base of the jack lies evenly on the ground.

- ▶ Turn ratchet ③ until the tyre is raised a maximum of 3 cm from the ground.
- ▶ Loosen and remove the wheel (→ page 408).

### Removing a wheel

#### Requirements:

- The vehicle is raised (→ page 405).

#### ! NOTE Mercedes-AMG vehicles

- ▶ Observe the notes in the Supplement. You could otherwise fail to recognise dangers.

When changing a wheel, avoid applying any force to the brake discs, as this could impair the level of comfort when braking.

#### ! NOTE Damage to the wheels' plastic elements when changing a wheel


Plastic elements on wheels may be damaged when removing and repositioning the wheel.

- ▶ Do not raise the wheels by the plastic elements when removing and repositioning.

#### ! NOTE Damage to threading from dirt on wheel bolts

- ▶ Do not place wheel bolts in sand or on a dirty surface.

- ▶ Unscrew the uppermost wheel bolt completely.



- ▶ Screw centring pin ① into the thread instead of the wheel bolt.

- ▶ Unscrew the remaining wheel bolts completely.
- ▶ Remove the wheel.

### Fitting a new wheel

#### Requirements:

- The wheel to be changed is removed and the centring pin is screwed in (→ page 408).

#### ! NOTE Mercedes-AMG vehicles

- ▶ Observe the notes in the Supplement. You could otherwise fail to recognise dangers.

#### ⚠ WARNING Risk of accident from losing a wheel

Oiled or greased wheel bolts can cause the wheel bolts to come loose, as too can damaged wheel bolts or wheel hub threads.

- ▶ Never oil or grease the threads.

- ▶ In the event of damage to the threads, contact a qualified specialist workshop immediately.
- ▶ Have the damaged wheel bolts or damaged hub threads replaced.
- ▶ Do not continue driving.

- ▶ Observe the information on the choice of tyres (→ page 401).

For tyres with a specified direction of rotation, an arrow on the side wall of the tyre indicates the correct direction of rotation. Observe the direction of rotation when fitting.

**!** **NOTE** Damage to the wheels' plastic elements when changing a wheel

Plastic elements on wheels may be damaged when removing and repositioning the wheel.

- ▶ Do not raise the wheels by the plastic elements when removing and repositioning.

- ▶ Slide the wheel to be mounted onto the centring pin and push it on.

**!** **WARNING** Risk of injury from tightening wheel bolts and nuts

If you tighten the wheel bolts or wheel nuts when the vehicle is raised, the jack could tip.

- ▶ Only tighten wheel bolts or wheel nuts when the vehicle is on the ground.

- ▶ Be sure to observe the instructions and safety notes on "Changing a wheel" (→ page 401).
- ▶ For safety reasons, only use wheel bolts which have been approved by Mercedes-Benz and for the wheel in question.
- ▶ Tighten the wheel bolts evenly in a diagonal pattern in the order indicated until they are finger-tight.
- ▶ Unscrew and remove the centring pin.
- ▶ Tighten the last wheel bolt until it is finger-tight.
- ▶ Lower the vehicle (→ page 409).

## Lowering the vehicle after a wheel change

### Requirements:


- The new wheel has been fitted (→ page 408).

**!** **NOTE** Risk of vehicle jack becoming trapped by the AIRMATIC system

If the AIRMATIC system has released air when raising the vehicle, the jack can become trapped when the vehicle is lowered.

- ▶ Start the drive system. This adapts the vehicle level.
- ▶ Remove the jack from under the vehicle.

- ▶ **To lower the vehicle:** place the ratchet onto the hexagon nut of the jack so that the letters "AB" are visible and turn anti-clockwise.



- ▶ Tighten the wheel bolts evenly in a diagonal pattern in the order indicated ① to ⑤ with an initial maximum force of 80 Nm.
- ▶ Tighten the wheel bolts evenly in a diagonal pattern in the order indicated ① to ⑤ with the specified tightening torque of 150 Nm.

**⚠ WARNING** Risk of accident due to incorrect tightening torque

The wheels could come loose if the wheel bolts or wheel nuts are not tightened to the prescribed torque.

- ▶ Ensure that the wheel bolts or wheel nuts are tightened to the prescribed tightening torque.
- ▶ If you are not sure, do not move the vehicle. Contact a qualified specialist workshop and have the tightening torque checked immediately.

- ▶ Check the tyre pressure of the newly fitted wheel and adjust it if necessary.
- ① The following does not apply if the new wheel is an emergency spare wheel.
- ▶ **Vehicles with a tyre pressure monitoring system:** restart the tyre pressure monitoring system (→ page 400).

## Emergency spare wheel

### Notes on the emergency spare wheel

**⚠ WARNING** Risk of accident caused by incorrect wheel and tyre dimensions

The wheel or tyre size and the tyre type of the emergency spare wheel or spare wheel and the wheel to be replaced may differ. The emergency spare wheel or spare wheel can significantly impair driving characteristics of the vehicle.

To prevent hazardous situations:

- ▶ Drive carefully.
- ▶ Never fit more than one emergency spare wheel or spare wheel that differs in size.
- ▶ Only use an emergency spare wheel or spare wheel briefly.
- ▶ Do not deactivate ESP®.
- ▶ Have the emergency spare wheel or spare wheel of a different size replaced at the nearest qualified specialist work-

shop. The new wheel must have the correct dimensions.

- ❗ The emergency spare wheel is secured in the emergency spare wheel bag in the boot.

Observe the following notes on fitting an emergency spare wheel:

- The maximum permissible speed with an emergency spare wheel fitted is 80 km/h.
- Do not fit the emergency spare wheel with snow chains.
- Replace the emergency spare wheel after six years at the latest, regardless of wear.
- Use the wheel bolts that are included with the emergency spare wheel.
- Check the tyre pressure of the emergency spare wheel fitted. Correct the pressure as necessary.

- ❗ The specified tyre pressure is stated on the label of the emergency spare wheel.

- ❗ **Vehicles with a tyre pressure monitoring system:** if an emergency spare wheel is fitted, the tyre pressure monitoring system cannot func-

tion reliably. For a few minutes after an emergency spare wheel is fitted, the system may still display the tyre pressure of the removed wheel. Only restart the system again when the emergency spare wheel has been replaced with a new wheel.

Be sure to also observe the following further related subjects:

- Notes on tyre pressure (→ page 397)
- Tyre pressure table (→ page 398)
- Notes on fitting tyres (→ page 401)
- Fitting an emergency spare wheel (→ page 405)

Notes on technical data

**NOTE** Mercedes-AMG vehicles

- ▶ Observe the notes in the Supplement. You could otherwise fail to recognise dangers.

The technical data was determined in accordance with EU Directives. The data stated only applies to vehicles with standard equipment. You can obtain further information from a Mercedes-Benz Service Centre.

**Only for certain countries:** you can find vehicle-specific vehicle data in the COC documents (CERTIFICATE OF CONFORMITY). These documents are supplied when the vehicle is delivered.

On-board electronics

Notes on tampering with the engine electronics

**NOTE** Premature wear through improper maintenance

- Improper maintenance may cause vehicle components to wear more quickly and the vehicle's operating permit may be invalidated.
- ▶ Always have work on the engine electronics and related components carried out at a qualified specialist workshop.

Two-way radios

Notes on fitting two-way radios

**WARNING** Risk of accident due to improper work on two-way radios

If two-way radios are manipulated or retrofitted incorrectly, the electromagnetic radiation from the two-way radios can interfere with the vehicle electronics and jeopardise the operating safety of the vehicle.

- ▶ You should have all work on electrical and electronic components carried out at a qualified specialist workshop.

**WARNING** Risk of accident due to improper operation of two-way radios

If you use two-way radios in the vehicle improperly, their electromagnetic radiation can disrupt the vehicle's electronics. This is the case in the following situations, in particular:

- The two-way radio is not connected to an exterior aerial.
- The exterior aerial is fitted incorrectly or is not a low-reflection aerial.


This could jeopardise the operating safety of the vehicle.

- ▶ Have the low-reflection exterior aerial fitted at a qualified specialist workshop.
- ▶ When operating two-way radios in the vehicle, always connect them to the low-reflection exterior aerial.

**! NOTE** Invalidation of the operating permit due to failure to comply with the instructions for installation and use

The operating permit may be invalidated if the instructions for installation and use of two-way radios are not observed.

- ▶ Only use approved frequency bands.
- ▶ Observe the maximum permissible output power in these frequency bands.
- ▶ Only use approved aerial positions.



**① Rear roof area**

On vehicles with a panoramic sliding sunroof, fitting an aerial is not permitted.

Use Technical Specification ISO/TS 21609 (Road Vehicles – "EMCs for installation of aftermarket radio frequency transmitting equipment") when retrofitting two-way radios. Comply with the legal requirements for detachable parts.

If your vehicle has fittings for two-way radio equipment, use the power supply and aerial connectors provided in the pre-installation. Observe the manufacturer's supplements when fitting.

**Two-way radio transmission output**

The maximum transmission output (PEAK) at the base of the aerial must not exceed the values in the following table.

**Frequency band and maximum transmission output**

| Frequency band                                     | Maximum transmission output |
|----------------------------------------------------|-----------------------------|
| 2-m frequency band<br>144 - 174 MHz                | 50 W                        |
| Terrestrial Trunked Radio (TETRA)<br>380 - 460 MHz | 10 W                        |
| 70-cm frequency band<br>430 - 470 MHz              | 35 W                        |



| Frequency band            | Maximum transmission output |
|---------------------------|-----------------------------|
| Two-way radio<br>2G       | 2 W                         |
| Two-way radio<br>3G/4G/5G | 0.5 W                       |

The following devices can be used in the vehicle without restrictions:

- two-way radios with a maximum transmission output of up to 100 mW
- two-way radios with transmitter frequencies in the 380 - 420 MHz frequency band and a maximum transmission output of up to 2 W (TETRA)
- mobile phones (2G/3G/4G/5G)

There are no restrictions when positioning the aerial on the outside of the vehicle for the following frequency bands:

- TETRA
- 2G/3G/4G/5G

Regulatory radio identification and notes

Regulatory radio identification of small components

Manufacturer information about radio-based vehicle components can be found using the key phrase "Regulatory radio identification" in the Digital Owner's Manual in the vehicle, on the internet and in the app.

Regulatory radio identification – Indonesia and Israel

Manufacturer information about radio-based vehicle components for Indonesia and Israel can be found using the key phrase "Regulatory radio identification – Indonesia and Israel" in the Digital Owner's Manual in the vehicle, on the internet and in the app.



 These are not small components. Information about small components can be found using the key phrase "Regulatory radio identification of small components".

Further component-specific information

Further component-specific information can be found using the key phrase "further component-specific information" in the Digital Owner's Manual in the vehicle, on the internet and in the app.


## Vehicle identification plate, VIN and engine number overview

### Vehicle identification plate



Vehicle identification plate (example: Kuwait)

- ① Vehicle manufacturer
- ② Place of manufacture
- ③ Manufacturing date
- ④ Vehicle model
- ⑤ VIN




Vehicle identification plate (example: all other countries)

- ① Vehicle manufacturer
- ② EU general operating permit number (only for certain countries)
- ③ VIN (vehicle identification number)
- ④ Maximum permissible gross vehicle weight (kg)


- ⑤ Maximum permissible gross weight of vehicle combination (kg) (only for specific countries)
- ⑥ Maximum permissible front axle load (kg)
- ⑦ Maximum permissible rear axle load (kg)
- ⑧ Paint code
- ① The data shown in the illustration is example data.

### VIN below the front right-hand seat



- ① Imprinted VIN (vehicle identification number)
- ② Floor covering

### VIN at the lower edge of the windscreen



- ① VIN (vehicle identification number) as label

The VIN as a label at the lower edge of the windscreen is only available in some countries.

### Engine number

Further information on motor numbers can be obtained at a qualified specialist workshop.

## Operating fluids

### Notes on operating fluids

**⚠ WARNING** Risk of injury from operating fluids harmful to your health

Operating fluids may be poisonous and harmful to your health.

- ▶ Observe the text on the original containers when using, storing or disposing of operating fluids.
- ▶ Always store operating fluids sealed in their original containers.
- ▶ Always keep children away from operating fluids.

**🌿 ENVIRONMENTAL NOTE** Pollution of the environment due to irresponsible disposal of operating fluids

Incorrect disposal of operating fluids can cause considerable damage to the environment.

▶ Dispose of operating fluids in an environmentally responsible manner.

Operating fluids include the following:

- lubricants
- coolant
- Brake fluid
- windscreen washer fluid
- climate control system refrigerant

Only use products approved by Mercedes-Benz. Damage caused by the use of products that have not been approved is not covered by the Mercedes-Benz warranty or goodwill gestures.

You can identify operating fluids approved by Mercedes-Benz by the following inscriptions on the container:

- MB-Freigabe (e.g. MB-Freigabe 229.51)
- MB-Approval (e.g. MB-Approval 229.51)

Further information on approved operating fluids is available at the following locations:

- in the Mercedes-Benz Specifications for Operating Fluids by entering the designation
  - at <https://bevo.mercedes-benz.com>
  - in the Mercedes-Benz BeVo App
- At a qualified specialist workshop

### Notes on brake fluid

Observe the notes on operating fluids (→ page 417).

**⚠ WARNING** Risk of an accident due to vapour pockets forming in the brake system

The brake fluid constantly absorbs moisture from the air. This lowers the boiling point of the brake fluid. If the boiling point is too low, vapour pockets may form in the brake system when the brakes are applied hard.

This impairs the braking effect.

- ▶ Have the brake fluid renewed at the specified intervals.

Have the brake fluid regularly replaced at a qualified specialist workshop.  
Only use a brake fluid approved by Mercedes-Benz according to MB-Freigabe or MB-Approval 331.0.

## Coolant

### Notes on coolant

Observe the notes on operating fluids (→ page 417).

**⚠ WARNING** Risk of fire- and injury from antifreeze

If antifreeze comes into contact with hot component parts in the engine compartment, it may ignite.

- ▶ Allow the drive system to cool down before you top up the antifreeze.
- ▶ Make sure that no antifreeze spills out next to the filler opening.

- ▶ Thoroughly clean the antifreeze from component parts before starting the vehicle.

**! NOTE** Damage caused by incorrect coolant

- ▶ Only use coolant that has been premixed with the required antifreeze protection.

Information on coolant is available at the following locations:

- In the Mercedes-Benz Specification for Operating Fluids 320.1
  - At <https://bevo.mercedes-benz.com>
  - In the Mercedes-Benz BeVo App
- At a qualified specialist workshop

**! NOTE** Overheating at high outside temperatures

If an inappropriate coolant is used, the engine cooling system is not sufficiently protected against overheating and corrosion at high outside temperatures.

- ▶ Only use coolant approved for Mercedes-Benz.
- ▶ Observe the instructions in the Mercedes-Benz Specifications for Operating Fluids 320.1.

Have the coolant regularly replaced at a qualified specialist workshop.

Proportion of antifreeze concentrate in the engine cooling system:

- A minimum of 50% (antifreeze protection down to about -37°C)
- A maximum of 55% (antifreeze protection down to -45°C)

## Notes on windscreen washer fluid

Observe the notes on operating fluids (→ page 417).

**! WARNING** Risk of fire and injury from windscreen washer concentrate

Windscreen washer concentrate is highly flammable. If it comes into contact with hot components, it may ignite.

- ▶ Make sure that windscreen washer concentrate is not spilled near to the filler opening.

**! NOTE** Damage to the exterior lighting due to unsuitable windscreen washer fluid

Unsuitable windscreen washer fluids may damage the plastic surface of the exterior lighting.

- ▶ Only use windscreen washer fluids which are also suitable for use on plastic surfaces, e.g. MB SummerFit or MB WinterFit.

**! NOTE** Blocked spray nozzles caused by mixing windscreen washer fluids

- ▶ Do not mix MB SummerFit and MB WinterFit with other windscreen washer fluids.

Do not use distilled or de-ionised water. Otherwise, the fill level sensor may be triggered erroneously.

Recommended windscreen washer fluid:

- above freezing point: e.g. MB SummerFit
- below freezing point: e.g. MB WinterFit

For the correct mixing ratio, refer to the information on the antifreeze container.

Mix washer fluid with windscreen washer fluid all year round.

### Windscreen washer system

#### Washer fluid reservoir capacity

| Model      | Filling volume |
|------------|----------------|
| All models | Maximum 3.7 l  |

### Vehicle data

#### Vehicle dimensions

The heights specified may vary as a result of the following factors:

- tyres
- load
- condition of the suspension
- optional equipment

#### Vehicle dimensions

| EQE 350+                                |         |
|-----------------------------------------|---------|
| Vehicle length                          | 4946 mm |
| Vehicle width including outside mirrors | 2103 mm |
| Vehicle width excluding outside mirrors | 1961 mm |
| Vehicle height                          | 1512 mm |
| Wheelbase                               | 3120 mm |

Weights and loads

Please observe the following notes for the specified vehicle data:

- Items of optional equipment increase the unladen weight and reduce the payload.
- Vehicle-specific weight information can be found on the vehicle identification plate (→ page 415).

Also observe the notes on loading the vehicle (→ page 124).

Maximum design speeds

**! NOTE** Tyres for vehicles with AMG DYNAMIC PLUS package

The specified maximum speed for vehicles with the **AMG DYNAMIC PLUS package** is only designed for a specific type of tyres.

- ▶ Only drive the specified maximum speed with summer tyres.

- ▶ Please also observe the notes on the approved tyre types. You could otherwise fail to recognise dangers.

You will find the information on the approved tyre types in the "Selecting, fitting and replacing tyres" section in the Owner's Manual of your vehicle.

Not for Mercedes-AMG vehicles:

Missing values were not available at the time of going to press.

Maximum permissible speed

|            |  |
|------------|--|
| All models |  |
|------------|--|

High-voltage battery


Notes on the power supply for vehicles with a high-voltage battery

In accordance with European standard EN 17186:2019 vehicle identifiers are located on the vehicle in the following places:

- On the inside of the socket flap
- On the charging cable connector

In addition, charging stations in European countries are equipped with energy supply identifiers. You can recharge your vehicle at charging stations where the charging station identifier corresponds to the vehicle identifier.

For further information on charging the high-voltage battery, refer to the "Charging the high-voltage battery" section (→ page 193).



- ① Supply type: AC  
Standard: EN 62196-2  
Style: type 2  
Plug type: charging cable socket and vehicle plug  
Voltage range: 480 V RMS

- ② Supply type: DC  
Standard: EN 62196-3  
Style: FF  
Plug type: charging cable socket and vehicle plug  
Voltage range: 50 V to 500 V
- ③ Supply type: DC  
Standard: EN 62196-3  
Style: FF  
Plug type: charging cable socket and vehicle plug  
Voltage range: 200 V to 920 V

Missing values were not available at the time of going to press.

### Maximum battery capacity and charging times

| EQE 350+              |             |
|-----------------------|-------------|
| Type                  | Lithium-ion |
| Usable energy content | 90.56 kWh   |

| EQE 350+                                           |                    |
|----------------------------------------------------|--------------------|
| Charge time – mode 2 with 1.8 kW charging capacity |                    |
| Charge time – mode 3 with 11 kW charging capacity  | Approx. 8 h 15 min |
| Charge time – mode 4 with 170 kW charging capacity | Approx. 32 min     |

Charging times – modes 2 and 3 apply to AC charging from 10% to 100% of the usable energy content.

Charging time – mode 4 applies to DC charging from 10% to 80% of the usable energy content.

The time taken to charge the battery depends on the charge status of the battery, the ambient temperature and the charging capacity of the battery. The charging capacity, in turn, depends on the supply voltage, the current intensity and the type of power supply.

The nominal voltage range for your vehicle can be found on the information label in the socket cover (→ page 193).

### Trailer hitch

#### General notes on the trailer hitch



Modifications to the cooling system may be necessary, depending on the vehicle model. The retrofitting of a trailer hitch is only permissible if a towing capacity is specified in your vehicle documents.

Further information can be obtained at a qualified specialist workshop.

#### Mounting dimensions of the trailer hitch

The overhang dimension and fastening points are valid for a trailer hitch installed at the factory.





- ① Fastening points
- ② Overhang dimension
- ③ Rear axle centre line

### Overhang dimension length

| Model    | ② Overhang dimension |
|----------|----------------------|
| EQE 350+ | 1033 mm              |

### Towing capacity

- ① The tongue weight is not included in the towing capacity.

### Towing capacity, braked (at a minimum start-off gradeability of 12%)

| Model    | Towing capacity, braked |
|----------|-------------------------|
| EQE 350+ | 750 kg                  |

### Towing capacity, unbraked

| Model    | Towing capacity, unbraked |
|----------|---------------------------|
| EQE 350+ | 750 kg                    |

### Maximum tongue weight and load capacity

- ❗ **NOTE** Damage caused by the trailer coming loose

If the tongue weight used is too low, the trailer may come loose.

- ▶ The tongue weight must not be below 50 kg.
- ▶ Use a tongue weight that is as close as possible to the maximum permissible tongue weight.

- ❗ **NOTE** Damage caused by the bicycle rack coming loose

When using a bicycle rack, both the maximal tongue weight and the maximal load capacity should be observed.

- ▶ Do not exceed the permissible load capacity.

Observe the additional notes on load capacity (→ page 295).

**Tongue weight**

| Model    | Maximum tongue weight |
|----------|-----------------------|
| EQE 350+ | 75 kg                 |

**Load capacity**

| EQE 350+                                                                           | Maximum load |
|------------------------------------------------------------------------------------|--------------|
| When attaching the bicycle rack to the ball head                                   | 75 kg        |
| When attaching the bicycle rack to the ball head and additionally to the guide pin | 100 kg       |

**Permissible rear axle load (trailer operation)****Trailer operation axle load**

| Model    | Axle load |
|----------|-----------|
| EQE 350+ | 1700 kg   |

## Display messages

### Introduction

#### Information about display messages

Display messages appear on the driver display.

Display messages with graphical symbols are simplified in the Owner's Manual and may differ from the symbols on the driver display. The driver display shows high-priority display messages in red. Certain display messages are accompanied by a warning tone.

Please act in accordance with the display messages and follow the additional notes in the Owner's Manual.

For some display messages, symbols will also be shown:

- ⓘ Further information
- [x] Hide display message

With the left-hand Touch Control, you can select the respective symbol by swiping to the left or right. Pressing ⓘ displays further information on the central display. Press the [x] symbol to hide the display message.

You can hide low-priority display messages by pressing the back button  or the left-hand Touch Control. The display messages will then be stored in the message memory.

Rectify the cause of a display message as quickly as possible.

High-priority display messages cannot be hidden. The driver display will show these display messages continuously until the cause of the display message has been rectified.

#### Calling up saved display messages

Driver's display:



The **Message memory: XX** message appears on the driver's display.

▶ Scroll through the display messages by swiping upwards or downwards on the left-hand Touch Control.

▶ **To exit the display:** press back button .

## Occupant safety

| Display messages                                                                                                                                                       | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p data-bbox="133 353 451 415">Restraint system malfunction Consult workshop</p>     | <p data-bbox="530 242 1165 273">* The restraint system is malfunctioning (→ page 44).</p> <div data-bbox="556 294 1939 576"> <p data-bbox="566 304 1403 335"><b>⚠ DANGER</b> Risk of fatal injuries due to restraint system malfunctions</p> <p data-bbox="572 353 1886 415">Components in the restraint system may be activated unintentionally or not deploy as planned in an accident. In the event of an accident, the high-voltage on-board electrical system may not be deactivated as intended.</p> <p data-bbox="572 425 1862 487">You may suffer an electric shock if you touch the damaged components of the high-voltage on-board electrical system.</p> <ul data-bbox="572 498 1725 570" style="list-style-type: none"> <li data-bbox="572 498 1725 529">► Have the restraint system checked and repaired immediately at a qualified specialist workshop.</li> <li data-bbox="572 539 1231 570">► After an accident, switch off the vehicle immediately.</li> </ul> </div>               |
|  <p data-bbox="133 710 459 772">Front left malfunction Consult workshop (example)</p> | <p data-bbox="530 599 1342 630">* The corresponding restraint system is malfunctioning (→ page 44).</p> <div data-bbox="556 651 1939 933"> <p data-bbox="566 662 1403 693"><b>⚠ DANGER</b> Risk of fatal injuries due to restraint system malfunctions</p> <p data-bbox="572 710 1886 772">Components in the restraint system may be activated unintentionally or not deploy as planned in an accident. In the event of an accident, the high-voltage on-board electrical system may not be deactivated as intended.</p> <p data-bbox="572 783 1862 845">You may suffer an electric shock if you touch the damaged components of the high-voltage on-board electrical system.</p> <ul data-bbox="572 855 1725 928" style="list-style-type: none"> <li data-bbox="572 855 1725 886">► Have the restraint system checked and repaired immediately at a qualified specialist workshop.</li> <li data-bbox="572 897 1231 928">► After an accident, switch off the vehicle immediately.</li> </ul> </div> |

| Display messages                                                                                                                              | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|-----------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Left windowbag malfunction Consult workshop (example)</p> | <p>* The corresponding restraint system is malfunctioning (→ page 44).</p> <div data-bbox="493 246 1880 388"> <p><b>⚠ WARNING</b> Risk of injury or fatal injury due to a malfunction in the windowbag</p> <p>The windowbag might be triggered unintentionally or might not be triggered at all in the event of an accident.</p> <p>► Have the windowbag checked and repaired immediately at a qualified specialist workshop.</p> </div>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <p>Front passenger airbag disabled See Owner's Manual</p>                                                                                     | <p>* The front passenger airbag has been disabled even though an adult or a person of adult build is on the front passenger seat. If additional forces are applied to the seat, the weight the system detects may be too low.</p> <div data-bbox="493 512 1880 758"> <p><b>⚠ WARNING</b> - Risk of injury or even fatal injury when the front passenger airbag is disabled</p> <p>If the front passenger airbag is disabled, It will not be deployed in the event of an accident and cannot perform its intended protective function.</p> <p>A person in the front passenger seat could then, for example, come into contact with the vehicle interior, especially if the person is sitting too close to the dashboard.</p> <p>► Be aware of the status of the front passenger airbag both before and during the journey.</p> </div> <div data-bbox="493 774 1443 933"> <p>► Stop the vehicle immediately in accordance with the traffic conditions.</p> <p>► Make sure that no objects are trapped under the front passenger seat.</p> <p>► Check the status of automatic front passenger airbag actuation (→ page 54).</p> <p>► If necessary, consult a qualified specialist workshop immediately.</p> </div> |

| Display messages                                         | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|----------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>Front passenger airbag enabled See Owner's Manual</p> | <p>* The front passenger airbag will be enabled while the vehicle is in motion in the following situations:</p> <ul style="list-style-type: none"> <li>• even when a child, a small adult or an object weighing less than the system weight threshold is located on the front passenger seat</li> <li>• even when the front passenger seat is not occupied</li> </ul> <p>The system may detect objects or forces that are adding to the weight applied to the seat.</p> <div data-bbox="554 412 1941 491"> <p> <b>WARNING</b> Risk of injury or death when using a child restraint system while the front passenger airbag is enabled</p> </div> <p>If you secure a child in a child restraint system on the front passenger seat and the front passenger airbag is enabled, the front passenger airbag can deploy in the event of an accident.</p> <p>The child could be struck by the airbag.</p> <p>► Ensure, both before and during the journey, that the status of the front passenger airbag is correct.</p> <p>NEVER use a rearward facing child restraint on a seat protected by an ACTIVE AIRBAG in front of it, DEATH or SERIOUS INJURY to the CHILD can occur.</p> <ul style="list-style-type: none"> <li>► Stop the vehicle immediately in accordance with the traffic conditions.</li> <li>► Make sure that no objects are trapped under the front passenger seat.</li> <li>► Check the status of automatic front passenger airbag actuation (→ page 54).</li> <li>► If necessary, consult a qualified specialist workshop immediately.</li> </ul> |

| Display messages                                     | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                            |
|------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PRE-SAFE inoperative See Owner's Manual              | <ul style="list-style-type: none"> <li>* The PRE-SAFE® functions are malfunctioning.               <ul style="list-style-type: none"> <li>► Consult a qualified specialist workshop.</li> </ul> </li> </ul>                                                             |
| PRE-SAFE impulse side inoperative See Owner's Manual | <ul style="list-style-type: none"> <li>* The PRE-SAFE® Impulse Side system is malfunctioning or inoperative after having already been triggered.               <ul style="list-style-type: none"> <li>► Consult a qualified specialist workshop.</li> </ul> </li> </ul> |

## Key

| Display messages                                                                                         | Possible causes/consequences and ► Solutions                                                                                                                                           |
|----------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>Replace key          | <ul style="list-style-type: none"> <li>* Have the key replaced.               <ul style="list-style-type: none"> <li>► Consult a qualified specialist workshop.</li> </ul> </li> </ul> |
| <br>Change key batteries | <ul style="list-style-type: none"> <li>* The key battery is discharged.               <ul style="list-style-type: none"> <li>► Replace the battery (→ page 82).</li> </ul> </li> </ul> |

| Display messages                                                                                                                  | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|-----------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Key not detected (white display message)</p> | <p>* The key is currently undetected.</p> <ul style="list-style-type: none"> <li>► Change the location of the key in the vehicle.</li> <li>► If the key is still not recognised, place it in the slot for starting with the key (→ page 180).</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|  <p>Key not detected (red display message)</p>   | <p>* The key cannot be detected and may no longer be in the vehicle.<br/>If the key is no longer in the vehicle and you switch off the vehicle:</p> <ul style="list-style-type: none"> <li>• You can no longer start the vehicle.</li> <li>• You cannot centrally lock the vehicle.</li> </ul> <p>► Ensure that the key is in the vehicle.</p> <p>If the key is in the vehicle and still not recognised:</p> <ul style="list-style-type: none"> <li>► Stop the vehicle immediately in accordance with the traffic conditions.</li> <li>► Place the key in the slot for starting the engine with the key (→ page 180).</li> </ul> <p>The key battery is weak or discharged.</p> <ul style="list-style-type: none"> <li>► Check the battery using the indicator lamp (→ page 80).</li> <li>► Replace the key battery, if necessary (→ page 82).</li> </ul> |



| Display messages                                                                                                          | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                     |
|---------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Key being initialised Please wait</p> | <ul style="list-style-type: none"> <li>* The vehicle is processing in order to teach in the new key. <ul style="list-style-type: none"> <li>► Wait until processing is complete.</li> </ul> </li> </ul>                                                                          |
| <p>Place the key in the marked space See Owner's Manual</p>                                                               | <ul style="list-style-type: none"> <li>* Key detection is malfunctioning. <ul style="list-style-type: none"> <li>► Change the location of the key in the vehicle.</li> <li>► Place the key in the slot for starting the engine with the key (→ page 180).</li> </ul> </li> </ul> |

## Lights

| Display messages                                                                                                   | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                     |
|--------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Left dipped beam (example)</p> | <ul style="list-style-type: none"> <li>* The corresponding light source is defective. <ul style="list-style-type: none"> <li>► Drive on carefully.</li> <li>► Consult a qualified specialist workshop immediately.</li> </ul> </li> <li>ⓘ LED light sources: the display message for the corresponding light appears only when all the light-emitting diodes in the light are faulty.</li> </ul> |

| Display messages                                                                                                                                          | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p data-bbox="133 308 439 365">Malfunction See Owner's Manual</p>       | <ul style="list-style-type: none"> <li>* The exterior lighting is malfunctioning.               <ul style="list-style-type: none"> <li>► Consult a qualified specialist workshop.</li> </ul> </li> <li>* <b>Vehicles with a trailer hitch:</b> a fuse may have blown.               <ul style="list-style-type: none"> <li>► Stop the vehicle in accordance with the traffic conditions.</li> <li>► Check the fuses and replace them if necessary (→ page 394).</li> </ul> </li> </ul> |
|  <p data-bbox="133 524 419 581">Automatic driving lights inoperative</p> | <ul style="list-style-type: none"> <li>* The light sensor for automatic driving lights is malfunctioning.               <ul style="list-style-type: none"> <li>► Consult a qualified specialist workshop.</li> </ul> </li> </ul>                                                                                                                                                                                                                                                       |
|  <p data-bbox="133 726 465 783">Active Light System inoperative</p>      | <ul style="list-style-type: none"> <li>* The active headlamps are malfunctioning.               <ul style="list-style-type: none"> <li>► Consult a qualified specialist workshop.</li> </ul> </li> </ul>                                                                                                                                                                                                                                                                               |

| Display messages                                                                                            | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                              |
|-------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Switch on headlamps</p> | <ul style="list-style-type: none"> <li>* You are driving without low-beam headlamps.           <ul style="list-style-type: none"> <li>► Turn the light switch to the  or <b>AUTO</b> position.</li> </ul> </li> </ul>    |
|  <p>Switch off lights</p>   | <ul style="list-style-type: none"> <li>* You are leaving the vehicle and the lights are still switched on.           <ul style="list-style-type: none"> <li>► Turn the light switch to the <b>AUTO</b> position.</li> </ul> </li> </ul>                                                                   |
| <p>DIGITAL LIGHT Functions limited</p>                                                                      | <ul style="list-style-type: none"> <li>* The DIGITAL LIGHT system is malfunctioning. The lighting system will continue to work even without the functions of the DIGITAL LIGHT system.           <ul style="list-style-type: none"> <li>► Consult a qualified specialist workshop.</li> </ul> </li> </ul> |
| <p>Check dipped-beam setting (left/right-side traffic)</p>                                                  | <ul style="list-style-type: none"> <li>* The type of traffic has been selected manually.           <ul style="list-style-type: none"> <li>► Check the setting and change it manually if necessary (→ page 152).</li> </ul> </li> </ul>                                                                    |
| <p>Dipped-beam setting (left/right-side traffic) Manual adjustment only</p>                                 | <ul style="list-style-type: none"> <li>* The automatic headlamp conversion for left-hand/right-hand traffic has malfunctioned.           <ul style="list-style-type: none"> <li>► Change the headlamps over manually (→ page 152).</li> </ul> </li> </ul>                                                 |

| Display messages                                                              | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                               |
|-------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>Adaptive Highbeam Assist currently unavailable See Owner's Manual</p>      | <p>* Adaptive Highbeam Assist is temporarily unavailable.<br/>The system limits have been reached (→ page 149).<br/>Once the cause of the problem is no longer present, the system will be available again. The <b>Adaptive Highbeam Assist available again</b> display message will appear.</p> <ul style="list-style-type: none"> <li>► Drive on</li> <li>► Operate the high beam manually until Adaptive High Beam Assist is available again.</li> </ul>                |
| <p>Adaptive Highbeam Assist inoperative</p>                                   | <p>* Adaptive Highbeam Assist is malfunctioning.</p> <ul style="list-style-type: none"> <li>► Drive on</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>► Stop the vehicle in accordance with the traffic conditions and restart the vehicle.</li> <li>► If the display message does not disappear: consult a qualified specialist workshop.</li> <li>► Until then, operate the high beam manually.</li> </ul>                                                  |
| <p>Adaptive Highbeam Assist Plus currently unavailable See Owner's Manual</p> | <p>* Adaptive Highbeam Assist Plus is temporarily unavailable.<br/>The system limits have been reached (→ page 150).<br/>Once the cause of the problem is no longer present, the system will be available again. The <b>Adaptive Highbeam Assist Plus available again</b> display message will appear.</p> <ul style="list-style-type: none"> <li>► Drive on</li> <li>► Operate the high beam manually until Adaptive High Beam Assist Plus is available again.</li> </ul> |

| Display messages                          | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                        |
|-------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Adaptive Highbeam Assist Plus inoperative | <ul style="list-style-type: none"> <li>* Adaptive Highbeam Assist Plus is malfunctioning. <ul style="list-style-type: none"> <li>► Drive on</li> <li>or</li> <li>► Stop the vehicle in accordance with the traffic conditions and restart the vehicle.</li> <li>► If the display message does not disappear: consult a qualified specialist workshop.</li> <li>► Until then, operate the high beam manually.</li> </ul> </li> </ul> |
| Hazard warning lamp system Malfunction    | <ul style="list-style-type: none"> <li>* The hazard warning lamp switch is malfunctioning. <ul style="list-style-type: none"> <li>► Consult a qualified specialist workshop.</li> </ul> </li> </ul>                                                                                                                                                                                                                                 |

## Climate control

| Display messages                                                                                                                             | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                   |
|----------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>inoperative High-voltage battery charging incomplete</p> | <ul style="list-style-type: none"> <li>* The high-voltage battery is charging. Pre-entry climate control cannot be switched on. <ul style="list-style-type: none"> <li>► Wait until the charging process has achieved a minimum charge.</li> </ul> </li> </ul> |

| Display messages                                                                                                                                                  | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                         |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Inoperative Charge high-voltage battery</p>                                  | <ul style="list-style-type: none"> <li>* The charge of the high-voltage battery is too low. Pre-entry climate control cannot be switched on.           <ul style="list-style-type: none"> <li>► Charge the high-voltage battery (→ page 193).</li> </ul> </li> </ul>                                                                                                                 |
|  <p>Pre-entry climate control via key available again after starting vehicle</p> | <ul style="list-style-type: none"> <li>* You have attempted to switch on pre-entry climate control more than three times with the vehicle switched off.           <ul style="list-style-type: none"> <li>► Start the vehicle for ten seconds.<br/>Pre-entry climate control is operational again.</li> </ul> </li> </ul>                                                             |
|  <p>Pre-entry climate control via key inoperative High-voltage battery low</p>   | <ul style="list-style-type: none"> <li>* The charge of the high-voltage battery is too low. Pre-entry climate control cannot be switched on.           <ul style="list-style-type: none"> <li>► Charge the high-voltage battery (→ page 193).<br/>When the high-voltage battery is sufficiently charged, pre-entry climate control will be operational again.</li> </ul> </li> </ul> |

Drive system

| Display messages                                                                                                                | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                       |
|---------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Towing not permitted See Owner's Manual</p> | <ul style="list-style-type: none"><li>* The drive system is malfunctioning.<ul style="list-style-type: none"><li>► Have the vehicle transported only using a transporter or trailer (→ page 388).</li></ul></li></ul>                                                                                                                              |
|  <p>Acoustic presence indicator inoperative</p> | <ul style="list-style-type: none"><li>* The sound generator (acoustic vehicle warning system) is malfunctioning. No driving noises are being produced. The vehicle may not be heard by other road users.<ul style="list-style-type: none"><li>► Drive with particular care.</li><li>► Consult a qualified specialist workshop.</li></ul></li></ul> |
| <p>To switch off the vehicle, press the Start/Stop button for at least 3 seconds or 3 times</p>                                 | <ul style="list-style-type: none"><li>* You have pressed the start/stop button while the vehicle is in motion.<ul style="list-style-type: none"><li>► To switch off the drive system while the vehicle is in motion (→ page 180).</li></ul></li></ul>                                                                                              |
| <p>Cannot start vehicle See Owner's Manual</p>                                                                                  | <ul style="list-style-type: none"><li>* It is not possible to start the vehicle. A malfunction has occurred in the drive system.<ul style="list-style-type: none"><li>► Switch the vehicle off and lock it.</li></ul></li></ul>                                                                                                                    |

| Display messages                                                                                                             | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                              | <p>► After waiting for a short time, unlock the vehicle and start it again.</p> <p>► If the display message appears again and the vehicle does not start, consult a qualified specialist workshop.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|  <p>Top up coolant See Owner's Manual</p>   | <p>* The coolant level is too low.</p> <div data-bbox="554 336 1939 440"> <p><b>!</b> <b>NOTE</b> Damage to the drive system due to insufficient coolant</p> <p>► Avoid long journeys with insufficient coolant.</p> </div> <p>► Have the cooling system of the drive system checked at a qualified specialist workshop.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|  <p>Coolant Stop Switch off the vehicle</p> | <p>* The coolant is too hot.</p> <p>► Stop the vehicle immediately in accordance with the traffic conditions and switch off the drive system.</p> <div data-bbox="554 609 1939 943"> <p><b>!</b> <b>WARNING</b> Risk of injury due to overheated vehicle</p> <p>If you open the bonnet in the event of an overheated vehicle or fire in the engine compartment, the following situations may occur:</p> <ul style="list-style-type: none"> <li>• You may come into contact with hot gases.</li> <li>• You may come into contact with other escaping hot operating fluids.</li> </ul> <p>► In the event of overheating or fire in the engine compartment, keep the bonnet closed and call the fire service.</p> <p>► Allow the overheated vehicle to cool down first if you need to open the bonnet.</p> </div> |






| Display messages                                                                 | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                 |
|----------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                  | <ul style="list-style-type: none"> <li>► Wait until the drive system has cooled down.</li> <li>► Make sure that the air supply to the vehicle radiator is not obstructed.</li> <li>► Avoiding high loads on the drive system, drive to the nearest qualified specialist workshop.</li> </ul> |
|  | <ul style="list-style-type: none"> <li>* The cooling system has detected a component fault.</li> <li>► Avoiding high loads on the drive system, drive to the nearest qualified specialist workshop.</li> </ul>                                                                               |
| <p>Socket flap blocked Please open manually</p>                                  | <ul style="list-style-type: none"> <li>* The socket flap is not opening automatically. An obstruction may be hindering the opening process.</li> <li>► Make sure that no objects are in the opening area.</li> <li>► Open the socket flap again.</li> </ul>                                  |
| <p>Please close socket flap manually. Obstruction detection active</p>           | <ul style="list-style-type: none"> <li>* The socket flap is not closing automatically. An obstruction may be hindering the closing process.</li> <li>► Make sure that no objects are in the closing area.</li> <li>► Close the socket flap again.</li> </ul>                                 |
| <p>Please close socket flap manually. Automatic function inoperative</p>         | <ul style="list-style-type: none"> <li>* The socket flap is not closing automatically. The motor of the socket flap may be defective.</li> <li>► Close the socket flap manually.</li> <li>► Consult a qualified specialist workshop.</li> </ul>                                              |

| Display messages                                                                                                 | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Charger cable connected</p> | <ul style="list-style-type: none"> <li>* You cannot pull away while the charging cable is connected.               <ul style="list-style-type: none"> <li>► Disconnect the charging cable from the vehicle.</li> </ul> </li> </ul>                                                                                                                                                                                                                                                                                                                      |
| <p>Not possible to unlock charging cable See Owner's Manual</p>                                                  | <ul style="list-style-type: none"> <li>* The charging cable connector cannot be removed from the charging station's socket.               <ul style="list-style-type: none"> <li>► Press the EMERGENCY OFF switch on the charging station.</li> </ul> <p>If the charging cable connector cannot be removed after that:</p> <ul style="list-style-type: none"> <li>► Request service personnel from the operator of the charging station via the emergency call button or the emergency numbers attached to the charging station.</li> </ul> </li> </ul> |
| <p>Vehicle not currently being charged Charging station fault</p>                                                | <ul style="list-style-type: none"> <li>* A malfunction has occurred in the charging station or the RFID card is not recognised.               <ul style="list-style-type: none"> <li>► Start the charging process at a different charging station.</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>► Have the RFID card checked to ensure it is functioning.</li> </ul> </li> </ul>                                                                                                                                                         |
| <p>Charging fault Please change charging method See Owner's Manual</p>                                           | <ul style="list-style-type: none"> <li>* A temporary malfunction has occurred in the charging station.               <ul style="list-style-type: none"> <li>► Wait until the malfunction has passed.</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>► Start the charging process at a different charging station.</li> </ul> </li> </ul>                                                                                                                                                                                                   |

| Display messages                                    | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|-----------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| AC charging inoperative<br>Consult workshop         | <ul style="list-style-type: none"> <li>* The charging process cannot be started due to a malfunction. <ul style="list-style-type: none"> <li>► Consult a qualified specialist workshop.</li> </ul> </li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| DC charging inoperative<br>Consult workshop         | <ul style="list-style-type: none"> <li>* The charging process cannot be started due to a malfunction. <ul style="list-style-type: none"> <li>► Consult a qualified specialist workshop.</li> </ul> </li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Reduced drive system performance See Owner's Manual | <ul style="list-style-type: none"> <li>* The drive system is outside the normal operating temperature range, e.g. due to extremely low or high outside temperatures.<br/>Drive system power output is reduced. The yellow reduced power output warning lamp  is lit.<br/>Once the operating temperature of the drive system returns to normal (e.g. after a short trip), the full output will be available again. The display message and the yellow reduced power output warning lamp  will go out. <ul style="list-style-type: none"> <li>► Drive on carefully.</li> </ul> </li> <li>* The high-voltage battery is not charged sufficiently.<br/>Drive system power output is reduced. The yellow reduced power output warning lamp  is lit. <ul style="list-style-type: none"> <li>► Drive on carefully.</li> <li>► Charge the high-voltage battery immediately.</li> </ul> </li> <li>* If the drive system power output is still reduced, there is a fault in the drive system. <ul style="list-style-type: none"> <li>► Drive on carefully.</li> <li>► Consult a qualified specialist workshop.</li> </ul> </li> </ul> |

| Display messages                                                                                                                                      | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|-------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Battery capacity too low<br/>Stop Charge immediately</p>         | <p>* The charge level of the high-voltage battery is so low that it is no longer possible to drive the vehicle. The drive system can no longer be restarted.</p> <p>When the drive system is restarted, the message <b>Battery capacity too low Stop Charge immediately</b> will appear again.</p> <ul style="list-style-type: none"> <li>► Stop the vehicle immediately in accordance with the traffic conditions.</li> <li>► Charge the high-voltage battery (→ page 193).</li> </ul>                                                                                                                                                                                           |
| <p>Please wait in READY status Warming battery See Owner's Manual</p>                                                                                 | <p>* Operational readiness is established <b>READY</b> and the transmission position <b>P</b> is engaged.</p> <p>The high-voltage battery is warmed up to the operating temperature. This process can take a few minutes and may be prolonged if defrosting of the windscreen  is activated.</p> <p>The heating process ends when transmission position <b>D</b> is engaged. However, when driving, the output is significantly limited until the high-voltage battery has reached its operating temperature.</p>                                                                              |
|  <p>Battery overheated Stop, everybody out! Outdoors if possible</p> | <p>* The high-voltage battery has overheated. There is a risk of fire.</p> <ul style="list-style-type: none"> <li>► Stop the vehicle immediately in accordance with the traffic conditions.</li> <li>► If possible, stop the vehicle in the open air and ensure that all vehicle occupants get out.</li> <li>① Supporting vehicle functions may activate automatically, e.g. the air-recirculation mode as part of climate control.</li> <li>► Do not continue driving.</li> <li>► If smoke is present, leave the danger zone and call the fire service immediately.</li> <li>► Consult a qualified specialist workshop even if there are no external signs of a fire.</li> </ul> |

| Display messages                                                                                                                            | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                       |
|---------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Malfunction</p>                                         | <ul style="list-style-type: none"> <li>* The drive system is malfunctioning. A warning tone will also sound.           <ul style="list-style-type: none"> <li>► Consult a qualified specialist workshop.</li> </ul> </li> </ul>                                                    |
|  <p>Malfunction Visit workshop</p>                          | <ul style="list-style-type: none"> <li>* The drive system is malfunctioning.           <ul style="list-style-type: none"> <li>► Consult a qualified specialist workshop.</li> </ul> </li> </ul>                                                                                    |
|  <p>Have high-voltage system checked See Owner's Manual</p> | <ul style="list-style-type: none"> <li>* A function restriction has occurred in the drive system.           <ul style="list-style-type: none"> <li>► Consult a qualified specialist workshop.</li> </ul> </li> </ul>                                                               |
| <p>Preparing drive system...</p>                                                                                                            | <ul style="list-style-type: none"> <li>* The insulation of the drive system is being tested. This process can last for up to ten seconds.</li> </ul>                                                                                                                               |
| <p>Consult workshop without starting the vehicle again</p>                                                                                  | <ul style="list-style-type: none"> <li>* It is not possible to restart the drive system due to a malfunction.           <ul style="list-style-type: none"> <li>► Do not switch off the drive system; drive on to the nearest qualified specialist workshop.</li> </ul> </li> </ul> |

| Display messages                                                                                                                   | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                   |
|------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Reserve level Charge high-voltage battery</p> | <ul style="list-style-type: none"> <li>* The charge level of the high-voltage battery has dropped into the reserve range. <ul style="list-style-type: none"> <li>► Charge the high-voltage battery (→ page 193).</li> </ul> </li> </ul>                                                                                                                                                        |
|  <p>Malfunction</p>                               | <ul style="list-style-type: none"> <li>* The drive system is malfunctioning. The output of your vehicle is restricted. <ul style="list-style-type: none"> <li>► Consult a qualified specialist workshop.</li> </ul> </li> </ul>                                                                                                                                                                |
|  <p>Stop Switch off the vehicle</p>               | <ul style="list-style-type: none"> <li>* The drive system is malfunctioning. <ul style="list-style-type: none"> <li>► Stop the vehicle immediately in accordance with the traffic conditions and switch off the drive system. Do not continue driving.</li> <li>► Do not tow the vehicle, stop towing if necessary.</li> <li>► Consult a qualified specialist workshop.</li> </ul> </li> </ul> |
|  <p>Malfunction Visit workshop</p>                | <ul style="list-style-type: none"> <li>* The drive system is malfunctioning. <ul style="list-style-type: none"> <li>► Consult a qualified specialist workshop.</li> </ul> </li> </ul>                                                                                                                                                                                                          |

| Display messages                                                                                                     | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|----------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Performance severely limited</p> | <p>* A malfunction has occurred in the high-voltage battery.<br/>Output and range are severely restricted.</p> <ul style="list-style-type: none"> <li>► Switch the vehicle off and lock it.</li> <li>► After waiting for a short time, unlock the vehicle and start it again.</li> </ul> <p>If the display message appears again:</p> <ul style="list-style-type: none"> <li>► Drive on carefully.</li> <li>► Fully charge the high-voltage battery (→ page 193).</li> </ul> <p>If the output and range are still reduced, there is a malfunction in the drive system.</p> <ul style="list-style-type: none"> <li>► Drive on carefully.</li> <li>► Consult a qualified specialist workshop.</li> </ul> |
| <p>High-voltage battery malfunction. No start in approx. XXX km Consult workshop (yellow display message)</p>        | <p>* A malfunction has occurred in the high-voltage battery.<br/>It will no longer be possible to start the electric drive system after the distance displayed has been covered.</p> <ul style="list-style-type: none"> <li>► Have the necessary maintenance work on the high-voltage battery carried out at a qualified specialist workshop.</li> </ul>                                                                                                                                                                                                                                                                                                                                               |

| Display messages                                                                                    | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                              |
|-----------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| High-voltage battery malfunction. No start in approx. XXX km Consult workshop (red display message) | <p>* A malfunction has occurred in the high-voltage battery.<br/>It will no longer be possible to start the electric drive system after the distance displayed has been covered.</p> <p>► Have the necessary maintenance work on the high-voltage battery carried out immediately at a qualified specialist workshop.</p> |
| High-voltage battery malfunction. Consult workshop without starting the vehicle again               | <p>* A malfunction has occurred in the high-voltage battery.<br/>It will no longer be possible to restart the drive system once it has been switched off.</p> <p>► Do not switch off the drive system; drive on to the nearest qualified specialist workshop.</p>                                                         |

## Vehicle

| Display messages                                                                  | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|-----------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <p>* The driver's display is inoperative due to a failed software update.<br/>The display message will be shown every time the engine is started.</p> <p><b>⚠ WARNING</b> Risk of accident due to failure of the driver display</p> <p>In the event that the driver display fails or malfunctions, you will not recognise function restrictions affecting systems relevant to safety. This may impair operating safety.</p> <p>► Park the vehicle safely as soon as possible and notify a qualified specialist workshop.</p> |



| Display messages                                                                                                                                     | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                      | <p>If the driver's display fails, you may not recognise function restrictions affecting systems relevant to safety or the speed display, for example. The operating safety of the vehicle may be impaired (→ page 320).</p> <p>► Have the vehicle checked by a qualified specialist workshop immediately.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|  <p>Vehicle is operational<br/>Switch off vehicle before exiting</p> | <p>* You are leaving the vehicle in a ready-to-drive state.</p> <p>► Get out of the vehicle, secure it against rolling away and take the key with you.</p> <p>► If you do not leave the vehicle, switch off the electrical consumers, e.g. the seat heating. Otherwise, the 12-V battery may discharge and starting the engine may be possible only with the help of a second battery (jump start).</p>                                                                                                                                                                                                                                                                                                                                                                                            |
|  <p>Check trailer hitch<br/>lock (white display message)</p>         | <p>* The trailer hitch is not operational during a journey with a trailer.</p> <div data-bbox="493 601 1880 826" style="border: 1px solid black; padding: 10px; margin: 10px 0;"> <p><b>⚠ WARNING</b> Risk of an accident if the ball neck is not locked</p> <p>The trailer may become detached.</p> <ul style="list-style-type: none"> <li>► Stop the vehicle immediately in accordance with the traffic conditions. Do not continue driving.</li> <li>► Uncouple the trailer and secure it against rolling away.</li> <li>► Initiate a new swivelling procedure and do not re-couple the trailer until the display message disappears.</li> </ul> </div> <p>► Initiate a new swivel movement (→ page 291).</p> <p>► When the display message disappears, couple up the trailer and drive on.</p> |


| Display messages                                         | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|----------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                          | <p>If the display message does not disappear, the trailer hitch is malfunctioning and the ball neck is not locked.</p> <ul style="list-style-type: none"> <li>► Do not couple up the trailer. Drive on without the trailer. Note the reduced ground clearance due to the unlocked ball neck.</li> <li>► Consult a qualified specialist workshop.</li> </ul> <p>* When the vehicle is stationary with a coupled trailer, the trailer hitch is not operational.</p> <ul style="list-style-type: none"> <li>► Uncouple the coupled trailer and secure it against rolling away.</li> <li>► <b>If the ball neck has been folded in:</b> unlock the ball neck (→ page 291).</li> <li>► Swivel the ball neck into the end position manually and let it engage.</li> <li>► <b>If the ball neck has been folded out:</b> unlock the ball neck (→ page 291).</li> <li>► Swivel the ball neck beneath the bumper manually and let it engage.</li> </ul> <p>If the display message does not disappear, the trailer hitch is malfunctioning and the ball neck is not locked.</p> <ul style="list-style-type: none"> <li>► Do not couple up the trailer. Drive on without the trailer. Note the reduced ground clearance due to the unlocked ball neck.</li> <li>► Consult a qualified specialist workshop.</li> </ul> |
| Head-up display currently unavailable See Owner's Manual | <p>* The head-up display is temporarily unavailable. Possible causes:</p> <ul style="list-style-type: none"> <li>• malfunctions in the power supply</li> <li>• signal interference</li> </ul> <ul style="list-style-type: none"> <li>► Stop in accordance with the traffic conditions and switch the vehicle off and on again.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |

| Display messages                                                                                                                            | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                             |
|---------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                             | <p>► If the display message still appears, consult a qualified specialist workshop.</p>                                                                                                                                                                                                                                                                                                                                                                                  |
| Head-up display inoperative                                                                                                                 | <p>* The head-up display has an internal error.</p> <p>► Consult a qualified specialist workshop.</p>                                                                                                                                                                                                                                                                                                                                                                    |
| Head-up display Brightness currently reduced See Owner's Manual                                                                             | <p>* The brightness of the head-up display is reduced. Possible causes:</p> <ul style="list-style-type: none"> <li>• Dirt on the windscreen in the camera's field of vision</li> <li>• Faulty exterior brightness signals</li> </ul> <p>► Switch on the windscreen wipers.</p> <p>► Clean the windscreen if necessary.</p> <p>► Switch the vehicle off and switch it back on</p> <p>► If the display message still appears, consult a qualified specialist workshop.</p> |
|  <p>Steering malfunction Drive carefully Visit workshop</p> | <p>* A power steering malfunction has occurred. Steering characteristics may be impaired as a result.</p> <p>► Drive on carefully.</p> <p>► Consult a qualified specialist workshop.</p>                                                                                                                                                                                                                                                                                 |

| Display messages                                                                                                                                                   | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Steering malfunction<br/>Increased physical effort<br/>See Owner's Manual</p> | <p>* The power steering assistance is malfunctioning.</p> <p><b>⚠ WARNING</b> Risk of an accident due to altered steering characteristics</p> <p>If the power assistance of the steering fails partially or completely, you will need to use more force to steer.</p> <ul style="list-style-type: none"> <li>► If safe steering is possible, drive on carefully.</li> <li>► Visit or consult a qualified specialist workshop immediately.</li> </ul>                                                                                          |
|  <p>Steering malfunction Stop immediately See Owner's Manual</p>                  | <p>* The steering is malfunctioning. Steering capability is significantly impaired.</p> <p><b>⚠ WARNING</b> Risk of accident if steering capability is impaired</p> <p>If the steering does not function as intended, the vehicle's operating safety is jeopardised.</p> <ul style="list-style-type: none"> <li>► Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances.</li> <li>► Consult a qualified specialist workshop.</li> </ul> |
|  <p>Rear axle steering currently malfunctioning</p>                               | <p>* The rear axle steering is temporarily unavailable. The turning circle may become wider.</p> <p>► Stop the vehicle in accordance with the traffic conditions and restart the vehicle.</p> <p>If the display message does not disappear:</p> <ul style="list-style-type: none"> <li>► Drive on carefully.</li> <li>► Consult a qualified specialist workshop.</li> </ul>                                                                                                                                                                   |

| Display messages                                                                                                             | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div data-bbox="82 194 272 294"></div> <div data-bbox="70 306 403 366">Rear axle steering Malfunction Visit workshop</div>   | <div data-bbox="465 194 1255 389"><ul style="list-style-type: none"><li>* The rear axle steering is malfunctioning.<br/>The rear axle has no steering capability.<br/>The steering wheel may be tilted when you drive in a straight line.<br/>► Adapt your speed and drive on carefully.<br/>► Consult a qualified specialist workshop immediately.</li></ul></div>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <div data-bbox="82 412 272 511"></div> <div data-bbox="70 524 403 584">Rear axle steering Malfunction Stop immediately</div> | <div data-bbox="465 412 1850 592"><ul style="list-style-type: none"><li>* The rear axle steering is malfunctioning.<br/>The rear axle has no steering capability.<br/>The steering wheel may be tilted considerably when you drive in a straight line.<br/>Depending on the steering wheel's tilted position, the steering wheel will also vibrate and a continuous warning tone will sound.</li></ul></div> <div data-bbox="506 615 1880 829"><div data-bbox="506 615 1880 664"><b>⚠ WARNING</b> Risk of accident if steering capability is impaired</div><div data-bbox="506 664 1880 829"><p>If the steering does not function as intended, the vehicle's operating safety is jeopardised.</p><ul style="list-style-type: none"><li>► Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances.</li><li>► Consult a qualified specialist workshop.</li></ul></div></div> <div data-bbox="491 850 1189 881"><p>► When stopping, bear the enlarged vehicle width in mind.</p></div> |

| Display messages                                                                  | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|-----------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Snow chain mode Maximum speed exceeded                                            | <ul style="list-style-type: none"> <li>* The maximum permissible speed for snow chain mode has been exceeded.               <ul style="list-style-type: none"> <li>► Drive more slowly.</li> </ul> </li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Active bonnet malfunction<br>See Owner's Manual                                   | <ul style="list-style-type: none"> <li>* The active bonnet (pedestrian protection) is malfunctioning or inoperative after having already been triggered.               <ul style="list-style-type: none"> <li>► Consult a qualified specialist workshop.</li> </ul> </li> </ul>                                                                                                                                                                                                                                                                                                                                                                         |
|  | <ul style="list-style-type: none"> <li>* At least one door is open.               <ul style="list-style-type: none"> <li>► Close all doors.</li> </ul> </li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|  | <ul style="list-style-type: none"> <li>* The bonnet is open.               <div data-bbox="554 552 1939 736"> <p><b>⚠ WARNING</b> Risk of accident due to driving with the bonnet unlocked</p> <p>The bonnet may open and block your view.</p> <ul style="list-style-type: none"> <li>► Never release the bonnet when driving.</li> <li>► Before every trip, ensure that the engine bonnet is locked.</li> </ul> </div> <ul style="list-style-type: none"> <li>► Stop the vehicle immediately in accordance with the traffic conditions.</li> <li>► Do not continue driving.</li> <li>► Consult a qualified specialist workshop.</li> </ul> </li> </ul> |

| Display messages                                                                                                                     | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                 |
|--------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                      | <ul style="list-style-type: none"> <li>* The boot lid is open.           <ul style="list-style-type: none"> <li>► Close the boot lid.</li> </ul> </li> </ul>                                                                                                                                                                                 |
| <p>Ambient light warning support inoperative</p>                                                                                     | <ul style="list-style-type: none"> <li>* The ambient lighting may not provide full visual warning support.           <ul style="list-style-type: none"> <li>► Lock the vehicle and unlock it again after a few minutes.</li> <li>► If the display message appears regularly, contact a qualified specialist workshop.</li> </ul> </li> </ul> |
|  <p>Rear left seat backrest not locked (Example)</p> | <ul style="list-style-type: none"> <li>* The seat backrest of the corresponding seat is not engaged.           <ul style="list-style-type: none"> <li>► Fold the seat backrest back until it engages.</li> </ul> </li> </ul>                                                                                                                 |
|  <p>Top up washer fluid</p>                          | <ul style="list-style-type: none"> <li>* The washer fluid level in the washer fluid reservoir has dropped below the minimum.           <ul style="list-style-type: none"> <li>► Top up the washer fluid (→ page 370).</li> </ul> </li> </ul>                                                                                                 |
| <p>Wiper Malfunction</p>                                                                                                             | <ul style="list-style-type: none"> <li>* The windscreen wiper is malfunctioning.           <ul style="list-style-type: none"> <li>► Restart the vehicle.</li> </ul> </li> </ul> <p>If the display message still appears:</p>                                                                                                                 |

| Display messages                                                                                                | Possible causes/consequences and ► Solutions                                                                                                                                                                                                 |
|-----------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Washer fluid flap open</p> | <ul style="list-style-type: none"> <li>► Consult a qualified specialist workshop.</li> </ul> <p>* The washer fluid filler flap is open.</p> <ul style="list-style-type: none"> <li>► Close washer fluid filler flap (→ page 370).</li> </ul> |

## Transmission

| Display messages                                     | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                               |
|------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Only select P when vehicle is stationary             | <ul style="list-style-type: none"> <li>* It is possible to select the park position <b>P</b> only if the vehicle is stationary.</li> <li>► Depress the brake pedal to stop.</li> <li>► Shift the transmission to park position <b>P</b> when the vehicle is stationary.</li> </ul>         |
| Apply brake to deselect P position                   | <ul style="list-style-type: none"> <li>* You have attempted to shift the transmission out of park position <b>P</b> and into another transmission position.</li> <li>► Depress the brake pedal.</li> <li>► Select transmission position <b>D</b>, <b>R</b> or neutral <b>N</b>.</li> </ul> |
| Apply brake and start vehicle to shift out of P or N | <ul style="list-style-type: none"> <li>* You have attempted to shift the transmission out of park position <b>P</b> or neutral <b>N</b> and into another transmission position.</li> <li>► Depress the brake pedal.</li> </ul>                                                             |



| Display messages                                                              | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                              |
|-------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                               | <ul style="list-style-type: none"> <li>► Start the vehicle.</li> <li>► Change the transmission position.</li> </ul>                                                                                                                                                                                                                                                                                                       |
| Apply brake to engage D or R                                                  | <ul style="list-style-type: none"> <li>* You have attempted to select transmission position <b>D</b> or <b>R</b>. <ul style="list-style-type: none"> <li>► Depress the brake pedal.</li> <li>► Select transmission position <b>D</b> or <b>R</b>.</li> </ul> </li> </ul>                                                                                                                                                  |
| Apply parking brake to park Visit workshop                                    | <ul style="list-style-type: none"> <li>* A malfunction has occurred in the emergency power supply to park position <b>P</b>. <ul style="list-style-type: none"> <li>► Consult a qualified specialist workshop.</li> <li>► Until then, always select park position <b>P</b> manually before you switch off the vehicle.</li> <li>► Before leaving the vehicle, apply the electric parking brake.</li> </ul> </li> </ul>    |
| Risk of vehicle rolling away<br>Driver's door open Trans-<br>mission not in P | <ul style="list-style-type: none"> <li>* The driver's door is not fully closed and transmission position <b>D</b>, <b>R</b> or neutral <b>N</b> is selected.<br/>The vehicle may roll away. <ul style="list-style-type: none"> <li>► Select park position <b>P</b> when switching off the vehicle.</li> </ul> </li> </ul>                                                                                                 |
| Risk of vehicle rolling away<br>Apply parking brake to park                   | <ul style="list-style-type: none"> <li>* The transmission is malfunctioning. Park position <b>P</b> cannot be selected. <ul style="list-style-type: none"> <li>► Park the vehicle safely.</li> <li>► Use the electric parking brake to secure the vehicle against rolling away.</li> <li>► On gradients, turn the front wheels so that the vehicle will roll towards the kerb if it starts moving.</li> </ul> </li> </ul> |

| Display messages                                                                      | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|---------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>Risk of vehicle rolling away<br/>N activated manually No automatic switch to P</p> | <p>* While the vehicle was at a standstill or driving at very low speed, neutral <b>[N]</b> was engaged with the drive system or the vehicle switched on.</p> <div data-bbox="556 277 1943 536"> <p><b>!</b> <b>NOTE</b> Damage to the vehicle due to rolling away</p> <p>When the vehicle is switched off or the driver's door is opened, automatic engagement of park position <b>[P]</b> is deactivated.</p> <p>The vehicle may roll away.</p> <ul style="list-style-type: none"> <li>► Be ready to brake.</li> <li>► Do not leave the vehicle unattended.</li> </ul> </div> <ul style="list-style-type: none"> <li>► Depress the brake pedal until the vehicle comes to a standstill.</li> <li>► Engage park position <b>[P]</b> when the vehicle is stationary with the brake pedal depressed.</li> <li>► To continue driving with the brake pedal depressed, select transmission position <b>[D]</b> or <b>[R]</b>.</li> </ul> |
| <p>N automatically activated<br/>Please engage transmission position again</p>        | <p>* Neutral <b>[N]</b> was automatically engaged when the vehicle was rolling or being driven.</p> <ul style="list-style-type: none"> <li>① When you open the driver's door in neutral <b>[N]</b>, park position <b>[P]</b> will be engaged automatically.</li> <li>► Engage park position <b>[P]</b> when the vehicle is stationary with the brake pedal depressed.</li> <li>► To continue driving with the brake pedal depressed, select transmission position <b>[D]</b> or <b>[R]</b>.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                               |

| Display messages                                            | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|-------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| N is selected Please select desired transmission position   | <ul style="list-style-type: none"> <li>* The accelerator pedal was depressed while the vehicle was rolling or moving in neutral <b>[N]</b>.               <ul style="list-style-type: none"> <li>► To accelerate the vehicle, select transmission position <b>[D]</b> or <b>[R]</b>.</li> </ul> </li> </ul>                                                                                                                                                                                  |
| Reversing not poss. Consult workshop                        | <ul style="list-style-type: none"> <li>* The transmission is malfunctioning. It is not possible to select transmission position <b>[R]</b>.               <ul style="list-style-type: none"> <li>► Consult a qualified specialist workshop.</li> </ul> </li> </ul>                                                                                                                                                                                                                           |
| Transmission Malfunction Stop                               | <ul style="list-style-type: none"> <li>* The transmission is malfunctioning. The transmission shifts to neutral <b>[N]</b> automatically.               <ul style="list-style-type: none"> <li>► Stop the vehicle immediately in accordance with the traffic conditions.</li> <li>► Depress the brake pedal.</li> <li>► Engage park position <b>[P]</b>.</li> <li>► Consult a qualified specialist workshop.</li> </ul> </li> </ul>                                                          |
| Consult workshop without changing the transmission position | <ul style="list-style-type: none"> <li>* The transmission is malfunctioning. It is no longer possible to change the transmission position.               <ul style="list-style-type: none"> <li>► If transmission position <b>[D]</b> is selected, consult a qualified specialist workshop and do not change the transmission position.</li> <li>► For all other transmission positions, park the vehicle safely.</li> <li>► Consult a qualified specialist workshop.</li> </ul> </li> </ul> |
| Auxiliary battery malfunction (white display message)       | <ul style="list-style-type: none"> <li>* There is a malfunction in the auxiliary battery.               <ul style="list-style-type: none"> <li>► Consult a qualified specialist workshop.</li> <li>► Until then, always select park position <b>[P]</b> manually before you switch off the vehicle.</li> </ul> </li> </ul>                                                                                                                                                                   |

| Display messages | Possible causes/consequences and ► Solutions                                                                      |
|------------------|-------------------------------------------------------------------------------------------------------------------|
|                  | <ul style="list-style-type: none"> <li>► Before leaving the vehicle, apply the electric parking brake.</li> </ul> |

## Brakes

| Display messages                                                                                                          | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|---------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Parking brake See Owner's Manual</p> | <p>* The yellow  indicator lamp is lit. The electric parking brake is malfunctioning.</p> <p><b>To apply:</b></p> <ul style="list-style-type: none"> <li>► Switch the vehicle off and switch it back on</li> <li>► Apply the electric parking brake manually (→ page 215).</li> </ul> <p>If it is not possible to apply the electric parking brake:</p> <ul style="list-style-type: none"> <li>► Consult a qualified specialist workshop.</li> <li>► Where necessary, also secure the parked vehicle against rolling away.</li> </ul> <p>* The yellow  indicator lamp and the red  indicator lamp are lit. The electric parking brake is malfunctioning.</p> <p><b>To release:</b></p> <ul style="list-style-type: none"> <li>► Switch the vehicle off and switch it back on</li> <li>► Release the electric parking brake manually (→ page 215).</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>► Release the electric parking brake automatically (→ page 214).</li> </ul> |

| Display messages | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                  | <p>If it is still not possible to release the electric parking brake:</p> <ul style="list-style-type: none"> <li>► Do not continue driving. Consult a qualified specialist workshop.</li> </ul> <p>* The yellow  indicator lamp is lit and the red  indicator lamp is flashing. The electric parking brake is malfunctioning.</p> <p>The electric parking brake could not be applied or released.</p> <ul style="list-style-type: none"> <li>► Switch the vehicle off and switch it back on</li> </ul> <p><b>To apply:</b></p> <ul style="list-style-type: none"> <li>► Release and then apply the electric parking brake manually (→ page 215).</li> </ul> <p><b>To release:</b></p> <ul style="list-style-type: none"> <li>► Apply and then release the electric parking brake manually.</li> </ul> <p>If it is not possible to apply the electric parking brake or the red  indicator lamp continues to flash:</p> <ul style="list-style-type: none"> <li>► Do not continue driving. Consult a qualified specialist workshop.</li> <li>► Where necessary, also secure the parked vehicle against rolling away.</li> </ul> <p>* The yellow  indicator lamp is lit and the red  indicator lamp flashes for approximately ten seconds after the electric parking brake has been applied or released. It then remains lit or goes out. The electric parking brake is malfunctioning.</p> <p><b>If the state of charge is too low:</b></p> |

| Display messages                                                                                               | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|----------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                | <p>► Charge the 12 V battery.</p> <p><b>To apply:</b></p> <p>► Apply the electric parking brake manually.</p> <p>If it is not possible to apply the electric parking brake:</p> <p>► Consult a qualified specialist workshop.</p> <p>► Where necessary, also secure the parked vehicle against rolling away.</p> <p><b>To release:</b></p> <p>► If the conditions for automatic release are fulfilled and the electric parking brake is not released automatically, release the electric parking brake manually (→ page 215).</p> <p>If it is still not possible to release the electric parking brake:</p> <p>► Do not continue driving. Consult a qualified specialist workshop.</p> |
|  <p>Release parking brake</p> | <p>* The red  indicator lamp is flashing.</p> <p>The electric parking brake is applied while you are driving:</p> <ul style="list-style-type: none"> <li>• A condition for automatic release of the electric parking brake has not been fulfilled (→ page 214).</li> <li>• You are performing emergency braking using the electric parking brake (→ page 215).</li> </ul> <p>► Check the conditions for automatic release of the electric parking brake.</p>                                                                                                                                          |


| Display messages                                                                                                               | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|--------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>Parking brake Switch on vehicle to release | <ul style="list-style-type: none"><li>► Release the electric parking brake manually.</li></ul> <ul style="list-style-type: none"><li>* The red  indicator lamp is lit.<br/>You have attempted to release the electric parking brake with the vehicle switched off.</li><li>► Switch on the vehicle.</li></ul>                                                                                                                                                                          |
| <br>Brake immediately                          | <ul style="list-style-type: none"><li>* A malfunction has occurred while the HOLD function was activated.<br/>A horn may also sound at regular intervals.<br/>You cannot start the vehicle system.</li><li>► Immediately depress the brake pedal firmly until the display message disappears.<br/>You cannot start the vehicle system again.</li></ul>                                                                                                                                                                                                                  |
| <br>Malfunction See Owner's Manual             | <ul style="list-style-type: none"><li>* The brake force boosting function is impaired.<br/>The hill start assist may be impaired.</li></ul> <div><p> <b>WARNING</b> Risk of an accident due to a brake system malfunction</p><p>If the brake system is malfunctioning, braking characteristics may be impaired.</p><ul style="list-style-type: none"><li>► Drive on carefully.</li><li>► Have the brake system checked immediately at a qualified specialist workshop.</li></ul></div> |

| Display messages                                                                                                                              | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|-----------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p data-bbox="133 308 433 334">Malfunction Stop vehicle</p> | <p data-bbox="530 194 1655 225">* The brake force boosting function is impaired and the braking characteristics may be affected.</p> <div data-bbox="554 246 1941 456"> <p data-bbox="566 256 1540 288"><b>▲ WARNING</b> Risk of accident and injury if brake force boosting is malfunctioning</p> <p data-bbox="572 303 1891 365">If brake force boosting is malfunctioning, increased brake pedal force may be necessary for braking. The braking characteristics may be impaired. The braking distance can increase in emergency braking situations.</p> <ul data-bbox="572 376 1318 448" style="list-style-type: none"> <li data-bbox="572 376 1318 407">► Stop in a safe location immediately. Do not continue driving!</li> <li data-bbox="572 417 1076 448">► Consult a qualified specialist workshop.</li> </ul> </div> |
|  <p data-bbox="133 593 409 619">Check brake fluid level</p>  | <p data-bbox="530 482 1231 508">* There is insufficient brake fluid in the brake fluid reservoir.</p> <div data-bbox="554 529 1941 754"> <p data-bbox="566 539 1292 570"><b>▲ WARNING</b> Risk of an accident due to low brake fluid level</p> <p data-bbox="572 586 1741 617">If the brake fluid level is too low, the braking effect and the braking characteristics may be impaired.</p> <ul data-bbox="572 627 1886 743" style="list-style-type: none"> <li data-bbox="572 627 1886 658">► Stop the vehicle as soon as possible, paying attention to road and traffic conditions. Do not continue driving.</li> <li data-bbox="572 669 1076 700">► Consult a qualified specialist workshop.</li> <li data-bbox="572 710 959 741">► Do not top up the brake fluid.</li> </ul> </div>                                         |
| <p data-bbox="133 774 405 831">Check brake pads See Owner's Manual</p>                                                                        | <p data-bbox="530 774 1060 800">* The brakepads have reached the wear limit.</p> <ul data-bbox="554 811 1056 842" style="list-style-type: none"> <li data-bbox="554 811 1056 842">► Consult a qualified specialist workshop.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |



Driving systems

| Display messages                                                                                                                  | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                  |
|-----------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div><p>Off</p></div>                             | <ul style="list-style-type: none"><li>* The HOLD function is deactivated because the vehicle is slipping or a condition for activation is not fulfilled.<ul style="list-style-type: none"><li>► Reactivate the HOLD function later or check the activation conditions for the HOLD function (→ page 222).</li></ul></li></ul> |
| <div><p>ATTENTION ASSIST inoperative</p></div>    | <ul style="list-style-type: none"><li>* ATTENTION ASSIST is malfunctioning.<ul style="list-style-type: none"><li>► Consult a qualified specialist workshop.</li></ul></li></ul>                                                                                                                                               |
| <div><p>ATTENTION ASSIST: Take a break!</p></div> | <ul style="list-style-type: none"><li>* ATTENTION ASSIST has detected fatigue or an increasing lack of concentration on the part of the driver (→ page 225).<ul style="list-style-type: none"><li>► If necessary, take a break.</li></ul></li></ul>                                                                           |

| Display messages                                                                                                                   | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                   |
|------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>ATTENTION ASSIST Microsleep Take a break!</p> | <ul style="list-style-type: none"> <li>* ATTENTION ASSIST has detected indicators of microsleep (→ page 225).<br/>A warning tone will also sound.</li> <li>► It is recommended that you take a break immediately.</li> <li>► Press the left-hand Touch Control and acknowledge the display message.</li> </ul> |
|  <p>--- km/h</p>                                  | <ul style="list-style-type: none"> <li>* Cruise control cannot be activated as not all activation conditions are fulfilled.</li> <li>► Observe the activation conditions for cruise control (→ page 228).</li> </ul>                                                                                           |
| Cruise control inoperative                                                                                                         | <ul style="list-style-type: none"> <li>* Cruise control is malfunctioning.</li> <li>► Consult a qualified specialist workshop.</li> </ul>                                                                                                                                                                      |
| Cruise control and Limiter inoperative                                                                                             | <ul style="list-style-type: none"> <li>* Cruise control and the limiter are malfunctioning.</li> <li>► Consult a qualified specialist workshop.</li> </ul>                                                                                                                                                     |
| Cruise control off                                                                                                                 | <ul style="list-style-type: none"> <li>* Cruise control has been deactivated.</li> </ul> <p>If there is an additional warning tone, cruise control has been deactivated automatically (→ page 227).</p>                                                                                                        |

| Display messages                                                                              | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                          |
|-----------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>--- km/h  | <ul style="list-style-type: none"> <li>* The limiter can temporarily not be engaged. Once the cause of the problem is no longer present, the system will be available again.</li> </ul>                                                                                                               |
| <br>passive   | <ul style="list-style-type: none"> <li>* If you depress the accelerator pedal beyond the point of resistance (kickdown), the limiter will be switched to passive mode (→ page 228).</li> </ul>                                                                                                        |
| Limiter inoperative                                                                           | <ul style="list-style-type: none"> <li>* The limiter is malfunctioning. <ul style="list-style-type: none"> <li>► Consult a qualified specialist workshop.</li> </ul> </li> </ul>                                                                                                                      |
| <br>--- km/h  | <ul style="list-style-type: none"> <li>* Active Distance Assist DISTRONIC cannot be activated as not all activation conditions are fulfilled. <ul style="list-style-type: none"> <li>► Comply with the activation conditions of Active Distance Assist DISTRONIC (→ page 233).</li> </ul> </li> </ul> |
| <br>suspended | <ul style="list-style-type: none"> <li>* If you depress the accelerator pedal beyond the setting of Active Distance Assist DISTRONIC, the system will switch to passive mode (→ page 230).</li> </ul>                                                                                                 |

| Display messages                                                                             | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                      |
|----------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Off</p> | <p>* Active Distance Assist DISTRONIC was deactivated. If a warning tone also sounds, Active Distance Assist DISTRONIC has deactivated automatically (→ page 233).</p>                                                                                                                                                                                                                                                            |
| <p>Active Distance Assist currently unavailable See Owner's Manual</p>                       | <p>* Active Distance Assist DISTRONIC is temporarily unavailable.<br/>The ambient conditions are outside the system limits (→ page 230).<br/>As soon as the ambient conditions are within the system limits, the system will become available again.</p> <p>► Drive on carefully.<br/>or<br/>► If the display message does not disappear, stop the vehicle in accordance with the traffic conditions and restart the vehicle.</p> |
| <p>Active Distance Assist inoperative</p>                                                    | <p>* Active Distance Assist DISTRONIC is malfunctioning.<br/>Other driving systems and driving safety systems may also be malfunctioning.</p> <p>► Drive on carefully.<br/>or<br/>► Stop the vehicle in accordance with the traffic conditions and restart the vehicle.<br/>► If the display message does not disappear: consult a qualified specialist workshop.</p>                                                             |

| Display messages                                            | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                       |
|-------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Active Distance Assist available again                      | <ul style="list-style-type: none"> <li>* Active Distance Assist DISTRONIC is operational again. <ul style="list-style-type: none"> <li>► Switch on Active Distance Assist DISTRONIC (→ page 233).</li> </ul> </li> </ul>                                                                                                                           |
| Speed Limit Assist currently unavailable See Owner's Manual | <ul style="list-style-type: none"> <li>* Speed Limit Assist is temporarily unavailable. <ul style="list-style-type: none"> <li>► Drive on<br/>Once the cause of the problem is no longer present, the system will be available again.</li> </ul> </li> </ul>                                                                                       |
| Speed limit (winter tyres) XXX km/h                         | <ul style="list-style-type: none"> <li>* You have reached the maximum permissible stored speed for winter tyres. It is not possible to exceed this speed.</li> </ul>                                                                                                                                                                               |
| Speed Limit Assist inoperative                              | <ul style="list-style-type: none"> <li>* Speed Limit Assist is malfunctioning. <ul style="list-style-type: none"> <li>► Drive on<br/>or<br/>► Stop the vehicle in accordance with the traffic conditions and restart the vehicle.<br/>► If the display message does not disappear: consult a qualified specialist workshop.</li> </ul> </li> </ul> |
| <div>120km/h!</div> Maximum speed exceeded                  | <ul style="list-style-type: none"> <li>* You have exceeded the maximum permissible speed (for certain countries only). <ul style="list-style-type: none"> <li>► Drive more slowly.</li> </ul> </li> </ul>                                                                                                                                          |

| Display messages                                                                  | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                         |
|-----------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Active Steering Assist currently unavailable See Owner's Manual                   | <p>* Active Steering Assist is temporarily unavailable.<br/>The ambient conditions are outside the system limits (→ page 238).<br/>As soon as the ambient conditions are within the system limits, the system will become available again.</p> <ul style="list-style-type: none"> <li>► Drive on</li> <li>► Check the tyre pressure if necessary.</li> </ul>                                                         |
| Active Steering Assist inoperative                                                | <p>* Active Steering Assist is malfunctioning. Active Distance Assist DISTRONIC remains available.</p> <ul style="list-style-type: none"> <li>► Drive on</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>► Stop the vehicle in accordance with the traffic conditions and restart the vehicle.</li> <li>► If the display message does not disappear: consult a qualified specialist workshop.</li> </ul> |
|  | <p>* Active Steering Assist has reached the system limits (→ page 238).<br/>You have not steered independently for a considerable period of time.</p> <ul style="list-style-type: none"> <li>► Take over the steering and drive on in accordance with the traffic conditions.</li> </ul>                                                                                                                             |
| Active Steering Assist currently unavailable due to multiple emergency stops      | <p>* Active Steering Assist is temporarily unavailable due to multiple emergency stops.</p> <ul style="list-style-type: none"> <li>► Take over the steering and stop in accordance with the traffic conditions.</li> <li>► Switch the vehicle off and switch it back on<br/>Active Steering Assist is available once more.</li> </ul>                                                                                |

| Display messages                                                                                                 | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Beginning emergency stop</p> | <ul style="list-style-type: none"> <li>* Your hands are not on the steering wheel. The Active Steering Assist will initiate an emergency stop (→ page 238).           <ul style="list-style-type: none"> <li>► Put your hands on the steering wheel.</li> </ul> </li> </ul> <p>Information on cancelling an emergency stop (→ page 241).</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <p>Active Emergency Stop Assist currently unavailable<br/>See Owner's Manual</p>                                 | <ul style="list-style-type: none"> <li>* Active Emergency Stop Assist is temporarily unavailable.<br/>The ambient conditions are outside the system limits (→ page 241).<br/>As soon as the ambient conditions are within the system limits, the system will become available again.           <ul style="list-style-type: none"> <li>► Drive on</li> <li>or</li> <li>► If the display message does not disappear, stop the vehicle in accordance with the traffic conditions and restart the vehicle.</li> </ul> </li> <li>* <b>Vehicles without the Driving Assistance Package:</b> Active Emergency Stop Assist is temporarily unavailable due to multiple emergency stops.           <ul style="list-style-type: none"> <li>► Take over the steering and stop in accordance with the traffic conditions.</li> <li>► Switch the vehicle off and switch it back on<br/>Active Emergency Stop Assist is available once more.</li> </ul> </li> </ul> |
| <p>Active Emergency Stop Assist inoperative</p>                                                                  | <ul style="list-style-type: none"> <li>* Active Emergency Stop Assist is malfunctioning.           <ul style="list-style-type: none"> <li>► Drive on</li> <li>or</li> </ul> </li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |


| Display messages                                                   | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                         |
|--------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                    | <ul style="list-style-type: none"> <li>► Stop the vehicle in accordance with the traffic conditions and restart the vehicle.</li> <li>► If the display message does not disappear: consult a qualified specialist workshop.</li> </ul>                                                                                                                                                                                                                               |
| Active Lane Change Assist currently unavailable See Owner's Manual | <p>* Active Lane Change Assist is temporarily unavailable.<br/>The ambient conditions are outside the system limits (→ page 242).<br/>As soon as the ambient conditions are within the system limits, the system will become available again.</p> <ul style="list-style-type: none"> <li>► Drive on</li> <li>or</li> <li>► If the display message does not disappear, stop the vehicle in accordance with the traffic conditions and restart the vehicle.</li> </ul> |
| Active Lane Change Assist inoperative                              | <p>* Active Lane Change Assist is malfunctioning.</p> <ul style="list-style-type: none"> <li>► Drive on</li> <li>or</li> <li>► Stop the vehicle in accordance with the traffic conditions and restart the vehicle.</li> <li>► If the display message does not disappear: consult a qualified specialist workshop.</li> </ul>                                                                                                                                         |
| Active Stop-and-Go Assist currently unavailable see Owner's Manual | <p>* Active Stop-and-Go Assist is temporarily unavailable. Active Distance Assist DISTRONIC and Active Steering Assist are still available.<br/>The ambient conditions are outside the system limits (→ page 230).<br/>As soon as the ambient conditions are within the system limits, the system will become available again.</p> <ul style="list-style-type: none"> <li>► Drive on</li> </ul>                                                                      |




| Display messages                                             | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                            |
|--------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Active Stop-and-Go Assist inoperative See Owner's Manual     | <p>* Active Stop-and-Go Assist is malfunctioning.<br/>Active Stop-and-Go Assist has been deactivated. Active Distance Assist DISTRONIC and Active Steering Assist are still available.</p> <p>► Drive on<br/>or<br/>► Stop the vehicle in accordance with the traffic conditions and restart the vehicle.<br/>► If the display message does not disappear: consult a qualified specialist workshop.</p> |
| Traffic Sign Assist currently unavailable See Owner's Manual | <p>* Traffic Sign Assist is temporarily unavailable.<br/>Once the cause of the problem is no longer present, the system will be available again.</p> <p>► It is possible to continue driving in compliance with the traffic regulations.</p>                                                                                                                                                            |
| Traffic Sign Assist inoperative                              | <p>* Traffic Sign Assist is malfunctioning.</p> <p>► It is possible to continue driving in compliance with the traffic regulations.<br/>or<br/>► Stop the vehicle in accordance with the traffic conditions and restart the vehicle.<br/>► If the display message does not disappear: consult a qualified specialist workshop.</p>                                                                      |
| Blind Spot Assist currently unavailable See Owner's Manual   | <p>* Blind Spot Assist is temporarily unavailable.<br/>The system limits have been reached (→ page 255).<br/>Once the cause of the problem is no longer present, the system will be available again.</p>                                                                                                                                                                                                |

| Display messages                                                            | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                  |
|-----------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                             | <p>► Drive on<br/>or<br/>► If the display message does not disappear, stop the vehicle in accordance with the traffic conditions and restart the vehicle.</p>                                                                                                                                                                                                                 |
| Blind Spot Assist inoperative                                               | <p>* Blind Spot Assist is malfunctioning.</p> <p>► Drive on<br/>or<br/>► Stop the vehicle in accordance with the traffic conditions and restart the vehicle.<br/>► If the display message does not disappear: consult a qualified specialist workshop.</p>                                                                                                                    |
| Blind Spot Assist not available when towing a trailer<br>See Owner's Manual | <p>* When you establish the electrical connection to the trailer, Blind Spot Assist will be unavailable.</p> <p>► Press the left-hand Touch Control and acknowledge the display message.</p>                                                                                                                                                                                  |
| Active Blind Spot Assist currently unavailable See Owner's Manual           | <p>* Active Blind Spot Assist is temporarily unavailable.<br/>The system limits have been reached (→ page 255).<br/>Once the cause of the problem is no longer present, the system will be available again.</p> <p>► Drive on<br/>or<br/>► If the display message does not disappear, stop the vehicle in accordance with the traffic conditions and restart the vehicle.</p> |


| Display messages                                                                | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                 |
|---------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Active Blind Spot Assist inoperative                                            | <p>* Active Blind Spot Assist is malfunctioning.</p> <p>► Drive on</p> <p>or</p> <p>► Stop the vehicle in accordance with the traffic conditions and restart the vehicle.</p> <p>► If the display message does not disappear: consult a qualified specialist workshop.</p>   |
| Active Blind Spot Assist not available when towing a trailer See Owner's Manual | <p>* When you establish the electrical connection to the trailer, Active Blind Spot Assist will be unavailable.</p> <p>► Press the left-hand Touch Control and acknowledge the display message.</p>                                                                          |
| Active Lane Keeping Assist currently unavailable See Owner's Manual             | <p>* Active Lane Keeping Assist is temporarily unavailable.</p> <p>The ambient conditions are outside the system limits (→ page 259).</p> <p>As soon as the ambient conditions are within the system limits, the system will become available again.</p> <p>► Drive on</p>   |
| Active Lane Keeping Assist inoperative                                          | <p>* Active Lane Keeping Assist is malfunctioning.</p> <p>► Drive on</p> <p>or</p> <p>► Stop the vehicle in accordance with the traffic conditions and restart the vehicle.</p> <p>► If the display message does not disappear: consult a qualified specialist workshop.</p> |

| Display messages                                                                                                                   | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Beginning emergency stop</p>                  | <p>* Your hands are not on the steering wheel. The Active Lane Keeping Assist will initiate an emergency stop (→ page 259).</p> <p>► Put your hands on the steering wheel.</p> <p>Information on cancelling an emergency stop (→ page 241).</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|  <p>temporarily unavailable<br/>Sensors dirty</p> | <p>* Front and corner radar sensors (hereafter "sensors") are malfunctioning. Possible causes:</p> <ul style="list-style-type: none"> <li>• The sensors are dirty</li> <li>• Heavy rain or snow</li> <li>• Extended country driving without other traffic, e.g. in the desert</li> </ul> <p>Driving systems and driving safety systems may be malfunctioning or temporarily unavailable. The brake system, steering and drive system will continue to function normally.</p> <p>► Drive on carefully.</p> <p>Once the causes of the problem are no longer present, the driving systems and driving safety systems will be available again and the corresponding symbols will be switched off.</p> <p>If the display message does not disappear:</p> <ul style="list-style-type: none"> <li>► Stop the vehicle in accordance with the traffic conditions.</li> <li>► Clean all sensor covers from outside (→ page 217).</li> <li>► Restart the vehicle.</li> </ul> |

| Display messages                                                                                                                                                      | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p data-bbox="72 715 354 772">temporarily unavailable<br/>Camera view restricted</p> | <p data-bbox="469 194 1282 220">* The view of the multifunction camera is restricted. Possible causes:</p> <ul data-bbox="499 236 1870 381" style="list-style-type: none"> <li data-bbox="499 236 1368 262">• Dirt on the windscreen in the field of vision of the multifunction camera</li> <li data-bbox="499 277 808 303">• Heavy rain, snow or fog</li> <li data-bbox="499 319 1870 381">• Mist on the inside of the windscreen: in certain weather conditions, mist can form on the inside of the windscreen during cold times of year in particular.</li> </ul> <p data-bbox="493 401 1870 464">  This mist on the windscreen will be removed automatically within a short time with the aid of a heater. The restriction is temporary.         </p> <p data-bbox="489 474 1876 536">Driving systems and driving safety systems may be malfunctioning or temporarily unavailable. The brake system, steering and drive system will continue to function normally.</p> <p data-bbox="489 547 747 578">  Drive on carefully.         </p> <p data-bbox="489 609 1876 671">Once the causes of the problem are no longer present, the driving systems and driving safety systems will be available again and the corresponding symbols will be switched off.</p> <p data-bbox="489 681 993 712">If the display message does not disappear:</p> <ul data-bbox="489 723 1608 837" style="list-style-type: none"> <li data-bbox="489 723 1211 754">  Stop the vehicle in accordance with the traffic conditions.         </li> <li data-bbox="489 764 1608 795">  Clean the windscreen, especially in the position of the multifunction camera (→ page 217).         </li> <li data-bbox="489 806 762 837">  Restart the vehicle.         </li> </ul> |

| Display messages                                                                                                             | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Restricted during trailer operation</p> | <p>* When the trailer socket is occupied, some driving systems will be available only to a limited extent.</p> <ul style="list-style-type: none"> <li>► Drive carefully if you are towing a trailer or have the bicycle rack mounted.</li> </ul>                                                                                                                                                                                                                                              |
| <p>Driver camera view currently restricted See Owner's Manual</p>                                                            | <p>* The view of the driver camera is reduced. Possible causes:</p> <ul style="list-style-type: none"> <li>• Objects or stickers are projecting into the driver camera's field of vision.</li> <li>• The driver camera is dirty.</li> </ul> <ul style="list-style-type: none"> <li>► Keep the driver camera's field of vision free.</li> <li>► Clean the driver camera if necessary. Please comply with the notes on caring for the interior relating to the display (→ page 375).</li> </ul> |

| Display messages                                                                                                   | Possible causes/consequences and Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|--------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Change steering wheel/<br>seat position until 6 dots<br>are visible on the upper<br>edge of the screen             | <ul style="list-style-type: none"><li>* The driver camera cannot capture your line of sight.<ul style="list-style-type: none"><li>▶ Change the steering wheel and seat position until six dots are visible on the top edge of the screen. The display message will appear again if the driver camera is again unable to detect your line of sight after 30 minutes.</li><li>The display message will no longer appear at all if you confirm the display message and the driver camera cannot detect your line of sight during the entire journey.</li></ul></li></ul>                                                                                                                                                                                                                                                                                 |
| Driver camera inoperative<br>See Owner's Manual                                                                    | <ul style="list-style-type: none"><li>* The driver camera is malfunctioning.<ul style="list-style-type: none"><li>▶ Consult a qualified specialist workshop.</li></ul></li></ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <br>Fault Drive at max. 80<br>km/h | <ul style="list-style-type: none"><li>* AIRMATIC is functioning only to a limited extent. The vehicle's handling characteristics may be affected.<div><div> <b>NOTE</b> The tyres on the front axle or the fenders could be damaged by large steering movements</div><ul style="list-style-type: none"><li>▶ Avoid large steering movements while driving and listen for scraping sounds.</li><li>▶ If you hear scraping sounds, pull over and stop the vehicle in accordance with the traffic conditions, and set a higher vehicle level if possible.</li></ul></div><ul style="list-style-type: none"><li>▶ Drive in a manner appropriate for the current level, but do not exceed 80 km/h.</li><li>▶ Consult a qualified specialist workshop.</li></ul></li></ul> |


| Display messages                                                                                                    | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|---------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Max. speed 20km/h</p>          | <p>* AIRMATIC is functioning only to a limited extent. The vehicle's handling characteristics may be affected.</p> <ul style="list-style-type: none"> <li>► The current level is too high. Do not drive at speeds greater than 20 km/h.</li> <li>► Consult a qualified specialist workshop.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|  <p>STOP Vehicle level too low</p> | <p>* You have pulled away despite the vehicle level being too low.</p> <ul style="list-style-type: none"> <li>► Stop the vehicle in accordance with the traffic conditions. The vehicle will be raised to the selected vehicle level.</li> <li>► Wait until the display message disappears before pulling away.</li> </ul> <p>If the display message does not disappear and a warning tone also sounds, AIRMATIC is malfunctioning:</p> <ul style="list-style-type: none"> <li>► do not drive at speeds greater than 80 km/h and consult a qualified specialist workshop immediately.</li> </ul> <div style="border: 1px solid black; padding: 10px; margin-top: 10px;"> <p><b>!</b> <b>NOTE</b> The tyres on the front axle or the fenders could be damaged by large steering movements</p> <ul style="list-style-type: none"> <li>► Avoid large steering movements while driving and listen for scraping sounds.</li> <li>► If you hear scraping sounds, pull over and stop the vehicle in accordance with the traffic conditions, and set a higher vehicle level if possible.</li> </ul> </div> <ul style="list-style-type: none"> <li>► Set a higher vehicle level (→ page 262). Depending on the malfunction, the vehicle will be raised.</li> </ul> |



| Display messages                                                                                                   | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|--------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Vehicle rising Please wait</p> | <ul style="list-style-type: none"> <li>* The vehicle level is too low. The vehicle will be raised to the selected vehicle level. <ul style="list-style-type: none"> <li>► Wait until the display message disappears before pulling away.</li> </ul> </li> </ul>                                                                                                                                                                                                                                                                                               |
|  <p>Compressor is cooling</p>      | <ul style="list-style-type: none"> <li>* Due to frequent level changes within a short space of time, the compressor first needs to cool down in order to set the selected vehicle level.<br/>When the compressor has cooled down, the vehicle will continue rising to the selected vehicle level. <ul style="list-style-type: none"> <li>► Drive on in a manner appropriate for the current level. Make sure that there is sufficient ground clearance.</li> </ul> </li> </ul>                                                                                |
| <p>PARKTRONIC inoperative<br/>See Owner's Manual</p>                                                               | <ul style="list-style-type: none"> <li>* Parking Assist PARKTRONIC is malfunctioning.<br/>Once the cause of the problem is no longer present, the system will be available again. <ul style="list-style-type: none"> <li>► Continue driving while paying attention to the vehicle's surroundings.</li> </ul> or <ul style="list-style-type: none"> <li>► Stop the vehicle in accordance with the traffic conditions and restart the vehicle.</li> <li>► If the display message still appears, consult a qualified specialist workshop.</li> </ul> </li> </ul> |
| <p>PARKTRONIC and manoeuvring assistant not available at rear when towing a trailer</p>                            | <ul style="list-style-type: none"> <li>* When you establish the electrical connection to the trailer, the rear Parking Assist PARKTRONIC and manoeuvring assistant will be unavailable. <ul style="list-style-type: none"> <li>► Press the left-hand Touch Control and acknowledge the display message.</li> </ul> </li> </ul>                                                                                                                                                                                                                                |


| Display messages                                                                       | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|----------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Limited availability of Active Parking Assist manoeuvring assistant See Owner's Manual | <ul style="list-style-type: none"> <li>* Active Parking Assist's manoeuvring assistant is temporarily unavailable or only partially available. <ul style="list-style-type: none"> <li>► Clean all sensors of the parking and camera system (→ page 373).</li> <li>► If the display message still appears, consult a qualified specialist workshop.</li> </ul> </li> </ul>                                                                                                                                   |
| Active Parking Assist and PARKTRONIC inoperative See Owner's Manual                    | <ul style="list-style-type: none"> <li>* <b>Vehicles with Active Parking Assist:</b> Active Parking Assist and Parking Assist PARKTRONIC are malfunctioning.<br/> <b>Vehicles without Active Parking Assist:</b> Parking Assist PARKTRONIC is malfunctioning. <ul style="list-style-type: none"> <li>► Stop the vehicle in accordance with the traffic conditions and restart the vehicle.</li> <li>► If the display message still appears, consult a qualified specialist workshop.</li> </ul> </li> </ul> |

### Driving safety systems

| Display messages                                                                                                                  | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|-----------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>currently unavailable See Owner's Manual</p> | <ul style="list-style-type: none"> <li>* ABS and ESP® are temporarily unavailable.<br/> Other driving systems and driving safety systems (e.g. BAS) may also be temporarily unavailable.<br/> The brake system will continue to operate normally. Braking distance may increase in an emergency braking situation.</li> </ul> <div style="background-color: #f0f0f0; padding: 10px; margin-top: 10px;"> <p><b>⚠ WARNING</b> Risk of skidding if ABS and ESP® are malfunctioning</p> <p>The wheels may lock during braking and ESP® does not perform any vehicle stabilisation.</p> </div> |

| Display messages                                                                                                                                                                                                  | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                                                                   | <p>The steerability and braking characteristics are heavily impaired and the braking distance may increase. In addition, other driving safety systems are switched off.</p> <ul style="list-style-type: none"><li>► Drive carefully on a suitable stretch of road, making slight steering movements at a speed above 30 km/h.</li><li>► If the display message does not disappear, consult a qualified specialist workshop immediately. Drive carefully.</li></ul>                                                                                                                                                                                                                                                                                                                             |
| <div></div> <p>inoperative See Owner's Manual</p> | <p>* ABS and ESP® are malfunctioning.</p> <p>Other driving systems and driving safety systems (e.g. BAS) may also be malfunctioning.</p> <p>The brake system will continue to operate normally. Braking distance may increase in an emergency braking situation.</p> <div><p><b>▲ WARNING</b> Risk of skidding if ABS and ESP® are malfunctioning</p><p>The wheels may block during braking and ESP® does not perform any vehicle stabilization.</p><p>The steerability and braking characteristics are heavily impaired and the braking distance may increase. In addition, other driving safety systems are switched off.</p><ul style="list-style-type: none"><li>► Drive on carefully.</li><li>► Have ABS and ESP® checked immediately at a qualified specialist workshop.</li></ul></div> |

| Display messages                                                                                                                  | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|-----------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>currently unavailable See Owner's Manual</p> | <p>* ESP® is temporarily unavailable.<br/>Other driving systems and driving safety systems (e.g. BAS) may also be malfunctioning.</p> <p><b>▲ WARNING</b> Risk of skidding if ESP is malfunctioning®</p> <p>If ESP® is malfunctioning, ESP® cannot carry out vehicle stabilisation. In addition, other driving safety systems are switched off.</p> <ul style="list-style-type: none"> <li>► Drive carefully on a suitable stretch of road, making slight steering movements at a speed above 30 km/h.</li> <li>► If the display message does not disappear, consult a qualified specialist workshop immediately. Drive carefully.</li> </ul> |
|  <p>inoperative See Owner's Manual</p>           | <p>* ESP® is malfunctioning.<br/>Other driving systems and driving safety systems (e.g. BAS) may also be malfunctioning.<br/>The brake system will continue to operate normally. Braking distance may increase in an emergency braking situation.</p> <p><b>▲ WARNING</b> Risk of skidding if ESP® is malfunctioning</p> <p>If ESP® is malfunctioning, ESP® cannot carry out vehicle stabilisation. In addition, other driving safety systems are switched off.</p> <ul style="list-style-type: none"> <li>► Drive on carefully.</li> <li>► Have ESP® checked at a qualified specialist workshop.</li> </ul>                                  |



| Display messages                                                                                                                                  | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|---------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p data-bbox="70 510 368 570">inoperative See Owner's Manual</p> | <p data-bbox="469 194 1520 270">* EBD, ABS and ESP® are malfunctioning.<br/>Other driving systems and driving safety systems (e.g. BAS) may also be malfunctioning.</p> <div data-bbox="491 291 1878 552"> <p data-bbox="506 301 1364 334"><b>▲ WARNING</b> Risk of skidding if EBD, ABS and ESP® are malfunctioning</p> <p data-bbox="512 353 1568 384">The wheels may block during braking and ESP® does not perform any vehicle stabilization.</p> <p data-bbox="512 394 1820 456">The steerability and braking characteristics are heavily impaired and the braking distance may increase. In addition, other driving safety systems are switched off.</p> <ul data-bbox="512 467 1479 539" style="list-style-type: none"> <li>► Drive on carefully.</li> <li>► Have the brake system checked immediately at a qualified specialist workshop.</li> </ul> </div> |
| <p data-bbox="70 601 391 692">Active Brake Assist Functions currently limited See Owner's Manual</p>                                              | <p data-bbox="469 601 1866 664">* For vehicles with the Driving Assistance Package, the following functions may be temporarily unavailable or only partially available:</p> <ul data-bbox="499 674 1064 788" style="list-style-type: none"> <li>• Active Brake Assist with cross-traffic function</li> <li>• Evasive Steering Assist</li> <li>• PRE-SAFE® PLUS</li> </ul> <p data-bbox="491 809 1378 845"><b>Vehicles with Blind Spot Assist:</b> PRE-SAFE® PLUS is temporarily unavailable.</p> <p data-bbox="491 850 1292 886">The ambient conditions are outside the system limits (→ page 245).</p> <p data-bbox="491 891 1604 928"><b>Vehicles without the Driving Assistance Package:</b> Active Brake Assist is temporarily unavailable.</p>                                                                                                                 |



| Display messages                                         | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|----------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                          | <p>► Drive on carefully.<br/>As soon as the ambient conditions are within the system limits, the system will become available again.</p> <p>or</p> <p>► If the display message does not disappear, stop the vehicle in accordance with the traffic conditions and restart the vehicle.</p>                                                                                                                                                                                                                                                                                                                                                                                                  |
| Active Brake Assist Functions limited See Owner's Manual | <p>* For vehicles with the Driving Assistance Package, the following functions may be temporarily unavailable or only partially available:</p> <ul style="list-style-type: none"> <li>• Active Brake Assist with cross-traffic function</li> <li>• Evasive Steering Assist</li> <li>• PRE-SAFE® PLUS</li> </ul> <p><b>Vehicles without the Driving Assistance Package:</b> Active Brake Assist is temporarily unavailable or only partially available.</p> <p>► Drive on carefully.</p> <p>or</p> <p>► Stop the vehicle in accordance with the traffic conditions and restart the vehicle.</p> <p>► If the display message does not disappear: consult a qualified specialist workshop.</p> |

Mercedes-Benz emergency call system

| Display messages                                                                                                   | Possible causes/consequences and Solutions                                                                                                                                                                                                                    |
|--------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div></div> <div>Inoperative</div> | <ul style="list-style-type: none"><li>* The Mercedes-Benz emergency call system is malfunctioning. The Mercedes me connect system is also malfunctioning.<ul style="list-style-type: none"><li>▶ Consult a qualified specialist workshop.</li></ul></li></ul> |

Battery

| Display messages                                                                                                                                      | Possible causes/consequences and Solutions                                                                                                                                                                                                                                                         |
|-------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div></div> <div>12 V on-board electrical system Visit workshop</div> | <ul style="list-style-type: none"><li>* The 12 V on-board electrical system is malfunctioning.<ul style="list-style-type: none"><li>▶ Consult a qualified specialist workshop immediately.</li></ul></li></ul>                                                                                     |
| <div></div> <div>Stop vehicle See Owner's Manual</div>                | <ul style="list-style-type: none"><li>* The 12 V battery is no longer being charged and the state of charge is too low.<div><div>! NOTE</div>Possible damage to the drive system if you continue driving<ul style="list-style-type: none"><li>▶ Do not continue driving.</li></ul></div></li></ul> |

| Display messages                                                                                                                                  | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                       |
|---------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                   | <p>► Consult a qualified specialist workshop.</p> <p>► Stop the vehicle immediately in accordance with the traffic conditions. Do not continue driving.</p> <p>► Switch off the vehicle.</p> <p>► Consult a qualified specialist workshop.</p>                                                                                                     |
|  <p>Start the vehicle to charge the 12 V battery</p>             | <p>* The vehicle is off and the state of charge of the 12 V battery is too low.</p> <p>► Switch off electrical consumers that are not required.</p> <p>► Drive for 30–60 mins.</p> <p>or</p> <p>► Charge the vehicle at a charging station (→ page 193).</p>                                                                                       |
|  <p>Stop vehicle Leave vehicle on to charge the 12 V battery</p> | <p>* The 12 V battery charge level is too low.</p> <p>► Stop the vehicle immediately in accordance with the traffic conditions. Do not continue driving.</p> <p>► Leave the vehicle running</p> <p>► If the display message disappears: drive on.</p> <p>► If the display message does not disappear: consult a qualified specialist workshop.</p> |



## Tyre pressure monitor

| Display messages                                                                                                | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|-----------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Tyre press. monitor currently unavailable                                                                       | <ul style="list-style-type: none"> <li>* There is interference from a powerful radio signal source. As a result, no signals from the tyre pressure sensors are being received. The tyre pressure monitoring system is temporarily unavailable.<br/>The tyre pressure monitoring system will restart automatically as soon as the cause has been rectified.<br/>► Drive on.</li> </ul>                                                                                                                                                                                        |
| Tyre press. monitor inoperative                                                                                 | <ul style="list-style-type: none"> <li>* The tyre pressure monitoring system is malfunctioning.</li> </ul> <div> <p><b>⚠ WARNING</b> There is a risk of an accident if the tyre pressure monitoring system is malfunctioning</p> <p>The tyre pressure monitoring system cannot issue a warning if there is pressure loss in one or more of the tyres. Tyres with insufficient tyre pressure may impair the driving characteristics as well as steering and braking.</p> <p>► Have the tyre pressure monitoring system checked at a qualified specialist workshop.</p> </div> |
| Tyre press. monitor inoperative No wheel sensors                                                                | <ul style="list-style-type: none"> <li>* The wheels fitted do not have suitable tyre pressure sensors. The tyre pressure monitoring system is deactivated.<br/>► Fit wheels with suitable tyre pressure sensors.</li> </ul>                                                                                                                                                                                                                                                                                                                                                  |
|  <p>Wheel sensor(s) missing</p> | <ul style="list-style-type: none"> <li>* There is no signal from the tyre pressure sensor in at least one wheel. No pressure value is displayed for the affected tyre.<br/>► Have the faulty tyre pressure sensor replaced at a qualified specialist workshop.</li> </ul>                                                                                                                                                                                                                                                                                                    |

| Display messages                                                                                                                           | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|--------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p data-bbox="133 306 294 337">Check tyre(s)</p>         | <p data-bbox="530 194 1306 267">* The tyre pressure in one or more tyres has dropped significantly.<br/>The wheel position is displayed. A warning tone also sounds.</p> <div data-bbox="556 288 1943 602"> <p data-bbox="566 298 1352 329"><b>⚠ WARNING</b> Risk of an accident due to insufficient tyre pressure</p> <ul data-bbox="580 344 1634 458" style="list-style-type: none"> <li>• The tyres can burst.</li> <li>• The tyres can wear excessively and/or unevenly.</li> <li>• The driving characteristics as well as the steering and braking may be greatly impaired.</li> </ul> <p data-bbox="572 479 1064 505">You could then lose control of the vehicle.</p> <ul data-bbox="572 521 1116 593" style="list-style-type: none"> <li>► Observe the recommended tyre pressures.</li> <li>► Adjust the tyre pressure if necessary.</li> </ul> </div> <p data-bbox="550 624 1272 697">           ► Stop the vehicle in accordance with the traffic conditions.<br/>           ► Check the tyre pressure (→ page 397) and the tyres.         </p> |
|  <p data-bbox="133 829 385 860">Rectify tyre pressure</p> | <p data-bbox="530 717 1856 780">* The tyre pressure is too low in at least one of the tyres, or the difference in tyre pressure between the individual wheels is too great.</p> <p data-bbox="550 790 1568 862">           ► Check the tyre pressure and add air, if necessary.<br/>           ► When the tyre pressure is correct, restart the tyre pressure monitor (→ page 400).         </p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |

| Display messages                                                                                                                       | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|----------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p data-bbox="70 308 312 336">Warning tyre defect</p> | <p data-bbox="469 194 1536 222">* The pressure in one or more tyres has dropped suddenly. The wheel position is displayed.</p> <div data-bbox="493 246 1878 593"> <p data-bbox="506 256 1237 284"><b>▲ WARNING</b> Risk of an accident from driving with a flat tyre</p> <ul data-bbox="520 305 1749 375" style="list-style-type: none"> <li>• The tyres can overheat and be damaged.</li> <li>• The driving characteristics as well as the steering and braking characteristics may be greatly impaired.</li> </ul> <p data-bbox="512 395 1003 423">You could then lose control of the vehicle.</p> <ul data-bbox="512 440 1822 582" style="list-style-type: none"> <li>► Do not drive with a flat tyre.</li> <li>► Do not exceed the maximum permissible driving distance in emergency mode and the maximum permissible speed with a flat MOExtended tyre.</li> <li>► Observe the notes on flat tyres.</li> </ul> </div> <p data-bbox="491 616 889 644">Notes on flat tyres (→ page 380).</p> <ul data-bbox="491 657 1209 727" style="list-style-type: none"> <li>► Stop the vehicle in accordance with the traffic conditions.</li> <li>► Check the tyres.</li> </ul> |
|  <p data-bbox="70 859 296 887">Tyre(s) overheated</p>  | <p data-bbox="469 749 1844 808">* At least one tyre is overheating. The affected tyres are displayed in red. At temperatures close to the limit value, the tyres are displayed in yellow.</p> <div data-bbox="493 831 1878 924"> <p data-bbox="506 842 1322 870"><b>▲ WARNING</b> Risk of an accident from driving with overheated tyres</p> <p data-bbox="512 888 838 916">Overheated tyres can burst.</p> </div>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |


| Display messages                                                                                      | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                          |
|-------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                       | <p>► Reduce speed so that the tyres cool down.</p>                                                                                                                                                                                                                                                                                    |
|  <p>Reduce speed</p> | <p>* At least one tyre is overheating. The affected tyres are displayed in red. At temperatures close to the limit value, the tyres are displayed in yellow.</p> <p><b>⚠ WARNING</b> Risk of an accident from driving with overheated tyres</p> <p>Overheated tyres can burst.</p> <p>► Reduce speed so that the tyres cool down.</p> |

## Warning and indicator lamps


### Overview of indicator and warning lamps

Some systems will perform a self-test when the vehicle is switched on. Some indicator and warning lamps may briefly light up or flash. This behaviour is non-critical. These indicator and warning lamps indicate a malfunction only if they light up or flash after the vehicle has been started or during a journey.

### Driver's display



### Driver's display with driver camera



### Indicator and warning lamps:

|                                                                                  |                                                 |
|----------------------------------------------------------------------------------|-------------------------------------------------|
|  | Restraint system (→ page 491)                   |
|  | Seat belt (→ page 491)                          |
|  | Reduced power (→ page 492)                      |
|  | System error (→ page 492)                       |
|  | Electrical fault (→ page 492)                   |
|  | Trailer hitch (→ page 493)                      |
|  | Power steering (yellow) (→ page 493)            |
|  | Power steering (red) (→ page 493)               |
|  | Rear axle steering (yellow)<br>(→ page 493)     |
|  | Rear axle steering (red)<br>(→ page 493)        |
|  | Electric parking brake (yellow)<br>(→ page 496) |
|  | Electric parking brake (red)<br>(→ page 496)    |
|  | Brakes (yellow) (→ page 496)                    |
|  | Brakes (red) (→ page 496)                       |
|  | Distance warning (→ page 498)                   |



Active Brake Assist (→ page 498)



Active Brake Assist (→ page 498)



Active Brake Assist (→ page 498)



AIRMATIC (→ page 498)



ABS (→ page 500)



ESP® (→ page 500)



ESP® OFF (→ page 500)



Mercedes-Benz emergency call system (→ page 502)



Tyre pressure monitoring system  
(→ page 503)



Standing lights (→ page 141)



Low beam (→ page 141)



High beam (→ page 143)



Turn signal light (→ page 143)



Rear fog lamp (→ page 141)



Manoeuvring brake function (→ page 286)

### Symbols on the central display:



Drive Away Assist (→ page 284)



Rear cross traffic warning (→ page 285)


## Occupant safety

| Warning/indicator lamp                                                                                                  | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|-------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Restraint system warning lamp</p>  | <p>* The restraint system red warning lamp is lit while the vehicle is on.<br/>The restraint system is malfunctioning (→ page 44).</p> <p><b>⚠ DANGER</b> Risk of fatal injuries due to restraint system malfunctions</p> <p>Components in the restraint system may be activated unintentionally or not deploy as planned in an accident. In the event of an accident, the high-voltage on-board electrical system may not be deactivated as intended.</p> <p>You may suffer an electric shock if you touch the damaged components of the high-voltage on-board electrical system.</p> <ul style="list-style-type: none"> <li>► Have the restraint system checked and repaired immediately at a qualified specialist workshop.</li> <li>► After an accident, switch off the vehicle immediately.</li> </ul> <ul style="list-style-type: none"> <li>► Drive on carefully.</li> <li>► Note the messages on the driver's display.</li> <li>► Consult a qualified specialist workshop immediately.</li> </ul> |
|  <p>Seat belt warning lamp flashes</p> | <p>* The red seat belt warning lamp flashes and an intermittent warning tone sounds.<br/>The driver or front passenger has not fastened his/her seat belt while the vehicle is in motion.</p> <ul style="list-style-type: none"> <li>► Fasten your seat belt (→ page 47).</li> </ul> <p>There are objects on the front passenger seat.</p> <ul style="list-style-type: none"> <li>► Remove the objects from the front passenger seat.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |

| Warning/indicator lamp                                                                                                                  | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                             |
|-----------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div></div> <div>Seat belt warning lamp lights up</div> | <p>* The red seat belt warning lamp lights up once the vehicle has started.<br/>In addition, an intermittent warning tone may sound.<br/>The red seat belt warning lamp reminds the driver and front passenger to fasten their seat belts.</p> <p>► Fasten your seat belt (→ page 47).</p> <p>If you have placed objects on the front passenger seat, the red seat belt warning lamp may remain lit.</p> |

Drive system

| Warning/indicator lamp                                                                                                            | Possible causes/consequences and ► Solutions                                                                                                                                                                                       |
|-----------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div></div> <div>Reduced-power warning lamp</div> | <p>* The yellow reduced-power warning lamp is on.<br/>Drive system power output is reduced.</p> <p>► Note the messages on the driver's display.</p>                                                                                |
| <div></div> <div>System error warning lamp</div>  | <p>* The red system error warning lamp is lit while the vehicle is in a state of operational readiness <span>READY</span>.<br/>There is a malfunction in the drive system.</p> <p>► Note the messages on the driver's display.</p> |

| Warning/indicator lamp                                                                                                                             | Possible causes/consequences and ► Solutions                                                                                                                                                                  |
|----------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p data-bbox="135 308 465 334">Electrical fault warning lamp</p> | <p data-bbox="512 195 1024 256">* The red electrical fault warning lamp is lit.<br/>There is a fault with the electrics.</p> <p data-bbox="532 267 1070 298">► Note the messages on the driver's display.</p> |

## Vehicle

| Warning/indicator lamp                                                                                                                              | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|-----------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p data-bbox="135 617 423 678">Trailer tow hitch warning lamp</p> | <p data-bbox="512 506 989 567">* The red trailer hitch warning lamp is lit.<br/>The trailer hitch is not operational.</p> <div data-bbox="536 588 1941 813"> <p data-bbox="546 598 1292 629"><b>⚠ WARNING</b> Risk of an accident if the ball neck is not locked</p> <p data-bbox="552 645 955 676">The trailer may become detached.</p> <ul data-bbox="552 686 1816 800" style="list-style-type: none"> <li data-bbox="552 686 1709 717">► Stop the vehicle immediately in accordance with the traffic conditions. Do not continue driving.</li> <li data-bbox="552 728 1231 759">► Uncouple the trailer and secure it against rolling away.</li> <li data-bbox="552 769 1816 800">► Initiate a new swivelling procedure and do not re-couple the trailer until the display message disappears.</li> </ul> </div> <p data-bbox="532 831 1070 862">► Note the messages on the driver's display.</p> |



| Warning/indicator lamp                                                                                                           | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|----------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Power steering warning lamp (yellow)</p>     | <p>* The yellow power steering warning lamp is lit while the vehicle is running. The power assistance or the steering itself is malfunctioning.</p> <p>► Note the messages on the driver's display.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|  <p>Power steering warning lamp (red)</p>        | <p>* The red power steering warning lamp is lit while the vehicle is running. The power assistance or the steering itself is malfunctioning.</p> <div data-bbox="473 469 1878 684"> <p><b>⚠ WARNING</b> Risk of accident if steering capability is impaired</p> <p>If the steering does not function as intended, the vehicle's operating safety is jeopardised.</p> <ul style="list-style-type: none"> <li>► Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances.</li> <li>► Consult a qualified specialist workshop.</li> </ul> </div> <p>► Note the messages on the driver's display.</p> |
|  <p>Rear axle steering warning lamp (yellow)</p> | <p>* The yellow rear axle steering warning lamp is lit while the vehicle is running. The rear axle steering is malfunctioning.</p> <p>► Note the messages on the driver's display.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |

| Warning/indicator lamp                                                                                                                                                                            | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div data-bbox="143 194 334 296"></div> <p data-bbox="133 308 445 368">Rear axle steering warning lamp (red)</p> | <p data-bbox="516 194 1382 254">* The red rear axle steering warning lamp is lit while the vehicle is running. The rear axle steering is malfunctioning.</p> <div data-bbox="536 277 1943 493"><p data-bbox="546 288 1298 322"><b>⚠ WARNING</b> Risk of accident if steering capability is impaired</p><p data-bbox="556 337 1608 365">If the steering does not function as intended, the vehicle's operating safety is jeopardised.</p><ul data-bbox="556 379 1897 482" style="list-style-type: none"><li data-bbox="556 379 1897 441">► Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances.</li><li data-bbox="556 451 1060 482">► Consult a qualified specialist workshop.</li></ul></div> <p data-bbox="536 513 1070 541">► Note the messages on the driver's display.</p> |

Brakes

| Warning/indicator lamp                                                                                                                                | Possible causes/consequences and Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|-------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div></div> <div>Electric parking brake indicator lamp (red)</div>    | <p>* The red electric parking brake indicator lamp flashes or is lit.<br/>The yellow electric parking brake indicator lamp is also lit in the event of a malfunction.</p> <p>► Note the messages on the driver display.</p>                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <div></div> <div>Electric parking brake indicator lamp (yellow)</div> |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <div></div> <div>Brake system warning lamp (yellow)</div>             | <p>* The yellow brake warning lamp is lit while the vehicle is running.</p> <div><div> <b>WARNING</b> Risk of an accident due to a brake system malfunction</div><div>If the brake system is malfunctioning, braking characteristics may be impaired.</div><div><div>► Drive on carefully.</div><div>► Have the brake system checked immediately at a qualified specialist workshop.</div></div></div> <p>The hill start assist may be malfunctioning.</p> <p>► Adjust your speed and drive on carefully, leaving a suitable distance to the vehicle in front.</p> |

| Warning/indicator lamp                                                                                                   | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|--------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Brake system warning lamp (red)</p> | <p>► If the driver display shows a display message, observe it.</p> <p>► Consult a qualified specialist workshop.</p> <p>* The red brake warning lamp is lit while the vehicle is running.</p> <p>Possible causes:</p> <ul style="list-style-type: none"> <li>• The brake force boosting is malfunctioning and the braking characteristics may be affected.</li> <li>• There is insufficient brake fluid in the brake fluid reservoir.</li> </ul> <p>► Note the messages on the driver display.</p> <p><b>⚠ WARNING</b> Risk of accident and injury if brake force boosting is malfunctioning</p> <p>If brake force boosting is malfunctioning, increased brake pedal force may be necessary for braking. The braking characteristics may be impaired. The braking distance can increase in emergency braking situations.</p> <p>► Stop in a safe location immediately. Do not continue driving!</p> <p>► Consult a qualified specialist workshop.</p> <p><b>⚠ WARNING</b> Risk of an accident due to low brake fluid level</p> <p>If the brake fluid level is too low, the braking effect and the braking characteristics may be impaired.</p> <p>► Stop the vehicle as soon as possible, paying attention to road and traffic conditions. Do not continue driving.</p> <p>► Consult a qualified specialist workshop.</p> |

| Warning/indicator lamp | Possible causes/consequences and ► Solutions |
|------------------------|----------------------------------------------|
|                        | <div>► Do not top up the brake fluid.</div>  |

Driving systems

| Warning/indicator lamp                                                                                                                            | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                      |
|---------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div></div> <div>Warning lamp for distance warning function</div> | <div>* The red distance warning lamp lights up while the vehicle is in motion. The distance to the vehicle in front is too small for the speed selected. If there is an additional warning tone, you are approaching an obstacle at too high a speed.</div> <div><div>► Be prepared to brake immediately.</div><div>► Increase the distance.</div></div> <div>Function of Active Brake Assist (→ page 245).</div> |
| <div></div> <div>Active Brake Assist warning lamp</div>           | <div>* The Active Brake Assist warning lamp is on. The system is switched off or the range of functions has been automatically restricted. This may be the case if the driver is not wearing a seat belt or another driving system has been activated.</div> <div>► Observe the notes on Active Brake Assist (→ page 245).</div>                                                                                  |

| Warning/indicator lamp                                                                                                                                | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                              |
|-------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p data-bbox="133 308 459 370">Active Brake Assist warning lamp</p> | <p data-bbox="512 194 1741 259">* The Active Brake Assist warning lamp is on.<br/>Due to dirty sensors or a malfunction, the system is not available or the range of functions is restricted.</p> <p data-bbox="532 267 1070 300">► Note the messages on the driver's display.</p>                                                                                        |
|  <p data-bbox="133 503 459 565">Active Brake Assist warning lamp</p> | <p data-bbox="512 389 1604 491">* The Active Brake Assist warning lamp is on.<br/>After you drive off, the system's range of functions is restricted due to the teach-in process.<br/>Depending on the ambient conditions, the teach-in process may take a few minutes.</p> <p data-bbox="532 503 1241 536">► Observe the notes on Active Brake Assist (→ page 245).</p>  |
|  <p data-bbox="133 695 435 757">Suspension warning lamp (yellow)</p> | <p data-bbox="512 581 1008 645">* The yellow AIRMATIC warning lamp is lit.<br/>A fault has occurred in AIRMATIC.</p> <p data-bbox="532 653 1070 686">► Note the messages on the driver's display.</p>                                                                                                                                                                     |
|  <p data-bbox="133 888 435 951">Suspension warning lamp (red)</p>    | <p data-bbox="512 774 973 839">* The red AIRMATIC warning lamp is lit.<br/>A fault has occurred in AIRMATIC.</p> <div data-bbox="532 854 1937 951"> <p data-bbox="546 868 1463 901"><b>!</b> <b>NOTE</b> The vehicle's driving characteristics will have changed significantly.</p> <p data-bbox="546 914 1060 947">► Consult a qualified specialist workshop.</p> </div> |

| Warning/indicator lamp | Possible causes/consequences and ► Solutions                                                                                      |
|------------------------|-----------------------------------------------------------------------------------------------------------------------------------|
|                        | <div><div>►</div>Note the messages on the driver's display.</div> <div><div>►</div>Consult a qualified specialist workshop.</div> |

Driving safety systems

| Warning/indicator lamp                                                                                                  | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div></div> <div>ABS warning lamp</div> | <div><div>* The yellow ABS warning lamp is lit while the vehicle is running.<br/>ABS is malfunctioning.</div><div>If an additional warning tone sounds, EBD is malfunctioning.</div><div>Other driving systems and driving safety systems may also be malfunctioning.</div><div><div>►</div>Note the messages on the driver display.</div></div> <div><div><div>⚠</div><div><b>WARNING</b> There is a risk of skidding if EBD or ABS is malfunctioning</div></div><div><div>The wheels may lock during braking.</div><div>The steerability and braking characteristics are heavily impaired and the braking distance may increase. In addition, other driving safety systems are switched off.</div><div><div>►</div>Drive on carefully.</div><div><div>►</div>Have the brake system checked immediately at a qualified specialist workshop.</div></div></div> |

| Warning/indicator lamp                                                                                               | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|----------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>ESP® warning lamp flashes</p>   | <p>* The yellow ESP® warning lamp flashes while the vehicle is in motion. One or more wheels have reached their grip limit (→ page 220).</p> <p>► Adapt your driving style to suit the road and weather conditions.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                |
|  <p>ESP® warning lamp lights up</p> | <p>* The yellow ESP® warning lamp is lit while the vehicle is running. ESP® is malfunctioning.</p> <p>Other driving systems and driving safety systems (e.g. BAS) may also be malfunctioning.</p> <p>► Note the messages on the driver's display.</p> <div data-bbox="536 526 1943 752"> <p><b>⚠ WARNING</b> Risk of skidding if ESP® is malfunctioning</p> <p>If ESP® is malfunctioning, ESP® cannot carry out vehicle stabilisation. In addition, other driving safety systems are switched off.</p> <ul style="list-style-type: none"> <li>► Drive on carefully.</li> <li>► Have ESP® checked at a qualified specialist workshop.</li> </ul> </div> |
|  <p>ESP® OFF warning lamp</p>       | <p>* The yellow ESP® OFF warning lamp is lit while the vehicle is running. ESP® is deactivated.</p> <p>Other driving systems and driving safety systems may also be inoperative.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |



| Warning/indicator lamp | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                        | <div><div><div><div><div></div><div><b>WARNING</b></div></div><div>Risk of skidding when driving with ESP® deactivated</div></div></div><div><p>ESP® does not act to stabilise the vehicle. The availability of further driving safety systems is also limited.</p><ul style="list-style-type: none"><li>► Drive on carefully.</li><li>► Deactivate ESP® only for as long as the situation requires.</li></ul><p>If ESP® cannot be activated, ESP® is malfunctioning.</p><ul style="list-style-type: none"><li>► Have ESP® checked immediately at a qualified specialist workshop.</li></ul></div></div> <div>► Observe the notes on deactivating ESP® (→ page 220).</div> |

Mercedes-Benz emergency call system

| Warning/indicator lamp                                                                                                                                                                             | Possible causes/consequences and ► Solutions                                                                                                                                                                                   |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div><div><div><div><div></div></div></div></div><div>Mercedes-Benz emergency call system warning lamp</div></div> | <div><p>*The Mercedes-Benz emergency call system is malfunctioning. The Mercedes me connect system is also malfunctioning.</p><ul style="list-style-type: none"><li>► Consult a qualified specialist workshop.</li></ul></div> |

## Tyre pressure monitor

| Warning/indicator lamp                                                                                                                          | Possible causes/consequences and ► Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|-------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Tyre pressure monitoring system warning lamp flashes</p>   | <p>*The yellow tyre pressure monitor warning lamp (pressure loss/malfunction) flashes for approximately one minute and then remains lit.<br/>The tyre pressure monitor is malfunctioning.</p> <div data-bbox="536 358 1943 539"> <p><b>⚠ WARNING</b> There is a risk of an accident if the tyre pressure monitoring system is malfunctioning</p> <p>The tyre pressure monitoring system cannot issue a warning if there is pressure loss in one or more of the tyres. Tyres with insufficient tyre pressure may impair the driving characteristics as well as steering and braking.</p> <p>► Have the tyre pressure monitoring system checked at a qualified specialist workshop.</p> </div>                                  |
|  <p>Tyre pressure monitoring system warning lamp lights up</p> | <p>*The yellow tyre pressure monitoring system warning lamp (pressure loss/malfunction) is lit.<br/>The tyre pressure monitoring system has detected tyre pressure loss in at least one of the tyres.</p> <div data-bbox="536 643 1943 955"> <p><b>⚠ WARNING</b> Risk of an accident due to insufficient tyre pressure</p> <ul style="list-style-type: none"> <li>• The tyres can burst.</li> <li>• The tyres can wear excessively and/or unevenly.</li> <li>• The driving characteristics as well as the steering and braking may be greatly impaired.</li> </ul> <p>You could then lose control of the vehicle.</p> <p>► Observe the recommended tyre pressures.</p> <p>► Adjust the tyre pressure if necessary.</p> </div> |

| Warning/indicator lamp | Possible causes/consequences and ► Solutions                                                                                                                                         |
|------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                        | <div data-bbox="469 194 499 220">►</div> Stop the vehicle in accordance with the traffic conditions. <div data-bbox="469 236 499 262">►</div> Check the tyre pressure and the tyres. |

## 1, 2, 3 ...

**4MATIC**, All-wheel drive

|                             |     |
|-----------------------------|-----|
| All-wheel distribution..... | 192 |
| Function.....               | 192 |

**360° Camera**

|                                                              |     |
|--------------------------------------------------------------|-----|
| Activating using GPS (reversing camera).....                 | 271 |
| Care.....                                                    | 373 |
| Managing activation points (reversing camera).....           | 271 |
| Opening the camera cover (reversing camera).....             | 271 |
| Selecting a view.....                                        | 271 |
| Setting (reversing camera).....                              | 271 |
| Switching automatic operation on/off (reversing camera)..... | 271 |

**A****A/C function**

|                                               |     |
|-----------------------------------------------|-----|
| Activating/deactivating (operating unit)..... | 164 |
| MBUX.....                                     | 165 |

|                                                                       |     |
|-----------------------------------------------------------------------|-----|
| <b>ABS (Anti-lock Braking System)</b> , Anti-lock braking system..... | 219 |
|-----------------------------------------------------------------------|-----|

|                                  |     |
|----------------------------------|-----|
| <b>Accident prevention</b> ..... | 284 |
|----------------------------------|-----|

|                                       |     |
|---------------------------------------|-----|
| <b>Accident, emergency call</b> ..... | 355 |
|---------------------------------------|-----|

**Acoustic locking verification signal**

|                              |    |
|------------------------------|----|
| Activating/deactivating..... | 81 |
|------------------------------|----|

**Acoustic presence indicator (sound generator)**

|            |     |
|------------|-----|
| Notes..... | 176 |
|------------|-----|

**Active Blind Spot Assist**

|                              |     |
|------------------------------|-----|
| Activating/deactivating..... | 259 |
| Brake application.....       | 257 |
| Function.....                | 255 |
| Trailer operation.....       | 257 |

|                                                   |     |
|---------------------------------------------------|-----|
| <b>Active bonnet</b> , Pedestrian protection..... | 368 |
|---------------------------------------------------|-----|

**Active Brake Assist**

|               |     |
|---------------|-----|
| Function..... | 245 |
| Setting.....  | 249 |

**Active Distance Assist DISTRONIC**

|                                      |     |
|--------------------------------------|-----|
| Activating.....                      | 233 |
| Active Emergency Stop Assist.....    | 241 |
| Active Lane Change Assist.....       | 242 |
| Calling up a speed.....              | 233 |
| Deactivating.....                    | 233 |
| Function.....                        | 230 |
| Increasing/decreasing the speed..... | 233 |

|                                   |     |
|-----------------------------------|-----|
| Route-based speed adaptation..... | 236 |
| Storing a speed.....              | 233 |

**Active Emergency Stop Assist**

|                     |     |
|---------------------|-----|
| Driving system..... | 241 |
|---------------------|-----|

**Active Lane Change Assist**

|                              |     |
|------------------------------|-----|
| Activating/deactivating..... | 244 |
| Function.....                | 242 |

**Active Lane Keeping Assist**

|                                          |     |
|------------------------------------------|-----|
| Activating/deactivating.....             | 261 |
| Activating/deactivating the warning..... | 261 |
| Function.....                            | 259 |
| Setting the sensitivity.....             | 261 |
| Trailer operation.....                   | 259 |

|                                    |     |
|------------------------------------|-----|
| <b>Active light function</b> ..... | 145 |
|------------------------------------|-----|

**Active Parking Assist**, Parking assistance systems

|                                 |     |
|---------------------------------|-----|
| Automatic braking function..... | 280 |
| Cross traffic warning.....      | 285 |
| Drive Away Assist.....          | 284 |
| Exiting a parking space.....    | 279 |
| Manoeuvring brake function..... | 286 |
| Parking.....                    | 277 |
| Pausing.....                    | 280 |

**Active Service System PLUS**

|                  |     |
|------------------|-----|
| ASSYST PLUS..... | 367 |
|------------------|-----|

|                                                                        |     |                                                |          |                                            |          |
|------------------------------------------------------------------------|-----|------------------------------------------------|----------|--------------------------------------------|----------|
| <b>Active Speed Limit Assist</b> .....                                 | 235 | Fragrance system.....                          | 168      | Warning lamp.....                          | 44       |
| <b>Active Steering Assist</b>                                          |     | Front climate control.....                     | 164      | <b>Airflow</b>                             |          |
| Activating/deactivating.....                                           | 240 | Ionisation.....                                | 168      | Setting.....                               | 161, 162 |
| Active Emergency Stop Assist.....                                      | 241 | Rear compartment climate control.....          | 167      | <b>AIRMATIC</b>                            |          |
| Active Lane Change Assist.....                                         | 242 | Selecting climate modes.....                   | 165      | Air suspension.....                        | 262      |
| Function.....                                                          | 238 | <b>Air distribution</b>                        |          | Vehicle level.....                         | 262      |
| <b>Active Stop-and-Go Assist</b>                                       |     | MBUX multimedia system.....                    | 166      | <b>Alarm system, ATA</b>                   |          |
| Function.....                                                          | 238 | Setting.....                                   | 161, 162 | Interior protection function.....          | 109      |
| <b>Adaptive brake lights</b> .....                                     | 224 | <b>Air freshener system</b> .....              | 168      | <b>Alternative route</b> .....             | 333      |
| <b>Adaptive cruise control, Active Distance Assist DISTRONIC</b> ..... | 236 | <b>Air inlet</b> .....                         | 370      | <b>Ambient lighting</b> .....              | 153      |
| <b>Adaptive Highbeam Assist, High beam</b>                             |     | <b>Air pressure</b> .....                      | 397      | <b>AMG TRACK PACE</b>                      |          |
| Activating/deactivating.....                                           | 150 | <b>Air vents</b>                               |          | Configuring.....                           | 328      |
| Function.....                                                          | 149 | Setting.....                                   | 174      | Drag Race.....                             | 327      |
| <b>Adaptive Highbeam Assist Plus</b>                                   |     | <b>Air/water duct</b> .....                    | 370      | Function.....                              | 324      |
| Function.....                                                          | 150 | <b>Airbag, Occupant safety</b>                 |          | Telemetry display.....                     | 328      |
| Switching on/off.....                                                  | 151 | Automatic front passenger airbag shut off..... | 53       | Track Race.....                            | 325      |
| <b>Additional door lock</b> .....                                      | 84  | Centre airbag (driver's backrest).....         | 49       | <b>Animals</b>                             |          |
| <b>After-sales service, ASSYST PLUS</b> .....                          | 367 | Deployment.....                                | 44       | Pets in the vehicle.....                   | 78       |
| <b>Air conditioning menu</b>                                           |     | Front airbag.....                              | 49       | <b>Anti-lock braking system, ABS</b> ..... | 219      |
| Air distribution.....                                                  | 166 | Overview.....                                  | 49       | <b>Anti-theft alarm system, ATA</b> .....  | 107      |
| Calling up.....                                                        | 164 | PASSENGER AIR BAG indicator lamps.....         | 54       | <b>Anti-theft protection, ATA</b>          |          |
| Climate control.....                                                   | 165 | Protection.....                                | 51       | Additional door lock.....                  | 84       |
|                                                                        |     | Reduced protection.....                        | 52       | Immobiliser.....                           | 107      |

|                                                 |     |                                                    |     |                                                    |     |
|-------------------------------------------------|-----|----------------------------------------------------|-----|----------------------------------------------------|-----|
| <b>Approval numbers</b> .....                   | 414 | <b>Attention assistant, ATTENTION ASSIST</b> ..... | 225 | <b>B</b>                                           |     |
| <b>Apps</b>                                     |     | <b>Authorised workshop</b> .....                   | 37  | <b>Bad weather light</b> .....                     | 146 |
| Mercedes me calls.....                          | 345 | <b>Automatic car wash</b> .....                    | 370 | <b>Ball neck</b>                                   |     |
| Mercedes me connect.....                        | 348 | <b>Automatic car wash mode</b> .....               | 370 | Folding out/in.....                                | 291 |
| <b>Assistance systems</b> .....                 | 218 | <b>Automatic climate control</b> .....             | 165 | Trailer coupling.....                              | 293 |
| <b>ASSYST PLUS</b>                              |     | <b>Automatic distance control, Active Dis-</b>     |     | <b>BAS, Brake Assist System</b> .....              | 219 |
| Battery disconnection periods.....              | 368 | tance Assist DISTRONIC, DISTRONIC.....             | 230 | <b>Battery (12 V battery)</b>                      |     |
| Service interval display.....                   | 367 | <b>Automatic driving lights</b> .....              | 142 | Charging.....                                      | 387 |
| Service requirements.....                       | 367 | <b>Automatic emergency call, Mercedes-</b>         |     | Notes.....                                         | 385 |
| <b>ATA, Anti-theft protection</b>               |     | Benz emergency call system.....                    | 355 | Replacing.....                                     | 387 |
| Deactivating the alarm.....                     | 108 | <b>Automatic front passenger airbag shutoff</b>    |     | <b>Battery (high-voltage on-board electrical</b>   |     |
| Function.....                                   | 107 | Function.....                                      | 53  | system).....                                       | 420 |
| Tow-away protection.....                        | 108 | PASSENGER AIR BAG indicator lamps.....             | 54  | <b>Battery (key)</b> .....                         | 82  |
| <b>ATA (anti-theft alarm system)</b>            |     | <b>Automatic measures after an accident,</b>       |     | <b>Beginner driver mode</b>                        |     |
| Priming/deactivating interior protec-           |     | Occupant safety.....                               | 58  | Activating/deactivating.....                       | 225 |
| tion.....                                       | 109 | <b>Automatic mirror folding function</b> .....     | 160 | <b>Belt</b> .....                                  | 45  |
| Priming/deactivating tow-away pro-              |     | <b>Automatic seat adjustment</b>                   |     | <b>Bicycle rack</b>                                |     |
| tection.....                                    | 109 | Setting.....                                       | 116 | Load capacity.....                                 | 422 |
| <b>ATTENTION ASSIST, Detecting inattentive-</b> |     | <b>Autonomous braking</b> .....                    | 245 | Trailer operation.....                             | 295 |
| ness                                            |     | <b>Axle load</b>                                   |     | <b>Blind Spot Assist, Active Blind Spot Assist</b> |     |
| Setting.....                                    | 227 | Trailer operation.....                             | 423 | Activating/deactivating.....                       | 259 |
| <b>ATTENTION ASSIST with microsleep</b>         |     |                                                    |     | Function.....                                      | 255 |
| <b>detection, Attention assistant</b> .....     | 225 |                                                    |     |                                                    |     |

- 
- Bluetooth®**..... 343
  - Bonnet**
    - Active bonnet..... 368
    - Opening/closing..... 368
  - Boot lid**
    - Activating/deactivating the limiter..... 100
    - HANDS-FREE ACCESS..... 98
    - Opening/closing..... 95
    - Power closing function..... 95
    - Switching the separate locking feature on/off..... 99
  - Brake Assist**
    - Brake Assist System (BAS)..... 219
  - Brake Assist System, BAS**
    - Active Brake Assist..... 245
  - Brake fittings**..... 181
  - Brake fluid**..... 417
  - Brake force distribution, EBD**..... 222
  - Brake lamps**
    - Adaptive brake lights..... 224
  - Brakes**
    - ABS (Anti-lock Braking System)..... 219
    - ABS, BAS, EBD..... 218
    - Active Brake Assist..... 245
    - Adaptive brake lights..... 224
    - Driving tips..... 181
    - HOLD function..... 222
    - Limited braking effect (salt-treated roads)..... 181
    - New/replaced brakepads/brake disks... 181
    - Post-collision brake..... 58
    - Running-in notes..... 181
  - Braking assistance, Brake Assist System**..... 219
  - Breakdown**
    - Flat tyre..... 380
    - Overview of aids..... 18
    - Tow-starting..... 394
    - Towing away..... 388
    - Transporting the vehicle..... 390
    - Wheel change..... 405
  - C**
  - Calls**
    - Mercedes me..... 344
  - Camera**
    - 360° Camera..... 266
    - Button..... 270
    - Information..... 217, 266
    - Reversing camera..... 264
  - Car key**..... 80
  - Car wash**..... 370
  - Car-to-X-Communication**
    - Displaying hazard warnings..... 338
  - Care**
    - 360° Camera..... 373
    - Air/water duct..... 370
    - Automatic car wash..... 370
    - Car parts..... 373
    - Decorative foil..... 373
    - Display..... 375
    - Exterior lighting..... 373
    - Head-up display..... 375
    - High-pressure cleaner..... 371
    - Paint..... 372
    - Plastic trim..... 375
    - Real wood/trim elements..... 375
    - Roof lining..... 375
    - Trailer hitch..... 373
    - Vehicle interior..... 375
    - Vehicle socket for the high-voltage battery..... 373

|                                                                  |     |
|------------------------------------------------------------------|-----|
| Washing by hand.....                                             | 372 |
| <b>Caring for plastic trim</b> .....                             | 375 |
| <b>Caring for real wood</b> .....                                | 375 |
| <b>Caring for the steering wheel</b> .....                       | 375 |
| <b>Caring for trim elements</b> .....                            | 375 |
| <b>Caring for wheels</b> .....                                   | 373 |
| <b>Central display</b> , Home screen.....                        | 311 |
| <b>Central locking system</b>                                    |     |
| Button.....                                                      | 85  |
| Key.....                                                         | 81  |
| <b>Centre airbag (driver's backrest)</b> .....                   | 49  |
| <b>Charge level display</b> .....                                | 210 |
| <b>Charge level/charge display</b> .....                         | 210 |
| <b>Charging</b>                                                  |     |
| 12 V battery.....                                                | 387 |
| At time of departure.....                                        | 211 |
| Charge level display.....                                        | 210 |
| Charging cable control panel.....                                | 199 |
| Charging station, mode 3.....                                    | 196 |
| Configuring weekly profile.....                                  | 211 |
| Ending the charging process (alternating current, mode 2/3)..... | 203 |

|                                                                    |     |
|--------------------------------------------------------------------|-----|
| Ending the charging process (direct current, mode 4).....          | 208 |
| Indicator lamps on vehicle socket.....                             | 200 |
| Mains socket, mode 2.....                                          | 195 |
| Maximum charging current (mains socket).....                       | 198 |
| Notes on the high-voltage battery.....                             | 387 |
| Rapid charging station, mode 4.....                                | 197 |
| Starting the charging process (alternating current, mode 2/3)..... | 201 |
| Starting the charging process (direct current, mode 4).....        | 205 |
| Stowing the charging cable.....                                    | 193 |
| USB port.....                                                      | 136 |
| Wallbox, mode 3.....                                               | 196 |
| Wirelessly charging a mobile phone.....                            | 137 |
| <b>Charging cable</b>                                              |     |
| Control panel.....                                                 | 199 |
| Stowing.....                                                       | 193 |
| <b>Charging settings</b> .....                                     | 211 |
| <b>Checking the coolant level</b> .....                            | 369 |
| <b>Child safety lock</b>                                           |     |
| Rear door.....                                                     | 77  |
| Side window (rear).....                                            | 78  |

|                                                              |    |
|--------------------------------------------------------------|----|
| <b>Child seat</b>                                            |    |
| Approval categories.....                                     | 64 |
| Basic instructions.....                                      | 59 |
| Fitting ISOFIX/i-Size.....                                   | 67 |
| Front passenger seat.....                                    | 74 |
| Recommendations for child restraint systems.....             | 62 |
| Risks/dangers.....                                           | 60 |
| Seats suitable for belt-secured child restraint systems..... | 71 |
| Seats suitable for i-Size child restraint systems.....       | 67 |
| Seats suitable for ISOFIX child restraint systems.....       | 66 |
| Securing.....                                                | 63 |
| Securing to the front passenger seat with the seat belt..... | 75 |
| Securing to the rear seat with the seatbelt.....             | 73 |
| Top Tether.....                                              | 69 |
| Without automatic front passenger airbag shutoff.....        | 74 |
| <b>Children</b>                                              |    |
| Avoiding dangers in the vehicle.....                         | 60 |
| Basic instructions.....                                      | 59 |



- 
- Chock**..... 404
  - City lighting**..... 146
  - Clean varnish**..... 372
  - Cleaning**
    - Air/water duct..... 370
    - Automatic car wash..... 370
    - Car parts..... 373
    - Decorative foil..... 373
    - High-pressure cleaner..... 371
    - Paint..... 372
    - Vehicle interior..... 375
    - Vehicle socket for the high-voltage battery..... 373
  - Cleaning carpets**..... 375
  - Cleaning seat covers**..... 375
  - Climate control**
    - A/C function..... 165
    - Activating/deactivating..... 164
    - Activating/deactivating (rear operating unit)..... 164
    - Activating/deactivating the A/C function (control panel)..... 164
    - Air conditioning menu..... 164
    - Air distribution..... 161, 162
    - Airflow..... 161, 162
    - Automatic control..... 165
    - Defrost..... 165
    - Demisting the windscreen..... 161
    - Demisting the windscreen (THERMOTRONIC)..... 162
    - Demisting windows..... 167
    - fine particle status display..... 164
    - Fragrance system..... 168
    - Front air vents..... 174
    - Immediate pre-entry climate control..... 174
    - Inserting/removing the flacon (fragrance system)..... 169
    - Ionisation..... 168
    - Notes..... 161
    - Pre-entry climate control for departure time..... 171
    - Pre-entry climate control when the vehicle is unlocked..... 170
    - Rear air vents..... 175
    - Rear operating unit..... 163
    - Rear window heater..... 161, 162
    - Setting..... 164
    - Switching air-recirculation mode on/off..... 167, 168
    - Synchronisation function..... 167
    - Temperature..... 161, 162
    - THERMATIC control panel..... 161
    - THERMOTRONIC control panel..... 162
    - Ventilation with comfort opening..... 102
    - Windscreen heater..... 170
  - COC papers, Certificate of conformity**..... 412
  - Cockpit**
    - Overview (central display)..... 6
    - Overview (MBUX Hyperscreen)..... 8
  - Collision detection (parked vehicle)**
    - Information..... 215, 216
  - Combination switch**
    - Lights..... 143
    - Windscreen wipers..... 155
  - Commuter route**..... 333
  - Component-specific information**..... 414
  - Content sharing menu**
    - Overview..... 311
  - Control elements**..... 23
  - Convenience closing**..... 102
  - Convenience doors**
    - Setting (MBUX multimedia system)..... 92

|                             |          |
|-----------------------------|----------|
| Convenience opening.....    | 102      |
| Coolant (engine)            |          |
| Notes.....                  | 418      |
| Cooling.....                | 161, 162 |
| Copyright.....              | 42       |
| Cornering light.....        | 145      |
| Correct use.....            | 37       |
| Cover, Roller sunblind..... | 103      |
| Crosswind Assist, ESP®..... | 221      |
| Cruise control              |          |
| Activating.....             | 228      |
| Calling up a speed.....     | 228      |
| Deactivating.....           | 228      |
| Function.....               | 227      |
| Requirements.....           | 228      |
| Setting a speed.....        | 228      |
| Storing a speed.....        | 228      |
| Cup holder, Drinks holder   |          |
| Rear.....                   | 134      |

## D

|                                          |     |
|------------------------------------------|-----|
| Damping system ADS PLUS, AIRMATIC        |     |
| AIRMATIC.....                            | 262 |
| Dashcam                                  |     |
| Notes.....                               | 340 |
| Selecting a USB device.....              | 340 |
| Starting/stopping a video recording..... | 340 |
| Data processing in the vehicle.....      | 39  |
| Data protection rights.....              | 42  |
| Data storage                             |     |
| Data protection rights.....              | 42  |
| Electronic control units.....            | 39  |
| Online services.....                     | 42  |
| Deactivating the alarm.....              | 108 |
| Dealership.....                          | 37  |
| Declaration of conformity                |     |
| Electromagnetic compatibility.....       | 27  |
| Importer addresses.....                  | 34  |
| Jack.....                                | 35  |
| Specific absorption rate.....            | 27  |
| TIREFIT kit.....                         | 35  |
| Wireless vehicle components.....         | 27  |
| Decorative foil.....                     | 373 |

|                                           |     |
|-------------------------------------------|-----|
| Defrost function.....                     | 165 |
| Destination entry, Navigation             |     |
| Entering a POI or address.....            | 332 |
| Diagnostics connection.....               | 36  |
| DIGITAL LIGHT                             |     |
| Activating/deactivating.....              | 149 |
| Active light function.....                | 145 |
| Assistance functions.....                 | 146 |
| Bad weather light.....                    | 146 |
| City lighting.....                        | 146 |
| Cornering light.....                      | 145 |
| Enhanced fog light function.....          | 146 |
| Motorway mode.....                        | 145 |
| Topographical compensation.....           | 146 |
| Digital Owner's Manual.....               | 20  |
| DIRECT SELECT lever                       |     |
| Engaging drive position.....              | 192 |
| Engaging neutral.....                     | 192 |
| Engaging park position.....               | 192 |
| Engaging park position automatically..... | 192 |
| Engaging reverse gear.....                | 191 |
| Function.....                             | 191 |

**Disconnect device**

High-voltage on-board electrical system..... 177

**Display**

Care..... 375  
Home screen..... 311

**Display (driver's display)**

Overview of displays..... 302

**Display (MBUX multimedia system)**

Calling up the Zero Layer..... 308  
Operating the Zero Layer..... 308  
Zero Layer (function)..... 305  
Zero Layer (overview)..... 306

**Display message**

Calling up on driver display..... 424

**Display messages**

 --- km/h..... 464  
 --- km/h..... 464  
 --- km/h..... 463  
 12 V on-board electrical system  
Visit workshop..... 484

 Acoustic presence indicator  
inoperative..... 436  
 Active Light System inoperative..... 431  
 ATTENTION ASSIST inoperative..... 462  
 ATTENTION ASSIST Microsleep  
Take a break!..... 463  
 ATTENTION ASSIST: Take a  
break!..... 462  
 Automatic driving lights inoper-  
ative..... 431  
 Battery capacity too low Stop  
Charge immediately..... 441  
 Battery overheated Stop, every-  
body out! Outdoors if possible..... 441  
 Beginning emergency stop.... 468, 473  
 Brake immediately..... 460  
 Change key batteries..... 428  
 Charger cable connected..... 439  
 Check brake fluid level..... 461

 Check trailer hitch lock (white  
display message)..... 446  
 Check tyre(s)..... 487  
 Compressor is cooling..... 478  
 Coolant Stop Switch off the  
vehicle..... 437  
 currently unavailable See Own-  
er's Manual..... 479  
 currently unavailable See Own-  
er's Manual..... 481  
 Fault Drive at max. 80 km/h..... 476  
 Front left malfunction Consult  
workshop (example)..... 425  
 Have high-voltage system  
checked See Owner's Manual..... 442  
 Inoperative Charge high-voltage  
battery..... 435  
 inoperative High-voltage battery  
charging incomplete..... 434  
 inoperative See Owner's Manual... 480

|                                                                                                                                                  |                                                                                                                                                                     |                                                                                                                                                                |
|--------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  inoperative See Owner's Manual... 481                          |  Max. speed 20km/h..... 477                                                        |  Rear left seat backrest not locked (Example)..... 452                      |
|  inoperative See Owner's Manual... 482                          |  Maximum speed exceeded..... 466                                                   |  Rectify tyre pressure..... 487                                             |
|  Inoperative..... 484                                           |  Off..... 465                                                                      |  Reduce speed..... 489                                                      |
|  Key being initialised Please wait.... 430                      |  Off..... 462                                                                      |  Release parking brake..... 459                                             |
|  Key not detected (red display message)..... 429                |  Parking brake See Owner's Manual..... 457                                         |  Replace key..... 428                                                       |
|  Key not detected (white display message)..... 429              |  Parking brake Switch on vehicle to release..... 460                               |  Reserve level Charge high-voltage battery..... 443                         |
|  Left dipped beam (example)..... 430                            |  passive..... 464                                                                  |  Restraint system malfunction Consult workshop..... 425                     |
|  Left windowbag malfunction Consult workshop (example)..... 426 |  Performance severely limited..... 444                                             |  Restricted during trailer operation..... 475                               |
|  Malfunction See Owner's Manual..... 431                        |  Pre-entry climate control via key available again after starting vehicle..... 435 |  Start the vehicle to charge the 12 V battery..... 485                      |
|  Malfunction See Owner's Manual..... 460                        |  Pre-entry climate control via key inoperative High-voltage battery low..... 435   |  Steering malfunction Drive carefully Visit workshop..... 448               |
|  Malfunction Stop vehicle..... 461                              |  Rear axle steering currently malfunctioning..... 449                              |  Steering malfunction Increased physical effort See Owner's Manual..... 449 |
|  Malfunction Visit workshop..... 443                            |  Rear axle steering Malfunction Stop immediately..... 450                          |  Steering malfunction Stop immediately See Owner's Manual..... 449          |
|  Malfunction Visit workshop..... 442                            |  Rear axle steering Malfunction Visit workshop..... 450                            |                                                                                                                                                                |
|  Malfunction..... 443                                           |                                                                                                                                                                     |                                                                                                                                                                |
|  Malfunction..... 442                                           |                                                                                                                                                                     |                                                                                                                                                                |

- |                                                                                                                    |     |                                                                                                                     |     |                                             |     |
|--------------------------------------------------------------------------------------------------------------------|-----|---------------------------------------------------------------------------------------------------------------------|-----|---------------------------------------------|-----|
|  Stop Switch off the vehicle..... | 443 |  Vehicle is operational Switch off |     | Active Distance Assist available again..... | 466 |
|  Stop vehicle Leave vehicle on to |     | vehicle before exiting.....                                                                                         | 446 | Active Distance Assist currently            |     |
| charge the 12 V battery.....                                                                                       | 485 |  Vehicle rising Please wait.....   | 478 | unavailable See Owner's Manual.....         | 465 |
|  STOP Vehicle level too low.....  | 477 |  Warning tyre defect.....          | 488 | Active Distance Assist inoperative.....     | 465 |
|  Stop vehicle See Owner's Man-    |     |  Washer fluid flap open.....       | 453 | Active Emergency Stop Assist cur-           |     |
| ual.....                                                                                                           | 484 |  Wheel sensor(s) missing.....      | 486 | rently unavailable See Owner's Manual...    | 468 |
|  suspended.....                   | 464 | AC charging inoperative Consult work-                                                                               |     | Active Emergency Stop Assist inoper-        |     |
|  Switch off lights.....           | 432 | shop.....                                                                                                           | 440 | ative.....                                  | 468 |
|  Switch on headlamps.....         | 432 | Active Blind Spot Assist currently                                                                                  |     | Active Lane Change Assist currently         |     |
|  temporarily unavailable Camera   |     | unavailable See Owner's Manual.....                                                                                 | 471 | unavailable See Owner's Manual.....         | 469 |
| view restricted.....                                                                                               | 474 | Active Blind Spot Assist inoperative.....                                                                           | 472 | Active Lane Change Assist inoperative...    | 469 |
|  temporarily unavailable Sensors  |     | Active Blind Spot Assist not available                                                                              |     | Active Lane Keeping Assist currently        |     |
| dirty.....                                                                                                         | 473 | when towing a trailer See Owner's                                                                                   |     | unavailable See Owner's Manual.....         | 472 |
|  Top up coolant See Owner's       |     | Manual.....                                                                                                         | 472 | Active Lane Keeping Assist inoperative...   | 472 |
| Manual.....                                                                                                        | 437 | Active bonnet malfunction See Own-                                                                                  |     | Active Parking Assist and                   |     |
|  Top up washer fluid.....         | 452 | er's Manual.....                                                                                                    | 451 | PARKTRONIC inoperative See Own-             |     |
|  Towing not permitted See Own-    |     | Active Brake Assist Functions cur-                                                                                  |     | er's Manual.....                            | 479 |
| er's Manual.....                                                                                                   | 436 | rently limited See Owner's Manual.....                                                                              | 482 | Active Steering Assist currently            |     |
|  Tyre(s) overheated.....          | 488 | Active Brake Assist Functions limited                                                                               |     | unavailable due to multiple emer-           |     |
|                                                                                                                    |     | See Owner's Manual.....                                                                                             | 483 | gency stops.....                            | 467 |

|                                                                           |     |                                                                                                    |     |                                                                           |     |
|---------------------------------------------------------------------------|-----|----------------------------------------------------------------------------------------------------|-----|---------------------------------------------------------------------------|-----|
| Active Steering Assist currently unavailable See Owner's Manual.....      | 467 | Apply parking brake to park Visit workshop.....                                                    | 454 | Consult workshop without changing the transmission position.....          | 456 |
| Active Steering Assist inoperative.....                                   | 467 | Auxiliary battery malfunction (white display message).....                                         | 456 | Consult workshop without starting the vehicle again.....                  | 442 |
| Active Stop-and-Go Assist currently unavailable see Owner's Manual.....   | 469 | Blind Spot Assist currently unavailable See Owner's Manual.....                                    | 470 | Cruise control and Limiter inoperative....                                | 463 |
| Active Stop-and-Go Assist inoperative See Owner's Manual.....             | 470 | Blind Spot Assist inoperative.....                                                                 | 471 | Cruise control inoperative.....                                           | 463 |
| Adaptive Highbeam Assist currently unavailable See Owner's Manual.....    | 433 | Blind Spot Assist not available when towing a trailer See Owner's Manual.....                      | 471 | Cruise control off.....                                                   | 463 |
| Adaptive Highbeam Assist inoperative....                                  | 433 | Cannot start vehicle See Owner's Manual.....                                                       | 436 | DC charging inoperative Consult workshop.....                             | 440 |
| Adaptive Highbeam Assist Plus currently unavailable See Owner's Manual... | 433 | Change steering wheel/ seat position until 6 dots are visible on the upper edge of the screen..... | 476 | DIGITAL LIGHT Functions limited.....                                      | 432 |
| Adaptive Highbeam Assist Plus inoperative.....                            | 434 | Charging fault Please change charging method See Owner's Manual.....                               | 439 | Dipped-beam setting (left/right-side traffic) Manual adjustment only..... | 432 |
| Ambient light warning support inoperative.....                            | 452 | Check brake pads See Owner's Manual.....                                                           | 461 | Driver camera inoperative See Owner's Manual.....                         | 476 |
| Apply brake and start vehicle to shift out of P or N.....                 | 453 | Check dipped-beam setting (left/right-side traffic).....                                           | 432 | Driver camera view currently restricted See Owner's Manual.....           | 475 |
| Apply brake to deselect P position.....                                   | 453 |                                                                                                    |     | Front passenger airbag disabled See Owner's Manual.....                   | 426 |
| Apply brake to engage D or R.....                                         | 454 |                                                                                                    |     | Front passenger airbag enabled See Owner's Manual.....                    | 427 |

|                                                                                                             |     |                                                                                       |     |                                                                               |     |
|-------------------------------------------------------------------------------------------------------------|-----|---------------------------------------------------------------------------------------|-----|-------------------------------------------------------------------------------|-----|
| Hazard warning lamp system Malfunction.....                                                                 | 434 | N automatically activated Please engage transmission position again.....              | 455 | Please wait in READY status Warming battery See Owner's Manual.....           | 441 |
| Head-up display Brightness currently reduced See Owner's Manual.....                                        | 448 | N is selected Please select desired transmission position.....                        | 456 | PRE-SAFE impulse side inoperative See Owner's Manual.....                     | 428 |
| Head-up display currently unavailable See Owner's Manual.....                                               | 447 | Not possible to unlock charging cable See Owner's Manual.....                         | 439 | PRE-SAFE inoperative See Owner's Manual.....                                  | 428 |
| Head-up display inoperative.....                                                                            | 448 | Only select P when vehicle is stationary.....                                         | 453 | Preparing drive system.....                                                   | 442 |
| High-voltage battery malfunction. Consult workshop without starting the vehicle again.....                  | 445 | PARKTRONIC and manoeuvring assistant not available at rear when towing a trailer..... | 478 | Reduced drive system performance See Owner's Manual.....                      | 440 |
| High-voltage battery malfunction. No start in approx. XXX km Consult workshop (red display message).....    | 445 | PARKTRONIC inoperative See Owner's Manual.....                                        | 478 | Reversing not poss. Consult workshop...                                       | 456 |
| High-voltage battery malfunction. No start in approx. XXX km Consult workshop (yellow display message)..... | 444 | Place the key in the marked space See Owner's Manual.....                             | 430 | Risk of vehicle rolling away Apply parking brake to park.....                 | 454 |
| Limited availability of Active Parking Assist manoeuvring assistant See Owner's Manual.....                 | 479 | Please close socket flap manually. Automatic function inoperative.....                | 438 | Risk of vehicle rolling away Driver's door open Transmission not in P.....    | 454 |
| Limiter inoperative.....                                                                                    | 464 | Please close socket flap manually. Obstruction detection active.....                  | 438 | Risk of vehicle rolling away N activated manually No automatic switch to P... | 455 |
|                                                                                                             |     |                                                                                       |     | Snow chain mode Maximum speed exceeded.....                                   | 451 |
|                                                                                                             |     |                                                                                       |     | Socket flap blocked Please open manually.....                                 | 438 |

|                                                                                               |     |                                                    |     |                                            |     |
|-----------------------------------------------------------------------------------------------|-----|----------------------------------------------------|-----|--------------------------------------------|-----|
| Speed limit (winter tyres) XXX km/h.....                                                      | 466 | <b>Distance control</b> , Active Distance Assist   |     | Protection against collision.....          | 284 |
| Speed Limit Assist currently unavailable See Owner's Manual.....                              | 466 | DISTRONIC, DISTRONIC.....                          | 230 | System limits.....                         | 284 |
| Speed Limit Assist inoperative.....                                                           | 466 | <b>Distance warning</b> , Active Brake Assist..... | 245 | <b>Drive position</b>                      |     |
| To switch off the vehicle, press the Start/Stop button for at least 3 seconds or 3 times..... | 436 | <b>DISTRONIC</b>                                   |     | Engaging.....                              | 192 |
| Traffic Sign Assist currently unavailable See Owner's Manual.....                             | 470 | Activating.....                                    | 233 | <b>Drive program display</b> .....         | 190 |
| Traffic Sign Assist inoperative.....                                                          | 470 | Active Distance Assist.....                        | 230 | <b>Drive programs</b>                      |     |
| Transmission Malfunction Stop.....                                                            | 456 | Deactivating variable limiter.....                 | 233 | DYNAMIC SELECT.....                        | 188 |
| Tyre press. monitor currently unavailable.....                                                | 486 | <b>Door</b>                                        |     | <b>Drive system</b>                        |     |
| Tyre press. monitor inoperative.....                                                          | 486 | Additional door lock.....                          | 84  | Manual switch-off.....                     | 177 |
| Tyre press. monitor inoperative No wheel sensors.....                                         | 486 | Child safety lock (rear door).....                 | 77  | Starting (emergency operation mode)....    | 180 |
| Vehicle not currently being charged                                                           |     | Closing the convenience doors.....                 | 87  | <b>Driver camera</b>                       |     |
| Charging station fault.....                                                                   | 439 | Emergency key.....                                 | 93  | Activating/deactivating.....               | 316 |
| Wiper Malfunction.....                                                                        | 452 | Opening (from the inside).....                     | 84  | Overview.....                              | 315 |
| <b>Displaying road names/house numbers</b> .....                                              | 333 | Opening the convenience doors.....                 | 87  | <b>Driver display</b> , Instrument cluster |     |
|                                                                                               |     | Power closing function.....                        | 92  | Function/notes.....                        | 298 |
|                                                                                               |     | Unlocking (inside).....                            | 84  | <b>Driver's display</b>                    |     |
|                                                                                               |     | <b>Door control panel</b>                          |     | Driver camera.....                         | 12  |
|                                                                                               |     | Seat operation.....                                | 16  | Menus.....                                 | 300 |
|                                                                                               |     | <b>Drag Race</b>                                   |     | Operating.....                             | 299 |
|                                                                                               |     | Setting.....                                       | 327 | Service due date.....                      | 367 |
|                                                                                               |     | <b>Drinks holder</b> , Cup holder.....             | 131 | Warning/indicator lamps.....               | 489 |
|                                                                                               |     | <b>Drive Away Assist</b>                           |     | <b>Driver's seat</b>                       |     |
|                                                                                               |     | Function.....                                      | 284 | Easy entry and exit feature.....           | 121 |
|                                                                                               |     | Manoeuvring assistant.....                         | 284 |                                            |     |



**Driving abroad**

Light adjustment low beam..... 141

**Driving safety system, Assistance systems, Driving system, Safety systems**

Active Blind Spot Assist..... 255  
 Active Brake Assist..... 245  
 Adaptive brake lights..... 224  
 ATTENTION ASSIST..... 225  
 BAS..... 219  
 Cameras..... 217  
 Cruise control..... 227  
 EBD (Electronic Brakeforce Distribution)..... 222  
 ESP® (Electronic Stability Program)..... 220  
 Hill Start Assist..... 223  
 HOLD function..... 222  
 On radar and ultrasonic sensors..... 217  
 Overview..... 218  
 STEER CONTROL..... 222  
 Traffic Sign Assist..... 251

**Driving tips**

Acoustic presence indicator (sound generator)..... 176  
 Electric mode..... 176  
 Light adjustment when driving abroad.... 141

Range maximisation..... 188  
 Rear axle steering..... 183

**Drowsiness detection, ATTENTION ASSIST.... 225**

**Duplicate key..... 83**

**Dynamic handling control system, ESP®..... 220**

**DYNAMIC SELECT**

Calling up the fuel consumption indicator..... 190  
 Configuring drive program I..... 190  
 Displaying vehicle data..... 190  
 Drive program display..... 190  
 Drive programs..... 188  
 Function..... 188  
 Operating (button)..... 190  
 Selecting a drive program..... 190

**E****Easy entry feature**

Setting..... 122

**Easy exit feature**

Setting..... 122

**EBD (electronic brake force distribution)..... 222**

**ECO Assist**

Activating/deactivating..... 187  
 Function..... 185

**ECO display..... 184**

**Electric Intelligence**

Route with charging stations..... 333

**Electric mode**

Notes..... 176

**Electric parking brake**

Automatic..... 214  
 Emergency braking..... 215  
 Manual..... 215

**Electrical fuses..... 394**

**Electromagnetic compatibility**

Declaration of conformity..... 27

**Electronic Stability Program, ESP®..... 220**

**Emergency**

Fire extinguisher..... 379  
 First-aid kit (soft sided)..... 379  
 Overview of aids..... 18  
 Safety vest..... 378  
 Warning triangle..... 379

|                                                 |     |  |  |  |  |
|-------------------------------------------------|-----|--|--|--|--|
| <b>Emergency braking</b>                        |     |  |  |  |  |
| Electric parking brake/hand brake.....          | 214 |  |  |  |  |
| <b>Emergency call</b>                           |     |  |  |  |  |
| Automatic.....                                  | 355 |  |  |  |  |
| Manual.....                                     | 356 |  |  |  |  |
| <b>Emergency call system, Mercedes</b>          |     |  |  |  |  |
| me connect.....                                 | 355 |  |  |  |  |
| <b>Emergency key</b>                            |     |  |  |  |  |
| Door.....                                       | 93  |  |  |  |  |
| Inserting/removing.....                         | 82  |  |  |  |  |
| <b>Emergency operation mode</b>                 |     |  |  |  |  |
| Starting the vehicle.....                       | 180 |  |  |  |  |
| <b>Emergency start (drive system).....</b>      | 394 |  |  |  |  |
| <b>Emergency stop assistant, Active Emer-</b>   |     |  |  |  |  |
| <b>gency Stop Assist.....</b>                   | 241 |  |  |  |  |
| <b>Emergency system.....</b>                    | 355 |  |  |  |  |
| <b>Energy flow display</b>                      |     |  |  |  |  |
| Displaying.....                                 | 329 |  |  |  |  |
| <b>Engine</b>                                   |     |  |  |  |  |
| Engine number.....                              | 415 |  |  |  |  |
| Switching off, start/stop button.....           | 212 |  |  |  |  |
| <b>Engine electronics.....</b>                  | 412 |  |  |  |  |
| <b>Engine number.....</b>                       | 415 |  |  |  |  |
| <b>Engine starting</b>                          |     |  |  |  |  |
| Start/stop button.....                          | 180 |  |  |  |  |
| <b>Environmentally friendly driving.....</b>    | 21  |  |  |  |  |
| <b>ERA-GLONASS test mode.....</b>               | 358 |  |  |  |  |
| <b>Error message</b>                            |     |  |  |  |  |
| Driver's display.....                           | 424 |  |  |  |  |
| <b>ESC, Electronic Stability Control.....</b>   | 220 |  |  |  |  |
| <b>ESP®</b>                                     |     |  |  |  |  |
| Crosswind Assist.....                           | 221 |  |  |  |  |
| Function.....                                   | 220 |  |  |  |  |
| Trailer stabilisation.....                      | 221 |  |  |  |  |
| <b>ESP® (Electronic Stability Program)</b>      |     |  |  |  |  |
| Activating/deactivating.....                    | 222 |  |  |  |  |
| <b>EU type approval number.....</b>             | 415 |  |  |  |  |
| <b>Exiting a parking space</b>                  |     |  |  |  |  |
| Drive Away Assist.....                          | 284 |  |  |  |  |
| <b>Exterior lighting</b>                        |     |  |  |  |  |
| Care.....                                       | 373 |  |  |  |  |
| <b>F</b>                                        |     |  |  |  |  |
| <b>Fatigue detection, ATTENTION ASSIST.....</b> | 225 |  |  |  |  |
| <b>Favourites.....</b>                          | 317 |  |  |  |  |
| <b>Film covering</b>                            |     |  |  |  |  |
| On cameras/sensors.....                         | 217 |  |  |  |  |
| On radar and ultrasonic sensors.....            | 217 |  |  |  |  |
| <b>fine particle status display.....</b>        | 164 |  |  |  |  |
| <b>Fire extinguisher.....</b>                   | 379 |  |  |  |  |
| <b>First-aid kit (soft sided).....</b>          | 379 |  |  |  |  |
| <b>Fitting</b>                                  |     |  |  |  |  |
| Snow chains.....                                | 396 |  |  |  |  |
| Tyres.....                                      | 408 |  |  |  |  |
| Wheels.....                                     | 408 |  |  |  |  |
| <b>Flacon.....</b>                              | 169 |  |  |  |  |
| <b>Flat towing, Tow bar system</b>              |     |  |  |  |  |
| Pulling/towing.....                             | 297 |  |  |  |  |
| <b>Flat tyre</b>                                |     |  |  |  |  |
| MOExtended.....                                 | 380 |  |  |  |  |
| Notes.....                                      | 380 |  |  |  |  |
| TIREFIT kit.....                                | 382 |  |  |  |  |
| Wheel change.....                               | 405 |  |  |  |  |
| <b>Floor mats.....</b>                          | 140 |  |  |  |  |
| <b>Fog light (extended range).....</b>          | 146 |  |  |  |  |
| <b>Fragrance.....</b>                           | 168 |  |  |  |  |

**Fragrance system**

- Inserting/removing the flacon..... 169
- Perfume vial..... 169

**Free software, Open Source Software..... 42****Frequencies**

- Mobile phone..... 413
- Two-way radio..... 413

**Front airbag..... 49****Front fog lamps..... 142****Front headlamps..... 141****Front passenger airbag shutoff,**

PASSENGER AIR BAG OFF..... 53

**Fuel consumption indicator**

- Calling up..... 190

**Function seat..... 16****Fuses**

- Cockpit..... 395
- Fuse assignment diagram..... 394
- Fuse box in the front passenger footwell..... 395
- Fuse box in the rear passenger compartment..... 395
- Notes..... 394

**G****General driving tips..... 181****Genuine parts..... 21****Glove compartment**

- Opening/closing..... 127

**GPS-based vehicle level**

- Setting..... 264

**Gross mass..... 415****H****Handbrake, Electric parking brake..... 214****Handling characteristics**

- Unusual..... 396

**HANDS-FREE ACCESS..... 98****Haptic accelerator pedal,**

Accelerator pedal..... 188

**Hazard warning light system..... 144****Hazard warning lights..... 144****Head restraint**

- Adjusting (rear)..... 115
- Front (adjusting mechanically)..... 114
- Rear (removing/fitting)..... 115

**Head-up display**

- Care..... 375
- Function..... 300
- Memory function..... 124
- Operating..... 301
- Switching on/off..... 302

**Headlamp flashing..... 143****Headlamps**

- Automatic..... 141

**Heating**

- Activating/deactivating..... 164
- Centre console..... 163
- Climate control..... 161, 162
- Rear window..... 162
- Windscreen..... 170

**Help call**

- Mercedes-Benz emergency call system.. 355

**High beam**

- Activating/deactivating..... 143

**High-pressure cleaner..... 371****High-voltage battery**

- Charge level display..... 210
- Charging at time of departure..... 211
- Charging cable control panel..... 199

|                                                                    |     |                                                  |     |                                                       |     |
|--------------------------------------------------------------------|-----|--------------------------------------------------|-----|-------------------------------------------------------|-----|
| Charging duration.....                                             | 420 | <b>High-voltage on-board electrical system</b>   |     | <b>In-Car Office, Online services</b>                 |     |
| Charging station, mode 3.....                                      | 196 | Charging cable control panel.....                | 199 | Features.....                                         | 350 |
| Configuring weekly profile.....                                    | 211 | Disconnect device.....                           | 177 | <b>Indicator/warning lamps</b> .....                  | 489 |
| Connection types.....                                              | 420 | Indicator lamps on vehicle socket.....           | 200 | <b>Individual drive program</b>                       |     |
| Disconnect device.....                                             | 177 | Manual disconnection.....                        | 177 | Configuring.....                                      | 190 |
| Ending the charging process (alternating current, mode 2/3).....   | 203 | <b>Hill Start Assist</b> .....                   | 223 | <b>Inside rearview mirror, Rear-view mirror</b> ..... | 158 |
| Ending the charging process (direct current, mode 4).....          | 208 | <b>HOLD function, Roll away protection</b>       |     | <b>Intelligent Light System</b>                       |     |
| Energy flow display.....                                           | 329 | Switching on/off.....                            | 223 | Activating/deactivating.....                          | 149 |
| Function/notes.....                                                | 387 | <b>Home screen</b>                               |     | Active light function.....                            | 145 |
| Mains socket, mode 2.....                                          | 195 | Central display.....                             | 311 | Adaptive Highbeam Assist.....                         | 149 |
| Maximum charging current (mains socket).....                       | 198 |                                                  |     | Adaptive Highbeam Assist Plus.....                    | 150 |
| Range.....                                                         | 420 | <b>I</b>                                         |     | Assistance functions.....                             | 146 |
| Range maximisation.....                                            | 188 | <b>i-Size child seat anchor</b>                  |     | Bad weather light.....                                | 146 |
| Rapid charging station, mode 4.....                                | 197 | Fitting.....                                     | 67  | City lighting.....                                    | 146 |
| Starting the charging process (alternating current, mode 2/3)..... | 201 | Suitable seats.....                              | 67  | Cornering light.....                                  | 145 |
| Starting the charging process (direct current, mode 4).....        | 205 | <b>Identification plate</b>                      |     | Enhanced fog light function.....                      | 146 |
| Stowing the charging cable.....                                    | 193 | Engine.....                                      | 415 | Motorway mode.....                                    | 145 |
| Type.....                                                          | 420 | Vehicle.....                                     | 415 | Overview.....                                         | 144 |
| Voltage types.....                                                 | 420 | <b>Immediate pre-entry climate control</b> ..... | 174 | Topographical compensation.....                       | 146 |
| Wallbox, mode 3.....                                               | 196 | <b>Immobiliser</b> .....                         | 107 | <b>Interior lighting</b>                              |     |
|                                                                    |     | <b>Implied warranty</b> .....                    | 39  | Ambient lighting.....                                 | 153 |
|                                                                    |     | <b>Importer addresses</b>                        |     | Setting.....                                          | 152 |
|                                                                    |     | Wireless components.....                         | 34  | Switch-off delay time.....                            | 154 |

**Interior protection**

Priming/deactivating..... 109

**Internet**

Mercedes me connect..... 348

**Ionisation**

Activating/deactivating (MBUX multi-media system)..... 168

**ISOFIX child seat anchor**

Fitting..... 67

Suitable seats..... 66

**J****Jack**

Declaration of conformity..... 35

**Jump-start connection**..... 387**K****Key**

Acoustic locking verification signal..... 81

Battery..... 82

Deactivating a function..... 81

Emergency key..... 82

Energy consumption..... 81

Function..... 80

Key ring attachment..... 82

Problem..... 83

Unlocking setting..... 81

**KEYLESS-GO**

Deactivating..... 81

Locking/unlocking the vehicle..... 85

Problem..... 87

Unlocking setting..... 81

**Knee airbag**..... 49**L****Lamp**

Interior lighting..... 152

**Lane Change Assistant, Active Lane**

Change Assist..... 242

**Lane Keeping Assist, Active Lane**

Keeping Assist..... 259

**Lane recognition**

Active Lane Change Assist..... 242

**Lane recognition (automatic)**

Active Lane Keeping Assist..... 259

**Language, System settings**

Notes..... 323

Setting..... 324

**Level control, AIRMATIC**..... 262**Light adjustment**

Driving abroad..... 141

**Light switch**..... 141**Lighting**

Intelligent Light System..... 144

**Lights**

Active light function..... 145

Adaptive Highbeam Assist..... 149

Adaptive Highbeam Assist Plus..... 150

Automatic driving lights..... 142

Bad weather light..... 146

City lighting..... 146

Combination switch..... 143

Cornering light..... 145

Fog light (extended range)..... 146

Hazard warning lights..... 144

High beam..... 143

Intelligent Light System..... 144

Interior lighting..... 152

Light adjustment when driving abroad.... 141

Locator lighting..... 152

Low beam..... 141

|                                                    |          |                                                   |     |                                          |     |
|----------------------------------------------------|----------|---------------------------------------------------|-----|------------------------------------------|-----|
| Motorway mode.....                                 | 145      | <b>Live Traffic Information</b>                   |     | Left-hand traffic.....                   | 152 |
| Parking lights.....                                | 141      | Switching the traffic information display on..... | 338 | Light adjustment when driving abroad.... | 141 |
| Rear fog light.....                                | 141, 142 | <b>Load capacity</b>                              |     | Right-hand traffic.....                  | 152 |
| Responsibility for lighting systems.....           | 141      | Bicycle rack.....                                 | 422 | Setting.....                             | 152 |
| Standing lights.....                               | 141      | <b>Loading</b>                                    |     | <b>Lubricants</b> .....                  | 417 |
| Switch-off delay time.....                         | 152      | Roof luggage rack.....                            | 130 | <b>Luggage</b>                           |     |
| Switching the Intelligent Light System on/off..... | 149      | Tie-down eyes.....                                | 130 | Securing.....                            | 124 |
| Turn signal light.....                             | 143      | <b>Loading guidelines</b> .....                   | 124 | <b>Luggage rack</b> .....                | 124 |
| <b>Lights assistant</b>                            |          | <b>Loads</b>                                      |     | <b>Lumbar support</b> .....              | 113 |
| High beam.....                                     | 150      | Securing.....                                     | 124 |                                          |     |
| <b>Limiter</b>                                     |          | <b>Locator lighting</b> .....                     | 152 | <b>M</b>                                 |     |
| Activating.....                                    | 228, 233 | <b>Locking/unlocking</b>                          |     | <b>Maintaining safe distance</b>         |     |
| Buttons.....                                       | 228      | Additional door lock.....                         | 84  | Active Distance Assist DISTRONIC.....    | 233 |
| Calling up a speed.....                            | 228      | Automatic locking.....                            | 87  | <b>Maintenance, ASSYST PLUS</b> .....    | 367 |
| Deactivating.....                                  | 228, 233 | Doors (from the inside).....                      | 84  | <b>Malfunction</b>                       |     |
| Function.....                                      | 228      | Emergency key.....                                | 93  | Restraint system.....                    | 44  |
| Passive mode.....                                  | 228      | KEYLESS-GO.....                                   | 85  | <b>Manoeuvring</b>                       |     |
| Permanent setting.....                             | 230      | Mercedes me connect.....                          | 84  | Manoeuvring assistant.....               | 284 |
| Requirements.....                                  | 228      | <b>Loud sound</b>                                 |     | <b>Manoeuvring assistance</b>            |     |
| Selecting.....                                     | 228      | PRE-SAFE® Sound.....                              | 57  | Cross traffic warning.....               | 285 |
| Setting a speed.....                               | 228      | <b>Low beam</b>                                   |     | <b>Manoeuvring assistant</b>             |     |
| Storing a speed.....                               | 228      | Activating/deactivating.....                      | 141 | Activating/deactivating.....             | 287 |
|                                                    |          |                                                   |     | Drive Away Assist.....                   | 284 |

|                                                                     |     |                                                                |     |                                                                                                    |     |
|---------------------------------------------------------------------|-----|----------------------------------------------------------------|-----|----------------------------------------------------------------------------------------------------|-----|
| Manoeuvring brake function.....                                     | 286 | Calling up the Zero Layer.....                                 | 308 | <b>Medical aids</b> .....                                                                          | 38  |
| <b>Manoeuvring brake function</b> , Protection<br>against collision |     | Collision detection.....                                       | 215 | <b>Memory function</b>                                                                             |     |
| System limits.....                                                  | 286 | Collision detection (parked vehicle).....                      | 216 | Function.....                                                                                      | 123 |
| <b>Map</b>                                                          |     | Configuring drive program I.....                               | 190 | Head-up display.....                                                                               | 124 |
| Displaying online map contents.....                                 | 338 | Coupling the steering wheel heater to<br>the seat heating..... | 121 | Outside mirrors.....                                                                               | 124 |
| Displaying weather information.....                                 | 338 | Driver camera.....                                             | 315 | Seat.....                                                                                          | 124 |
| Moving.....                                                         | 337 | Home screen.....                                               | 311 | Steering wheel.....                                                                                | 124 |
| Selecting the map orientation.....                                  | 337 | Memory Park Assist.....                                        | 290 | <b>Memory Parking Assist</b>                                                                       |     |
| Setting the map scale.....                                          | 337 | Notes.....                                                     | 304 | Exiting a parking space.....                                                                       | 290 |
| <b>Massage programmes</b>                                           |     | Operating the touchscreen.....                                 | 312 | Parking.....                                                                                       | 289 |
| Overview.....                                                       | 117 | Operating the Zero Layer.....                                  | 308 | Parking assistance systems.....                                                                    | 287 |
| Resetting the settings.....                                         | 118 | Overview.....                                                  | 304 | Recording.....                                                                                     | 288 |
| Selecting the front seats.....                                      | 118 | Restoring (factory settings).....                              | 324 | Setting.....                                                                                       | 290 |
| <b>Maximum full-stop braking</b> , Brake<br>Assist System.....      | 219 | Setting route-based speed adaptation....                       | 238 | <b>Menus (driver's display)</b>                                                                    |     |
| <b>Maximum permissible gross vehicle weight</b> ...                 | 415 | Telephone.....                                                 | 341 | Notes.....                                                                                         | 300 |
| <b>Maximum speeds</b> .....                                         | 420 | Zero Layer (function).....                                     | 305 | <b>Mercedes me App</b>                                                                             |     |
| <b>MBUX</b>                                                         |     | Zero Layer (overview).....                                     | 306 | Activating on-demand features.....                                                                 | 24  |
| Air conditioning menu.....                                          | 164 | <b>MBUX Voice Assistant</b>                                    |     | Information.....                                                                                   | 349 |
| <b>MBUX multimedia system</b>                                       |     | Function.....                                                  | 313 | <b>Mercedes me calls</b>                                                                           |     |
| Activating/deactivating snow chain<br>mode.....                     | 397 | Voice prompting.....                                           | 314 | Arranging a service appointment.....                                                               | 346 |
|                                                                     |     | <b>Media</b>                                                   |     | Calling the Mercedes-Benz Customer<br>Centre after automatic accident/<br>breakdown detection..... | 345 |
|                                                                     |     | Overview of the functions and symbols...                       | 360 | Calls via the overhead control panel.....                                                          | 344 |
|                                                                     |     | <b>Media display</b>                                           |     |                                                                                                    |     |
|                                                                     |     | Operating.....                                                 | 312 |                                                                                                    |     |

|                                         |     |
|-----------------------------------------|-----|
| Consenting to the transfer of data..... | 346 |
| Information.....                        | 345 |
| Mercedes-Benz Customer Centre.....      | 345 |
| Transferred data.....                   | 347 |

### **Mercedes me connect**

|                                    |     |
|------------------------------------|-----|
| Accident/Breakdown Management..... | 349 |
| Information.....                   | 348 |
| Transferred data.....              | 349 |

### **Mercedes-AMG vehicles**

|            |     |
|------------|-----|
| Notes..... | 176 |
|------------|-----|

### **Mercedes-Benz emergency call system**

|                               |     |
|-------------------------------|-----|
| Automatic emergency call..... | 355 |
| Data processing.....          | 358 |
| Data transfer.....            | 356 |
| ERA GLONASS test mode.....    | 358 |
| Information.....              | 353 |
| Manual emergency call.....    | 356 |
| Overview.....                 | 355 |
| Self-diagnosis.....           | 358 |

|                                        |           |
|----------------------------------------|-----------|
| <b>Mercedes-Benz GenuineParts.....</b> | <b>21</b> |
|----------------------------------------|-----------|

|                                          |           |
|------------------------------------------|-----------|
| <b>Mercedes-Benz service centre.....</b> | <b>37</b> |
|------------------------------------------|-----------|

|                            |            |
|----------------------------|------------|
| <b>Message memory.....</b> | <b>424</b> |
|----------------------------|------------|

|                           |            |
|---------------------------|------------|
| <b>Mirror heater.....</b> | <b>170</b> |
|---------------------------|------------|

### **Mirrors**

|                              |     |
|------------------------------|-----|
| Mirror folding function..... | 160 |
| Outside mirrors.....         | 157 |
| Rear-view mirror.....        | 158 |

### **Mobile phone**

|                                                     |     |
|-----------------------------------------------------|-----|
| Authorising, Remote Parking Assist.....             | 284 |
| Frequencies.....                                    | 413 |
| Maximum transmission output.....                    | 413 |
| Notes on wireless charging.....                     | 137 |
| Wireless charging (front).....                      | 138 |
| Wireless charging (rear passenger compartment)..... | 139 |

|                        |            |
|------------------------|------------|
| <b>Model type.....</b> | <b>415</b> |
|------------------------|------------|

|                              |            |
|------------------------------|------------|
| <b>MOExtended tyres.....</b> | <b>380</b> |
|------------------------------|------------|

|                           |            |
|---------------------------|------------|
| <b>Motorway mode.....</b> | <b>145</b> |
|---------------------------|------------|

## **N**

### **Navigation**

|                            |     |
|----------------------------|-----|
| Activating.....            | 330 |
| Electric Intelligence..... | 333 |
| Notes.....                 | 330 |
| Overview.....              | 330 |

### **Neutral**

|               |     |
|---------------|-----|
| Engaging..... | 192 |
|---------------|-----|

|                                           |            |
|-------------------------------------------|------------|
| <b>Nodding off, ATTENTION ASSIST.....</b> | <b>225</b> |
|-------------------------------------------|------------|

## **O**

|                             |           |
|-----------------------------|-----------|
| <b>Occupant safety.....</b> | <b>45</b> |
|-----------------------------|-----------|

|                                                                    |           |
|--------------------------------------------------------------------|-----------|
| <b>On-board diagnostics interface, Diagnostics connection.....</b> | <b>36</b> |
|--------------------------------------------------------------------|-----------|

### **On-board electronics**

|                         |     |
|-------------------------|-----|
| Engine electronics..... | 412 |
| Two-way radios.....     | 412 |

|                               |           |
|-------------------------------|-----------|
| <b>On-demand feature.....</b> | <b>24</b> |
|-------------------------------|-----------|

|                             |           |
|-----------------------------|-----------|
| <b>Online services.....</b> | <b>42</b> |
|-----------------------------|-----------|

|                                                 |           |
|-------------------------------------------------|-----------|
| <b>Open Source Software, Free software.....</b> | <b>42</b> |
|-------------------------------------------------|-----------|

|                                             |    |
|---------------------------------------------|----|
| <b>Opening the boot lid using your foot</b> |    |
| HANDS-FREE ACCESS.....                      | 98 |

|                                             |    |
|---------------------------------------------|----|
| <b>Opening the tailgate using your foot</b> |    |
| HANDS-FREE ACCESS.....                      | 98 |

### **Operating fluids**

|                              |     |
|------------------------------|-----|
| Brake fluid.....             | 417 |
| Coolant (engine).....        | 418 |
| Windscreen washer fluid..... | 418 |

### **Operating safety**

|                  |    |
|------------------|----|
| Information..... | 24 |
|------------------|----|



**Outside mirrors**

|                                        |     |
|----------------------------------------|-----|
| Automatic anti-dazzle mode.....        | 158 |
| Automatic mirror folding function..... | 160 |
| Blind Spot Assist.....                 | 255 |
| Folding in/out.....                    | 157 |
| Memory function.....                   | 124 |
| Parking position.....                  | 159 |
| Setting.....                           | 157 |
| Warning lamp.....                      | 255 |

|                                    |           |
|------------------------------------|-----------|
| <b>Overhead control panel.....</b> | <b>14</b> |
|------------------------------------|-----------|

**Overview**

|                                 |     |
|---------------------------------|-----|
| Manoeuvring brake function..... | 286 |
|---------------------------------|-----|

|                                 |           |
|---------------------------------|-----------|
| <b>Overview of airbags.....</b> | <b>49</b> |
|---------------------------------|-----------|

|                            |           |
|----------------------------|-----------|
| <b>Owner's Manual.....</b> | <b>23</b> |
|----------------------------|-----------|

**P**

|                        |            |
|------------------------|------------|
| <b>Paint code.....</b> | <b>415</b> |
|------------------------|------------|

**Park position**

|                              |     |
|------------------------------|-----|
| Engaging.....                | 192 |
| Selecting automatically..... | 192 |

**Parking, PARKTRONIC**

|                             |     |
|-----------------------------|-----|
| Electric parking brake..... | 271 |
|-----------------------------|-----|

**Parking aid, Active Parking**

|                         |     |
|-------------------------|-----|
| Assist, PARKTRONIC..... | 271 |
|-------------------------|-----|

|                                                   |            |
|---------------------------------------------------|------------|
| <b>Parking Assist, Active Parking Assist.....</b> | <b>275</b> |
|---------------------------------------------------|------------|

**Parking Assist PARKTRONIC**

|                              |     |
|------------------------------|-----|
| Activating.....              | 275 |
| Adjusting warning tones..... | 275 |
| Deactivating.....            | 275 |
| Function.....                | 271 |

**Parking assistance systems, PARKTRONIC**

|                            |     |
|----------------------------|-----|
| Drive Away Assist.....     | 284 |
| Manoeuvring assistant..... | 284 |

**Parking brake, Electric parking brake**

|               |     |
|---------------|-----|
| Electric..... | 214 |
|---------------|-----|

|                            |            |
|----------------------------|------------|
| <b>Parking lights.....</b> | <b>141</b> |
|----------------------------|------------|

**Parking position**

|                                                                                 |     |
|---------------------------------------------------------------------------------|-----|
| Outside mirrors.....                                                            | 159 |
| Storing the position of the passenger<br>outside mirror using reverse gear..... | 159 |

**PARKTRONIC**

|                              |     |
|------------------------------|-----|
| Adjusting warning tones..... | 275 |
|------------------------------|-----|

**PASSENGER AIR BAG**

|                                             |    |
|---------------------------------------------|----|
| Status display, front passenger airbag..... | 54 |
|---------------------------------------------|----|

|                                                  |            |
|--------------------------------------------------|------------|
| <b>Pedestrian protection, Active bonnet.....</b> | <b>368</b> |
|--------------------------------------------------|------------|

|                                   |            |
|-----------------------------------|------------|
| <b>Permissible axle load.....</b> | <b>415</b> |
|-----------------------------------|------------|

|                                      |            |
|--------------------------------------|------------|
| <b>Permitted towing methods.....</b> | <b>388</b> |
|--------------------------------------|------------|

|                                                  |           |
|--------------------------------------------------|-----------|
| <b>Pets in the vehicle, Occupant safety.....</b> | <b>78</b> |
|--------------------------------------------------|-----------|

|                                                   |           |
|---------------------------------------------------|-----------|
| <b>Post-collision brake, Occupant safety.....</b> | <b>58</b> |
|---------------------------------------------------|-----------|

**Power closing function**

|               |    |
|---------------|----|
| Boot lid..... | 95 |
| Door.....     | 92 |

**Power supply**

|                                       |     |
|---------------------------------------|-----|
| Start/stop button.....                | 178 |
| Switching on (start/stop button)..... | 178 |

**Pre-entry climate control**

|                                   |          |
|-----------------------------------|----------|
| At departure time.....            | 172      |
| At time of departure.....         | 171, 173 |
| immediate.....                    | 174      |
| when the vehicle is unlocked..... | 170      |
| When vehicle is unlocked.....     | 171      |

**Pre-heating**

|                                |     |
|--------------------------------|-----|
| Pre-entry climate control..... | 170 |
|--------------------------------|-----|

**PRE-SAFE®, Anticipatory occupant protection, Occupant safety, Preventative occupant protection system**

|                      |    |
|----------------------|----|
| Function.....        | 57 |
| PRE-SAFE® Sound..... | 57 |

|                                                |     |                                              |     |                                                          |          |
|------------------------------------------------|-----|----------------------------------------------|-----|----------------------------------------------------------|----------|
| Reversing measures.....                        | 57  | <b>Rain closing function</b>                 |     | <b>Rear window heater.....</b>                           | 161, 162 |
| <b>PRE-SAFE® Impulse Side, Occupant safety</b> |     | Side windows.....                            | 101 | <b>Rear-view mirror</b>                                  |          |
| Deployment.....                                | 44  | Sliding sunroof.....                         | 106 | Automatic anti-dazzle mode.....                          | 158      |
| Function.....                                  | 58  | <b>Rain sensor</b>                           |     | <b>Recuperation, Brakes, Driving tips</b>                |          |
| <b>PRE-SAFE® PLUS</b>                          |     | Side windows.....                            | 101 | Function.....                                            | 184      |
| Function.....                                  | 57  | Sliding sunroof.....                         | 106 | Setting.....                                             | 185      |
| <b>Profile</b>                                 |     | Windscreen wipers.....                       | 155 | <b>Recycling, Take-back of end-of-life vehicles.....</b> | 21       |
| Notes.....                                     | 316 | <b>Range</b>                                 |     | <b>Registration.....</b>                                 | 37       |
| <b>Protection against collision</b>            |     | Notes.....                                   | 298 | <b>Regulatory radio identification</b>                   |          |
| Manoeuvring brake function.....                | 286 | <b>Range maximisation</b>                    |     | Indonesia.....                                           | 414      |
| <b>Protection of the environment</b>           |     | Activating/deactivating.....                 | 188 | Israel.....                                              | 414      |
| Take-back of end-of-life vehicles.....         | 21  | Function.....                                | 188 | Small components.....                                    | 414      |
| <b>Q</b>                                       |     | <b>REACH regulation.....</b>                 | 38  | <b>Remote Parking Assist</b>                             |          |
| <b>QR code rescue card.....</b>                | 39  | <b>Reading lamp</b>                          |     | Authorising a mobile phone.....                          | 284      |
| <b>Qualified specialist workshop.....</b>      | 37  | Interior lighting.....                       | 152 | Function.....                                            | 280      |
| <b>R</b>                                       |     | <b>Rear axle steering.....</b>               | 183 | Operating.....                                           | 281      |
| <b>Radar and ultrasonic sensors.....</b>       | 217 | <b>Rear compartment climate control.....</b> | 167 | <b>Replacement key, Duplicate key.....</b>               | 83       |
| <b>Radio</b>                                   |     | <b>Rear door (child safety lock)</b>         |     | <b>Reset function (MBUX multimedia sys-</b>              |          |
| Overview of functions/symbols.....             | 364 | Securing.....                                | 77  | tem), Restoring (factory settings).....                  | 324      |
| <b>Radio equipment approval numbers.....</b>   | 414 | <b>Rear fog light.....</b>                   | 142 | <b>Responsibility</b>                                    |          |
|                                                |     | <b>Rear seat belt</b>                        |     | Driving safety systems.....                              | 217      |
|                                                |     | Status display.....                          | 48  | <b>Restraint system, Occupant safety</b>                 |          |
|                                                |     |                                              |     | Basic instructions for children.....                     | 59       |

|                                                  |     |                                                      |     |                                           |     |
|--------------------------------------------------|-----|------------------------------------------------------|-----|-------------------------------------------|-----|
| Function in the event of an accident.....        | 44  | <b>Roof lining</b> .....                             | 375 | <b>S</b>                                  |     |
| Functionality.....                               | 44  | <b>Roof luggage rack</b>                             |     | <b>Safety systems</b>                     |     |
| Limited protection.....                          | 43  | Loading.....                                         | 130 | Overview.....                             | 218 |
| Malfunction.....                                 | 44  | Securing.....                                        | 130 | <b>Safety vest</b> .....                  | 378 |
| Protection.....                                  | 43  | <b>Route</b>                                         |     | <b>Seat</b>                               |     |
| Self-test.....                                   | 44  | Alternative route.....                               | 333 | adjusting (electrically).....             | 113 |
| Warning lamp.....                                | 44  | Commuter route.....                                  | 333 | Adjusting (Seat Comfort).....             | 110 |
| <b>Reverse gear</b>                              |     | Electric Intelligence.....                           | 333 | Automatic adjustment.....                 | 116 |
| Engaging.....                                    | 191 | Selecting a type.....                                | 333 | Centre airbag (driver's backrest).....    | 49  |
| <b>Reversing camera</b>                          |     | <b>Route guidance with augmented reality</b>         |     | Configuring settings.....                 | 116 |
| 360° Camera.....                                 | 264 | Activating.....                                      | 333 | Correct driver's seat position.....       | 110 |
| Activating using GPS (360° Camera).....          | 271 | Activating/deactivating the traffic                  |     | Folding back the backrest (rear).....     | 129 |
| Care.....                                        | 373 | light view.....                                      | 255 | Folding the backrest forwards (rear)..... | 127 |
| Function.....                                    | 264 | Displaying road names/house num-                     |     | Locking the backrest (rear).....          | 130 |
| Managing activation points (360°                 |     | bers.....                                            | 333 | Lumbar support.....                       | 113 |
| Camera).....                                     | 271 | Switching video on or off.....                       | 333 | Massage programme overview.....           | 117 |
| Opening the camera cover (360°                   |     | <b>Route-based speed adaptation</b>                  |     | Memory function.....                      | 124 |
| Camera).....                                     | 271 | DISTRONIC.....                                       | 236 | Resetting the settings.....               | 118 |
| Setting the 360° Camera.....                     | 271 | <b>Run-flat characteristics, MOExtended tyres...</b> | 380 | Settings.....                             | 16  |
| Switching automatic operation on/off             |     | <b>Running-in notes</b> .....                        | 181 | Side airbag.....                          | 49  |
| (360-degree Camera).....                         | 271 |                                                      |     | Workout programme overview.....           | 117 |
| <b>Roll away protection, HOLD function</b> ..... | 222 |                                                      |     | <b>Seat belt</b>                          |     |
| <b>Roller sunblind</b>                           |     |                                                      |     | Activating/deactivating seat belt         |     |
| Sliding sunroof.....                             | 103 |                                                      |     | adjustment.....                           | 48  |

|                                                |     |                                                    |     |                                                                                                |     |
|------------------------------------------------|-----|----------------------------------------------------|-----|------------------------------------------------------------------------------------------------|-----|
| Adjusting the height.....                      | 47  | <b>Service centre</b> .....                        | 37  | Problem.....                                                                                   | 106 |
| Automatic tightening.....                      | 48  | <b>Service interval display, ASSYST PLUS</b> ..... | 367 | Rain closing function.....                                                                     | 106 |
| Care.....                                      | 375 | <b>Service, ASSYST PLUS</b> .....                  | 367 | <b>Smartphone integration, Android Auto, Apple CarPlay®, Mobile phone, Smartphone, iPhone®</b> |     |
| Fastening.....                                 | 47  | <b>Setting a speed</b> .....                       | 227 | Overview.....                                                                                  | 352 |
| Protection.....                                | 45  | <b>Shortening the braking distance</b>             |     | <b>Snow chain mode</b>                                                                         |     |
| Rear seat belt status display.....             | 48  | BAS.....                                           | 219 | Activating/deactivating.....                                                                   | 397 |
| Reduced protection.....                        | 46  | <b>Side airbag</b> .....                           | 49  | <b>Snow chains</b> .....                                                                       | 396 |
| Releasing.....                                 | 48  | <b>Side windows</b>                                |     | <b>Socket</b>                                                                                  |     |
| Warning lamp.....                              | 48  | Automatic function.....                            | 101 | 12 V (front passenger footwell).....                                                           | 136 |
| <b>Seat belt adjustment</b>                    |     | Child safety lock (rear).....                      | 78  | Trailer operation.....                                                                         | 293 |
| Activating/deactivating.....                   | 48  | Convenience closing.....                           | 102 | <b>Socket flap, Socket flap</b> .....                                                          | 193 |
| Function.....                                  | 48  | Convenience opening.....                           | 102 | <b>Software update</b>                                                                         |     |
| <b>Seat belt tensioners</b>                    |     | Open/close with key.....                           | 102 | System updates.....                                                                            | 320 |
| Deployment.....                                | 44  | Opening/closing.....                               | 100 | <b>SOS button, Mercedes me</b> .....                                                           | 344 |
| <b>Seat belt warning</b> .....                 | 48  | Problem.....                                       | 103 | <b>Sound</b>                                                                                   |     |
| <b>Seat heating</b>                            |     | Rain closing function.....                         | 101 | PRE-SAFE® Sound.....                                                                           | 57  |
| Activating/deactivating.....                   | 118 | <b>Skid chains</b> .....                           | 396 | Wheels/tyres.....                                                                              | 396 |
| <b>Seat ventilation</b>                        |     | <b>Sliding sunroof</b>                             |     | <b>Sound generator</b>                                                                         |     |
| Switching on/off.....                          | 119 | Automatic functions.....                           | 106 | Acoustic presence indicator.....                                                               | 176 |
| <b>Self-test</b>                               |     | Closing.....                                       | 103 |                                                                                                |     |
| Automatic front passenger airbag shut off..... | 54  | Closing with key.....                              | 102 |                                                                                                |     |
| Restraint system.....                          | 44  | Opening.....                                       | 103 |                                                                                                |     |
| <b>Sensors</b> .....                           | 373 | Opening with the key.....                          | 102 |                                                                                                |     |

|                                                    |     |                                                |          |
|----------------------------------------------------|-----|------------------------------------------------|----------|
| <b>Sound menu</b>                                  |     |                                                |          |
| Functions overview.....                            | 366 | <b>Starting the engine</b>                     |          |
| <b>Spare parts, Mercedes-Benz GenuineParts....</b> | 21  | Start/stop button.....                         | 180      |
| <b>Spare wheel</b>                                 |     | <b>Starting-off aid</b>                        |          |
| Emergency spare wheel.....                         | 410 | Drive Away Assist.....                         | 284      |
| <b>Specialist workshop.....</b>                    | 37  | Hill Start Assist.....                         | 223      |
| <b>Specific absorption rate.....</b>               | 27  | <b>Status display</b>                          |          |
| <b>Speed</b>                                       |     | Front passenger airbag.....                    | 54       |
| Limiting with the Limiter.....                     | 228 | <b>STEER CONTROL, Steer Assist.....</b>        | 222      |
| Storing in cruise control.....                     | 233 | <b>Steering</b>                                |          |
| Storing in DISTRONIC.....                          | 233 | Rear axle steering.....                        | 183      |
| Storing in the Limiter.....                        | 233 | <b>Steering wheel</b>                          |          |
| <b>Speed Limit Assist</b>                          |     | Driver's airbag.....                           | 49       |
| Setting.....                                       | 251 | Manually adjusting.....                        | 120      |
| System limits.....                                 | 250 | Memory function.....                           | 124      |
| <b>Speed limit for winter tyres</b>                |     | <b>Steering wheel heater</b>                   |          |
| Setting.....                                       | 230 | Coupling to seat heating.....                  | 121      |
| <b>Standing lights.....</b>                        | 141 | <b>Stopping</b>                                |          |
| <b>Start/stop button</b>                           |     | Parking the vehicle.....                       | 212      |
| Parking the vehicle.....                           | 212 | <b>Stowage space, Stowage areas</b>            |          |
| Starting the vehicle.....                          | 180 | Front centre console.....                      | 126      |
| Switching on the power supply/vehicle..            | 178 | <b>Stowage spaces</b>                          |          |
| <b>Starting assistance.....</b>                    | 387 | Armrest.....                                   | 126      |
|                                                    |     | Centre console (front).....                    | 126      |
|                                                    |     | Door.....                                      | 126      |
|                                                    |     | Glove compartment.....                         | 126      |
|                                                    |     | <b>Suspension, AIRMATIC</b>                    |          |
|                                                    |     | AIRMATIC.....                                  | 262      |
|                                                    |     | <b>SVHC</b>                                    |          |
|                                                    |     | Substances of very high concern.....           | 38       |
|                                                    |     | <b>Switch-off delay time</b>                   |          |
|                                                    |     | From outside.....                              | 152      |
|                                                    |     | Interior.....                                  | 154      |
|                                                    |     | <b>Switching air-recirculation mode on/off</b> |          |
|                                                    |     | .....                                          | 167, 168 |
|                                                    |     | <b>System settings</b>                         |          |
|                                                    |     | Overview of the system settings menu....       | 320      |
|                                                    |     | Reset function (MBUX multimedia system).....   | 324      |
|                                                    |     | <b>T</b>                                       |          |
|                                                    |     | <b>Take-back of end-of-life vehicles</b>       |          |
|                                                    |     | Protection of the environment.....             | 21       |
|                                                    |     | <b>Technical data</b>                          |          |
|                                                    |     | Axle load (trailer operation).....             | 423      |
|                                                    |     | Component-specific information.....            | 414      |
|                                                    |     | Fastening points of the trailer hitch.....     | 421      |

|                                            |     |                                                 |            |                                      |            |
|--------------------------------------------|-----|-------------------------------------------------|------------|--------------------------------------|------------|
| High-voltage battery.....                  | 420 | Operating modes.....                            | 343        | <b>Touch Control</b>                 |            |
| Information.....                           | 412 | Telephone menu overview.....                    | 343        | Driver's display.....                | 299        |
| Mounting dimensions of a trailer hitch.... | 421 | Wireless charging (mobile phone, rear)...       | 139        | Operating.....                       | 312        |
| Overhang dimension of the trailer hitch..  | 421 | Wirelessly charging a(mobile phone, front)..... | 138        | <b>Touch-sensitive controls.....</b> | <b>23</b>  |
| Regulatory radio identification.....       | 414 | <b>Telephony operating modes</b>                |            | <b>Touchscreen</b>                   |            |
| Regulatory radio identification – Indo-    |     | Bluetooth® telephony.....                       | 343        | Operating.....                       | 312        |
| nesia and Israel.....                      | 414 | <b>Temperature</b>                              |            | <b>Tow bar system</b>                |            |
| Tongue weight.....                         | 422 | Setting (THERMOTRONIC).....                     | 162        | Towing away.....                     | 297        |
| Towing capacity.....                       | 422 | <b>THERMATIC</b>                                |            | <b>Tow-away protection</b>           |            |
| Vehicle dimensions.....                    | 419 | Air conditioning control panel.....             | 161        | Priming/deactivating.....            | 109        |
| <b>Telemetry display</b>                   |     | <b>THERMOTRONIC</b>                             |            | <b>Tow-starting.....</b>             | <b>394</b> |
| Calling up.....                            | 328 | Air conditioning control panel.....             | 162        | <b>Towing, Tow bar system</b>        |            |
| <b>Telephone</b>                           |     | <b>Tie-down eyes.....</b>                       | <b>130</b> | Pulling/towing.....                  | 297        |
| Authorising a mobile phone Remote          |     | <b>TIREFIT kit</b>                              |            | Towing methods.....                  | 388        |
| Parking Assist.....                        | 284 | Declaration of conformity.....                  | 35         | <b>Towing away.....</b>              | <b>388</b> |
| Bluetooth®.....                            | 343 | Storage location.....                           | 381        | <b>Towing eye</b>                    |            |
| Connecting a mobile phone using a          |     | <b>Toll system</b>                              |            | Storage location.....                | 393        |
| passkey.....                               | 343 | Windscreen.....                                 | 160        | <b>Towing methods.....</b>           | <b>388</b> |
| Connecting a mobile phone using            |     | <b>Tongue weight.....</b>                       | <b>422</b> | <b>Track Race</b>                    |            |
| Secure Simple Pairing.....                 | 343 | <b>Top Tether.....</b>                          | <b>69</b>  | Setting.....                         | 325        |
| Emergency call.....                        | 355 | <b>Topographical compensation</b>               |            | <b>Traffic information</b>           |            |
| Menu.....                                  | 344 | Intelligent Light System.....                   | 146        | Switching on the display.....        | 338        |
| Notes.....                                 | 341 |                                                 |            |                                      |            |
| Notes on wireless charging (mobile         |     |                                                 |            |                                      |            |
| phone).....                                | 137 |                                                 |            |                                      |            |

|                                                             |     |                                           |     |
|-------------------------------------------------------------|-----|-------------------------------------------|-----|
| <b>Traffic Jam Assistant</b>                                |     |                                           |     |
| Active Stop-and-Go Assist.....                              | 238 |                                           |     |
| <b>Traffic light view</b>                                   |     |                                           |     |
| Activating/deactivating.....                                | 255 |                                           |     |
| Information.....                                            | 255 |                                           |     |
| <b>Traffic light warning/display.....</b>                   | 251 |                                           |     |
| <b>Traffic Sign Assist</b>                                  |     |                                           |     |
| Function.....                                               | 251 |                                           |     |
| Setting.....                                                | 254 |                                           |     |
| <b>Trailer coupling, Ball neck.....</b>                     | 291 |                                           |     |
| <b>Trailer drawbar, Pulling/towing, Tow bar system.....</b> | 297 |                                           |     |
| <b>Trailer hitch</b>                                        |     |                                           |     |
| Axle load.....                                              | 423 |                                           |     |
| Bicycle rack.....                                           | 295 |                                           |     |
| Care.....                                                   | 373 |                                           |     |
| Coupling up/uncoupling a trailer.....                       | 293 |                                           |     |
| Fastening points.....                                       | 421 |                                           |     |
| Folding the ball neck out/in.....                           | 291 |                                           |     |
| General notes.....                                          | 421 |                                           |     |
| Mounting dimensions.....                                    | 421 |                                           |     |
| Overhang dimension.....                                     | 421 |                                           |     |
| Socket.....                                                 | 293 |                                           |     |
| Tongue weight.....                                          | 422 |                                           |     |
|                                                             |     | Towing capacity.....                      | 422 |
|                                                             |     | <b>Trailer operation</b>                  |     |
|                                                             |     | Active Blind Spot Assist.....             | 257 |
|                                                             |     | Active Lane Keeping Assist.....           | 259 |
|                                                             |     | Bicycle rack.....                         | 295 |
|                                                             |     | Coupling up/uncoupling a trailer.....     | 293 |
|                                                             |     | Folding the ball neck out/in.....         | 291 |
|                                                             |     | Notes.....                                | 290 |
|                                                             |     | Socket.....                               | 293 |
|                                                             |     | <b>Trailer stabilisation, ESP®.....</b>   | 221 |
|                                                             |     | <b>Transmission</b>                       |     |
|                                                             |     | DIRECT SELECT lever.....                  | 191 |
|                                                             |     | Drive programs.....                       | 188 |
|                                                             |     | DYNAMIC SELECT button.....                | 188 |
|                                                             |     | Engaging drive position.....              | 192 |
|                                                             |     | Engaging neutral.....                     | 192 |
|                                                             |     | Engaging park position.....               | 192 |
|                                                             |     | Engaging reverse gear.....                | 191 |
|                                                             |     | Transmission position display.....        | 191 |
|                                                             |     | Transmission positions.....               | 191 |
|                                                             |     | <b>Transmission position display.....</b> | 191 |
|                                                             |     | <b>Transporting</b>                       |     |
|                                                             |     | Vehicle.....                              | 390 |
|                                                             |     | <b>Tuneln, Internet radio</b>             |     |
|                                                             |     | Calling up.....                           | 365 |
|                                                             |     | <b>Turn signal indicator.....</b>         | 143 |
|                                                             |     | <b>Turn signal light.....</b>             | 143 |
|                                                             |     | <b>TV</b>                                 |     |
|                                                             |     | HD programmes.....                        | 363 |
|                                                             |     | <b>Two-way radios</b>                     |     |
|                                                             |     | Frequencies.....                          | 413 |
|                                                             |     | Installation.....                         | 412 |
|                                                             |     | Transmission output.....                  | 413 |
|                                                             |     | <b>Type approval number EG.....</b>       | 415 |
|                                                             |     | <b>Tyre inflation compressor.....</b>     | 35  |
|                                                             |     | <b>Tyre pressure</b>                      |     |
|                                                             |     | Checking.....                             | 399 |
|                                                             |     | TIREFIT kit.....                          | 382 |
|                                                             |     | Tyre pressure table.....                  | 398 |
|                                                             |     | <b>Tyre pressure monitoring system</b>    |     |
|                                                             |     | Function.....                             | 399 |
|                                                             |     | Restarting.....                           | 400 |
|                                                             |     | <b>Tyre pressure table.....</b>           | 398 |
|                                                             |     | <b>Tyre sealant.....</b>                  | 382 |
|                                                             |     | <b>Tyre tread.....</b>                    | 396 |

**Tyre-change tool kit**

Overview..... 404

**Tyres**

Breakdown..... 380

Checking..... 396

Checking the temperature..... 399

Fitting..... 408

Interchanging..... 404

MOExtended..... 380

Noise..... 396

Notes on fitting..... 401

Removing..... 408

Replacing..... 401, 405

Selection..... 401

Snow chains..... 396

Storing..... 404

TIREFIT kit..... 382

Tyre pressure table..... 398

Unusual handling characteristics..... 396

**U****Unfastening**..... 48**Unlocking setting**..... 81**Updates**

Important system updates..... 320

**USB port**

Front..... 126

Rear..... 136

**User profiles**

Adding a user..... 317

Selecting options..... 317

**V****Valet service mode**

Activating/deactivating..... 224

Function..... 224

**Variable limiter**

Function..... 228

Operating..... 228

**Vehicle**

Additional door lock..... 84

Automatic locking..... 87

Collision detection..... 215

Correct use..... 37

Data storage..... 39

Diagnostics connection..... 36

Emergency key..... 93

Equipment..... 23

Implied warranty..... 39

KEYLESS-GO..... 85

Locking/unlocking (from inside)..... 85

Locking/unlocking using the emer-

gency key..... 93

Lowering..... 409

Medical aids..... 38

QR code rescue card..... 39

Raising..... 405

REACH regulation..... 38

Registration..... 37

Setting collision detection (parked

vehicle)..... 216

Starting (emergency operation mode).... 180

Starting (start/stop button)..... 180

SVHC/substances of very high concern... 38

Switching off, start/stop button..... 212

Switching on, start/stop button..... 178

Towing..... 297

Transporting..... 390

ventilate / comfort opening..... 102

**Vehicle camera**

Information..... 217



**Vehicle data**

|                                  |     |
|----------------------------------|-----|
| Displaying (DYNAMIC SELECT)..... | 190 |
| Maximum speeds.....              | 420 |
| Vehicle height.....              | 419 |
| Vehicle length.....              | 419 |
| Vehicle width.....               | 419 |
| Weights.....                     | 420 |
| Wheelbase.....                   | 419 |

|                                 |     |
|---------------------------------|-----|
| <b>Vehicle dimensions</b> ..... | 419 |
|---------------------------------|-----|

|                                |    |
|--------------------------------|----|
| <b>Vehicle equipment</b> ..... | 23 |
|--------------------------------|----|

|                                                 |     |
|-------------------------------------------------|-----|
| <b>Vehicle identification number, VIN</b> ..... | 415 |
|-------------------------------------------------|-----|

**Vehicle identification plate**

|                                               |     |
|-----------------------------------------------|-----|
| EU type approval number.....                  | 415 |
| Maximum permissible gross vehicle weight..... | 415 |
| Model type.....                               | 415 |
| Paint code.....                               | 415 |
| Permissible axle load.....                    | 415 |
| VIN.....                                      | 415 |

|                          |    |
|--------------------------|----|
| <b>Vehicle key</b> ..... | 80 |
|--------------------------|----|

**Vehicle level**

|               |     |
|---------------|-----|
| AIRMATIC..... | 262 |
|---------------|-----|

|                              |     |
|------------------------------|-----|
| <b>Vehicle sensors</b> ..... | 217 |
|------------------------------|-----|

**Vehicle socket**

|                      |     |
|----------------------|-----|
| Care.....            | 373 |
| Indicator lamps..... | 200 |

**Vehicle start**

|                        |     |
|------------------------|-----|
| Start/stop button..... | 180 |
|------------------------|-----|

**Vehicle tool kit, Tool**

|                  |     |
|------------------|-----|
| TIREFIT kit..... | 381 |
| Towing eye.....  | 393 |

|                                               |     |
|-----------------------------------------------|-----|
| <b>Ventilating, Convenience opening</b> ..... | 102 |
|-----------------------------------------------|-----|

|                          |     |
|--------------------------|-----|
| <b>Ventilation</b> ..... | 174 |
|--------------------------|-----|

|                    |     |
|--------------------|-----|
| <b>Vents</b> ..... | 174 |
|--------------------|-----|

**VIN, Vehicle identification number**

|                           |     |
|---------------------------|-----|
| Engine compartment.....   | 415 |
| Identification plate..... | 415 |
| Seat.....                 | 415 |

**Vision**

|                        |     |
|------------------------|-----|
| Demisting windows..... | 167 |
| Windscreen heater..... | 170 |

**W**

|                                  |     |
|----------------------------------|-----|
| <b>Warning system, ATA</b> ..... | 107 |
|----------------------------------|-----|

|                               |          |
|-------------------------------|----------|
| <b>Warning triangle</b> ..... | 378, 379 |
|-------------------------------|----------|

**Warning/indicator lamp**

|                                                                                                                                           |          |
|-------------------------------------------------------------------------------------------------------------------------------------------|----------|
|  ABS warning lamp.....                                 | 500      |
|  Active Brake Assist warning lamp.....                 | 498, 499 |
|  Brake system warning lamp (red)...                    | 497      |
|  Brake system warning lamp (yellow).....               | 496      |
|  Electric parking brake indicator lamp (red).....      | 496      |
|  Electric parking brake indicator lamp (yellow).....   | 496      |
|  Electrical fault warning lamp.....                    | 493      |
|  ESP® OFF warning lamp.....                            | 501      |
|  ESP® warning lamp flashes.....                        | 501      |
|  ESP® warning lamp lights up.....                      | 501      |
|  Mercedes-Benz emergency call system warning lamp..... | 502      |
|  Power steering warning lamp (red).....                | 494      |

|                                                                                                                                               |     |
|-----------------------------------------------------------------------------------------------------------------------------------------------|-----|
|  Power steering warning lamp<br>(yellow).....                | 494 |
|  Rear axle steering warning lamp<br>(red).....               | 495 |
|  Rear axle steering warning lamp<br>(yellow).....            | 494 |
|  Reduced-power warning lamp.....                             | 492 |
|  Restraint system warning lamp.....                          | 491 |
|  Seat belt warning lamp flashes.....                         | 491 |
|  Seat belt warning lamp lights up....                        | 492 |
|  Suspension warning lamp (red).....                          | 499 |
|  Suspension warning lamp (yellow)<br>low).....               | 499 |
|  System error warning lamp.....                              | 492 |
|  Trailer tow hitch warning lamp.....                         | 493 |
|  Tyre pressure monitoring system warning lamp flashes.....   | 503 |
|  Tyre pressure monitoring system warning lamp lights up..... | 503 |

|                                                                                                                                      |     |
|--------------------------------------------------------------------------------------------------------------------------------------|-----|
|  Warning lamp for distance<br>warning function..... | 498 |
| <b>Warning/indicator lamps</b>                                                                                                       |     |
| Driver's display.....                                                                                                                | 489 |
| PASSENGER AIR BAG.....                                                                                                               | 54  |
| <b>Washer fluid</b>                                                                                                                  |     |
| Windscreen washer fluid.....                                                                                                         | 418 |
| <b>Washing by hand</b> .....                                                                                                         | 372 |
| <b>Water tank</b> .....                                                                                                              | 370 |
| <b>Weather information</b> .....                                                                                                     | 338 |
| <b>Web browser</b>                                                                                                                   |     |
| Overview.....                                                                                                                        | 351 |
| <b>Wedge</b> .....                                                                                                                   | 404 |
| <b>Weight information</b> .....                                                                                                      | 415 |
| <b>Wheel change</b>                                                                                                                  |     |
| Fitting a new wheel.....                                                                                                             | 408 |
| Lowering the vehicle.....                                                                                                            | 409 |
| Preparation.....                                                                                                                     | 405 |
| Raising the vehicle.....                                                                                                             | 405 |
| Removing a wheel.....                                                                                                                | 408 |
| <b>Wheel rotation</b> .....                                                                                                          | 404 |

## Wheels

|                                       |          |
|---------------------------------------|----------|
| Breakdown.....                        | 380      |
| Care.....                             | 373      |
| Checking.....                         | 396      |
| Checking the tyre temperature.....    | 399      |
| Fitting.....                          | 408      |
| Interchanging.....                    | 404      |
| MOExtended.....                       | 380      |
| Noise.....                            | 396      |
| Notes on fitting.....                 | 401      |
| Removing.....                         | 408      |
| Replacing.....                        | 401, 405 |
| Selection.....                        | 401      |
| Snow chains.....                      | 396      |
| Storing.....                          | 404      |
| TIREFIT kit.....                      | 382      |
| Tyre pressure.....                    | 397      |
| Tyre pressure monitoring system.....  | 399      |
| Unusual handling characteristics..... | 396      |

## Wi-Fi

|                  |     |
|------------------|-----|
| Configuring..... | 322 |
|------------------|-----|

## Window airbag

49

## Windows

|               |     |
|---------------|-----|
| Care.....     | 373 |
| De-icing..... | 165 |



## Publication details

Germany

### Internet

Further information about Mercedes-Benz vehicles and about Mercedes-Benz AG can be found on the following websites:

<https://www.mercedes-benz.com>

<https://www.daimler.com>

### Documentation team

You are welcome to forward any queries or suggestions you may have regarding this Owner's Manual to the technical documentation team at the following address:

Mercedes-Benz AG, HPC: CAC, Customer Service,  
70546 Stuttgart, Germany

©Mercedes-Benz AG: Not to be reprinted, translated or otherwise reproduced, in whole or in part, without written permission from Mercedes-Benz AG.

### Vehicle manufacturer

Mercedes-Benz AG

Mercedesstraße 120

70372 Stuttgart

As at 05.08.21



### Digital – in the vehicle

Familiarise yourself with the contents of the Owner's Manual directly via the vehicle's multimedia system (menu item "Vehicle information"). Start with the quick guide or broaden your knowledge with practical tips.



### Vehicle document wallet

Here you can find comprehensive information about operating your vehicle and about services and guarantees in printed form.



### Digital – on the Internet

You can find the Owner's Manual on the Mercedes-Benz homepage.



### Digital – as an App

The Mercedes-Benz Guides App is available free-of-charge in familiar App stores.



2955848700Z102

Order no. P295 0039 02 Part no. 295 584 87 00 Z102  
Edition NA2022-03b



Apple® iOS



Android™